



Intel NetStructure® Host Media Processing

Diagnostics Guide

August 2006



INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH INTEL® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER, AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF INTEL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT. Intel products are not intended for use in medical, life saving, life sustaining, critical control or safety systems, or nuclear facility applications.

Intel may make changes to specifications and product descriptions at any time, without notice.

This Intel NetStructure® Host Media Processing Diagnostics Guide as well as the software described in it is furnished under license and may only be used or copied in accordance with the terms of the license. The information in this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by Intel Corporation. Intel Corporation assumes no responsibility or liability for any errors or inaccuracies that may appear in this document or any software that may be provided in association with this document.

Except as permitted by such license, no part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means without the express written consent of Intel Corporation.

Copyright © 2005-2006, Intel Corporation

Dialogic, Intel, Intel logo, and Intel NetStructure are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

* Other names and brands may be claimed as the property of others.

Publication Date: August 2006

Document Number: 05-2494-003

Intel
1515 Route 10
Parsippany, NJ 07054

For **Technical Support**, visit the Intel Telecom Support Resources website at:
<http://developer.intel.com/design/telecom/support>

For **Products and Services Information**, visit the Intel Telecom and Compute Products website at:
<http://www.intel.com/design/network/products/telecom>

For **Sales Offices** and other contact information, visit the Buy Telecom Products page at:
<http://www.intel.com/buy/networking/telecom.htm>



Contents

	Revision History	9
	About This Publication	11
	Purpose	11
	Intended Audience	11
	How to Use This Publication	11
	Related Information	13
1	Diagnostics Overview	15
	1.1 Common Diagnostic Tasks	15
	1.2 Tool Classification by Problem Type	16
	1.3 Tcl/Tk Requirement	17
2	Checking Intel NetStructure® Boards	19
	2.1 Preparations	19
	2.2 Checking an Individual Board	19
	2.3 Unsupported Boards	20
	2.4 Tracing Firmware	20
3	Diagnosing First Call Issues	21
	3.1 Preparation	21
	3.2 Monitoring the Signal	21
	3.3 Monitoring the Status of Alarms	23
4	Diagnosing PSTN Protocol Issues	25
	4.1 Preparation	25
	4.2 Checking the Protocol Configuration	25
5	Debugging Software	31
	5.1 Troubleshooting Runtime Issues	31
	5.2 Collecting System Data to Diagnose an Application Failure or Crash	32
	5.3 Creating a System Configuration Archive	33
6	CallInfo Reference	35
	6.1 Description	35
	6.2 Guidelines	35
	6.3 Options	36
7	CAS Trace Reference	37
	7.1 Description	37
	7.2 Guidelines	37
	7.3 Options	37
8	DebugAngel Reference	41
	8.1 Description	41
	8.2 Guidelines	41

8.3	Command Line Options	41
8.4	Additional Configuration Options	42
9	DigitDetector Reference	43
9.1	Description	43
9.2	Guidelines	43
9.3	Options	43
10	DM3Insight Reference	45
11	DM3post Reference	47
11.1	Description	47
11.2	Guidelines	47
11.3	Options	48
12	Getver Reference	51
12.1	Description	51
12.2	Options	51
12.3	Output	52
13	ISDN Trace Reference	53
13.1	Description	53
13.2	Guidelines	53
13.3	Options	53
14	Intel Telecom Subsystem Summary Tool Reference	55
14.1	Description	55
14.2	Command Line Interface	55
14.3	Graphical User Interface (Windows only)	56
14.4	Information Collected by its_sysinfo	56
14.5	System Information Data Structuring	59
15	KernelVer Reference	61
15.1	Description	61
15.2	Options	61
16	MercMon Reference	63
16.1	Description	63
16.2	Guidelines	63
16.2.1	Class Driver Counters	63
16.2.2	Protocol Driver Counters	64
16.3	Options	67
17	PKD Trace Reference	69
17.1	Description	69
17.2	Guidelines	69
17.3	Options	70
17.4	Sample Scenarios	70
18	Phone Reference	73
18.1	Description	73
18.2	Guidelines	73

18.3	Options	73
19	PSTN Diagnostics Tool Reference	75
19.1	Description	75
19.2	Guidelines	76
19.3	Preparing to Run the PSTN Diagnostics Tool	76
19.4	Running the PSTN Diagnostics Tool	76
19.4.1	Starting the PSTN Diagnostics Tool	76
19.4.2	The Main Window	77
19.4.3	The View Bar	78
19.4.4	Option Buttons and Command Buttons	78
19.4.5	Keyboard Navigation	83
19.5	Checking the pstndiag Log File	83
19.6	PSTN Diagnostics Menus	84
19.6.1	File menu	84
19.6.2	Log menu	84
19.6.3	View menu	85
19.6.4	Help menu	85
19.7	PSTN Diagnostics Command Line Options	85
20	QScript Reference	87
20.1	Description	87
20.2	File Directories	87
20.3	QScript Environment Variables	87
21	Runtime Trace Facility (RTF) Reference	89
21.1	Description	89
21.2	Installing RTF	90
21.3	RTF Configuration File	90
21.3.1	RTFConfig Tag	91
21.3.2	Logfile Tag	93
21.3.3	Global Tag	95
21.3.4	GLabel Tag	96
21.3.5	GClient Tag	97
21.3.6	GClientLabel Tag	97
21.3.7	Module Tag	98
21.3.8	MLabel Tag	99
21.3.9	MClient Tag	100
21.3.10	MClientLabel Tag	100
21.3.11	Precedence Scheme for Module/Client Labels	101
21.4	Restrictions and Limitations	102
21.4.1	Guidelines for Editing the RTF Configuration File	102
21.5	rtftool Command	103
21.5.1	Pausing and Reloading RTF	103
21.5.2	Clearing the RTF Trace Log File Contents	104
21.5.3	Running RTF in Preservation Mode	104
21.6	Example RTF Configuration Files	104
21.6.1	Example 1: Tracing disabled - RtfConfigWin.xml	104
21.6.2	Example 2: Tracing enabled, logfile path and size specified, preservation mode OFF, one module configured - RTFConfigLinux.xml	105
21.6.3	Example 3: Tracing enabled, logfile path and size specified, several modules	

configured, global configuration used - RTFConfigWin.xml	106
21.7 Configuring Remote RTF Logging	107
21.7.1 Introduction	108
21.7.2 Configuring the Client System	108
21.7.3 Configuring the Server System	108
21.7.4 Cautions.	109
21.7.5 Disabling Remote Logging.	109
22 Status Monitor Reference	111
22.1 Description	111
22.2 Guidelines.	111
22.3 Options	111
Glossary	113
Index	115

Figures

1	PSTN Diagnostics Tool - Board Level View	22
2	PSTN Diagnostics Tool - Outbound Channel (Upper Pane) & Inbound Channel (Lower Pane)	26
3	PSTN Diagnostics Tool - Making a Call.	27
4	PSTN Diagnostics Tool - Call Completed and Released	29
5	PSTN Diagnostics Tool - System Level View	77
6	PSTN Diagnostics Tool - View Bar	78
7	Toggle Command Buttons.	79
8	Direct Command Buttons.	79
9	Channel State Command Buttons	79
10	Outbound Call Control Command Buttons	80
11	Inbound Call Command Buttons	80
12	Call Hold Command Buttons	81
13	Call Transfer Command Buttons	82
14	SendISDN Command Button.	82
15	Misc. Commands Buttons	82
16	External Application Command Button	83
17	RTF Configuration File Tag Structure	91
18	RTF Configuration File Edited to Configure the Client System	108
19	RTF Configuration File Edited to Configure the Server System	109
20	Example of Status Monitor Output.	112

Tables

1	Log Files Archived by its_sysinfo	57
---	---	----



Revision History

This revision history summarizes the changes made in each published version of this document.

Document No.	Publication Date	Description of Revisions
05-2494-003	August 2006	Runtime Trace Facility (RTF) Reference : Added Configuring Remote RTF Logging .
05-2494-002	June 2006	Collecting System Data to Diagnose an Application Failure or Crash : Revised procedure for using its_sysinfo Creating a System Configuration Archive : Revised procedure for using its_sysinfo. Getver Reference : Chapter revised to document the new version of this tool. PDK Trace Reference : In Description , added information about which boards support the tool. Phone Reference : Removed reference to Audio Control tool. QScript Reference : Removed Audio Control tool and CASSignal Editor from the list of administrative utilities. Runtime Trace Facility (RTF) Reference : Updated this chapter to document the new version of RTF. Updated Module Tag section and removed Table 3 since the most current list of modules is in the RTF configuration file. Updated module and label names in RTF Configuration File and Example RTF Configuration Files . Added information to maxbackups . Revised to indicate that text output (rather than binary) is the default. Removed the following line from the RTF configuration file: <!DOCTYPE RTFConfig SYSTEM "RTFConfig.dtd" >. Status Monitor Reference : Added to guidelines: tool is not intended for use with boards that are configured for ISDN. Intel Telecom Subsystem Summary Tool Reference : Chapter revised to document the new version of this tool.
05-2494-001	December 2005	Initial version of document. Much of the information contained in this document was previously published in the <i>Intel NetStructure Host Media Processing Diagnostics Guide</i> , document number 05-2356-003.





About This Publication

The following topics provide information about this publication:

- [Purpose](#)
- [Intended Audience](#)
- [How to Use This Publication](#)
- [Related Information](#)

Purpose

This guide provides procedures that can help you resolve problems you encounter when using Intel NetStructure® Host Media Processing (HMP) software and the Intel NetStructure® boards intended for use with the HMP software. This guide also describes the individual diagnostic tools that are provided with the HMP software.

Note: The boards are optional. HMP software can be used without boards.

Intended Audience

This publication is intended for:

- System Integrators
- Toolkit Developers
- Independent Software Vendors (ISVs)
- Original Equipment Manufacturers (OEMs)

How to Use This Publication

Refer to this document after you have installed the supported Intel NetStructure boards (optional) and the HMP software that includes the diagnostic tools.

The information in this guide is organized as follows:

- [Chapter 1, “Diagnostics Overview”](#) provides a brief overview of the diagnostic tools.

Each of the following chapters discuss diagnostic tasks. Details about the tool used to perform the task are provided in the tool reference chapters that follow these task chapters. This information is cross-referenced between the task and reference chapters.

- [Chapter 2, “Checking Intel NetStructure® Boards”](#)
- [Chapter 3, “Diagnosing First Call Issues”](#)

- [Chapter 4, “Diagnosing PSTN Protocol Issues”](#)
- [Chapter 5, “Debugging Software”](#)

The remaining chapters provide reference information about the diagnostic tools. The chapters are organized in alphabetical order:

- [Chapter 6, “CallInfo Reference”](#) - The CallInfo tool detects call information using an Intel NetStructure board’s Telephony Service Provider (TSP) resource.
- [Chapter 7, “CAS Trace Reference”](#)- The CAS Trace tool enables you to track the bit level transitions on a robbed bit or CAS line.
- [Chapter 8, “DebugAngel Reference”](#) - The DebugAngel tool provides low level firmware tracing to aid in low level debugging.
- [Chapter 9, “DigitDetector Reference”](#) - The DigitDetector tool provides the ability to detect digits at the local end of a channel connection.
- [Chapter 10, “DM3Insight Reference”](#) - DM3Insight is a tool used to capture message and stream traffic from an Intel NetStructure board’s device driver.
- [Chapter 11, “DM3post Reference”](#)- The DM3post tool can perform diagnostics on a stopped board at any time to detect and isolate possible hardware faults.
- [Chapter 12, “Getver Reference”](#) - The Getver tool displays the version of an Intel NetStructure board’s binary file.
- [Chapter 13, “ISDN Trace Reference”](#) - The ISDNtrace tool provides the ability to track Layer 3 (Q.931) messages on the ISDN D-channel. ISDNtrace prints messages on the screen in real time.
- [Chapter 14, “Intel Telecom Subsystem Summary Tool Reference”](#) - The Intel® Telecom Subsystem Summary Tool (its_sysinfo) provides a simple way to collect information about systems built using Intel® telecom products, such as HMP and boards supported by HMP.
- [Chapter 15, “KernelVer Reference”](#) - The KernelVer tool can be used to verify whether or not a processor has crashed.
- [Chapter 16, “MercMon Reference”](#) - MercMon provides counter information about Intel NetStructure board device drivers (Class Driver and Protocol Drivers).
- [Chapter 17, “PDK Trace Reference”](#)- The PDK Trace tool allows those who use a DM3 PDK protocol to log specific information related to the operation of the protocol.
- [Chapter 18, “Phone Reference”](#) - The Phone tool uses the TSC and ToneGen instances and requires a TSC component. The Phone tool can control a single DM3 resource channel (make calls, wait for calls etc.), monitor channel and call states, and send call control operations to a DM3 Global Call resource.
- [Chapter 19, “PSTN Diagnostics Tool Reference”](#) - The PSTN Diagnostics tool (pstndiag) is a utility for diagnosing and troubleshooting public switched telephone network (PSTN) connectivity problems on Intel NetStructure boards.
- [Chapter 20, “QScript Reference”](#) - This chapter provides information about QScript utilities, which are a subset of the diagnostic utilities.
- [Chapter 21, “Runtime Trace Facility \(RTF\) Reference”](#)- The RTF tool provides a mechanism for tracing the execution path of the runtime libraries for the HMP software. The resulting log file/debug stream output helps troubleshoot runtime issues for applications that are built with HMP software.

- [Chapter 22, “Status Monitor Reference”](#) - The Status Monitor tool enables you to track the state of the TSC as well as the state of the bits on a robbed bit or CAS line.

Related Information

Refer to the following documents and websites for more information:

- *Intel NetStructure® Host Media Processing Software Installation Guide* - This document describes how to install the HMP Software.
- *Intel NetStructure® Host Media Processing Software Administration Guide* - This publication describes how to perform the various tasks related to obtaining, activating, and otherwise working with HMP Software license as well as other administration tasks.
- *Intel NetStructure® Host Media Processing Software Release Guide* - This document provides information about the release such as product features, system requirements, and user documentation.
- *Intel NetStructure® Host Media Processing Software Release Update* - This document addresses release issues such as known problems and documentation updates.
- For technical support, go to <http://developer.intel.com/design/telecom/support/>.
- For information about Intel NetStructure Host Media Processing products, go to <http://www.intel.com/design/telecom/software/hmp.htm>.
- For information about Intel® telecom products, go to <http://www.intel.com/design/network/products/telecom/index.htm>.



This chapter presents an overview of the diagnostic tools and the debugging/troubleshooting tasks that can be performed with them.

- [Common Diagnostic Tasks](#) 15
- [Tool Classification by Problem Type](#)..... 16
- [Tcl/Tk Requirement](#)..... 17

1.1 Common Diagnostic Tasks

This section provides a list of diagnostic tasks that can be performed by using the various diagnostics tools. Another way to find the tool and procedure you need is to look at problem types. Refer to [Section 1.2, “Tool Classification by Problem Type”](#), on page 16.

Hardware and Firmware Diagnostics

The following tasks can be accomplished using the diagnostic tools:

Checking the hardware

You can use the Dm3post and KernelVer tools to troubleshoot the physical boards in your system. Refer to the following chapters:

- [Chapter 2, “Checking Intel NetStructure® Boards”](#)
- [Chapter 11, “DM3post Reference”](#)
- [Chapter 15, “KernelVer Reference”](#)

Checking the firmware

You can use the DebugAngel, MercMon, and PDK Trace tools to diagnose and trace problems with a board’s firmware. Refer to the following:

- [Section 2.4, “Tracing Firmware”](#), on page 20
- [Chapter 8, “DebugAngel Reference”](#)
- [Chapter 16, “MercMon Reference”](#)
- [Chapter 17, “PDK Trace Reference”](#)

Software and Application Diagnostics

The following tasks can be accomplished using the diagnostic tools:

Checking the network connections

You can use the PSTN Diagnostics, Digit Detector, and CallInfo tools to check your board’s network connections. Refer to the following:

- [Chapter 3, “Diagnosing First Call Issues”](#)
- [Chapter 19, “PSTN Diagnostics Tool Reference”](#)

- [Chapter 6, “CallInfo Reference”](#)

Checking the PSTN protocol configuration

You can use the PSTN Diagnostics tool to check your board’s protocol configuration. Refer to the following:

- [Chapter 4, “Diagnosing PSTN Protocol Issues”](#)
- [Chapter 19, “PSTN Diagnostics Tool Reference”](#)

Collecting system data to diagnose an application failure or crash

You can use the Intel Telecom Subsystem Summary Tool (its_sysinfo) to collect the system data you will need to send to Intel’s Support Services to troubleshoot an application failure or crash. Refer to the following:

- [Section 5.2, “Collecting System Data to Diagnose an Application Failure or Crash”](#), on page 32
- [Chapter 14, “Intel Telecom Subsystem Summary Tool Reference”](#)

Creating a system configuration archive

As part of a quality control effort, you might want to baseline your systems by retrieving all available information using the Intel Telecom Subsystem Summary Tool (its_sysinfo). Refer to the following:

- [Section 5.3, “Creating a System Configuration Archive”](#), on page 33
- [Chapter 14, “Intel Telecom Subsystem Summary Tool Reference”](#)

Tracing Runtime Libraries

You can use the Runtime Trace Facility (RTF) tool to trace the execution path of various HMP runtime libraries. Refer to the following:

- [Section 5.1, “Troubleshooting Runtime Issues”](#), on page 31
- [Chapter 21, “Runtime Trace Facility \(RTF\) Reference”](#)

1.2 Tool Classification by Problem Type

This section groups the diagnostic tools by problem type. The list that follows can help you locate the appropriate tool to use based on the problem you are having:

Board, Firmware, or Hardware Failures

To troubleshoot the physical boards in your system, use the following procedures and tools:

- [Section 2.2, “Checking an Individual Board”](#), on page 19
- [Chapter 11, “DM3post Reference”](#)
- [Chapter 15, “KernelVer Reference”](#)

To diagnose and trace problems with a board’s firmware, use the following procedures and tools:

- [Section 2.4, “Tracing Firmware”](#), on page 20
- [Chapter 8, “DebugAngel Reference”](#)
- [Chapter 16, “MercMon Reference”](#)

PSTN Connectivity

You can use the PSTN Diagnostics, Digit Detector, and CallInfo tools to check your board’s network connections. Refer to the following:

- [Chapter 3, “Diagnosing First Call Issues”](#)
- [Chapter 19, “PSTN Diagnostics Tool Reference”](#)
- [Chapter 6, “CallInfo Reference”](#)

PSTN Protocol Debugging

You can use the PSTN Diagnostics tool to check your board’s protocol configuration. Refer to the following:

- [Chapter 3, “Diagnosing First Call Issues”](#)
- [Chapter 19, “PSTN Diagnostics Tool Reference”](#)

Debugging Software

You can use the Runtime Trace Facility (RTF) tool and Intel Telecom Subsystem Summary Tool (its_sysinfo) for some general software debugging. Refer to the following:

- [Section 5.1, “Troubleshooting Runtime Issues”, on page 31](#)
- [Section 5.2, “Collecting System Data to Diagnose an Application Failure or Crash”, on page 32](#)
- [Section 5.3, “Creating a System Configuration Archive”, on page 33](#)
- [Chapter 21, “Runtime Trace Facility \(RTF\) Reference”](#)
- [Chapter 14, “Intel Telecom Subsystem Summary Tool Reference”](#)

1.3 Tcl/Tk Requirement

The HMP for Linux diagnostics scripts still require the Tcl/Tk language be installed on the system. HMP for Windows installs Tcl/Tk (refer to the HMP for Windows Installation Guide for more information about Tcl/Tk and other third party software). HMP uses builds from the dm3qtech_2.5 branch, which rely on a third party Tcl/Tk package.



Checking Intel NetStructure® Boards

This chapter provides procedures for checking the Intel NetStructure® hardware and firmware in your system.

- Preparations 19
- Checking an Individual Board 19
- Unsupported Boards 20
- Tracing Firmware 20

2.1 Preparations

To find out which boards are in your system and which slots they are in, use the Configuration Manager (DCM).

Note: DCM is described in the HMP Administration Guide.

2.2 Checking an Individual Board

This section provides a procedure for using the DM3post tool to check an individual Intel NetStructure board at any time to detect and isolate possible hardware faults. For more information on this tool, refer to [Chapter 11, “DM3post Reference”](#).

To use the DM3post tool to check a board, follow this procedure:

1. Make sure the board is in a “Stopped” state. This is necessary because DM3post will reset the specified board, forcing the Control Processor (CP) POST diagnostics to run.

DM3post will then retrieve the POST results from the SRAM and provide a PASS/FAIL indication. The board will remain in a stopped state and you will be required to restart the board.

2. Run the DM3post command, specifying the slot and bus number of the board. For example, the following command runs the DM3post tool on a board in slot 17, bus 0:

```
dm3post -s17 -b0
```

3. You will get the following response:

```
Do you wish to continue (y/n)?
```

If you answer Y, the following will be printed to the screen:

```
dm3post processing...
```

The success/failure message will be printed to the screen when POST is complete.

2.3 Unsupported Boards

The HMP software will not prevent you from installing an unsupported board. However, the configuration manager will not show any unsupported boards. An error message about the unsupported board(s) will appear in a log file in the *log* directory with the following filename: *rtf*.txt* (for example, *rtflog-10072005-14h47m25.639s.txt*). The following is a sample error message:

```
10/04 14:55:50.784 1792 1820 OAMSYSLOG ErrorEx NCMAPI - Board bus-1,
slot-9, model-256, serialNumber-KU005523 is not supported in this release
```

2.4 Tracing Firmware

This section describes how to use the DebugAngel tool to perform low-level firmware tracing for low-level debugging. For more information about the DebugAngel tool, refer to [Chapter 8, “DebugAngel Reference”](#).

DebugAngel polls the boards in the system and posts **qPrintf()** statements from the resources and DM3 kernel to a log file.

To use DebugAngel, follow these steps:

1. Install the service and start it running in automatic mode by entering the following command:

```
DebugAngel -install
```

2. When you need to refer to the firmware trace log, look in the *log* directory:

- On a Windows system, information is logged to the file *DebugAngel.log* in the *%INTEL_DIALOGIC_DIR%\log* directory.
- On a Linux system, information is logged to the file *debugangel.log* in the *\$(INTEL_DIALOGIC_DIR)/log* directory.

Command line options and configuration options for DebugAngel are provided in [Chapter 8, “DebugAngel Reference”](#).

This chapter describes how to use the PSTN Diagnostics tool (pstndiag) to determine what is preventing your system from successfully completing the first call.

- Preparation 21
- Monitoring the Signal 21
- Monitoring the Status of Alarms 23

For more information about the pstndiag tool, refer to [Chapter 19, “PSTN Diagnostics Tool Reference”](#).

3.1 Preparation

Before you perform the procedures described in this chapter, refer to the following sections:

- [Section 19.2, “Guidelines”](#), on page 76
- [Section 19.3, “Preparing to Run the PSTN Diagnostics Tool”](#), on page 76
- [Section 19.4.1, “Starting the PSTN Diagnostics Tool”](#), on page 76.


The main window displays a tree or hierarchy of the components in your system. Components include all boards that have been downloaded in the system, all trunks within a board, and all channels within a trunk.

3.2 Monitoring the Signal

Use the following procedure to verify that a connection exists between your board and the network (or other device depending on your system setup):

1. On the pstndiag tool’s main window, double-click on a specific board to display the board level view and check the connection of all trunks on this board. A sample screen is illustrated in [Figure 1](#).

Figure 1. PSTN Diagnostics Tool - Board Level View



- In the board level view, check that the Signal indicator is green for each trunk. The color green indicates a connection between the trunk and another device. The color grey indicates no connection exists. (The various indicators for each trunk, Red, Yellow, Signal, and Loopback, mimic the indicators on the physical board.)
- If the Signal indicator is green for all trunks on the board, then a connection exists between all trunks and another device. You can then proceed to check the status of alarms as described in [Section 3.3, “Monitoring the Status of Alarms”](#), on page 23.

If the Signal indicator is grey for a trunk, no connection exists. The cause may be a hardware problem or a faulty connection.

Note: The Loopback indicator shows whether your board is set for loopback test mode. If loopback is in place, the Loopback indicator is orange; otherwise, the indicator is grey. You should not have your board in loopback test mode for normal operation of the pstndiag tool.

- Repeat steps 1 through 3 for all boards in your system.

3.3 Monitoring the Status of Alarms

After determining that the Signal indicator for all boards in your system is green as described in [Section 3.2, “Monitoring the Signal”](#), on page 21, check the status of alarms on each trunk.

On the pstndiag tool’s main window, double-click on a specific board to display the board level view and check the status of the following alarms on each trunk (see [Figure 1, “PSTN Diagnostics Tool - Board Level View”](#), on page 22 for an illustration):

Red

Red alarm. A red alarm is generated by the line (trunk) of the board being monitored to report a loss of synchronization (RLOS) in the signal being received. This alarm is declared after the condition has existed for a specific time period, typically defined as 2.5 seconds (default). The red alarm condition will exist until the synchronization has been recovered and remains recovered for 12 seconds (default).

Yellow

Yellow alarm. A yellow alarm is generated by the line (trunk) of the board being monitored to signify that a red alarm condition exists at the receiving (local) end. The yellow alarm is sent as long as the red alarm condition exists at the receiver device.

Note: It’s possible for the Signal indicator to be green and a yellow or red alarm to be on at the same time. This situation indicates a possible configuration problem (such as trunk configuration mismatch) or hardware problem.

RAI

Remote Alarm Indication. If on, this box is yellow. This alarm is turned on by the firmware indicating a problem on the remote end. In this situation, the Signal indicator for the trunk will also be red.

AIS

Alarm Indication Service. This alarm can be turned on by you as a test on a specific trunk. This alarm is not typically used.

TS16RAI

TS16 Remote Alarm Indication. This alarm only applies to E1 lines with Channel Associated Signaling (CAS).

TS16AIS

TS16 Alarm Indication Service. This alarm only applies to E1 lines with Channel Associated Signaling (CAS).

D Channel

D channel state. This alarm only applies to ISDN with Common Channel Signaling (CCS). If the indicator is green, this means that the D channel is available. If the indicator is grey, this means that the channel is not available.



This chapter describes how to check the protocol configuration using the PSTN Diagnostics (pstndiag) tool.

- Preparation 25
- Checking the Protocol Configuration 25

For more information about the pstndiag tool, refer to [Chapter 19, “PSTN Diagnostics Tool Reference”](#).

4.1 Preparation

Before you use the pstndiag tool as described in this chapter, refer to the following sections:

- [Section 19.2, “Guidelines”](#), on page 76
- [Section 19.3, “Preparing to Run the PSTN Diagnostics Tool”](#), on page 76

After determining that a network connection exists as described in [Chapter 3, “Diagnosing First Call Issues”](#), check the protocol configuration. If the protocol is not properly configured, calls will not be successfully made. To check the protocol configuration, you will make and receive calls on your system. Protocols are configured on a trunk basis.

The procedure described in this section applies to a system with a loopback test setup or a system using a network connection setup.

If you can successfully make and receive calls in a system with loopback test setup, you can rule out any hardware problems. If you then test your system using a network connection setup, and are unsuccessful in making and receiving calls, you will need to check the board configuration settings. The configuration settings on the board and the switch should match; for example, the line type, the line coding, and the signaling protocol.

4.2 Checking the Protocol Configuration


Use the following procedure to check the protocol configuration:

1. If you have not already done so, start the pstndiag tool, as described in [Section 19.4.1, “Starting the PSTN Diagnostics Tool”](#), on page 76.

The main window displays a tree or hierarchy of the components in your system, including all boards that have been downloaded in the system, all trunks within a board, and all channels within a trunk.

2. Shift-double-click on a channel (for example, Chan 0.1.1) to display the channel in the lower pane. This channel will be the transmitting (outbound) channel.
3. Shift-double-click on a channel in another trunk (for example, Chan 0.2.1) to display the channel in the lower pane. This channel will be the receiving (inbound) channel.
4. To view both inbound and outbound channels on your screen, click on the “**1 System**” button (upper pane button) and select “**Chan 0.1.1**” (outbound channel). This channel level view replaces the system level view and is displayed in the upper pane. The inbound channel is displayed in the lower pane.


Figure 2. PSTN Diagnostics Tool - Outbound Channel (Upper Pane) & Inbound Channel (Lower Pane)



5. For the outbound channel (upper pane), click the **CallInfo** button to view additional options, and select the **Edit MakeCall Parameters** option. A new set of fields is displayed.
6. Enter the originating telephone number or extension in the **OrigAddr** field.
7. Enter the destination telephone number or extension in the **DestAddr** field.

Note: The Call Progress, CallId, and ConCallId fields are not typically used and should not be modified. The Call Progress field specifies the level of call progress analysis on the line. The CallId and ConCallId fields contain internal values used by the firmware to keep track of call information.

Figure 3. PSTN Diagnostics Tool - Making a Call




8. For the outbound channel (upper pane), click the **MakeCall Parameters** button to view options, and select the CallInfo button.
9. For the outbound channel (upper pane), click the **SetChanState** button and set the channel in service.
10. For the inbound channel (lower pane), click the **SetChanState** button and set the channel in service.
11. For the outbound channel (upper pane), click the **Channel State** button to view additional options, and select Outbound Call Control Commands.
12. For the inbound channel (lower pane), click the **Channel State** button to view additional options, and select Inbound Call Control Commands.

13. Click the **MakeCall** button to start the call. Notice that the CallInfo fields are updated after a call is made, enabling you to monitor the state of the call. For example, the Called ID (DNIS) field shows the telephone number dialed by a caller. The Caller ID (ANI) field shows the telephone number of the incoming call. Also the CallState field shows the state of the call (such as Connected or not) and the ChanState field shows the state of the channel (such as Active or not).
14. For the inbound channel (lower pane), click the **Accept** button to accept the incoming call. Notice that the CallState for the inbound channel will show “Accepted.” If the expected state is not being displayed, it may indicate a protocol configuration problem.
15. For the inbound channel (lower pane), click the **Answer** button to answer the incoming call. Notice that the CallState for the inbound channel now shows “Connected.” If the expected state is not being displayed, it may indicate a protocol configuration problem.
16. After you have verified that a call is successfully made, click the **Release** button for the outbound channel to end the call. The CallState for the inbound channel will show “Disconnected”. The CallState for the outbound channel will not change yet.
17. Click the **Release** button for the inbound channel to end the call. The CallState for the outbound and inbound channels will show “Null / Normal”. The ChanState for the outbound and inbound channels will show “Idle”. If the expected state is not being displayed, it may indicate a protocol configuration problem.

Note: In a channel level view, a log pane is displayed below the **Text Log** button. This log pane only displays events for that particular channel. To change the view between text format and graphical format, click the **Text Log** button.

Figure 4. PSTN Diagnostics Tool - Call Completed and Released





This chapter provides several procedures that can be useful for general software debugging:

- [Troubleshooting Runtime Issues](#) 45
- [Collecting System Data to Diagnose an Application Failure or Crash](#) 32
- [Creating a System Configuration Archive.](#) 33

5.1 Troubleshooting Runtime Issues

This section describes how to use the Runtime Trace Facility (RTF) for tracing the execution path of various runtime libraries. For a complete description of the RTF refer to [Chapter 21, “Runtime Trace Facility \(RTF\) Reference”](#).

Use the following procedure to customize and activate the RTF’s tracing capabilities:

1. Locate the RTF configuration file. The default installation location is determined by the INTEL_DIALOGIC_CFG environment variable.

Note: The INTEL_DIALOGIC_CFG environment variable is set when the Intel® Dialogic® system software is installed. Refer to the *Intel Dialogic System Release Software Installation Guide* for information about Intel Dialogic system software environment variables. To determine the variable setting on a Linux system, type `echo $INTEL_DIALOGIC_CFG`. To determine the variable setting on a Windows system, type `set INTEL_DIALOGIC_CFG`.

2. If you are familiar with XML syntax, use any ASCII text editor to open the RTF configuration file (*RtfConfigWin.xml* for Windows and *RtfConfigLinux.xml* for Linux). If you are not familiar with XML syntax, open the RTF configuration file with XML editor software.

3. Edit the RTF configuration file to customize the RTF tracing capabilities. Refer to [Section 21.3, “RTF Configuration File”](#), on page 90 for complete information about editing the RTF configuration file. The RTF configuration file includes the following XML tags:

- **RTFConfig:** This tag’s attributes configure the RTF. All other tags in the RTF configuration file are children of this tag. This tag must appear one time in the RTF configuration file. The RTF tracing capabilities are turned on by default. Refer to [Section 21.3.1, “RTFConfig Tag”](#), on page 91 for complete information about the RTFConfig tag. The RTFConfig tag includes the following child tags:
 - **Logfile:** This is the first child tag of the RTFConfig tag. The Logfile tag’s attributes set the parameters for the RTF logfile output. This tag is an optional part of the RTF configuration file. Refer to [Section 21.3.2, “Logfile Tag”](#), on page 93 for complete information about the Logfile tag.
 - **Global:** This is the second child tag of the RTFConfig tag. The Global tag is used to specify the global configuration. Configuration settings at the global level are valid for all modules in the RTF configuration file. When a module is traced at the global

level, all activity related to that particular module is traced. However, global tag settings have the lowest priority; they can be overridden by settings in individual Module tags. Refer to [Section 21.3.3, “Global Tag”](#), on page 95 for complete information about the Global tag.

- **Module:** This is the third child tag of the RTFConfig tag. The Module tag is used to specify the trace configuration for a particular module. The default RTF configuration contains pre-defined module tags for traceable runtime libraries. You can edit the **state** attributes of these pre-defined module tags or delete these pre-defined module tags. The default setting for each module’s **state** attribute is 1, meaning that tracing is enabled by default for each module in the *.xml* file. If you choose to delete modules, keep in mind that the *RtfConfigLinux.xml* and *RtfConfigWin.xml* files must contain at least one Module tag. Refer to [Section 21.3.7, “Module Tag”](#), on page 98 for complete information about the Module tag.
4. When you are finished editing the RTF configuration file, save and close the file.
 5. Start your application. As your application runs, RTF will trace the runtime libraries according to RTF configuration file settings. Refer to the individual entries in the log file or debug stream to review the trace statements generated by the runtime libraries.
 6. If you wish to dynamically edit the RTF trace levels while your application runs, it is not necessary to stop the RTF. Instead, perform the following:
 1. Open the RTF configuration file.
 2. Customize the settings in the RTF configuration file.
 3. Save and close the RTF configuration file.
 4. Issue the `rtftool reload` command to reload RTF configuration file and restart the RTF engine.

Note: Keep in mind that changes made to the RTF configuration file will not be reflected in the RTF output until the tool has been reloaded.
 7. At any time, you can issue the `rtftool` command to pause/restart RTF. RTF will not provide trace output while it is paused.

5.2 Collecting System Data to Diagnose an Application Failure or Crash

This section describes how to use the Intel® Telecom Subsystem Summary Tool (`its_sysinfo`) to collect the system data you will need to send to Intel’s Support Services to troubleshoot an application failure or crash.

Here are two sample scenarios in which you might use the `its_sysinfo` tool to gather system data:

- A telephony application you are running exits or gets terminated unexpectedly. At that point, you would launch the Intel Telecom Subsystem Summary Tool (`its_sysinfo`) to collect the log files and environment information to send to Intel’s Support Services using your credentials.
- Your telephony application doesn't work as expected. For example, an attempt to make a call fails. At that point, you would run the Intel Telecom Subsystem Summary Tool to gather the log files and environment information to send to Intel’s Support Services.

To familiarize yourself with the Intel Telecom Subsystem Summary Tool (`its_sysinfo`) and all the data it collects, refer to [Chapter 14, “Intel Telecom Subsystem Summary Tool Reference”](#).

Follow this procedure to use `its_sysinfo` to collect system data to pass along for troubleshooting:

1. Start the tool.
 - Linux systems – On the command line, enter `its_sysinfo filename` where *filename* is the name you want to give the zip file. The `its_sysinfo` tool will collect system information and compress it into the zip file. If you do not specify any filename, then the information gets compressed in a zip file with the default name *its_sysinfo.zip*.
 - Windows systems:
 1. Click on *its_sysinfo.exe* in `%INTEL_DIALOGIC_DIR%\bin`.
 2. Click the **Generate** button. A dialog box appears on which you must name the archive file into which you want the information to be collected. The default filename is *its_sysinfo.zip*.
 3. Click the **Save** button and `its_sysinfo` will start collecting information.
 4. A pop-up window displaying “Data collection completed. Zip archive was created as <zip file name>” will appear to indicate completion of *its_sysinfo.exe* execution. Click the **OK** button. The archive file is in the location specified in the tool.
2. Use any standard compression/decompression tool (such as WinZip*) to extract and review the data or send the zip file to Intel’s Support Services.

5.3 Creating a System Configuration Archive

This section describes how to use the Intel® Telecom Subsystem Summary Tool (`its_sysinfo`) to create a system configuration archive.

As part of a quality control effort, you might want to baseline your systems by retrieving all available information through `its_sysinfo`. You would archive this baseline system information and use it as a point of comparison to any system that exhibits erroneous behavior. This would provide you with a means of performing an initial cause/effect analysis when you troubleshoot the problem.

To familiarize yourself with the Intel Telecom Subsystem Summary Tool (`its_sysinfo`) and all the data it collects, refer to [Chapter 14, “Intel Telecom Subsystem Summary Tool Reference”](#).

Follow this procedure to use `its_sysinfo` to create a system configuration archive:

1. Start the tool.
 - Linux systems – On the command line, enter `its_sysinfo filename` where *filename* is the name you want to give the zip file. The `its_sysinfo` tool will collect system information and compress it into the zip file. If you do not specify any filename, then the information gets compressed in a zip file with the default name *its_sysinfo.zip*.
 - Windows systems:
 1. Click on *its_sysinfo.exe* in `%INTEL_DIALOGIC_DIR%\bin`.

2. Click the **Generate** button. A dialog box appears on which you must name the archive file into which you want the information to be collected. The default filename is *its_sysinfo.zip*.
 3. Click the **Save** button and *its_sysinfo* will start collecting information.
 4. A pop-up window displaying “Data collection completed. Zip archive was created as <zip file name>” will appear to indicate completion of *its_sysinfo.exe* execution. Click the **OK** button. The archive file is in the location specified in the tool.
2. Retain the archive file as your baseline system information.

This chapter provides reference information about the CallInfo tool. The following topics are included:

- [Description](#) 35
- [Guidelines](#) 35
- [Options](#) 36

6.1 Description

The CallInfo tool detects call information using the board's Telephony Service Provider (TSP) resource. The CallInfo tool confirms that the TSP component is working correctly by monitoring select messages on a per call basis.

6.2 Guidelines

CallInfo is a QScript utility. For more information about QScript utilities, refer to [Chapter 20](#), "QScript Reference".

To use CallInfo, specify the call-related messages you want to monitor as follows:

1. Launch the CallInfo tool from the command line.
2. Click the **Action** menu on the CallInfo display. Highlight **Select Ids** and select the group of call-related events you want to trace. The following menu selections are available:
 - CallInfoSet: TSP-related call messages
 - IE Set: Information elements of ISDN-related messages (focuses on small pieces of information)
 - ISDNMsgSet: ISDN-related messages
3. A window of events specific to the event group that you selected will appear. Select the messages you want to trace by clicking on them.
4. After you select messages, click the **Action** menu and choose **DetectEvt**. The tool will start monitoring the messages you selected. As a new call comes in, it will write over the old call information in the CallInfo display. A separate console window will open that tracks messages coming in and shows the message sequence.
5. If you want to stop tracing events you selected and select other events to trace, click the **Action** menu and select **CancelEvt**. Then follow steps 2 through 4 again.
6. To exit the CallInfo tool completely, select **Action > Exit** or close the window.

6.3 Options

The CallInfo tool uses the following command line options:

-board <n>

Logical ID of board (required). Use the Configuration Manager (DCM) to obtain the board's logical ID.

Note: DCM is described in the HMP Administration Guide.

-line <n>

Line number that the tool will monitor (optional). The default value is 1.

-chan<n>

Channel number that the tool will monitor (optional). The default value is 1.

The following example runs the CallInfo tool on board 0, line 1, channel 1:

```
callinfo -board 0 -line 1 -chan 1
```

This chapter provides reference information about the CAS Trace tool. The following topics are included:

- [Description](#) 37
- [Guidelines](#) 37
- [Options](#) 37

7.1 Description

The CAS Trace tool enables you to track the bit level transitions on a robbed bit or CAS line. CAS Trace prints messages on the screen in real time. The CAS Trace tool can be configured to output the messages into a circular log file.

The CAS Trace tool is used for troubleshooting problems with an entire span. CAS Trace is used for long-term debugging and logging for problems with timing, hung channels, and improper bit states.

7.2 Guidelines

The CAS Trace tool consumes a portion of the CPU for each trunk that is logged and may generate an exception if CTRL-C is used to exit the tool.

It may take several seconds to start the monitoring on all the trunks

The CAS instance is not valid until the line is in service, so you will have to run an application or the Lineadmin and Phone tools to set the channel in-service before using this application. For information about the Lineadmin tool, refer to the Administration Guide for the software release. For information about the Phone tool, refer to [Chapter 18, “Phone Reference”](#).

7.3 Options

The CAS Trace tool uses the following command line options:

`-board <board list>`

Logical ID of board (or boards) to trace (optional). The default is the lowest ID present in the system. Use the Configuration Manager (DCM) to obtain the board’s logical ID.

Note: DCM is described in the HMP Administration Guide.

`-line <list of lines>`

Line number that the tool will monitor (optional). The default value is 1.

-k <file size>

Size of each file to create in kilobytes (optional). If this option is not present the file size will be infinite.

-# <number of files to create>

The number of files to trace to in a circular fashion. Each file will be the size specified with **-k** (optional). The default is a single file.

-f <filename>

This will be the base filename. The board, line, and file numbers will be appended to the end of this name (optional). The default is *CasTrace.log*.

-nodisplay

This flag will turn off the screen output to help reduce CPU overhead (optional). The default is to have the screen display on. The display can also be toggled on and off by pressing **d** during runtime.

-t1 / -e1

This flag will tell the system if you are using a T1 protocol or and E1 protocol (optional). The default is T1. If you specify this incorrectly, you may not be able to initialize and monitor the upper channels.

The following will run the CAS Trace tool on boards 0 and 1 for all four spans. Each line will trace to two 1 MB files:

```
CAStrace -board 0 1 -line 1 2 3 4 -# 2 -k 1000
```

The output will look like the example below:

```
[ timestamp ] B## L## T## Rx=ABCD Tx=ABCD +delta (mS)
-----
[10/29 23:33:33.218] B0 L1 T1 Rx=1100 Tx=0000
[10/29 23:33:33.828] B0 L1 T2 Rx=0000 Tx=0000
[10/29 23:33:33.828] B0 L1 T1 Rx=1100 Tx=1100 +610
[10/29 23:33:34.531] B0 L1 T2 Rx=1100 Tx=0000 +703
[10/29 23:33:34.593] B0 L1 T2 Rx=1100 Tx=1100 +62
[10/29 23:33:34.609] B0 L1 T2 Rx=1100 Tx=0000 +16
[10/29 23:33:34.718] B0 L1 T3 Rx=1100 Tx=0000
[10/29 23:33:35.468] B0 L1 T1 Rx=0000 Tx=1100 +1640
[10/29 23:33:35.500] B0 L1 T3 Rx=1100 Tx=1100 +782
[10/29 23:33:35.562] B0 L1 T1 Rx=0000 Tx=0000 +94
[10/29 23:33:35.656] B0 L1 T4 Rx=1100 Tx=0000
[10/29 23:33:35.656] B0 L1 T1 Rx=0000 Tx=0000 +94
[10/29 23:33:36.625] B0 L1 T5 Rx=1100 Tx=0000
[10/29 23:33:36.843] B0 L1 T1 Rx=1100 Tx=0000 +1187
[10/29 23:33:36.906] B0 L1 T1 Rx=1100 Tx=1100 +63
[10/29 23:33:36.921] B0 L1 T1 Rx=1100 Tx=0000 +15
[10/29 23:33:37.203] B0 L1 T3 Rx=0000 Tx=1100 +1703
[10/29 23:33:37.328] B0 L1 T6 Rx=1100 Tx=0000
[10/29 23:33:37.328] B0 L1 T3 Rx=0000 Tx=0000 +125
[10/29 23:33:37.421] B0 L1 T3 Rx=0000 Tx=0000 +93
[10/29 23:33:37.843] B0 L1 T4 Rx=1100 Tx=1100 +2187
[10/29 23:33:37.875] B0 L1 T2 Rx=1100 Tx=1100 +3266
[10/29 23:33:37.875] B0 L1 T5 Rx=1100 Tx=1100 +1250
```

The output is separated into the following columns:

- Timestamp - the time at which the event is received down to msec
- B## - the board's logical ID



- L## - the line number
- T## - the timeslot
- Rx=ABCD - the state of the Receive bits
- Tx=ABCD - the state of the Transmit bits
- Delta - the time between the last transition in msec (if this is blank, it is the initial bit state)



This chapter provides reference information about the DebugAngel tool. The following topics are included:

- Description. 41
- Guidelines 41
- Command Line Options. 41
- Additional Configuration Options. 42

8.1 Description

The DebugAngel tool provides low-level firmware tracing to aid in low-level debugging. Running as a Windows service or Linux Daemon, it polls the DM3 boards in the system and posts **qPrintf()** statements from the resources and DM3 kernel to a log file.

8.2 Guidelines

Once the service is running, no further action is needed. Any changes to your system (for example, new boards) are automatically detected. On a Windows system, information is logged to the file *DebugAngel.log* in the *%INTEL_DIALOGIC_DIR%\log* directory. On a Linux system, information is logged to the file *debugangel.log* in the *\${INTEL_DIALOGIC_DIR}/log* directory.

8.3 Command Line Options

This section explains the command line options that can be used with the DebugAngel tool.

To install the service and start it running in automatic mode, enter the command:

```
DebugAngel -install
```

The DebugAngel tool uses the following options when it is invoked from the command line.

Notes: 1. Command line options are mutually exclusive.

2. On Linux systems, you must start DebugAngel from *\${INTEL_DIALOGIC_DIR}/bin*.

- instonly
Installs the service without starting it.
- start
Starts the service.
- stop
Stops the service.

- manual
Changes the service startup mode to manual.
- auto
Changes the service startup mode to automatic (default).
- remove
Removes the service (and stops it if it was started).
- status
Shows the service status.

8.4 Additional Configuration Options

Additional configuration options for DebugAngel are available under the Windows registry key *HKEY_LOCAL_MACHINE\SOFTWARE\Dialogic\DebugAngel*.

Warning: Incorrect manipulation of the Windows registry can render your system unusable, requiring that you reinstall Windows. Only a system administrator qualified to modify the registry should change the DebugAngel configuration.

The configuration options in the registry include:

DebugLevel -> 0

1 writes the log information to DebugView.

MaxFileSize -> 0

0 = no max. When the max size is reached, the file is truncated to 0.

LogFile -> default file name

AutoRename -> 1

1 (default) avoids erasing the file when the computer is restarted; the file is renamed (name).bak. Other options are: 0 = don't back up 2 = rename file to (name).(Day/Time_String) 3 = uses multiple files.

MaxFiles -> 1

Used by AutoRename 3 (default is 1 file).

This chapter provides reference information about the DigitDetector tool. The following topics are included:

- [Description](#). 43
- [Guidelines](#) 43
- [Options](#). 43

9.1 Description

The DigitDetector tool demonstrates the use of a DM3 board's Tone Generator and Signal Detector components. It provides the ability to detect digits at the local end of a channel connection.

9.2 Guidelines

DigitDetector is a QScript utility. For more information about QScript utilities, refer to [Chapter 20, "QScript Reference"](#).

To use the DigitDetector tool, you need a physical connection to the board. For example, two network interface trunks can be looped or you might use a connection between end users. You can then use the Phone tool at one end of the channel to generate dialed digits that can be detected by the Digit Detector tool. For information about the Phone tool, refer to [Chapter 18, "Phone Reference"](#).

9.3 Options

The DigitDetector tool uses the following command line options:

-board <n>

Logical ID of board (required). Use the Configuration Manager (DCM) to obtain the board's logical ID.

Note: DCM is described in the HMP Administration Guide.

-line <n>

Line number that the tool will monitor for digits (optional). The default value is 1.

-chan<n>

Channel number that the tool will monitor for digits (optional). The default value is 1.

The following example runs the DigitDetector tool on board 0, line 1, channel 1:

```
digitdetector -board 0 -line 1 -chan 1
```



This chapter provides information about the DM3Insight tool.

DM3Insight is a tool used to capture message and stream traffic from the DM3 device driver. DM3Insight can be used for the following:

- Debugging/understanding applications, driver, kernel by capturing traffic and analyzing the trace output
- Viewing messages that are encountered only between the device driver and the DM3 board
- Eliminating orphan messages and streams
- Calculating the turnaround time for messages
- Viewing messages from the board that have incorrect source/destination address or transaction Id and therefore never reach the application
- Viewing error messages from the board like Std_MsgError or QMsgUndelivered, which are not handled (or reported) by simple applications

For complete information about configuring and using the DM3Insight tool, refer to the DM3Insight online help file (*DM3Insight.chm*). The default directory for this file is %INTEL_DIALOGIC_DIR%\bin¹ for Windows* systems.

-
1. To find out what the INTEL_DIALOGIC_DIR directory is, type `echo %INTEL_DIALOGIC_DIR%` on a command prompt and note the path displayed.



This chapter provides reference information about the DM3post tool. The following topics are included:

- [Description](#). 47
- [Guidelines](#) 47
- [Options](#). 48

A procedure for using this tool is provided in [Section 2.2, “Checking an Individual Board”](#), on page 19.

11.1 Description

The DM3post tool, sometimes referred to as “POST-on-demand”, can perform diagnostics on a stopped board at any time to detect and isolate possible hardware faults.

- Notes:**
1. This tool can be run on Intel NetStructure[®] DNI boards.
 2. This tool cannot be run on the HMP “virtual board” (in the display on the Configuration Manager [DCM] Main Window, the HMP product appears as “HMP_Software” under the DM3 board group).

11.2 Guidelines

The board must be in a “stopped” state before the DM3post tool can be run. If you do not use the reset option (`-r`), DM3post will *not* reset the board and will only retrieve the POST results for the last reset that occurred. If you use DM3post with the reset option, DM3post will force a full reset of the specified board, forcing the Control Processor (CP) POST diagnostics to run. DM3post will then retrieve the POST results from the SRAM and provide a PASS/FAIL indication to you. The board will remain in a stopped state, so you must restart the board.

DM3post also provides an option to run POST on a chassis level. By using the chassis option (`-c`), DM3post will retrieve the results of the last run POST for all DM3 boards in the chassis. By using the chassis option with the reset option, you can run POST on all DM3 boards in the system. When using the chassis option, it is not necessary to provide the bus and slot numbers. Any option other than the reset option will be ignored when using the chassis option. In addition to output on the screen, more detailed output is logged to a log file, `dm3post.log`, by default.

- Notes:**
1. Signal Processors (SP) are not diagnosed by DM3post. However, SP health is verified as part of the board’s download process. Therefore sufficient diagnostic coverage for hardware is obtained when a board passes POST and is successfully downloaded.
 2. For the slot number (`-s` option), provide the PCI slot number. This information may be obtained from the Configuration Manager (DCM), which is described in the HMP Administration Guide.

11.3 Options

The following command line options are used with the DM3post tool:

- s<n>
slot number (required). Use the Configuration Manager (DCM) to obtain the board's slot number.
Note: DCM is described in the HMP Administration Guide.
- b<n>
bus number (optional if there is only one bus *or* if the slot number is unique)
- l
logs event (optional). Output is logged to *dm3post.log*.
- q
suppresses output (optional). The tool operates in silent mode.
- r
resets board before retrieving diagnostics results (optional). If not set, results displayed will be those generated at board startup.
- h
displays the tool's help screen
- v
displays the program version

Example 1: Run DM3post on a board in slot 17, bus 0

The following example runs DM3post on a board in slot 17, bus 0:

```
dm3post -s17 -b0
```

You will get the following response:

```
You have chosen to read the initial POST diagnostic results from the board in slot 17, bus 0. No board reset will occur.
```

```
Do you wish to continue (y/n)?
```

If you answer Y, the following will be printed to the screen:

```
Retrieving results...
```

The success/failure message will be printed to the screen when POST is complete. Here is an example:

```
SUCCESS: POST passed for board in slot 17, bus 0. Diagnostic Codes: 0x03 0xfc
```

Example 2: Dm3 post run with the reset option on a board in slot 17, bus 0

The following example runs DM3post with the reset option on a board in slot 17, bus 0:

```
dm3post -s17 -b0 -r
```


You will get the following response:

```
You have chosen to run diagnostics on the board in slot 17, bus 0.  
Do you wish to continue (y/n)?
```

If you answer Y, the following will be printed to the screen:

```
dm3post processing...
```

The success/failure message will be printed to the screen when POST is complete. Here is an example:

```
SUCCESS: POST passed for board in slot 17, bus 0. Diagnostic Codes: 0x03 0xfc
```



This chapter provides reference information about the getver tool.

- Description. 51
- Options. 51
- Output 52

12.1 Description

The getver (Get Version) software application outputs version information for files that are part of the Intel® Telecom software installation. You specify the file for which you want the version. For example, the following command prints the version string of the *ssp.mlm* file to the screen:

```
getver ssp.mlm
```

Using getver, you can get version information for the following files provided that they follow supported versioning formats:

- Intel NetStructure® board firmware files: **.srec*, **.mlm*
- Intel NetStructure board files: **.hot*, **.psi*
- Windows* Dynamic Load Library files: **.dll*
- Linux* Dynamic Load Library files: **.so*
- Other files part of the Intel Telecom software that follow supported versioning formats (the OA&M executable binaries and libraries have a version that getver can display)

Getver is located in the *bin* directory:

- Windows: *%INTEL_DIALOGIC_DIR%bin*
- Linux: */\${INTEL_DIALOGIC_DIR}/bin*

12.2 Options

This section provides the command line arguments for getver:

```
getver -? <filename> -s -CPU <argument value>
```

Note the following:

- If you are using switches or options, you must use the sequence given above.
- *-?* is a option argument that prints out usage information
- *-s* acts as a switch for processing *srec* files, to be used only if the *srec* file does not end with the *.srec* extension.

- `-CPU` is a case-sensitive option argument to be used for `srec` files only if `getver <filename>` fails. Some possible values are PPC, ONYX, and C6X.

Note: You must specify the path to the file if you do not execute `getver` from the directory in which the file is located (in this case, the `data` directory).

12.3 Output

Getver will print the version string of the specified file to the screen unless it encounters an unknown versioning format. In such a case, `getver` will print the following message to the screen:

```
Version format not recognized - file not processed
```

Here are some examples of output:

- Expected output for new “DLcid” versioning format:
Version: <The version number string following "DLcid">
- Expected Output for old “DLcid” versioning format
Embedded name: <embedded name>
Version: <version number> Build <build number>
- Expected output for Windows versioning format:
Version: <version number>

This chapter provides reference information about the ISDNtrace tool. The following topics are included:

- Description. 53
- Guidelines 53
- Options. 53

13.1 Description

The ISDNtrace tool provides the ability to track Layer 3 (Q.931) messages on the ISDN D-channel. ISDNtrace prints messages on the screen in real time. This trace information can also be captured into a file.

13.2 Guidelines

The ISDNtrace tool consumes a portion of the CPU for each trunk that is logged and may generate an exception if CTRL-C is used to exit the tool. An exception may also be generated if you use an invalid parameter in the command.

13.3 Options

Options

The ISDNtrace tool uses the following command line options:

-b<n>

Logical ID of board (required). Use the Configuration Manager (DCM) to obtain the board's logical ID.

Note: DCM is described in the HMP Administration Guide.

-d<n>

The D-channel number (trunk number) on the specified board (required). The default value is 1.

-f<file>

Output file name (required to save output in a file).

Note: A space is used after the **-f** option but not after **-b** or **-d** options.



The following example runs the ISDNtrace tool on board 0, D-channel 1 and prints the output to a *trace.txt* file:

```
isdntrace -b0 -d1 -f trace.txt
```

This chapter describes the Intel[®] Telecom Subsystem Summary Tool (`its_sysinfo`) and the information it collects. This chapter contains the following information about `its_sysinfo`:

- Description. 55
- Command Line Interface. 55
- Graphical User Interface (Windows only). 56
- Information Collected by `its_sysinfo`. 56
- System Information Data Structuring 59

14.1 Description

The Intel Telecom Subsystem Summary Tool (`its_sysinfo`) provides a simple way to collect information about systems built using Intel[®] telecom products. The `its_sysinfo` tool collects data from the system on which you execute it and provides you with information about the system environment: the operating system, computer architecture, HMP software, and operational logs.

The `its_sysinfo` tool also enables you to collect baseline information about the system for quick review of configuration issues when determining system configuration consistency. This information is collected in a file, compressed, and archived as part of the complete system information collection in an archive file named `its_sysinfo.zip` (or a name you specify). If the installed system is configured in such a way that the baseline information is not available, the `its_sysinfo` tool will indicate “No Information Available.”

In addition to the standard information captured by the `its_sysinfo` tool, you can manually add files to the archive that is created by `its_sysinfo.exe` after you run the tool so you can preserve additional information that might help with resolving issues.

Procedures for using this tool can be found in the following sections:

- Section 5.2, “Collecting System Data to Diagnose an Application Failure or Crash”, on page 32
- Section 5.3, “Creating a System Configuration Archive”, on page 33

14.2 Command Line Interface

On the command line, enter `its_sysinfo filename` where *filename* is the name you want to give the zip file (it can be the complete path). The `its_sysinfo` tool will collect system information

and compress it into the zip file. If you do not specify any filename, then the information gets compressed in a zip file with the default name *its_sysinfo.zip*.

14.3 Graphical User Interface (Windows only)

On a Windows system, you can use a GUI to run *its_sysinfo* as follows:

1. Click on *its_sysinfo.exe* in %INTEL_DIALOGIC_DIR%\bin.
2. Click the **Generate** button. A dialog box appears on which you must name the archive file into which you want the information to be collected. The default filename is *its_sysinfo.zip*.
3. Click the **Save** button and *its_sysinfo* will start collecting information.
4. A pop-up window displaying “Data collection completed. Zip archive was created as <zip file name>” will appear to indicate completion of *its_sysinfo.exe* execution. Click the **OK** button. The archive file is in the location specified in the tool.

14.4 Information Collected by *its_sysinfo*

The following information is collected under *its_sysinfo.htm*, which is one of the files that is added to the archive:

- **General System Information**
 - **Environment Variables** – information about the operating system environment variables
 - **System Event Logs** – See **Table 1**.
 - **Memory and Processor** – information about the platform’s available and used memory and CPU type and number as of the time you executed the *its_sysinfo* tool
 - **Operating System** – information about the operating system’s version, service pack, and language
 - **/proc/meminfo file** – Linux only
- **Information Specific to Intel Telecom Products**
 - **Installed Devices** – *its_sysinfo* collects information about devices detected in Intel Telecom Subsystem configurations and startup.
 - **Configuration Settings for Installed Devices** – *its_sysinfo* captures the stored values used by the configuration tool for Intel Telecom Subsystem configurations and startup. For more information about the configuration tool, refer to the configuration guide(s) for the system release.
 - **Firmware Files and Versions** – *its_sysinfo* collects information about the files listing all firmware file names and version numbers.
 - **FCD Files** – *its_sysinfo* collects information about the *.fcd* files used by the configuration tool for Intel Telecom Subsystem configurations and startup. For more information about FCD files, refer to the administration guide for the HMP release.
 - **PCD Files** – *its_sysinfo* collected information for the *.pcd* file used by the configuration tool for Intel Telecom Subsystem configurations and startup. For more information about PCD files, refer to the administration guide for the HMP release.

- **CONFIG Files** – its_sysinfo collects information about the *.config* file used by the configuration tool for Intel Telecom Subsystem configurations and startup. For more information about CONFIG files, refer to the administration guide for the HMP release.
- **Global Call Configuration** – its_sysinfo collects information about the Global Call PDK subsystem configuration, which is contained in the *pdk.cfg* file. This file specifies the Global Call protocol modules and the country dependent parameter settings downloaded to each device. For more information about Global Call Configuration, refer to the *Global Call Country Dependent Parameters (CDP) Configuration Guide*, which can be found on this website: <http://resource.intel.com/telecom/support/releases/protocols/index.htm>.
- **Build Information** – its_sysinfo collects information about the contents of the *buildinfo.ini* file used for the installed Intel Telecom Software Subsystem. The *buildinfo.ini* file contains information about what is in the build of the software.
- **Board Memory Dumps**
- **Intel Telecom Subsystem Event Viewer Data** – its_sysinfo collects information about the last events reported to the operating system and to the event logger from the Intel Telecom Subsystem.
- **File Versions**

The its_sysinfo tool also checks for the log files listed in Table 1 and adds them to the archive.

Note: It is possible to specify a name for some log files. However, its_sysinfo only collects files with default names.

Table 1. Log Files Archived by its_sysinfo

Log Files	Windows	Linux
OA& M Files	\$(SystemRoot)\System32\anm_debug.log \$(SystemRoot)\System32\anm_trace.log %INTEL_DIALOGIC_DIR%\log\ClusterPkg.log %INTEL_DIALOGIC_DIR%\log\ClusterPkg.log.0 Or \$(SystemRoot)\System32\ClusterPkg.log* \$(SystemRoot)\System32\confslot.log %INTEL_DIALOGIC_DIR%\log\ctbb*.log Or \$(SystemRoot)\System32\ctbb*.log dlgcInstall.log is in \$(TEMP) %INTEL_DIALOGIC_DIR%\log\dlgcyslogger.log %INTEL_DIALOGIC_DIR%\log\DM3AutoDump.log \$(SystemRoot)\System32\dm3bsp.log \$(SystemRoot)\System32\dm3fdspdll.log \$(SystemRoot)\System32\frustatus.log %INTEL_DIALOGIC_DIR%\log\GenLoad.log %INTEL_DIALOGIC_DIR%\log\merc.log Or \$(SystemRoot)\System32\merc.log %INTEL_DIALOGIC_DIR%\log\ncm.ini %INTEL_DIALOGIC_DIR%\log\oam.log %INTEL_DIALOGIC_DIR%\log\Sctsassi.log	\$(INTEL_DIALOGIC_DIR)/log/board*.log \$(INTEL_DIALOGIC_DIR)/log/clusterpkg.log \$(INTEL_DIALOGIC_DIR)/log/clusterpkg.log.* \$(INTEL_DIALOGIC_DIR)/log/dgsyslogger.log \$(INTEL_DIALOGIC_DIR)/log/genload.log \$(INTEL_DIALOGIC_DIR)/log/iptconf.log \$(INTEL_DIALOGIC_DIR)/log/oam.log

Table 1. Log Files Archived by its_sysinfo (Continued)

Log Files	Windows	Linux
Demos	%INTEL_DIALOGIC_DIR%\log\rgademo.log %INTEL_DIALOGIC_DIR%\log\Board[#].log	\$(INTEL_DIALOGIC_DIR)/log/rgademo.log \$(INTEL_DIALOGIC_DIR)/log/Board[#].log \$(INTEL_DIALOGIC_DIR)/log/dlgrhdemo.log
RTF log Files	<Logfile path>/rtflog*.txt <Logfile path> found in \$(INTEL_DIALOGIC_DIR)\cfg\RtfConfigwin.xml or \$(DLFCGPATH)\rtfconfig.xml	<Logfile path>/rtflog*.txt <Logfile path> specified in \$(INTEL_DIALOGIC_DIR)/cfg/RtfConfigLinux.xml
	<Logfile path>/rtflog.txt <Logfile path> specified in \$(DLFCGPATH)\rtfconfig.xml	<Logfile path>/rtflog*.txt <Logfile path> specified in \$(DLGCGPATH)/RtfConfigLinux.xml
CASTrace log Files	\$(INTEL_DIALOGIC_DIR)\log\CASttrace.log	\$(INTEL_DIALOGIC_DIR)/log/CASttrace.log.*
Debug Angel Files	\$(INTEL_DIALOGIC_DIR)\bin\DebugAngel.log	\$(INTEL_DIALOGIC_DIR)/log/debugangel.*
Pstndiag Trace log Files	\$(INTEL_DIALOGIC_DIR)\log\pstndiag.*	\$(INTEL_DIALOGIC_DIR)/log/pstndiag.*
IP Protocol Files	\$(SystemRoot)\System32\gc_h3r.log Or \$(INTEL_DIALOGIC_DIR)\bin\gc_h3r.log \$(SystemRoot)\System32\rtvsp1.log Or \$(INTEL_DIALOGIC_DIR)\bin\rtvsp1.log \$(SystemRoot)\System32\sdplug.txt Or \$(INTEL_DIALOGIC_DIR)\bin\sdplug.txt \$(SystemRoot)\System32\siplug.txt Or \$(INTEL_DIALOGIC_DIR)\bin\siplug.txt Note: This is obsolete. IP protocols supports RTF.	\$(HOME)/g*.log \$(HOME)/rtvsp1.log Note: This is obsolete. IP protocols supports RTF.
Dr. Watson Dump and Log Files	\$(USERPROFILE)\Local Settings\Application Data\Microsoft\Dr Watson\DrWtsn32.log	
its_sysinfo logfile files...	its_sysinfo.log	its_sysinfo.log

- Notes:**
1. Windows: INTEL_DIALOGIC_DIR=C:\Program Files\Dialogic and SystemRoot=C:\WINNT
 2. Linux: INTEL_DIALOGIC_DIR=/usr/dialogic/ and HOME=/root

14.5 System Information Data Structuring

Data collected by its_sysinfo will be available as a single compressed file that contains the following:

- A master data file in HTML format.
- 0 or more files as attachments. The HTML file will contain links and explanations of the attachments.
- An application operation log file generated the during data collecting process.
- The operation log files and attachments will be put in the compressed zip file.



This chapter provides reference information about the kernelver tool. The following topics are provided:

- Description. 61
- Options. 61

15.1 Description

The KernelVer tool queries the board's kernel running on a particular processor for its version number. This tool can be used to verify whether or not a processor has crashed.

15.2 Options

The kernelver tool uses the following command line options:

- b<n>
Logical ID of board (required). Use the Configuration Manager (DCM) to obtain the board's logical ID.
Note: DCM is described in the HMP Administration Guide.
- d<level>
Do not modify. Leave this at the default value of 0.
- f<file>
Output file name (required to save output in a file).
- p<n>
Processor number (required). Lowest allowable value is 1.
- l<n>
Number of times the program will retrieve the version (optional). You can use this option to repeatedly ping the board's kernel to generate message traffic.
- h
Displays the help screen.
- v
Displays the version number.

The following example runs the KernelVer tool on board 1, processor 2:

```
kernelver -b1 -p2
```



This chapter provides reference information about the MercMon tool. The following topics are included:

- [Description](#) 63
- [Guidelines](#) 63
- [Options](#) 67

16.1 Description

MercMon provides counter information about DM3 board device drivers (Class Driver and Protocol Drivers). These drivers maintain various counters that can aid in monitoring system activities and interpreting system behaviors.

16.2 Guidelines

The MercMon tool provides counter information about a DM3 board's class driver and protocol driver. The following sections list the types of counters for each driver:

- [Class Driver Counters](#)
- [Protocol Driver Counters](#)

16.2.1 Class Driver Counters

This section provides details about the class driver counters that are used by the MercMon tool. The class driver counters are as follows:

Note: All counters are on a per board basis except for FailMpathFind and FailStrmFind.

CompleteReads

returns the size (in bytes) of all the read requests completed by the protocol driver (i.e., the actual size in KB of all the data read from the board)

CompleteSends

returns the size (in bytes) of all the messages sent to or received from the board

CompleteWrites

returns the size (in bytes) of all the write requests completed by the Protocol Driver (i.e., the actual size in KB of all the data written to the board)

FailMpathFind

returns the number of times a request to get a message handle (Mpath) failed (global counter)

FailStrmFind

returns the number of times a request to get a stream handle failed (global counter)

- NumCanTakes**
returns the number of “can takes” received for that board
- NumReads**
returns the total number of read requests sent down to the protocol driver
- NumSends**
returns the total number of messages sent down to the protocol driver
- NumWrites**
returns the total number of write requests sent down to the protocol driver
- NumWriteSplit**
returns the number of write requests, which were split for that board
- NumOpenedStreams**
returns the number of open streams on that board at any given time
- NumCloseStreamErr**
returns the number of stream close requests failed on that particular board
- NumOpenStreamErr**
returns the number of stream open requests failed on that particular board
- NumStreamClose**
returns the number of stream close requests on that particular board
- NumStreamOpen**
returns the number of stream open requests on that particular board
- SizeReads**
returns the size (in bytes) of all the messages posted down to the protocol driver
- SizeSends**
returns the size (in bytes) of all the messages sent down to the protocol driver
- SizeWrites**
returns the size (in bytes) of all the write requests sent down to the protocol driver
- TimeoutReads**
returns the number of read requests that timed out
- TimeoutSends**
returns the number of messages that timed out while waiting to be sent to the board or awaiting a reply from the board
- TimeoutWrites**
returns the number of write requests that timed out

16.2.2 Protocol Driver Counters

This section provides details about the protocol driver counters that are used by the MercMon tool. The protocol driver counters are as follows:

- MsgsInPerSramSession**
returns the number of messages read from the SRAM in one session

MsgsOutPerSramSession	returns the number of messages written to the SRAM in one session
NoInDataDPCisr	returns the number of times when we received an interrupt but there was no data transfer between the SRAM and the HOST
StrmsOutPerSramSession	returns the number of streams written to the SRAM in one session (i.e., number of data blocks written)
StrmsInPerSramSession	returns the number of streams read from the SRAM in one session (i.e., the number of data blocks read)
TotalAsyncMsgQDone	returns the number of requests completed in the AsyncMsgQ
TotalBadSramAddr	returns the number of times we tried reading a message/data (streams) from the SRAM but the SRAM address was wrong
TotalBadSramAddrAlloc	returns the number of times the system tried to allocate a data block but the address was wrong
TotalBadSramAddrRelease	returns the number of times the system tried to release a data block but the address was wrong
TotalBadSramDataCount	returns the total number of times we got a data block of size greater than the SRAM_DATA_BLOCK_SIZE
TotalBadSramOffset	returns the number of times we tried reading data (streams) from the SRAM but the offset calculation was incorrect
TotalBadSramOffsetAlloc	returns the number of times we allocated data block but the offset was incorrect
TotalBigMessagesRcvd	returns the number of times we read a “BIG” message from the SRAM (i.e., message size greater than 24 bytes)
TotalBigMessagesSent	returns the number of times we wrote a “BIG” message to the SRAM (i.e., message size greater than 24 bytes)
TotalBogusInterrupts	Not Used
TotalDpcOverruns	returns the total number of DPC overruns (i.e., we were not expecting an interrupt but we got one)
TotalDmaInterrupts	returns the total number of interrupts received from the board for performing DMA

- TotalFatSramBlocks**
returns the number of times the system received a “CHAINED” data block (i.e., the data blocks are linked together)
- TotalIrpcCancelled**
returns the total number of cancelled requests in any queue
- TotalMsgInQ**
returns the number of requests in the Message In Queue, which are awaiting a reply from a board
- TotalMsgInQDone**
returns the number of requests completed from the Message In Queue (i.e., requests completed and sent to the application)
- TotalMsgInSram**
returns the total number of messages read from the SRAM
- TotalMsgOutQDone**
returns the number of requests completed from the Message Out Queue (these requests are sent to the board and then moved to the Message In Queue, if expecting a reply, or completed and sent to the application)
- TotalMsgOutSram**
returns the total number of messages written to the SRAM
- TotalMsgOverruns**
returns the total number of overruns for the orphan message queue (i.e., we had an orphan message but there was no space in the Orphan Message Queue)
- TotalMsgTimeouts**
returns the total number of requests timed out while waiting to be written to the SRAM or awaiting a reply from the SRAM (i.e. either in the Message In Q, Message Out Q or the Async Message Q)
- TotalOrphanMsgsv**
returns the total number of Orphan Messages (i.e., messages which were read from the SRAM but do not have any pending requests from the application)
- TotalOrphanMsgVolume**
returns the size (in bytes) of the messages present in the Orphan message queue at any given time
- TotalOrphanStrms**
returns the total number of Orphan Streams in the Orphan Stream Table (i.e., data which was read from the SRAM but did not have any pending Read Requests from the application)
- TotalOrphanStrmMatches**
returns the total number of streams matched in the Orphan Stream table
- TotalOrphanStrmVolume**
returns the size (in bytes) of the data present in the Orphan Stream table at any given time
- TotalSramDataFull**
returns a count of the number of times the HOST tried to write a stream (data) to the SRAM but the SRAM was full

- TotalSramGrantInterrupts**
returns the number of “HOST SRAM PENDING” interrupts
- TotalSramGrantLost**
not used
- TotalSramInterrupts**
returns the total number of “NORMAL” interrupts received from the board (e.g., there is something to read from the SRAM)
- TotalSramMsgFull**
returns a count of the number of times the HOST tried to write a message to the SRAM but the SRAM was full
- TotalStrmInQ**
returns the number of read requests pending in the Stream In Queue
- TotalStrmInQDone**
returns the number of read requests completed from the Stream In Queue (i.e., read requests completed and sent to the application)
- TotalStrmInSram**
returns the number of data packets read from the SRAM
- TotalStrmOutQ**
returns the number of writes performed by the user on that particular board. It is also incremented whenever the application sends an End Of Stream command.
- TotalStrmOutQDone**
returns the number of Write requests completed from the Stream Out Queue (i.e., Write requests completed and sent to the application)
- TotalStrmOutSram**
returns the number of data packets written to the SRAM
- TotalStrmOverruns**
returns the number of Overruns for the Orphan Stream Table (e.g., we had an Orphan Stream but we had exceeded the maximum amount of memory allocated for the Orphan Stream Table or we could not allocate memory.)
- TotalStrmTimeouts**
returns the total number of Read or Write Requests timed out (from the Stream In Queue or the Stream Out Queue)
- TotalUnknownInterrupts**
returns the total number of unknown interrupts received from the board

16.3 Options

The MercMon tool uses the following command line options:

- /f<file>**
log file name (default is *mercmon.log*)

- `/t<n>`
display timer. The time interval (in milliseconds) between each screen refresh (default is 1000).
- `/l<n>`
logging interval. The time interval (in seconds) between each log file update (default is 600).
- `/w`
enable/disable logging to a file (default is enabled)
- `/?`
displays the help screen

The following example enables logging to the *mercmon.log* file every five minutes and refreshes the screen every two seconds:

```
mercmon /t 2000 /l 300
```

This chapter provides reference information about the PDK Trace tool. The following topics are included:

- Description. 69
- Guidelines 69
- Options. 70
- Sample Scenarios. 70

17.1 Description

The DM3 PDK Protocol Trace (PDK Trace) tool allows those who use a DM3 PDK protocol to log specific information related to the operation of the protocol. The PDK Trace tool is useful for protocol developers because it can trace the runtime states, input signals, output signals, and decision branches of the SDL protocol. The PDK Trace tool allows you to specify which channels on the board to begin tracing. This can be a single channel on one trunk, a single channel on multiple trunks, a range of channels on one trunk, or a range of channels on multiple trunks.

PDK Tracing will work on any of the following products with a PDK protocol loaded: Intel NetStructure® DM/V, DM/V-A, DM/V-B, DM/F, and DMT160TEC boards. PDK tracing is not supported for Intel NetStructure® on DM3 architecture analog boards and Intel NetStructure® DM/IP boards.

Note: If you are using an Intel NetStructure DM/IP board and get the following error message, you can ignore it (the error message appears in DebugAngel - see [Chapter 8, “DebugAngel Reference”](#)):

```
001:CP1:Cause-Tag : 80013, Error File :qkernerr.h.-Failed to find tracer component address
```

17.2 Guidelines

The PDK Trace tool’s executable name is *pdktrace.exe* for the Windows operating system and *pdktrace* for the Linux operating system. The PDK Trace tool is a command line application that will create a system process thread to interact with the DM3 system to capture trace data. This data will be streamed to a file on the host system.

Upon completion of tracing, the data will be stored on the host system in a file specified when tracing was started (default: *pdktrace.log*). The file is in an unreadable binary format and will need to be converted to a readable format. For help with this, contact technical support (<http://resource.intel.com/telecom/support/contact.htm>).

17.3 Options

The PDK Trace tool uses the following command line options:

-b#

This **required** option specifies the logical board ID of the board to trace.

Example: `pdktrace -b0` where 0 is the logical board ID of the destination board.

-l[#] or -l[#-#]

Specify which trunk(s) the channels to be traced are located on. The default value is 1 (trunk 1).

Example 1: `pdktrace -b0 -l[1] /* Single trunk */`

Example 2: `pdktrace -b0 -l[1-4] /* Range of trunks */`

-c[#] or -c[#-#]

Specify which channel(s) on the specified trunks to trace. The default value is 1 (channel 1).

Example 1: `pdktrace -b0 -l[1] -c[5] /* Single channel */`

Example 2: `pdktrace -b0 -l[1-4] -c[1-30] /* Range of channels */`

-f[filename]

Specify the name of a file on the host system to write the trace data to. The default is `pdktrace.log`.

-i

This option is **required** only when you **first** use the PDK Trace tool. This option is used to initialize the DM3 Tracer Component in the firmware.

Note: This option should only be used the first time the utility is executed after the board is downloaded

-v

Prints the version number of the utility.

-, -h

Prints the help screen (command line options) for the utility.

Warning: Due to memory constraints in the embedded DM3 system, the tool will limit the number of channels that can be traced simultaneously to 60. Trying to trace more than 60 channels per board can cause unpredictable results.

17.4 Sample Scenarios

The following are some sample scenarios in which the PDK Trace tool can be used and the command line options used to specify each configuration. These sample scenarios assume that the logical ID of the board being used is 0.

Scenario 1: For board 0, trace channel 1 on trunk 1

```
pdktrace -b0
pdktrace -b0 -l[1]
pdktrace -b0 -l[1] -c[1]
```

Scenario 2: For board 0, trace channels 10-20 on trunk 1

```
pdktrace -b0 -c[10-20]
pdktrace -b0 -l[1] -c[10-20]
```

Scenario 3: For board 0, trace channel 1 on trunks 1-4

```
pdktrace -b0 -l[1-4]
pdktrace -b0 -l[1-4] -c[1]
```

Scenario 4: For board 0, trace channels 1-24 on trunks 1-4

```
pdktrace -b0 -l[1-4] -c[1-24]
```

Note: If any of the above scenarios were being executed on a board for the first time after it was downloaded, the `-i` command line option should also be used as follows:

```
pdktrace -b0 -l[1-4] -c[1-24] -i
```



This chapter provides reference information about the Phone tool. The following topics are included:

- [Description](#) 73
- [Guidelines](#) 73
- [Options](#) 73

18.1 Description

The Phone tool uses the TSC and ToneGen instances and requires a TSC component. The Phone tool can control a single DM3 resource channel (make calls, wait for calls etc.), monitor channel and call states, and send call control operations to a DM3 Global Call resource.

18.2 Guidelines

Phone is a QScript utility. For more information about QScript utilities, refer to [Chapter 20](#), “QScript Reference”.

18.3 Options

The Phone tool uses the following command line options:

`-b<n>`

Logical ID of board (required). Use the Configuration Manager (DCM) to obtain the board's logical ID.

Note: DCM is described in the HMP Administration Guide.

`-l<n>`

Line number (optional). The default value is 1.

`-chan<n>`

Channel number (optional). The default value is 1.

The following example runs the Phone tool on board 1, line 1:

```
phone -b1 -l1
```



PSTN Diagnostics Tool Reference **19**

This chapter provides the following reference information about the PSTN Diagnostics tool (pstndiag):

- [Description](#) 75
- [Guidelines](#) 76
- [Preparing to Run the PSTN Diagnostics Tool](#) 76
- [Running the PSTN Diagnostics Tool](#) 76
- [Checking the pstndiag Log File](#) 83
- [PSTN Diagnostics Menus](#) 84
- [PSTN Diagnostics Command Line Options](#) 85

For information about how to use the pstndiag tool to perform diagnostic tasks, refer to these chapters:

- [Chapter 3, “Diagnosing First Call Issues”](#)
- [Chapter 4, “Diagnosing PSTN Protocol Issues”](#)

19.1 Description

The PSTN Diagnostics tool (pstndiag) is a utility for diagnosing and troubleshooting public switched telephone network (PSTN) connectivity problems on specific hardware products based on DM3 architecture.

The pstndiag tool allows you to perform the following activities:

- Query the system for board information
- View all boards in the system that have been downloaded
- Monitor all components (boards, trunks, channels) in the system, and view trunk and channel information, such as trunk status, alarm status, channel state, and call state
- Display the protocol family running on a channel (ISDN or CAS)
- Produce a consolidated log file for all components that are being actively monitored in the system
- Display a previously saved log file
- Launch the ISDNtrace and CAStrace tools to perform further diagnostic tests

19.2 Guidelines

The following restrictions apply to the pstndiag tool:

- The tool is not supported on boards based on Springware architecture.
- It is recommended that you view or monitor no more than 8 channels in your system at one time. Viewing more than 8 channels at one time may negatively impact system performance.
- The pstndiag tool will only identify and list boards with PSTN front-end interfaces. Boards that do not have PSTN front-end interfaces (for example, resource only) will not be presented and cannot be monitored or manipulated by pstndiag.

Pstndiag is a QScript utility. For more information about QScript utilities, refer to [Chapter 20, “QScript Reference”](#).

19.3 Preparing to Run the PSTN Diagnostics Tool

Before running the pstndiag tool, ensure that you have performed the following tasks:

1. The HMP software has been properly installed.
2. The HMP system has been started for the boards in your system. The pstndiag tool will detect boards that have already been downloaded.

19.4 Running the PSTN Diagnostics Tool

This section provides instructions for running the pstndiag tool and describes the user interface. The following topics are covered:

- [Starting the PSTN Diagnostics Tool](#)
- [The Main Window](#)
- [The View Bar](#)
- [Option Buttons and Command Buttons](#)
- [Keyboard Navigation](#)

19.4.1 Starting the PSTN Diagnostics Tool

This section contains instructions for starting the pstndiag tool in Windows and in Linux.

To start the pstndiag tool in **Windows**, follow these instructions:

1. Open a command prompt window. The default location of the tool is `%INTEL_DIALOGIC_DIR%\qscript\tools\pstndiag\`. However, you can run the tool from any location.
2. At the command prompt, type:
`pstndiag`

To start the pstndiag tool in **Linux**, type `pstndiag` from the command line of a `cmd` prompt. No arguments are required because the path is set by the install of the Intel Dialogic System Release software.


- Notes:**
1. You can specify options at the command line. For more information on these options, see [Section 19.7, “PSTN Diagnostics Command Line Options”](#), on page 85.
 2. If a board is stopped after you have launched the pstndiag tool, you will need to exit from the tool, restart the board, and relaunch the tool to use it again.

19.4.2 The Main Window

After you have launched the pstndiag tool, the **main window** displays a hierarchical tree of all known components in your system. This view is called the **system level view**. The tree consists of three levels: board, trunk, and channel. At the top level, the tree lists all boards that have been downloaded in your system. For each board, all trunks (or spans) are listed. For each trunk, all channels within a trunk are listed. Each of these components (board, trunk, channel) is called a device. The tree can be collapsed or expanded by clicking on the + and - icons.

Figure 5 illustrates a system level view of a DM/V960A-4T1-PCI board.

Figure 5. PSTN Diagnostics Tool - System Level View



The numbering convention, *x.y.z*, is used to identify a component in the tree, for example “**Channel 0.2.1**”, where:


- *x* is an integer that represents the **board** logical ID, in this example **0**
- *y* is an integer that represents the **trunk** on that board, in this example **2**
- *z* is an integer that represents the **channel** number on that trunk, in this example **1**

If only one number is used in the identifier, this number represents the board, such as Board 0 and Board 1. If two numbers are used in the identifier, such as Trunk 0.2 and Trunk 1.5, the first number represents the board and the second number represents the trunk.

19.4.3 The View Bar

The **view bar** contains two option buttons: one (1) represents the upper pane, and the other (2) represents the lower pane. When you first launch the `psndiag` tool, the system level view is displayed in the upper pane; the lower pane is empty. The view bar shows these two option buttons: “**1 System**” and “**2 None**”. Figure 6 illustrates a sample view bar.

Figure 6. PSTN Diagnostics Tool - View Bar



The label on the option button changes according to what is displayed in that pane. Once a component has been opened, it is then available from both option buttons. To display a component in the upper pane or lower pane, select it from the appropriate option button. To close a view, right-click on the component in the option button and click close view. Alternatively, double-clicking on a component in the system level view displays that component in the upper pane. Shift-double-clicking displays the component in the lower pane.

A view can display a system, a board, a trunk, a channel, or a log file. For example, in a back-to-back test scenario, you might want to display two channel level views at one time. Or you might want to display a board level view and a log file view.


19.4.4 Option Buttons and Command Buttons

Option buttons are buttons that provide additional options. These buttons are identified by a short horizontal bar, as seen in Figure 9 through Figure 16. Click on a button to view additional options, and click on an option to select it. An action occurs, or a new set of parameters is displayed. The use of option buttons allows related information to be grouped together and helps to reduce clutter on the screen.

Command buttons are buttons that when pressed activate a command. There are two types of command buttons: those that toggle between two actions (these are identified by two periods following the button name) and those that issue a command directly. For example, the


ResetLineDevice.. button in Figure 7 toggles between setting a channel in service and out of service.

Figure 7. Toggle Command Buttons



Examples of command buttons that issue a command directly are the MakeCall, DialDigits, Drop, and Release buttons in a channel level view shown in Figure 8. Click on a button to issue a command.

Figure 8. Direct Command Buttons



Following is a list of the option buttons. There is a submenu of command buttons under each of the option buttons.

Channel State Commands

The commands under this button are as follows:


SetChanState

Set a channel in service or out of service

ResetLineDevice

Drop all calls on the channel and return the call state to Idle

Figure 9. Channel State Command Buttons



Outbound Call Control Commands

The commands under this button are as follows:

MakeCall

Place an outgoing call

- Drop
Delete a call
- DialDigits
Generate signals for selecting and establishing a connection
- Release
Release the active call on the channel.

Figure 10. Outbound Call Control Command Buttons




Inbound Call Control Commands

The commands under this button are as follows:

- AnswerCall
Answer the call
- AcceptCall
Accept the call (this precedes the option of handing off the call to another client or party)
- ProceedCall
Proceed the call (this sends the call proceeding message to the originating side, and waits for Accept (to accept call) or Answer (to answer call) as a subsequent command from the host for further progress of the call). This is available only for ISDN.
- RejectCall
Reject the call
- RedirectCall
Redirect the call elsewhere.

Figure 11. Inbound Call Command Buttons



Call Hold Commands

Note: The following commands are advanced functions for technical support use only.

The commands under this button are as follows:

HoldCall

Place a call on hold. A call that is on hold is disconnected from the external receive and transmit data streams that are associated with the Telephony Service Channel (TSC) instance. Once the call is on hold, the client is free to establish a new call, either by making an outbound call, or by receiving an inbound call.

RetrieveCall

Retrieve a call that is on hold, and bring it to the active state. The completion of the Retrieve Call operation is indicated via a Call State event that reports the call state transition to Connected. Note that if there is a call active when the RetrieveCall command is issued, then that call will be placed on hold, so the command can be used to alternate between two calls.

ReconnectCall

An alternative to the RetrieveCall command, ReconnectCall will retrieve a call that is on hold and make it the active call. The difference is that if a call is active when the command is issued, that call will be dropped rather than put on hold.

Figure 12. Call Hold Command Buttons



Call Transfer Commands

Note: The following commands are advanced functions for technical support use only.

The commands under this button are as follows:

BlindTransfer (single-stage blind-transfer)

Place the target call on hold, make a consultation call to the destination address, and then hand off the target call to the destination without determining the outcome of the consultation call. The target call's call state will transition first to HoldPendXfer, and then to Idle.

InitTransfer (part of multi-stage transfer)

Place the target call on hold (HoldPendXfer) and initiate a consultation call to the destination address.

CompleteTransfer (part of multi-stage transfer)

Transfer the call that was the target of the InitTransfer command to the destination address.

CancelTransfer (part of multi-stage transfer)

Cancel a supervised transfer by dropping the consultation call and reconnecting to the call that was the target of the transfer operation.

Figure 13. Call Transfer Command Buttons




SendISDN Command

Note: The following command is an advanced function for technical support use only.

The command under this button is as follows:

SendISDN
Sends an arbitrary call-associated Q.931 ISDN Message.

Figure 14. SendISDN Command Button



Misc. Commands

Note: The following commands are advanced functions for technical support use only.

The commands under this button are as follows:


Complete
This command is not currently used.

CancelComplete
This command is not currently used.

Park
This command is not currently used.

Pickup
This command is not currently used.


Figure 15. Misc. Commands Buttons



External Applications

The Audio command is not functional.

Figure 16. External Application Command Button



19.4.5 Keyboard Navigation

You can use the following keyboard keys to navigate through the pstndiag tool:

Up Arrow/Down Arrow

Scrolls through devices in the tree.

Left Arrow/Right Arrow

Collapses or expands a level in the tree.

Return or Double-click

When a component is highlighted, creates a view for this component in the upper pane.

Shift-Return or Shift-Double-click

When a component is highlighted, creates a view for this component in the lower pane.

Right-click

When a button in the View bar is highlighted, displays the close view option.

19.5 Checking the pstndiag Log File

This section describes the log file generated by the pstndiag tool.

Logging starts automatically when you launch the pstndiag tool. Logging information is written to the log file for any component (board, trunk, and channel) that is being monitored and opened in a view. The log file is in binary format and must be viewed in the pstndiag tool.

Caution: The diagnostics log file has no maximum size. After completing diagnostics tasks, you should exit the pstndiag tool. Do not run the pstndiag tool indefinitely; otherwise, the resulting log file may consume a large amount of disk space.

The default log file name is *pstndiag.yyyyymmdd.hhmmss.pdlog*, where *yyyy* is the year, *mm* is the month, *dd* is the day, *hh* is the hour, *mm* is the minute, and *ss* is the second when the file is created. Each time the tool is run, a new log file is created. Running multiple copies of the tool will result in multiple log files. The log file is written by default to the standard log directory:

- Windows - %INTEL_DIALOGIC_DIR%/log
- Linux - \${INTEL_DIALOGIC_DIR}/log

The log file generated by the pstndiag tool captures all events associated with your use of this tool. There are two types of events: application events (AppEvent) and message events (MsgEvent). The application events are generated as actions occur in the pstndiag tool; for example, line out of service. Message events are messages from the firmware in response to application events or asynchronous events; for example, trunk active. If you run other applications such as demos, only message events are generated. The log file also captures application errors (AppErrors).

A time stamp is provided for each event as it occurs. The event is associated with a board, trunk, or channel. For example, AppEvent(0.2.1) is associated with board 0, trunk 2, and channel 1. The log file also provides a graphical view of each event as it occurs over time.

To display the current log file, select View running log from the Log menu. To view a previously saved log file, select Open log file from the File menu.

19.6 PSTN Diagnostics Menus

This section provides a reference to the menus available in the PSTN Diagnostics or pstndiag tool:

- [File menu](#)
- [Log menu](#)
- [View menu](#)
- [Help menu](#)

19.6.1 File menu

The File menu contains the following menu options:

Open log file

Opens a previously saved log file.

Exit

Exits the tool.

19.6.2 Log menu

The Log menu contains the following menu options:

View running log

Displays the current log file in a window.

Logging active

Enables logging. The default setting is logging enabled. To disable logging, you can use the “-nolog” option at the command line. For information on command line options, see [Section 19.7, “PSTN Diagnostics Command Line Options”](#), on page 85.

19.6.3 View menu

The View menu contains the following menu options:

Open system view

Opens a system level view.

Open new view

Opens a board, trunk, or channel level view.

19.6.4 Help menu

The Help menu contains the following menu options:

About

Displays the version number of the pstndiag tool as well as copyright information.

Command line

Displays information about command line options.

General information

Displays information about menus, menu options, and views.

19.7 PSTN Diagnostics Command Line Options

Command line options enable you to bypass the system level view and display a specific board, trunk, or channel level view when you start the pstndiag tool.

The following command line options are available:

-b<*b*>

Starts with a specified board level view, where <*b*> represents the board logical ID.

Example: -b3 will display the board level view for Board 3 in your system.

-board <*b*>

Same as -b<*b*>.

-c<*b*>.<*t*>.<*c*>

Starts with a specified channel level view, where <*b*> represents the board logical ID, where <*t*> represents the trunk (span) on the board, and where <*c*> represents the channel.

Example: -c3.1.24 will display the channel level view for channel 24 on trunk 1 of board 3.

-chan <*b*>.<*t*>.<*c*>

Same as -c<*b*>.<*t*>.<*c*>.

-t<*b*>.<*t*>

Starts with a specified trunk level view, where <*b*> represents the board logical ID and where <*t*> represents the trunk on that board.

Example: -t3.1 will display the trunk view for trunk 1 of board 3.

-trunk <*b*>.<*t*>

Same as -t<*b*>.<*t*>.

- help
Displays help information for the tool.
- logto <*file*>
Saves log information from open views to the specified file name.
- nolog
Does not automatically log events for open views.
- noscan
Does not perform an initial system scan to determine available resources. All views must be opened manually in this mode. Using this option can reduce the time it takes for the tool to start.
- openlog <*file*>
Starts by displaying the specified log file. The log file extension is *.pdlog* (this file must be viewed in the pstndiag tool). When specifying a directory path, use forward slash.
Example: -openlog c:/temp/test.pdlog

This chapter provides information about QScript utilities, which are a subset of the diagnostic utilities.

- [Description](#) 87
- [File Directories](#) 87
- [QScript Environment Variables](#) 87

20.1 Description

The QScript utilities are a subset of the diagnostic utilities. QScript is an object-oriented scripting tool developed for the Intel NetStructure® boards.

The following diagnostic utilities use QScript:

- CallInfo
- DigitDetector
- Phone
- PSTN Diagnostics or pstndiag (uses several QScript utilities)

20.2 File Directories

The directory for the Windows batch file used to invoke the QScript tools is:

```
%systemroot%\program files\diallogic\bin
```

The QScript tools developed by Intel are located in:

```
%systemroot%\program files\diallogic\qscript
```

Note: Do not run a *<toolname>.qs* file directly. Batch files have been created which call the QScript interpreter to run the *<toolname>.qs* file. To use a QScript utility, specify the utility name and parameters on the command line.

20.3 QScript Environment Variables

This section describes the QScript environment variables:

- [INTEL_DIALOGIC_QSCRIPT Environment Variable](#)
- [Single Session Variable](#)

INTEL_DIALOGIC_QSCRIPT Environment Variable

In a Windows environment, this variable is set during software installation.

Single Session Variable

Set the variable for a single session using the `set` command. To permanently set the environment variable for all login sessions, update the variable in the System Properties Environment tab.

Runtime Trace Facility (RTF) Reference

This chapter provides an overview of the Runtime Trace Facility (RTF), including information about editing the RTF configuration file (*RtfConfigLinux.xml* for Linux* and *RtfConfigWin.xml* for Windows*) file to set tracing configuration options. Reference information about the RTF command line options is also included. This chapter contains the following subsections:

- Description. 89
- Installing RTF 90
- RTF Configuration File 90
- Restrictions and Limitations 102
- rtftool Command 103
- Example RTF Configuration Files. 104
- Configuring Remote RTF Logging 107

A procedure for using the tool is provided in [Chapter 5, “Debugging Software”](#).

21.1 Description

RTF provides a mechanism for tracing the execution path of the runtime libraries for the Intel NetStructure® Host Media Processing (HMP) software. All libraries that use RTF write their trace messages to a log file. The resulting log file helps troubleshoot runtime issues for applications that are built with HMP software.

RTF obtains trace control settings and output formatting from an RTF configuration file (*RtfConfigLinux.xml* for Linux and *RtfConfigWin.xml* for Windows). Each runtime library has several levels of tracing that can be dynamically enabled/disabled by editing the RTF configuration file while your application runs. This allows RTF to be configured to meet specific needs.

Major RTF components include:

- Client library (*librtfmt.dll* for Windows, *librtf.so* for Linux): Dynamic loaded library that provides the software interface to make use of RTF functionality.
- Configuration file (*RtfConfigWin.xml* for Windows, *RtfConfigLinux.xml* for Linux): Editable file that allows you to customize the tracing and output capabilities of RTF (for example, which runtime libraries RTF will trace, the trace levels, location and size of backup log files.)
Note: You must have administrative rights to modify the *RtfConfig*.xml* files.
- Server application (*RtfServer.exe* for Windows, *RtfServer* for Linux): Service that communicates to all RTF clients, receives trace data from clients, and dispatches data to disk.

- Utility program (*rtftool.exe* for Windows, *rtftool* for Linux): Command line application that allows you to execute RTF functionality from command line or shell scripts.
- Utility program (*RtfTrace.exe*): Command line application that allows you to execute RTF functionality from command line or shell scripts. This is provided for backward compatibility only. All of this utility's functionality is covered in *rtftool.exe*.

21.2 Installing RTF

RTF files are installed as part of the Intel Dialogic system software installation. The RTF configuration file's default installation directory is determined by the INTEL_DIALOGIC_CFG environment variable. Refer to the *Intel Dialogic System Release Software Installation Guide* for information about Intel Dialogic system software environment variables. Because the RTF configuration file's **trace** attribute is set to 1, RTF tracing is enabled by default. Other than editing the RTF configuration file to customize trace settings for your development environment, there are no special configuration steps for starting RTF.

21.3 RTF Configuration File

To make full use of RTF, you will want to modify the RTF configuration file (*RtfConfigLinux.xml* for Linux, *RtfConfigWin.xml* for Windows). This configuration file allows you to define which trace messages will be included in the RTF output. This subsection provides some guidelines for modifying the RTF configuration file and reference information about the file's XML tags and attributes.

Note: You must have administrative rights to modify the *RtfConfig*.xml* files.

The RTF configuration file uses several terms that should be understood before attempting to edit the file. The following definitions should be kept in mind as you edit the RTF configuration file:

module

a binary file, typically an executable or a shared object library file (.so). An RTF module corresponds to a library or software module that has internal RTF APIs incorporated into its source code.

client

an entity for identifying a device (e.g. "dxxxB1C1"), component (e.g. "WaveFileSource") or a function (e.g. "**dx_play**()") that is to be traced by RTF.

label

an attribute associated with a trace statement (e.g. "Error", "Warning", "Info", "External API entry", "External API exit" etc.). A trace statement's label is used by the trace data output for categorization purposes.

trace entry

individual entries in the trace data output. The trace data output is typically sent to a file or debug stream.

0

when a 0 appears next to a configuration item in the RTF configuration file, it indicates that the configuration item is disabled.


1 when a 1 appears next to a configuration item in the RTF configuration file, it indicates that the configuration item is enabled.

The RTF configuration file's top-level document tag is the RTFConfig tag. The following three tags are child tags of the RTFConfig tag:

1. Logfile
2. Global
3. Module

Figure 17 shows the XML tag structure and tag attributes of the RTF configuration file:

Figure 17. RTF Configuration File Tag Structure



21.3.1 RTFConfig Tag

RTFConfig is the document tag. This tag is a mandatory component of the RTF configuration file; it can be found at the top of the RTF configuration file. A sample RTFConfig tag entry is shown below:

```
<RTFConfig trace="1" tracelocation="TRACE_LOG" timestamp="1"
logformat="ALIGN">

<!-- Logfile section goes here -->

<!-- Global section goes here -->

<!-- Module sections go here -->

</RTFConfig>
```

The RTFConfig tag includes the following attributes:

trace

This attribute is used to enable or disable the RTF tracing capabilities. Valid values are as follows:

- 0
RTF tracing is disabled.
- 1
RTF tracing is enabled. This is the default setting.

tracelocation

This attribute has no affect on the file and will be removed in a future release. By default, trace output is sent to a log file.

timestamp

This attribute has no affect and will be removed in a future release. By default, each log file name includes a time stamp.

logformat

This attribute defines the format of the log file. The following two values are supported:

ALIGN

Aligns the trace entry fields in the log file into comma separated columns. The top of each column includes a header that provides a description of the column's content. This is the default setting.

UNALIGN

Separates the trace entry fields in the log files with commas. Column alignment is not done.

- Notes:** 1. If you set the logformat attribute to ALIGN, you can customize the widths of the various columns. The following attributes in the RTF configuration file allow you to define the aligned column widths:
- **ModuleWidth number** - Allows you to customize the number of characters that appear in the Module column. The default setting is 10. There is no maximum setting.
 - **ClientWidth number** - Allows you to customize the number of characters that appear in the Client column. The default setting is 15. There is no maximum setting.

- **LabelWidth number** - Allows you to customize the number of characters that appear in the Label column. The default setting is 10. There is no maximum setting.
- 2. Using the ALIGN setting makes the log file easier to read but it does not make efficient use of hard drive space. This inefficiency is exacerbated as the log file grows. The UNALIGN format is separated by commas so it can be parsed by a spreadsheet or database program to make the file easier to read.

21.3.2 Logfile Tag

The Logfile tag is the first child tag of the RTFConfig tag. The Logfile tag provides logistical information about the log file(s) used to store trace output.

If you would like to customize the appearance and settings of the log file, edit the Logfile tag within the RTF configuration file. The Logfile tag appears under the RTFConfig tag in the RTF configuration file.

A sample Logfile tag entry from the *RtfConfigLinux.xml* file is shown below:

```
<Logfile path="$(INTEL_DIALOGIC_DIR)/log" size="300" maxbackups="10"
preserve_size="300" preserve_maxbackups="10"
duplicate_to_debug_console="0" log_format="text"/>
```

A sample Logfile tag entry for the *RtfConfigWin.xml* file is shown below:

```
<Logfile path="$(INTEL_DIALOGIC_DIR)\log" size="300" maxbackups="10"
preserve_size="300" preserve_maxbackups="10"
duplicate_to_debug_console="0" log_format="text"/>
```

The Logfile tag includes the following attributes:

path

Indicates a valid directory path for the log file. The default path for Linux is *\$(INTEL_DIALOGIC_DIR)/log*. The default path for Windows is *\$(INTEL_DIALOGIC_DIR)\log*. The INTEL_DIALOGIC_DIR environment variable is defined as part of the HMP software installation routine. Refer to the *Intel Dialogic System Release Software Installation Guide* for more information about the INTEL_DIALOGIC_DIR environment variable.

size

Sets the maximum size, in Kilobytes (KB), of the log file when RTF is run with preservation mode turned OFF. The default setting is 300. When the file reaches its maximum size, RTF “rolls over” the log file, much like a circular buffer. The previous log file is saved as a timestamped text file. RTF aligns the entries so that the oldest entry is always at the top of the log file and the newest entry is always at the bottom of the log file.

- Notes:**
1. Due to the internal buffers used by RTF, the actual size of the log file may be up to 1 MB larger than the size attribute's value. For example, if the size attribute is set to 1000 KB, the actual log file may grow up to 2000 KB.
 2. This attribute is only applicable when RTF preservation mode is turned OFF. When RTF preservation mode is ON, the `preserve_size` attribute determines the size of the log file. Refer to [Section 21.5.3, "Running RTF in Preservation Mode"](#), on page 104 for information about preservation mode.

maxbackups

Indicates the maximum number of backup log files the RTF creates when the RTF is run with preservation mode turned OFF. If this attribute is set to 0, all trace information is written to one log file. If this attribute is set to 1 or greater, all trace information is initially written to one log file. When the size of this initial log file reaches the threshold defined in the Logfile tag's size attribute, the RTF trace data "rolls over" into a second log file. When the size threshold is reached in the second log file, the RTF trace data "rolls over" into a third log file. This sequence occurs until the number of backup log files created equals the `maxbackups` attribute setting. When the "roll over" occurs, the previous log file is saved under the following timestamped name:

```
rtflog-<year><month><day>-<hour>h<minute>m.<second>s.txt
```

If the number of backup log files exceeds the number defined in `maxbackups`, the oldest backup file will be deleted and a new one will be created, on a first in, first out basis. The default `maxbackups` value is 10.

- Notes:**
1. This attribute is only applicable when RTF preservation mode is turned OFF. When RTF preservation mode is ON, the `preserve_maxbackup` attribute determines the number of backup log files. Refer to [Section 21.5.3, "Running RTF in Preservation Mode"](#), on page 104 for information about preservation mode.
 2. There is no limit to the maximum backups imposed by the RTF itself. However, a higher limit will increase the usage of disk space and impact performance since RTF needs to keep track of all backup files and remove old ones as necessary.

preserve_size

Sets the maximum size, in Kilobytes (KB), of the log file when the RTF is run with preservation mode turned ON. The default setting is 300. When the file reaches its maximum size, RTF "rolls over" the log file, much like a circular buffer. The previous log file is saved as a timestamped text file. RTF aligns the entries so that the oldest entry is always at the top of the log file and the newest entry is always at the bottom of the log file.

- Note:** This attribute is only applicable when RTF preservation mode is turned ON. When RTF preservation mode is OFF, the size attribute determines the size of the log file. Refer to [Section 21.5.3, "Running RTF in Preservation Mode"](#), on page 104 for information about preservation mode.

preserve_maxbackups

Indicates the maximum number of backup log files the RTF creates when the RTF is run with preservation mode turned ON. If this attribute is set to 0, all trace information is written to one log file. If this attribute is set to 1 or greater, all trace information is initially written to one log file. When the size of this initial log file reaches the threshold defined in the Logfile tag's preserve_size attribute, the RTF trace data “rolls over” into a second log file. When the size threshold is reached in the second log file, the RTF trace data “rolls over” into a third log file. This sequence occurs until the number of backup log files created equals the preserve_maxbackups attribute setting. When the “roll over” occurs, the previous log file is saved under the following timestamped name:

```
rtflog-<year><month><day>-<hour>h<minute>m.<second>s_p.txt
```

Note: The _p suffix appears in the log file name because preservation mode is turned ON.

The default preserve_maxbackups value is 10.

Note: This attribute is only applicable when RTF preservation mode is turned ON. When RTF preservation mode is OFF, the maxbackups attribute determines the number of backup log files. Refer to [Section 21.5.3, “Running RTF in Preservation Mode”](#), on page 104 for information about preservation mode.

duplicate_to_debug_console

This attribute determines whether or not trace information is duplicated in the debug console (Windows) or the standard error output (Linux). Possible settings are as follows:

1

The trace output information will be duplicated on the debug console for Windows systems or the standard error output for Linux systems.

0

The trace output information will not be duplicated on the debug console for Windows systems or the standard error output for Linux systems. This is the default setting.

log_format

This attribute determines the format of the output log file. By default, this is set to “text” (the trace output log is written in readable, text file format). However, you can change the attribute to “binary” to get binary output.

21.3.3 Global Tag

The Global tag is the second child tag of the RTFConfig tag. The Global tag is used to specify the global configuration. Global configuration settings are valid for all modules included in the RTF configuration file. However, the Global tag has the lowest priority in the RTF configuration file. Therefore, the global configuration settings can be overridden by individual settings at the Module tag level (see [Section 21.3.7, “Module Tag”](#), on page 98). The Global tag cannot occur more than one time in the RTF configuration file. The Global tag can either be empty:

```
<Global>

<!-- This is an example of an empty Global tag -->

</Global>
```

or the Global tag can have GLabel and/or GClient child tags. There are no attributes associated with the Global tag.

21.3.4 GLabel Tag

The GLabel tag is a child tag of the Global tag; it is used to configure global labels. If a label is defined at the GLabel level then all module and client behavior will be governed by this configuration (unless overridden for a given module at the MLabel level).

The following line may appear in the default *RtfConfigLinux.xml* file:

```
<GLabel name = "Error" state = "1"/>
```

This line indicates that tracing of all Error labels is turned on by default. To disable this default behavior, you can delete this line or change the "Error" state attribute setting to 0.

The following lines appear in the default *RtfConfigWin.xml* file:

```
<GLabel name = "Error" state = "1"/>
<GLabel name = "Exception" state = "1"/>
```

These lines indicate that tracing of all Error labels and all Exception labels is turned on by default. To disable this default behavior, you can delete these lines or change the "Error" state attribute and "Exception" state attribute setting to 0.

The GLabel tag has the following two attributes:

name

Indicates the name of the global label to be configured. *You must define the name of the global label*; there is no default value. Examples of possible labels include:

- "Error" (enabled at the Global level by default)
- "Debug"
- "Info"
- "Warning"

Note: Refer to the default RTF configuration file's MLabel name attributes. These default entries are for the HMP Software runtime libraries. Any of these runtime library label names can be included in a GLabel tag.

state

Specifies the state of the label. Valid values are as follows:

1

Label is enabled at the global level. All trace messages associated with this label will be sent to the trace output. This is the default value.

0

Label is disabled at the global level. Trace messages associated with this label will not be sent to the trace output.

21.3.5 GClient Tag

The GClient tag is a child tag of the Global tag; it is used to configure global clients (devices). If a client is defined at the GClient level then all client behavior will be governed by this configuration (unless overridden for a given client at the MClient level). The GClient tag can be empty or have GClientLabel children tags. The GClient tag has the following two attributes:

name

Indicates the name of the client to be configured. *You must define the name of the global client;* there is no default value. Examples of possible client names include:

- “dxxxB1C1” (voice device)
- “dxxxB2C2” (voice device)
- “ipmB2C2” (IP media device)

Note: Refer to the *Standard Runtime Library API for Windows Operating Systems Programming Guide* for more information about client names for Intel Dialogic libraries and devices.

state

Specifies the state of the client. Valid values are as follows:

1

Client is enabled at the global level. All trace messages associated with this client will be sent to the trace output. This is the default value.

0

Client is disabled at the global level. Trace messages associated with this client will not be sent to the trace output.

21.3.6 GClientLabel Tag

The GClientLabel tag is a child tag of the GClient tag; it is used to specify a label for a global client. The GClientLabel tag has the following two attributes:

name

Indicates the name of a client label to be configured. *You must define the name of the client label*; there is no default value. Examples of possible client labels include:

- “Error”
- “Warning”
- “Entry”

Note: Refer to the default RTF configuration file’s `MLabel name` attributes. These default entries are for the HMP Software runtime libraries. Any of these runtime library label names can be included in a `GClientLabel` tag.

state

Specifies the state of the label. Valid values are as follows:

1

Client label is enabled at the global level. Trace messages associated with this label will be sent to the trace output. This is the default value.

0

client label is disabled at the global level. Trace messages associated with this label will not be sent to the trace output.

21.3.7 Module Tag

This tag is used to specify configuration for various modules. Module tags have a higher priority than global tags so settings at the module level override settings at the global level. For example, if the state of a label “Error” is set to “1” in the global section and “Error” is set to “0” for an individual module, then the label “Error” will not be traced for that particular module. The module section must exist in the configuration file, even if the section is empty. Possible child tags of the Module tag are `MClient` and `MLabel`.

The RTF configuration file contains modules for the HMP Software runtime libraries. The following example shows that the module name for the Fax Library is “spwrfax”:

```
<!-- Fax Library -->
- <Module name="spwrfax" state="1">
  <MLabel name="DEBG" state="0" />
  <MLabel name="INFO" state="0" />
  <MLabel name="APPL" state="0" />
  <MLabel name="WARN" state="0" />
  <MLabel name="ERR1" state="1" />
  <MLabel name="EXCE" state="0" />
</Module>
```

You can edit the state attributes of the modules to enable (set state = “1”) or disable (set state = “0”) the tracing. Alternatively, you can delete one or more modules from the default RTF configuration file if you are not interested in tracing certain runtime libraries.

Note: The RTF configuration file contains some older sections that have been retained for backward compatibility.

The Module tag includes the following attributes:

name

Indicates the name of a module to be configured. HMP Software runtime libraries have module names in the default RTF configuration file. Example module names in the RTF configuration file include:

- “gc”
- “libsrl”
- “spwrdevmgmt”

state

Specifies the state of the module. Valid values are as follows:

- 1
Module is enabled. Trace messages associated with this label will be sent to the trace output. This is the default value.
- 0
Module is disabled. Trace messages associated with this label will not be sent to the trace output.

21.3.8 MLabel Tag

The MLabel tag is a child tag of the Module tag. The MLabel tag is used to configure module labels. If a label is defined at the global level and the same label is defined at the module level, the module level configuration overrides the global configuration for the module. The MLabel tag has the following two attributes:

name

Indicates the name of the label to be configured. The HMP Software runtime libraries have module label names in the default RTF configuration file. Example module label names in the RTF configuration file include:

- “APPL”
- “DEBG”
- “WARN”

state

Specifies the state of the label. Valid values are as follows:

- 1
Label is enabled. Trace messages associated with this label will be sent to the trace output. This is the default value.

0

Label is disabled. Trace messages associated with this label will not be sent to the trace output.

Note: When the state attribute is not included or not defined, the default value is 1. However, the HMP Software runtime library module labels that exist in the default RTF configuration file have their state attribute initially set to 0.

21.3.9 MClient Tag

The MClient tag is a child tag of the Module tag; it is used to configure a specific client for the module. The MClient tag can be empty or have MClientLabel children tags. The MClient tag has the following two attributes:

name

Indicates the name of the client to be configured. The HMP Software runtime libraries have pre-defined module client names in the default RTF configuration file. Example clients include:

- “dxxxB1C1” (voice device)
- “dxxxB2C2” (voice device)
- “ipmB2C2” (IP media device)

Note: Refer to the *Standard Runtime Library API for Windows Operating Systems Programming Guide* for more information about client names for Intel Dialogic libraries and devices.

state

Specifies the state of the client. Valid values are as follows:

1

Client is enabled. Trace messages associated with this client will be sent to the trace output. This is the default value.

0

Client is disabled. Trace messages associated with this client will not be sent to the trace output.

Note: When the **state** attribute is not included or not defined, the default value is 1.

21.3.10 MClientLabel Tag

The MClientLabel tag is a child tag of the MClient tag; it is used to specify a label for a client. The MClientLabel tag has the following two attributes

name

Indicates the name of a label to be configured. *You must define the name of the label*; there is no default value. Example labels include:

- “APPL”

- “DEBG”
- “WARN”

Note: A complete list of labels for a given library can be found in the RTF configuration file.

state

Specifies the state of the label. Valid values are as follows:

1

Label is enabled. Trace messages associated with this label will be sent to the trace output. This is the default value.

0

Label is disabled. Trace messages associated with this label will not be sent to the trace output.

21.3.11 Precedence Scheme for Module/Client Labels

This section summarizes the precedence scheme of settings in RTF module/client labels. Basically, RTF has three types of handles for use in determining if a trace statement will be filtered. They are modules, clients, and labels. A trace statement can use filtering of either of the following:

module+label

For trace statements that use module+label, the trace will only be stored in a file when both module and label are enabled.

module+client+label.

For trace statements that use module+client+label, the trace will only be stored in a file when module, client and label are all enabled.

When it is not provided in the configuration file, default enable/disable settings for the three types of handles are:

- Module: disabled.
- Client: enabled.
- Label: disabled.

For handles set in the configuration file, the precedence order is:

- Module: No precedence order since it is only available at a module level. No global level.
- Client: Settings in the module section override settings in the global section.
- Label: For trace statements *without* client handles, settings in the module section override settings in the global section. For trace statements *with* client handles, settings in the module/client section override settings in the client/label section; settings in the client/label section override settings in the module section; and settings in the module section override settings in the global section.

Figure 17 shows the hierarchy of the possible handles and how they relate to one another.

21.4 Restrictions and Limitations

Keep the following restrictions and limitations in mind when using RTF:

- If you run full RTF logging on high-density systems, you may experience I/O throughput degradation. It is recommended that you do not run RTF with full logging on high-density systems or any field-deployed systems. Instead, use just the default error-enabled logging.
- If you install the I an *Error after install attempting to launch* error message. The error message appears because FAT32 does not support file system access control. However, RTF will continue to function.
- When RTF logging is enabled, logs are stored in the $\$(INTEL_DIALOGIC_DIR)log$ directory. You should take necessary precautions to ensure that the directory never fills.
- Occasionally, errors that appear in the RTF log can be ignored in certain circumstances. Check the “Release Issues” chapter in the *Release Update* for the Intel telecom software you are using (System Release or Host Media Processing [HMP]). Such errors will be listed and explained in the “Release Issues” table.

21.4.1 Guidelines for Editing the RTF Configuration File

Keep the following rules in mind when editing the RTF configuration file:

1. Do not change the name of the file. The filename must remain at its default setting.
2. The RTF configuration file is broken down into four sections. The sequence of the sections must always be as follows:
 - a. RTFconfig
 - b. Logfile configuration
 - c. Global configuration
 - d. Module configuration
3. RTF uses the following default log file names:
 - *rtflog-<year><month><day>-<hour>h<minute>m.<second>s.txt* when preservation mode is OFF.
 - *rtflog-<year><month><day>-<hour>h<minute>m.<second>s_p.txt* when preservation mode is turned ON.
4. The Global configuration section can only appear one time in the RTF configuration file.
5. If a there is configuration information which conflicts in the global and module sections (for example, the global section enables a trace label for a client, but the module section disables this same label for the same client), then the module configuration overrides the global configuration.
6. Configuration information which is repeated later in the file will take precedence. For example, if there are two module configurations for *spwrvoice*, the configuration information lower in the file will dictate tracing behavior for that module.

Note: This should not be done, but it is mentioned here so the behavior can be recognized if this situation occurs by error.
7. RTF is case sensitive. Therefore, the trace labels “Error” and “error” are considered to be two distinctly different trace labels.

8. Simultaneous tracing of multiple HMP Software libraries may have an adverse effect on system performance.
9. If you run full RTF logging on high-density systems, you may experience I/O throughput degradation (specifically if you enable tracing on the MClient name MUTEX). It is recommended that you do not run RTF with full logging on high-density systems or any field-deployed systems. Contact customer support before enabling extensive logging. Instead, use just the default error-enabled logging.
10. RTF affects running processes/applications only. If you enable RTF prior to starting your application, the RTF will not provide trace information until your application has started.
11. If you wish to dynamically edit the RTF trace levels while your application runs, it is not necessary to stop RTF. Instead, perform the following:
 - a. Open the RTF configuration file.
 - b. Customize the settings in the RTF configuration file.
 - c. Save and close the RTF configuration file.
 - d. Issue the `rtftool reload` command to reload RTF configuration file and restart the RTF engine.

Note: Keep in mind that changes made to the RTF configuration file will not be reflected in the RTF output until the tool has been reloaded.
12. At any time, you can issue the `rtftool` command to pause/restart RTF. RTF will not provide trace output while it is paused. Refer to [Section 21.5, “rtftool Command”](#), on page 103 for more information.
13. Save the original *RtfConfigWin.xml* file or *RtfConfigLinux.xml* file, as it is advisable to return to the original logging level when finished using the RTF logging mechanism.

21.5 rtftool Command

This section explains the `rtftool` command, which is used to control RTF and modify the trace output. The `rtftool` command is issued from the command line. The `rtftool` command can be issued from any directory.

21.5.1 Pausing and Reloading RTF

RTF tracing is enabled by default. Use the `rtftool` command to pause, resume and reload the RTF's tracing capabilities. The `rtftool` command has the following pause and reload variations:

```
rtftool pause
```

Pauses RTF tracing. Trace output will not be written to the log file while RTF is paused.

```
rtftool resume
```

Resumes RTF tracing. Issue this command to resume tracing after RTF has been paused.

```
rtftool reload
```

Reloads an updated RTF configuration file (*RtfConfigLinux.xml* or *RtfConfigWin.xml*) and restarts RTF, using the settings from the updated RTF configuration file.

Note: You do not need to pause RTF tracing before issuing the `rtftool reload` command. RTF supports dynamic updates to the RTF configuration file. Simply edit and save the file, then issue the `rtftool reload` command to begin tracing with the updated RTF configuration file settings.

21.5.2 Clearing the RTF Trace Log File Contents

Use the `rtftool` command to clear all trace data from the RTF log file. The following command line option clears the RTF log file contents:

```
rtftool clean [-f]
```

Clears the RTF log file contents. When the `-f` option is used, RTF will not ask the user for confirmation before clearing the log file.

21.5.3 Running RTF in Preservation Mode

You can set RTF to run in preservation mode. Preservation mode allows you to determine whether old trace data is overwritten or preserved in a separate file when the log file grows to its maximum size. When preservation mode is turned ON, RTF will append a `_p` to the end of each RTF log file name; RTF will not delete or overwrite these `_p` log files. Use the `preserve_size` and `preserve_maxbackup` Logfile tag attributes to set the size and number of backup log files, respectively. Use the following command line option to enable/disable preservation mode:

```
rtftool preservation {on | off}
```

Turns RTF preservation mode ON and OFF.

21.6 Example RTF Configuration Files

This section provides a number of example *RtfConfig*.xml* files along with a brief explanation of how the file settings affect the RTF trace output. Note that the same rules/examples covered in this section apply to both the *RtfConfigWin.xml* and *RtfConfigLinux.xml* file.

21.6.1 Example 1: Tracing disabled - RtfConfigWin.xml

```
<?xml version="1.0" standalone="no"?>
```

```
<RTFConfig trace="0" tracelocation="TRACE_LOG" logformat="ALIGN"
timestamp="1">
```

```
<Logfile path="$(INTEL_DIALOGIC_DIR)\log" size="1000" maxbackups="2"
preserve_size="300" preserve_max_backups="10"
duplicate_to_debug_console="0" log_format="text"/>
```



```

<Global>

</Global>

<Module name="spwrvoice" state = "1">
    MLabel name="ERR1" state = "1"/>
    MLabel name="WARN" state = "0"/>
</Module>

</RTFConfig >

```

Explanation

The RTFConfig tag's trace attribute is set to 0 so tracing is disabled. Trace output will not be created. Set the trace attribute to 1 to activate tracing.

21.6.2 Example 2: Tracing enabled, logfile path and size specified, preservation mode OFF, one module configured - RTFConfigLinux.xml

```

<?xml version="1.0" standalone="no"?>

<RTFConfig trace="1" tracelocation="TRACE_LOG" timestamp="1"
logformat="ALIGN">

<Logfile path="$(INTEL_DIALOGIC_DIR)/log" size="1000" maxbackups="2"
preserve_size="300" preserve_max_backups="10"
duplicate_to_debug_console="0" log_format="text"/>

<Global>

</Global>

<Module name="spwrvoice" state = "1">
    MLabel name="ERR1" state = "1"/>
    MLabel name="WARN" state = "1"/>
</Module>

</RTFConfig >

```

Explanation

The RTFConfig tag's trace attribute is set to 1 so tracing is enabled. The Global tag is empty, so there is no global configuration. For this example, tracing is only configured at the module level.

The path for the log file is `$(INTEL_DIALOGIC_DIR)/log`. Preservation mode is OFF, so the size and maxbackup attributes apply while the preserve_size and preserve_max_backups attributes are

ignored. The maximum logfile size is 1000KB. The system maintains a maximum of 2 backup log files.

The only module configured for trace is *spwrvoice*. This means that all clients (devices) for this module are configured to trace ERR1 and WARN labels.

21.6.3 Example 3: Tracing enabled, logfile path and size specified, several modules configured, global configuration used - RTFConfigWin.xml

```
<?xml version="1.0" standalone="no"?>
<RTFConfig trace="1" tracelocation="TRACE_LOG" logformat="ALIGN">

<Logfile path="$(INTEL_DIALOGIC_DIR)\log" size="1000" maxbackups="2"
preserve_size="300" preserve_max_backups="10"
duplicate_to_debug_console="0" log_format="text"/>

<Global>
  <GLabel name="Entry" state = "1"/>
  <GClient name="dxxxB1C2" >
    <GClientLabel name="Exit" state = "1"/>
  </GClient>
</Global>

<Module name="spwrvoice" state = "1">
  MLabel name="ERR1" state = "1"/>
  MLabel name="WARN" state = "0"/>
</Module>

<Module name="spwrvoice">
  <MLabel name="ERR1" state = "0"/>
  <MLabel name="WARN" state = "1"/>

  <MClient name="dxxxB1C2" >
    <MClientLabel name="ERR1"/>
  /MClient>
</Module>

<Module name="faxntf" state = "1">
  <MLabel name="WARN" state = "1"/>
</Module>

<Module name="dtintf">
  <MClient name="dxxxB2C1">
    <MClientLabel name="EXCE"/>
  </MClient>
```

```
</Module>
```

```
</RTFConfig >
```

Explanation

The trace attribute of the RTFConfig tag is set to 1 so tracing is enabled.

The logfile path is $\$(INTEL_DIALOGIC_DIR)log$. Preservation mode is ON, so the size and maxbackup attributes are ignored while the preserve_size and preserve_max_backups attributes apply. The maximum logfile size is 300KB. The system maintains a maximum of 10 backup log files (filenames appended with a *_p*).

The Global section is present in the configuration file, so all modules will have this global configuration. This configures “Entry” as a global label and “dxxxB1C2” is a global client for label “Exit”.

In the module section, there are two configurations for *spwrvoice* so the later configuration will take precedence. Since the state of *spwrvoice* is not specified, it takes default value “1”. Tracing is enabled for the module *spwrvoice* but only for the “WARN” label.

The client “dxxxB1C2” is also configured to trace in the *spwrvoice* module with the label “ERR1”. Therefore the client “dxxxB1C2” in *spwrvoice* is traced for the label “ERR1”, even though it is disabled in the module section. While all other clients of *spwrvoice* are configured to be traced for only label “WARN”, as “WARN” is the only label configured to be traced for the module.

The *faxntf* module is configured to trace “WARN” (from the module section) and “Entry” (from the global section).

The *dtintf* module is configured to trace “Entry” (from the global section). “dxxxB1C2” in *dtintf* is configured to trace “Entry” (from the global section) and “Exit” (from the global client). The other client “dxxxB2C1” is configured to trace “Entry” (from the global configuration) and “EXCE” (from the module client section). All other clients of this module are configured to trace “Entry” (from the global section) since these labels are configured for the module.

21.7 Configuring Remote RTF Logging

This section contains the following information:

- [Introduction](#)
- [Configuring the Client System](#)
- [Configuring the Server System](#)
- [Cautions](#)
- [Disabling Remote Logging](#)

21.7.1 Introduction

RTF servers can be configured to communicate with each other. This provides remote tracing capability. A trace produced on one machine can be re-directed and stored on another machine on the network. This section describes how to configure remote RTF logging.

The terminology used to describe remote RTF logging is as follows:

Client (remote) system

A system that contains System Release software and telephony boards and is running the end-user telephony application.

Server (management/help desk system)

A system that contains the System Release software and will be used to collect RTF logs from one or more client systems.

21.7.2 Configuring the Client System

To configure the client system, edit the RTF configuration file (*RtfConfigLinux.xml* for Linux and *RtfConfigWin.xml* for Windows) as follows:

1. Locate the line containing the tag `Network mode=` and set its value to "client".
2. Locate the line containing the tag `server_name=` and set its value to either the fully-qualified domain name or IP address of the server system.
3. Optionally, you may change the TCP port used by locating the line containing `Client port_number=` and changing its value to the port number you wish to use. Note that you must make a corresponding change on the server system (see [Configuring the Server System](#)).
4. If the System Release has not yet been started, run `dlstart`. Otherwise, cause the RTF program to reload the updated configuration file by running `rtftool reload`.

Figure 18 shows a portion of a sample RTF configuration file edited to configure the client system.

Figure 18. RTF Configuration File Edited to Configure the Client System

```
<?xml version="1.0" standalone="no" ?>
- <RTFConfig trace="1" tracelocation="TRACE_LOG" timestamp="1" logformat="ALIGN">
  <Logfile path="$(INTEL_DIALOGIC_DIR)/log" size="500" maxbackups="10" preserve_size="500"
    preserve_maxbackups="10" duplicate_to_debug_console="0" log_format="text" />
  <StatusTrace state="off" />
  <Network mode="client" />
  <Server port_number="4567" max_connection="1" />
  <Client port_number="1234" server_name="192.168.93.227" />
```

21.7.3 Configuring the Server System

To configure the server system, edit the RTF configuration file (*RtfConfigLinux.xml* for Linux and *RtfConfigWin.xml* for Windows) as follows:

1. Locate the line containing the tag `Network mode=` and set its value to "server". The value of `server_name=` must be 127.0.0.1.

2. Optionally, you may change the TCP port used by locating the line containing `Server port_number=` and changing its value to the port number you wish to use. Note that you must make a corresponding change on the client system(s) (see [Configuring the Client System](#)).
3. If the System Release has not yet been started, run `dlstart`. Otherwise, cause the RTF program to reload the updated configuration file by running `rtftool reload`.

Figure 19 shows a portion of a sample RTF configuration file edited to configure the server system.

Figure 19. RTF Configuration File Edited to Configure the Server System

```
<?xml version="1.0" standalone="no" ?>
- <RTFConfig trace="1" tracelocation="TRACE_LOG" timestamp="1" logformat="ALIGN">
  <Logfile path="$(INTEL_DIALOGIC_DIR)/log" size="500" maxbackups="10" preserve_size="500"
    preserve_maxbackups="10" duplicate_to_debug_console="0" log_format="text" />
  <StatusTrace state="off" />
  <Network mode="server" />
  <Server port_number="1234" max_connection="1" />
  <Client port_number="4567" server_name="127.0.0.1" />
```

21.7.4 Cautions

Following are some cautions to keep in mind when configuring remote RTF logging:

1. If the value of the `server_name` field is a hostname, the name must be resolvable either via DNS query or via `/etc/hosts`. Failure of hostname resolution will prevent remote logging from occurring.
2. Depending on the level of RTF logging enabled, application or network performance may be impacted. The impact may be more significant if VoIP technology is being used.
3. Having multiple client systems log to a central server is possible by setting the `max_connection=` parameter in the server's RTF configuration file, but this capability should be used with caution.

21.7.5 Disabling Remote Logging

To disable remote logging, set the value of `Network mode=` to "off". The Intel NetStructure® Host Media Processing (HMP) software ships with remote logging disabled.



This chapter provides reference information about the Status Monitor tool. This chapter contains the following information:

- [Description](#) 111
- [Guidelines](#) 111
- [Options](#) 111

22.1 Description

The Status Monitor tool enables you to track the state of the TSC as well as the state of the bits on a robbed bit or CAS line. You can use Status Monitor for both troubleshooting and administration. For troubleshooting, you can monitor the call state for problems such as hung channels. For administration, you can watch call progress and channel usage.

22.2 Guidelines

Following are guidelines for using the Status Monitor tool:

- The Status Monitor tool consumes a portion of the CPU for each trunk that is logged and may generate an exception if CTRL-C is used to exit the tool. It may take a long time to start the monitoring: about 1 minute per board.
- The CAS instance is not valid until the line is in service, so you will have to run an application or the Phone tool to set the channel in-service before using the bit monitoring feature. For information about the Phone tool, refer to [Chapter 18, “Phone Reference”](#).
- The Status Monitor tool is best viewed in resolutions greater than 1024 x 768.
- The Status Monitor tool is not intended for use with boards that are configured for ISDN.

22.3 Options

Status Monitor has the following option:


- board <board list>
Logical ID of the board(s) to trace (optional). The default is to monitor all Intel NetStructure® DNI boards in the system. Use the Configuration Manager (DCM) utility to obtain the board's logical ID.

The following will run the Status Monitor tool on boards 0 and 1:

```
StatusMon -board 0 1
```

Figure 20 provides an example of output from the Status Monitor tool.

Figure 20. Example of Status Monitor Output



The following numbered list corresponds to the labels in Figure 20.

1. You can toggle between monitored boards by clicking on the tab that represents the board ID.
2. This part of the display shows the current alarm state on the trunk (red, yellow, or green).
3. Use this button to invoke the Lineadmin tool to view and set additional alarms.
4. This part of the display allows you to monitor the call state for each line on the board.
5. Clicking on a line will cause the bit information to be displayed in this window. (All 1's will be displayed for ISDN lines.)



Glossary

ANI: Automatic Number Identification. A telephone service that provides the telephone number of an incoming call. ANI is also known as Caller ID.

Automatic Number Identification: See ANI.

B channel: A bearer channel that carries the main data.

bit oriented : Communications protocols in which control information may be coded in a single bit.

CAS: Channel Associated Signaling. Signaling in which the signals necessary to switch a given circuit are transmitted via the circuit itself or via a signaling channel permanently associated with it.

called ID: A telephone service that identifies for the receiver what telephone number was dialed by the caller. This is also known as DNIS.

caller ID: A telephone service that provides the telephone number of an incoming call. Caller ID is also known as ANI.

channel: A path of communication, either electrical or electromagnetic, between two or more points. Also called a circuit, facility, line, link or path.

D channel: A channel that carries control and signaling information.

Dialed Number Identification Service: See DNIS.

DNIS: Dialed Number Identification Service. A telephone service that identifies for the receiver what telephone number was dialed by the caller. This is also known as Called ID.

Integrated Services Digital Network: See ISDN.

ISDN: Integrated Services Digital Network. An integrated digital network in which the same time-division switches and digital transmission paths are used to establish connections for different services. ISDN services include telephone, data, electronic mail, and facsimile. The method used to accomplish a connection is often specified: for example, switched connection, nonswitched connection, exchange connection, ISDN connection.

line loopback: A signal used to command the far-end receiver to loop back the received line signal.

loopback: A state of a transmission facility in which the received signal is returned towards the sender; a type of diagnostic test in which the transmitted signal is returned to the sending device after passing through a data communications link or network, which allows the returned signal to be compared with the transmitted signal for troubleshooting purposes.

loop start: Seizing (starting) a line by bridging through a resistance the tip and ring (both wires) of a telephone line. In residential installations, the loop start trunk is the most common.

metallic circuit: A circuit in which metallic conductors are used and in which the ground or earth forms no part.

metallic loopback: Metallic loopback loops the data back to the network at the physical port on the back card of a service module, whereas local loopback loops the data back to the network through the framer in the service module.

OSD: Operating System Distribution.

payload: In a set of data, such as a data field, block, or stream, being processed or transported, the part that represents user information and user overhead information, and may include user-requested additional information, such as network management and accounting information.

payload loopback: A signal used to command the far-end receiver to loop back the received payload.

POST: Power-On Self Test. A series of diagnostic tests used to verify that the DM3 architecture board components are working properly.

PSTN: Public Switched Telephone Network.

Public Switched Telephone Network: PSTN. A domestic telecommunications network usually accessed by telephones, key telephone systems, private branch exchange trunks, and data arrangements.

signaling : To set up and tear down calls, some form of signaling is required (simple examples are ringing and dial tone).

trunk: In a communications network, a single transmission channel between two points that are switching centers or nodes, or both.

wink start: A signal sent between two telecommunications devices as part of a “handshake” protocol.

A

- ALIGNED 92
- application failure or crash 32
- archiving system configuration 33

B

- board, checking 19

C

- CallInfo tool 35
- CAS Trace tool 37
- check network connection 21
- checking an individual DM3 architecture board 19
- checking the protocol configuration 25
- class driver counters 63
- client 90
- ClientWidth 92
- collecting the system data 32
- command line options
 - pstndiag tool 85
- Control Processor 19
- creating a system configuration archive 33

D

- DebugAngel 20
- DebugAngel tool 41
- detecting and isolating possible hardware faults 19
- diagnostic tasks
 - checking log file 83
 - checking protocol configuration 25
- Digit Detector tool 43
- DM3 PDK Protocol Trace 69
- DM3Insight.chm 45
- DM3post 19
- document tag 91

F

- firmware tracing 20

G

- GClient tag 97
- GClientLabel 97
- GLabel tag 96
- Global Call 73
- Global tag 95

I

- Intel Telecom Subsystem Summary Tool 32, 33
- ISDN D-channel 53
- ISDN-related messages 35
- ISDNtrace tool 53
- its_sysinfo 32, 33

K

- KernelVer tool 61

L

- label 90
- LabelWidth 93
- log files
 - pstndiag tool 83
- Logfile tag 93
- logformat 92

M

- MClient 98
- MClient tag 100
- MClientLabel tag 100
- mercmon
 - class driver counters 63
 - protocol driver counters 64
- MLabel 98
- MLabel tag 99
- module 90
- ModuleWidth 92

N

network connection, checking 21

P

path 93

PDK Trace tool 69

phone tool 73

protocol configuration, checking 25

protocol driver counters 64

psndiag 25, 83

- command line options 85

- keyboard navigation 83

- lower pane 78

- upper pane 78

- view bar 78

psndiag tool 21, 25

R

RTF configuration file 90

RTF tool 31

RTFConfig tag 91

RtfConfigLinux.xml 89

RtfConfigWin.xml 89

runtime libraries 31

Runtime Trace Facility 31

S

Signal Detector 43

Signal Processors 47

size 93

state 97

Status Monitor tool 111

system configuration archive 33

T

Telephony Service Provider 35

Tone Generator 43

trace 92

trace entry 90

tracelocation 92

Tracing disabled 104

TSC 73

TSP 35

U

UNALIGNED 92