



# **Dialogic<sup>®</sup> Diva<sup>®</sup> softSS7 Software for Linux version 1.5.2**

Reference Guide

## Copyright Notice And Legal Disclaimer

Copyright © 2006-2008 Dialogic Corporation. All Rights Reserved. You may not reproduce this document in whole or in part without permission in writing from Dialogic Corporation at the address provided below.

All contents of this document are furnished for informational use only and are subject to change without notice and do not represent a commitment on the part of Dialogic Corporation or its subsidiaries ("Dialogic"). Reasonable effort is made to ensure the accuracy of the information contained in the document. However, Dialogic does not warrant the accuracy of this information and cannot accept responsibility for errors, inaccuracies or omissions that may be contained in this document.

INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH DIALOGIC® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN A SIGNED AGREEMENT BETWEEN YOU AND DIALOGIC, DIALOGIC ASSUMES NO LIABILITY WHATSOEVER, AND DIALOGIC DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF DIALOGIC PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY INTELLECTUAL PROPERTY RIGHT OF A THIRD PARTY.

Dialogic products are not intended for use in medical, life saving, life sustaining, critical control or safety systems, or in nuclear facility applications.

It is possible that the use or implementation of any one of the concepts, applications, or ideas described in this document, in marketing collateral produced by or on web pages maintained by Dialogic may infringe one or more patents or other intellectual property rights owned by third parties. Dialogic does not provide any intellectual property licenses with the sale of Dialogic products other than a license to use such product in accordance with intellectual property owned or validly licensed by Dialogic and no such licenses are provided except pursuant to a signed agreement with Dialogic. More detailed information about such intellectual property is available from Dialogic's legal department at 9800 Cavendish Blvd., 5th Floor, Montreal, Quebec, Canada H4M 2V9. **Dialogic encourages all users of its products to procure all necessary intellectual property licenses required to implement any concepts or applications and does not condone or encourage any intellectual property infringement and disclaims any responsibility related thereto. These intellectual property licenses may differ from country to country and it is the responsibility of those who develop the concepts or applications to be aware of and comply with different national license requirements.**

Dialogic, Dialogic Pro, Brooktrout, Cantata, SnowShore, Eicon, Eicon Networks, Eiconcard, Diva, SIPcontrol, Diva ISDN, TruFax, Realblobs, Realcomm 100, NetAccess, Instant ISDN, TRXStream, Exnet, Exnet Connect, EXS, ExchangePlus VSE, Switchkit, N20, Powering The Service-Ready Network, Vantage, Connecting People to Information, Connecting to Growth, Making Innovation Thrive, and Shiva, among others as well as related logos, are either registered trademarks or trademarks of Dialogic. Dialogic's trademarks may be used publicly only with permission from Dialogic. Such permission may only be granted by Dialogic's legal department at 9800 Cavendish Blvd., 5th Floor, Montreal, Quebec, Canada H4M 2V9. Any authorized use of Dialogic's trademarks will be subject to full respect of the trademark guidelines published by Dialogic from time to time and any use of Dialogic's trademarks requires proper acknowledgement.

The names of actual companies and products mentioned herein are the trademarks of their respective owners.

This document discusses one or more open source products, systems and/or releases. Dialogic is not responsible for your decision to use open source in connection with Dialogic products (including without limitation those referred to herein), nor is Dialogic responsible for any present or future effects such usage might have, including without limitation effects on your products, your business, or your intellectual property rights.

## Software License Agreement

**This Software License Agreement ("Agreement") is a legal Agreement for the conditional use of the software provided herein ("Program") between you, the end-user, and Dialogic Corporation ("Dialogic"). By downloading, copying or otherwise using the Program, you agree to be bound by the terms of the foregoing license.**

YOU ASSUME RESPONSIBILITY FOR THE SELECTION OF THE PROGRAM TO ACHIEVE YOUR INTENDED RESULTS, AND FOR THE INSTALLATION, USE, AND RESULTS OBTAINED FROM THE PROGRAM.

The Program may contain certain software applications and portions of applications which are provided to You under terms and conditions which are different from this Agreement (such as open source or community source) or which require Dialogic to provide Customer and its Subsidiaries with certain notices and/or information (collectively "Excluded Code"). Dialogic will identify such Excluded Code in a text file or about box or in a file or files referenced thereby (and shall include any associated license agreement, notices and other related information therein), or the Excluded Code will contain or be accompanied by its own license agreement. Your use of the Excluded Code will be subject to the terms and conditions of such other license agreement solely to the extent such terms and conditions are inconsistent with the terms and conditions of this Agreement or are required by such other license agreement. By using or not uninstalling such Excluded Code after the initial installation of the Excluded Code you acknowledge and agree to all such license agreements, notices and information.

### License

Under the terms and conditions of this Agreement:

- You may install and use one copy of the Program on a single-user computer, file server, or on a workstation of a local area network.
- Some or all functions of the Program may be available solely if the Program is used with one or more legally acquired Dialogic Activation Key(s).
- To obtain an Activation Key you must first purchase a Proof of Purchase Code (PPC). A PPC may be included in your software or hardware package or you may have to purchase it separately.
- You will receive your Activation Key upon registering the Proof of Purchase Code as directed in the PPC document.
- It may be possible to install multiple Activation Keys into the Program; in such a case, the total functionality provided by the Program will be the sum of the licensed functionalities controlled by the installed Activation Keys as long as the maximum capabilities of the Program are not exceeded and the functionalities are compatible.
- Your Activation Key(s) will restrict your use of the Program. At least one of the following restriction schemes will be available to you when you register each Proof of Purchase Code (PPC) and request an Activation Key.
  - The Activation Key may be associated with a specific Dialogic hardware device. In this case, the licensed functionality controlled by the Activation Key will be available solely if the same Dialogic hardware is present in the computer. You can move the Program to another computer solely if you move the specified Dialogic hardware to the new computer.
  - The Activation Key may be associated with a specific Dialogic-supplied software protection device ('dongle'). In this case, the licensed functionality controlled by the Activation Key will be available solely if the same dongle is present in the computer. You can move the Program to another computer solely if you also move the dongle to the new computer.
  - The Activation Key may be associated with your specific computer hardware platform. In this case, the licensed functionality controlled by the Activation Key will be available solely if no significant change is made to the hardware installed in the computer. Replacement Activation Keys may be issued at the discretion of Dialogic solely if Dialogic can determine that you have not moved the Program to another computer. Sufficient information must be provided to Dialogic to allow it to make that determination.
- In addition to the above restrictions, each Activation Key may have a specific term of use commencing from the date of PPC registration. In this case, the licensed functionality controlled by the Activation Key will not be available after the Activation Key has expired.
- The Activation process requires that you enter the following information into the web-based system to obtain an Activation Key:
  - Proof of Purchase Code (PPC)
  - The Device ID provided to You by the 'Activation' function in the Program
  - Your email address so that the Activation Key can be delivered to You by email
- Dialogic will retain the information above for the following purposes:
  - Validation of future requests from You for replacement Activation Keys
  - Sending renewal reminders to You in the case of limited time licenses.
- If the Dialogic hardware device that Activation Keys are associated with is judged to be defective by Dialogic following its standard practices, Dialogic Support will issue to You replacement Activation Keys associated with the replacement device upon receipt of the faulty device by Dialogic. Replacement of the faulty device is subject to the terms of Dialogic's Hardware Warranty. If a valid Advance Replacement Insurance policy is in place for the Dialogic hardware, Dialogic will endeavor to expedite provision of Activation Keys associated with the replacement device.

- If the Dialogic-supplied software protection device (a 'dongle' or 'USB-stick') that Activation Keys are associated with is judged to be defective by Dialogic following its standard practices, Dialogic Support will issue to You replacement Activation Keys associated with the replacement device upon receipt by Dialogic of the failed device. Replacement of the faulty device is subject to the terms of Dialogic's Hardware Warranty.
- You may copy the Program into any machine readable or printed form for backup in support of your use of one copy of the Program;
- You may make one copy of Dialogic's documentation provided that all copyright notices contained within the documentation are retained;
- You may transfer the Program, documentation and the license to another eligible party within your Company if the other party agrees to accept the terms and conditions of this Agreement. If You transfer the Program and documentation You must at the same time either transfer all copies whether in printed or machine readable form to the same party or destroy any copies not transferred;
- You may not rent or lease the Program. You may not reverse engineer, decompile or disassemble the Program. You may not use, copy, modify or transfer the Program and documentation, or any copy, modification or merged portion, in whole or in part, except as expressly provided for in this Agreement;
- You may not modify the Program in order to circumvent or subvert the protection mechanisms inherent in the program or attempt to use a time-limited Activation Key after it has expired;
- If You transfer possession of any copy, modification or merged portion of the Program or documentation to another party in any way other than as expressly permitted in this Agreement, this license is automatically terminated.

**Term**

The license is effective until terminated. You may terminate it at any time by destroying the Program and documentation together with all copies, modifications and merged portions in any form.

It will also terminate upon conditions set forth elsewhere in this Agreement or if you fail to comply with any terms or conditions of this Agreement at any time. You agree upon such termination to destroy the Program and documentation together with all copies, modifications and merged portions in any form.

**Limited Warranty**

The only warranty Dialogic makes, beyond the replacement of Activation Keys under the terms set out above, is that the medium on which the Program is recorded will be replaced without charge if Dialogic, in good faith, determines that it was defective in materials or workmanship and if returned to your supplier with a copy of your receipt within ninety (90) days from the date you received it. Dialogic offers no warranty for your reproduction of the Program. This Limited Warranty is void if failure of the Program has resulted from accident, misuse, abuse or misapplication.

**Customer Remedies**

Dialogic's entire liability and You and Your Authorized Users exclusive remedy shall be, at Dialogic's option, either (a) return of the price paid or (b) repair or replacement of the Program that does not meet the above Limited Warranty. Any replacement Program will be warranted for the remainder of the original Warranty period.

**No Other Warranties**

Dialogic disclaims all other warranties, either express or implied, including but not limited to implied warranties or merchantability and fitness for a particular purpose and the warranty against latent defects, with respect to the Program and the accompanying documentation. This limited warranty gives You specific legal rights. You may have others, which may vary from jurisdiction to jurisdiction.

**No Liability for Consequential Damage**

In no event shall Dialogic, its subsidiaries, directors, employees or suppliers be liable for any damages whatsoever (including without limitation, damages for loss of business profits, business interruption, loss of information, or other pecuniary loss and indirect, consequential, incidental, economic or punitive damages) arising out of the use of or inability to use this Program, even if Dialogic has been advised of the possibility of such damages. As some jurisdictions do not allow the exclusion or limitation for certain damages, some of the above limitations may not apply to You or your Authorized Users.

**Limit of Liability**

The entire aggregate liability of Dialogic under any provision of this agreement shall be limited to the amount actually paid by You for the affected Program. Dialogic's subsidiaries, directors, employees and suppliers shall have no liability under this Agreement.

**Right to Audit**

If this Program is licensed for use in a Company, your Company agrees to keep all usual and proper records and books of accounts and all usual proper entries relating to each installation of the Program during the term of this Agreement and for a period of three (3) years thereafter. During this period, Dialogic may cause an audit to be made of the applicable records and of the installations of the Program in order to verify Your compliance with this Agreement and prompt adjustment shall be made to compensate for any errors or omissions disclosed by such audit. Any such audit shall be conducted by an independent certified public accountant selected by Dialogic and shall be conducted during the regular business hours at Your offices and in such a manner as not to interfere with Your normal business activities. Any such audit shall be paid for by Dialogic unless material discrepancies are disclosed.

For such purposes, 'material discrepancies' shall mean the Company exceeding by three percent (3%) or more the number of licensed channels for any function of the Program or the Company exceeding the licensed number of Authorized Users by three percent (3%) or more. If material discrepancies are disclosed, Your Company agrees to pay Dialogic for the costs associated with the audit as well as the license fees for the additional licensed channels or Authorized Users. In no event shall audits be made more frequently than semi-annually unless the immediately preceding audit disclosed a material discrepancy.

**Supplementary Software**

Any Supplementary Software provided with the Dialogic Program referred to in this License Agreement is provided 'as is' with no warranty of any kind.

**U.S. Government Restricted Rights**

The Program and documentation are provided with RESTRICTED RIGHTS. Use, duplication or disclosure by the U.S. Governments is subject to restrictions as set forth in subparagraph c) 1) ii) of The Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraph c) 1) and 2) of the Commercial Computer Software-Restricted Rights at 48 CFR52.227-19, as applicable.

**Governing Law**

This Agreement shall be construed and controlled by the laws in force in the Province of Quebec, Canada.

**Contractor/ manufacturer is:**

DIALOGIC CORPORATION.

9800 Cavendish Blvd., Montreal, Quebec, Canada H4M 2V9

This Agreement has been drafted in English at the express wish of the parties. Ce contrat a été rédigé en anglais à la demande expresse des parties.

# Contents

<b>Copyright Notice And Legal Disclaimer.....</b>	<b>2</b>
<b>Software License Agreement .....</b>	<b>3</b>
<b>About This Publication .....</b>	<b>7</b>
How to use this online guide .....	7
Structure of this guide .....	7
<b>About The Dialogic® Diva® softSS7 Software .....</b>	<b>8</b>
Dialogic® Diva® softSS7 signaling features .....	8
Supported hardware .....	9
<b>Preparing The Dialogic® Diva® Media Boards.....</b>	<b>10</b>
<b>Installing The Dialogic® Diva® softSS7 Software .....</b>	<b>11</b>
<b>Software Configuration .....</b>	<b>13</b>
Activate the license .....	13
Configuration in the Dialogic® Diva® Configuration web interface .....	17
Configuration with the Dialogic® Diva® Configuration Wizard .....	20
Test the Dialogic® Diva® Media Board .....	21
Change the Dialogic® Diva® softSS7 software configuration file .....	22
<b>Starting The Dialogic® Diva® softSS7 Software.....</b>	<b>23</b>
Verify if Dialogic® Diva® softSS7 software is running .....	23
<b>Tracing.....</b>	<b>25</b>
Tracing with the Dialogic® Diva® Configuration web interface .....	25
Dynamic tracing .....	26
<b>Uninstalling.....</b>	<b>28</b>
<b>Issues While Running The Dialogic® Diva® softSS7 Software .....</b>	<b>30</b>
<b>Glossary.....</b>	<b>31</b>
<b>Appendix.....</b>	<b>32</b>
Back to Back test .....	36
First divaSS7.cfg file .....	36
Second divaSS7.cfg file .....	40
Example: One SS7 link on one controller and 31 CICs on another controller .....	43
Dialogic® Diva® Configuration Wizard settings for the Dialogic® Diva® softSS7 software .....	46
ISUP: list of messages .....	56

## About This Publication

### How to use this online guide

- To view a section, click the corresponding bookmark located on the left.
- To view a topic that contains further information, click the corresponding blue underlined phrase.
- You may wish to print out the pages required for installing the drivers.

### Structure of this guide

This guide provides a detailed description of how to install and configure the Dialogic® Diva® softSS7 software.

This guide is structured as follows:

Section	Contents
<a href="#">About The Dialogic® Diva® softSS7 Software</a>	The Dialogic® Diva® softSS7 features and supported Dialogic® Diva® Media Boards.
<a href="#">Preparing The Dialogic® Diva® Media Boards</a>	Preparations before using the Diva softSS7 software.
<a href="#">Installing The Dialogic® Diva® softSS7 Software</a>	Installation of the Diva softSS7 software.
<a href="#">Software Configuration</a>	Modifications in the Dialogic® Diva® Configuration Wizard, activation and installation of the license file.
<a href="#">Starting The Dialogic® Diva® softSS7 Software</a>	Start and verification of the Diva softSS7 software.
<a href="#">Tracing</a>	Creation of traces with the Diva Configuration Wizard.
<a href="#">Uninstalling</a>	Uninstallation of the Diva softSS7 software.
<a href="#">Issues While Running The Dialogic® Diva® softSS7 Software</a>	How to solve problems with the Diva softSS7 software.
<a href="#">Glossary</a>	Common terms in the SS7 environment.
<a href="#">Appendix</a>	Examples and explanation of the default Dialogic® Diva® softSS7 configuration file.

## CHAPTER 1

### About The Dialogic® Diva® softSS7 Software

The Diva softSS7 software is an add-on for the Dialogic® Diva® System Release software. The Diva softSS7 software enables you to have connectivity over the SS7 signaling network and still be able to use applications with standard programming interfaces like CAPI and the Dialogic® Diva® SDK.

This reference guide describes the basic Linux configuration for the Diva softSS7 software. It is intended to provide advice and instructions on how to install the Diva softSS7 modules as add-on software for the Diva System Release software.

#### Dialogic® Diva® softSS7 signaling features

- Basic inbound and outbound calls
- Support for ETSI (ITU-T) SS7 MTP3/ISUP protocols
- SS7 Signaling End Point (SEP) functionality
- Connection to other SEP or Signaling Transfer Point (STP)
- Associated signaling mode (SS7 link and bearer channels on same trunk)
- Quasi-associated signaling mode via STP (one or more SS7 link(s) on one or more trunk(s), bearer channels on different trunks)
- User-defined trunk number(s) and 64 kbps timeslot(s) for signaling link(s)
- Up to eight E1 trunks per installation
- Up to 247 bearer channels per installation
- Up to eight linksets
- Support of B-channel types (speech, 3.1 kHz audio, 64 kbps transparent, Data, 3G Video GW)
- Configuration for MTP 1-3, ISUP and call control parameters per text file
- Blocking/unblocking according to ITU-T ISUP
- Disabling incoming/outgoing calls on specific channels (CICs)
- User mode management interface for all layers
- Enable dynamic change of:
  - blocking states
  - disabling incoming/outgoing calls
  - debug mask
  - via user mode management interface
- Representation of layer 1 state on ISUP via blocking, e.g. if Layer 1 goes down on a trunk, the related interface is blocked
- Event disabling signaling is represented on ISUP via blocking, e.g., if the signaling connection between the trunk card and the SS7 system service is down, the related interface is blocked
- Restricted representation of blocking state and disabling incoming/outgoing calls on specific channels via the Dialogic® Diva® Management software.
- 24-bit point code support as used in China



### **Supported hardware**

The Dialogic® Diva® softSS7 software supports the following Dialogic® Diva® Media Boards:

#### **Diva PRI 3.0:**

- Diva PRI/E1/T1-CTI
- Diva PRI/E1/T1-8
- Diva PRI/E1-30

#### **Diva V-PRI:**

- Diva V-PRI/E1-30

#### **Diva Multiport PRI:**

- Diva V-2PRI/E1/T1
- Diva V-4PRI/E1/T1

## **CHAPTER 2**

### **Preparing The Dialogic® Diva® Media Boards**

To use your Diva Media Board with the Dialogic® Diva® softSS7 software, you need to install the Dialogic® Diva® System Release software version 8.5. You can download the files for installing the software from the Dialogic web site at:

<http://www.dialogic.com/worldwide/products/MediaGateways>

The online Dialogic® Diva® System Release 8.5LIN Reference Guide provides help for the installation of the software. You can download it from the Dialogic web site at:

<http://www.dialogic.com/worldwide/support/docs.htm>

The drivers of the Diva softSS7 software are installed together with the Dialogic® Diva® drivers.


## CHAPTER 3

### Installing The Dialogic® Diva® softSS7 Software

The Dialogic® Diva® softSS7 software drivers are provided together with the Dialogic® Diva® System Release software. If you upgrade from an former version and have not changed the folder structure, the configuration of that version is used.

To install the Diva softSS7 software, do the following:

1. Execute the following command: # `./Diva4Linux_installer-<build number>.bin`.



```
root@tick:/home/ss7
[root@tick ss7]# ./Diva4Linux_installer_8.5-108-51.bin

-----
Installing Diva Service Release 8.5 LIN (Beta)
incl.
- softIP 2.2
- SIPcontrol 1.6
- softSS7 1.5
-----

1) Extracting archive to /tmp/divas ...
   OK

2) Unpacking archive ...
   OK

3) Checking License ...
   License Agreement accepted.

4) determining system type ...
   rpm found

5) searching previous versions

   no previous versions found. Proceeding with installation.

6) installing Diva for Linux
   success.

7) installing Diva softIP 2.2
   success.

8) installing Diva SIPcontrol 1.6
   success.

9) installing Diva softSS7 1.5 ...
   - mtp3/mtp2
   - isup
   - additional files and docs
   - restoring configuration backup
   success.

10) installing additional components

11) cleaning up ...
```

```
+-----+
|               DIVAS4LINUX INSTALLATION COMPLETE               |
+-----+
|
|       Please start Dialogic Diva Build Wizard
|       (cd /usr/lib/opensdiva/divas/src; ./Build)
|       to build and install drivers for Dialogic Diva ISDN Adapters
|       -
|       Please start Dialogic Diva Configuration Wizard
|       (/usr/lib/opensdiva/divas/Config)
|       to detect and configure all installed Dialogic Diva ISDN Adapters
|       -
|       Diva HTTP Configuration Server started at port '10005'
|       To enable Web interface access please set password in the file
|       '/usr/lib/opensdiva/divas/httpd/login/login'
|       -
|
+-----+

Configuration recovered and saved to '/usr/lib/opensdiva/divas/divas_cfg.rc' file
Board feature licenses recovered and saved to '/usr/lib/opensdiva/divas/licenses'
```

2. During the installation, you will be asked to accept the End-User License Agreement and to confirm the installation.
3. After the installation is complete, press the **Return** button to finish the installation.
4. Follow the instructions shown in the graphic above:
  - Start the Dialogic® Diva® Build Wizard (cd /usr/lib/opensdiva/divas/src; ./Build) to build and install drivers for Dialogic® Diva® ISDN Media Boards.
  - Start the Dialogic® Diva® Configuration Wizard (/usr/lib/opensdiva/divas/Config) to detect and configure all installed Diva ISDN Media Boards.
  - Start the Dialogic® Diva® HTTP Configuration Server at port 10005. To enable web interface access, set password in the file /usr/lib/opensdiva/divas/httpd/login/login

You can now configure the Diva softSS7 software as described in [Software Configuration](#) on page 13.

## CHAPTER 4

### Software Configuration

After you have installed the Dialogic® Diva® System Release software as described in [Installing The Dialogic® Diva® softSS7 Software](#) on page 11, open the Dialogic® Diva® Configuration Wizard to make some necessary changes. You can either use:

- the Dialogic® Diva® Configuration web interface as described on page 17, or
- the Diva Configuration Wizard as described page 20.


Before you start to configure the necessary settings, activate the license file as described below.

#### Activate the license

If you received a Proof of Purchase Code (PPC) for the Dialogic® Diva® softSS7 software instead of a license file from Dialogic, you need to activate your license via the Dialogic web portal. The license activation procedure is different in the web interface (see below) than in the Diva Configuration Wizard (see page 14).

#### License activation in the Dialogic® Diva® Configuration web interface

1. Open the following web site: <http://www.dialogic.com/activate>
2. Follow the instructions on the web site.
3. If you are asked to enter your Device Unique ID (DUID), obtain this number as follows:
  - Open the web interface and under **System control (driver start/stop)** click **Start** to start the drivers.
  - Click **License Management** on the left side of the web interface to open the dialog with the license overview. The DUID is only displayed, if the driver is started.
  - Copy the DUID number of the Diva softSS7 software to the clipboard.



4. If you need to do the web activation using another computer, open an editor, paste the DUID, and save the file.

5. Paste the Device Unique ID from the **License Management** section into the web site.
6. Follow the remaining instructions.
7. The license file will be generated and sent to the email address you entered. Save the license file.
8. Open the **License Management** dialog again.
9. In this dialog, go to **Diva softSS7** and click **Browse** next to **Upload softSS7 license file**.
10. Go to the directory in which you saved the license file and click **Open**.
11. Click **Upload**, to activate the license file.



### License activation in the Dialogic® Diva® Configuration Wizard

1. Open the following web site: <http://www.dialogic.com/activate>
2. Follow the instructions on the web site.
3. If you are asked to enter your Device Unique ID (DUID), obtain this number as follows:

- Go to /usr/lib/opensdiva/divas and execute following command # ./licman -ss7 to start the Dialogic® Diva® License Manager. In order to see the DUID, you need to start the driver first.

```
[root@tick divas]# ./licman -h

usage:
  licman <Option[s]> [-v]

  licman -ss7      : SS7 Licensing: show all installed Boards DUID
  licman -sctrl    : SIPcontrol Licensing: show all installed Boards      DUID
  licman -sip      : SOFTIP Licensing: show System DUID
  licman -crd      : CARD Features Licensing: show Card UID
  licman -i <Licence File> <Target Directory>
                    Verify the license and install it to target directory
  licman -p <Target Directory>
                    Verify the licenses in the Install dir and list all valid features
  licman -g <Board Serial Number>
                    Generate an ISDN Boards DUID from its Serial Number
  licman -b
                    Show the License Manager Build Numbers
  licman -e <Licence File>
                    Evaluate License File
  option -v anyplace: verbose mode

[root@tick divas]# ./licman -ss7
Board[1]: Serial Nr: 1455 DUID: NBIN7S23RMXUWF2IMWFDERSKGAG
[root@tick divas]#
```

- In the Diva License Manager, the serial numbers and DUIDs are displayed for the installed Dialogic® Diva® Media Boards.
- Copy and paste the Device Unique ID from the Diva License Manager into the web site.
  - Follow the remaining instructions.
  - The license file will be generated and sent to the email address you entered. The license file you receive as an attachment of an email that will look similar to this example: SC71000\_000093\_N13ZC4VYX22PR4NHG3UVDP1T2AJ.lic
  - Copy the license file to the computer where you installed the Diva softSS7 software, for example /home/ss7.
  - The License Manager is located in the directory /usr/lib/opensdiva/divas.
  - To install the license enter the following command:

```
# ./licman -i <License File> <Target Directory>
```

The target directory is /usr/lib/opensdiva/divas.ss7.

In the example below, the license file is located in /home/ss7/.

```
[root@tick divas]# ./licman -i /home/ss7/DSC710000008836981262AF8557C5B_NBIN7S23RMXUWF2IMWFDERSKGAG.lic /usr/lib/opensdiva/divas.ss7/
Signature is OK
Product DSC7
Version 1000
Duid NBIN7S23RMXUWF2IMWFDERSKGAG
Created 2007-02-02
Name DSC7_SS7_Link
Expires 3000-01-01
Value 8

Product DSC7
Version 1000
Duid NBIN7S23RMXUWF2IMWFDERSKGAG
Created 2007-02-02
Name DSC7_SS7_E1_Trunk
Expires 3000-01-01
Value 1

[root@tick divas]#
```

- 10.** To read the license, you need to execute the following command:

```
/usr/lib/opensdiva/divas/ licman -e /home/ss7/ <name of your license file>
```

The name of your license file is similar to: DSC71000\_000192\_ NCZ3QSHC1RAH1524V3YEH4MNSAU.lic and the marked section in the graphic shows you where to find it.

- 11.** The License Manager also shows the enabled SS7 link, the DCS7\_SS7\_Link value, and the expiration date of the license file.
- 12.** With the command: /usr/lib/opensdiva/divas/licman -p /usr/lib/opensdiva/divas.ss7/ -v you can verify how many licenses, ss7 links, and E1 trunks are installed.

```
[root@tick divas]# ./licman -h

usage:
  licman <Option[s]> [-v]

  licman -ss7      : SS7 Licensing: show all installed Boards DUID
  licman -sctrl    : SIPcontrol Licensing: show all installed Boards   DUID
  licman -sip      : SOFTIP Licensing: show System DUID
  licman -crd      : CARD Features Licensing: show Card UID
  licman -i <Licence File> <Target Directory>
                    Verify the license and install it to target directory
  licman -p <Target Directory>
                    Verify the licenses in the Install dir and list all valid features
  licman -g <Board Serial Number>
                    Generate an ISDN Boards DUID from its Serial Number
  licman -b
                    Show the License Manager Build Numbers
  licman -e <Licence File>
                    Evaluate License File
  option -v anyplace: verbose mode

[root@tick divas]# ./licman -p /usr/lib/opensdiva/divas.ss7/ -v
Current AKI File: DSC710000008836981262AF8557C5B_NBIN7S23RMXUWF2IMWFDERSKGAG.lic
CertFile: /usr/lib/eicon/divas.ss7/akirootcert.pem
GetFeatures from File DSC710000008836981262AF8557C5B_NBIN7S23RMXUWF2IMWFDERSKGAG.lic
Product: DSC7
In 1 License Files Found:
  Installed SS7 1.5 Features:
    E1 Trunks: 1
    T1 Trunks: 0
    Links: 8
[root@tick divas]#
```



## Configuration in the Dialogic® Diva® Configuration web interface

You can configure the necessary settings in the Diva Configuration web interface.



1. Open the Diva Configuration Wizard web interface and select **Board Configuration**.
2. Click the board icon of the Dialogic® Diva® Media Board that you want to configure.

3. Select **SS7 - Support for SS7** as D-channel protocol to enable the SS7 protocol.

Dialogic

HOME Board Configuration - Detail

Dialogic Diva PRI/E1/T1-CTI PCI v3, SN:1455

Parameter	Value
D-Channel Protocol:	SS7 - Support for SS7
Interface mode/Resource board:	TE - mode
Direct Inward Dialing (DID):	No <a href="#">Configure Call Routing</a>
DID Collect Timeout:	0 (default)
Layer 1 Framing:	National default (default)
TX Attenuation:	0 dBm (default)
Voice Companding:	National default (default)
View Extended Configuration	No

Save Cancel

4. If the network provides the clock for the signaling, the **Interface Mode** should be set to **TE - mode**.
5. Depending on your network you can either switch CRC4 on or off.
6. The default setting for **Layer 1 framing** is **National default**.
7. The rest of the settings are default Diva Media Board settings.
8. After you have made the above changes to your configuration, click **Save** to save the changes. The settings are saved in the "divas\_cfg.rc" file.
9. Restart your Diva Media Board. To do so, click the **System control (driver start/stop)** link and under **Driver Status** click **Stop** and then **Start**.

10. Set the Diva softSS7 software to start automatically at start-up. To do so, click the **System configuration** link, enable **ITU-T SS7 support (softSS7 1.5)** and set **Start driver on system boot** to **Yes**.


The screenshot displays two configuration windows from the Dialogic software. The top window, titled 'System Settings', has a left sidebar with categories: Configuration (Board configuration, System configuration, SIPcontrol configuration, softSS7 configuration, Call Routing configuration), System (System control, System environment, System messages), Status (Board monitor, View call history, View statistics, View report), Debugging (Support/Troubleshooting, Trace/Debug, View trace file, View recovered trace buffer, View adapter recovered trace buffer), and Licensing (License Management). The 'System configuration' link is selected. The main area shows a table of parameters with checkboxes for enabling various interfaces. The 'Applications/Interfaces' section is expanded, showing 'DIVA API / CAPI 2.0 interface' checked, 'SIP-PSTN gateway (SIPcontrol 1.6)' unchecked, 'SIP enabled CAPI (softIP 2.2)' unchecked, and 'ITU-T SS7 support (softSS7 1.5)' checked. Below this are several dropdown menus for FAX CLASS 2 options, resolutions, and link RTF. The bottom window, titled 'Startup Options', contains a table of parameters with dropdown menus for setting values like 'Verify serial number', 'Debug mode for microcode load', 'Forced (insmod -f) driver load', 'Write call history to /var/log/divalog', 'Activate Diva SNMP support', 'Start driver on system boot', 'Automatic reboot after system error', and 'Load MAINT debug/trace driver'. The 'Start driver on system boot' is set to 'Yes'. At the bottom of the 'Startup Options' window are 'Save' and 'Cancel' buttons.

Parameter	Value
Applications/Interfaces:	<input type="checkbox"/> TTY interface <input type="checkbox"/> PIAFS support for TTY <input type="checkbox"/> fax/voice support for TTY <input checked="" type="checkbox"/> DIVA API / CAPI 2.0 interface <input type="checkbox"/> SIP-PSTN gateway (SIPcontrol 1.6) <input type="checkbox"/> SIP enabled CAPI (softIP 2.2) <input checked="" type="checkbox"/> ITU-T SS7 support (softSS7 1.5)
FAX CLASS 2 options:	Enable ECM, Compression and V.34 (33600)
FAX CLASS 2 V.34 options:	off
FAX CLASS 2 resolutions:	Normal/Fine
Extended FAX CLASS 2 options:	off
PIAFS link RTF:	15 frames (default)
CAPI Call distribution:	Group Optimization
Call Rate Limit	off (default)


Parameter	Value
Verify serial number:	Yes
Debug mode for microcode load:	No
Forced (insmod -f) driver load:	No
Write call history to /var/log/divalog:	Yes
Activate Diva SNMP support:	No
Start driver on system boot:	Yes
Automatic reboot after system error:	No
Load MAINT debug/trace driver:	Yes

### Configuration with the Dialogic® Diva® Configuration Wizard


1. To start the Diva Configuration Wizard, execute the following command:  
# /usr/lib/opensdiva/divas/Config
2. Install the license file as described in [Activate the license](#) on page 13.
3. Set the interface type to **ITU-T SS7 support (softSS7 1.5)** and select **CAPI 2.0 interface**.




4. Set the D-Channel protocol to **SS7 - SS7 Support**.




5. Depending on the Telco's network, select as layer 1 framing either **Multiframing (CRC4)** or **Doubleframing (no CRC4)**.




6. Set the voice companding option as specified by the operator. For Europe, A-law is normally used.



7. Save the changes and select **Bind every Diva Board to own M-Board**.



8. Select **Start driver on system boot** to automatically start the Dialogic® Diva® SS7 software at start-up.



For a complete overview of the settings, see the [Dialogic® Diva® Configuration Wizard settings for the Dialogic® Diva® softSS7 software](#) on page 46.

### Test the Dialogic® Diva® Media Board

After the restart of the system, plug the 2MB trunk into one port of your Diva Media Board. If the red LED of this port is turned off, your configuration is working properly from the hardware point of view. If the red LED remains lit, make sure that the other end of the cable is properly connected to the end-point. If that is the case, verify the configuration with help of the Dialogic® Diva® Configuration web interface or the Dialogic® Diva® Configuration Wizard.

## Loopback test

If your Diva Media Board has various ports or you have various Diva Media Boards installed, you can also do a loopback test. To do so, plug the loopback cable in the ports you want to test. If the red LED is turned off, your configuration is working properly on a hardware/electrical level. If it remains lit, you need to verify the configuration with help of the Diva Configuration web interface or the Diva Configuration Wizard.

## Change the Dialogic® Diva® softSS7 software configuration file

A default configuration file is installed with the Diva softSS7 software package. This configuration file (called "divaSS7.cfg") is text-based. You need to change the configuration file and enter your own SS7 configuration parameters either in the Dialogic® Diva® Configuration web interface

The screenshot shows the Dialogic Diva Configuration web interface. The top navigation bar includes 'HOME', 'SS7 Configuration', and 'REFERENCE GUIDES'. The left sidebar contains a 'Configuration' menu with sub-items: Board configuration, System configuration, SIPcontrol configuration, softSS7 configuration (selected), and Call Routing configuration. Below this are 'System' (System control, System environment, System messages), 'Status' (Board monitor, View call history, View statistics, View report), 'Debugging' (Support/Troubleshooting, Trace/Debug, View trace file, View recovered trace buffer, View adapter recovered trace buffer), and 'Licensing' (License Management). The main content area is titled 'View/edit SS7 config file' and displays the following configuration text:

```
#-----
# STACK_STANDARD_TYPE : Specifies the variant of the stack
# ITU= 1, ETSI=2
#-----
STACK_STANDARD_TYPE          1
#-----
# NETWORK_INDICATOR : Specifies the network indicator of ISUP and MTP3
# International 0 = 0, International 1 / SPARE = 1,
# National 0 = 2, National 1 (Reserved for national use) = 3
#-----
NETWORK_INDICATOR            2
#-----
# MTP3 and ISUP are communicating via (local) sockets with each other
# -> therefore the below paragraph is required
# MTP3_IP_ADDRESS             - IP of MTP3
# ISUP_IP_ADDRESS             - IP of ISUP
# MTP3_SERVER_PORT            - MTP3 server port to which the ISUP client is connecting
# ISUP_SERVER_PORT            - ISUP server port to which the MTP3 client is connecting
# MTP3_CLIENT_TO_ISUP_PORT     - MTP3 client port which connects to the ISUP server
# ISUP_CLIENT_TO_MTP3_PORT    - ISUP client port which connects to the MTP3 server
# all entries are required
#-----
MTP3_IP_ADDRESS               127.0.0.1
MTP3_SERVER_PORT              12900
MTP3_CLIENT_TO_ISUP_PORT      13100
ISUP_IP_ADDRESS               127.0.0.1
ISUP_SERVER_PORT              14000
ISUP_CLIENT_TO_MTP3_PORT      14100
#-----
# DEBUG MASKs
# set debug mask according to the definitions below
```

A 'change config' button is located at the bottom right of the configuration text area.

or in a text editor when opening it from `/usr/lib/pendiva/divas.ss7`.

See the [Appendix](#) on page 32 for a more detailed description of this file.

## CHAPTER 5

### Starting The Dialogic® Diva® softSS7 Software

After you installed the Diva softSS7 software and the license file and made the necessary changes to the "divaSS7.cfg" configuration file, you can start the Diva softSS7 software.

1. Got to `/usr/lib/opendiva/divas.ss7`.
2. Start the Diva softSS7 software with the command `# ./StartSoftSS7`, which starts the `./ss7_mtp3_cmtmp2_stack` and `./ss7_isup_cc_stack` processes.


```
[root@tick divas.ss7]# ./StartSS7
Starting Diva softSS7 ... 18437 ?      00:00:00 ss7_isup_cc_sta
OK
[root@tick divas.ss7]# ps -ef | grep ss7
root      18434      1  0 19:05 ?          00:00:00 ./ss7_mtp3_cmtmp2_stack
root      18437      1  0 19:05 ?          00:00:00 ./ss7_isup_cc_stack
root      18442 16578  0 19:06 pts/0      00:00:00 grep ss7
[root@tick divas.ss7]# ./StopSS7
[root@tick divas.ss7]# ps -ef | grep ss7
root      18447 16578  0 19:06 pts/0      00:00:00 grep ss7
[root@tick divas.ss7]#
```

3. To stop the Diva softSS7 software you need to execute the `stopSS7` script as shown in the graphic above.

### Verify if Dialogic® Diva® softSS7 software is running

To verify if the Diva SS7 software starts up properly, you can use the following commands, before you start it.

1. Enable Diva tracing. Go to `/usr/lib/opendiva/divas` and type in `# ./Trace`. Click **OK**.



2. List the available trace possibilities with the command `divactrl ditrace -l`.

3. Since only the SS7 information is relevant, you need to disable the other information elements, by setting their trace masks on zero. To do so, use the command
- ```
divactrl ditrace -d 1,2,3,4 -m 0x0.
```

```
[root@tick divas]# ./divactrl ditrace -l

-----
ditrace, BUILD (108-22[108-120]-Feb 26 2008-17:11:43)
-----
0:00:00.000 01 - DIDD(3.0)
0:00:00.000 02 - DIVAS(2.0)
0:00:00.000 03 - MAINT(3.1)
0:00:04.348 04 - ADAPTER:1 SN:1455
0:00:05.824 05 - User IDI(2.0)
0:00:05.856 06 - MTPX(108-344-SRC)
0:00:06.870 07 - CAPI20(2.0)
-----

[root@tick divas]# ./divactrl ditrace -d 1,2,3,4,5,6,7 -m 0x0
[root@tick divas]# ./divactrl ditrace -p > trace.txt &
[1] 9484
[root@tick divas]# tail -f trace.txt
```

4. The default trace masks for the Diva softSS7 software are saved in the divaSS7.cfg configuration file. The default masks for tracing are:

```
ISUP_CC_DEBUG_MASK 0x00000007 # set to STATUS|ERROR|WARN
MTP3_MTP2_DEBUG_MASK 0x00000007 # set to STATUS|ERROR|WARN
```

5. Write the output from the trace to a file, `divactrl ditrace -p > [file-name]`. In the above graphic, the trace is written to a file named `trace.txt`.
6. Do a `tail -f [file-name]` and start the Diva softSS7 software.

```
3:25:14.678 L F S-CMTP2[1]: Changing state time Thu Feb 28 18:07:14 2008
3:25:14.679 L F S-CMTP2[2]: RX - MTP2_TO_MTP3_InService
3:25:14.679 L F S-CMTP2[2]: Changing state to IN_SERVICE
3:25:14.679 L F S-CMTP2[2]: Changing state time Thu Feb 28 18:07:14 2008
3:25:14.681 L F S-CMTP2[3]: RX - MTP2_TO_MTP3_InService
3:25:14.681 L F S-CMTP2[3]: Changing state to IN_SERVICE
3:25:14.681 L F S-CMTP2[3]: Changing state time Thu Feb 28 18:07:14 2008
3:25:14.681 L F S-CMTP2[4]: RX - MTP2_TO_MTP3_InService
3:25:14.681 L F S-CMTP2[4]: Changing state to IN_SERVICE
3:25:14.681 L F S-CMTP2[4]: Changing state time Thu Feb 28 18:07:14 2008
3:25:14.733 L F S-MTP23: Alarm/Event reported for LINK 3 : status NOT AVAILABLE (0x80000000)
3:25:14.733 L F S-MTP23: Alarm/Event reported for SELF PC : status RESTARTING
3:25:14.733 L F S-MTP23: Alarm/Event reported for ROUTE 1 : status AVAILABLE (ROUTE)
3:25:14.733 L F S-MTP23: Alarm/Event reported for ROUTE 1 : status AVAILABLE (ROUTE)
3:25:14.733 L F S-MTP23: Alarm/Event reported for LINK 3 : status AVAILABLE (0x00000000)
3:25:14.733 L F S-MTP23: Alarm/Event reported for ROUTE 1 : status AVAILABLE (ROUTE)
3:25:14.737 L F S-MTP23: Alarm/Event reported for LINK 4 : status NOT AVAILABLE (0x80000000)
3:25:14.737 L F S-MTP23: Alarm/Event reported for ROUTE 1 : status AVAILABLE (ROUTE)
3:25:14.737 L F S-MTP23: Alarm/Event reported for LINK 4 : status AVAILABLE (0x00000000)
3:25:14.738 L F S-MTP23: Alarm/Event reported for LINK 1 : status NOT AVAILABLE (0x80000000)
3:25:14.738 L F S-MTP23: Alarm/Event reported for ROUTE 1 : status AVAILABLE (ROUTE)
3:25:14.738 L F S-MTP23: Alarm/Event reported for LINK 1 : status AVAILABLE (0x00000000)
3:25:14.739 L F S-MTP23: Alarm/Event reported for LINK 2 : status NOT AVAILABLE (0x80000000)
3:25:14.739 L F S-MTP23: Alarm/Event reported for ROUTE 1 : status AVAILABLE (ROUTE)
3:25:14.739 L F S-MTP23: Alarm/Event reported for LINK 2 : status AVAILABLE (0x00000000)
3:25:20.732 L F S-MTP23: Alarm/Event reported for SELF PC : status ACCESSIBLE
3:25:20.732 L F S-MTP23: Alarm/Event reported for DPC 130: status ACCESSIBLE
3:25:20.732 L 10 S-CC: isup_resume_ind - for DPC:130
3:25:20.732 L 10 S-CC: cc_term_set_term_active_state_by_DPC - set 244 terminals for DPC 130 into ACTIVE
3:25:20.732 L 10 S-CC/01/: isup_resume_ind - state from 0000:0000:0000:0000:0000:0000:0000:0000 to 0111:1111:1111:1111:0111:1111:1111:1111
3:25:20.732 L 10 S-CC/02/: isup_resume_ind - state from 0000:0000:0000:0000:0000:0000:0000:0000 to 0111:1111:1111:1111:1111:1111:1111:1111
3:25:20.732 L 10 S-CC/03/: isup_resume_ind - state from 0000:0000:0000:0000:0000:0000:0000:0000 to 0111:1111:1111:1111:1111:1111:1111:1111
3:25:20.732 L 10 S-CC/04/: isup_resume_ind - state from 0000:0000:0000:0000:0000:0000:0000:0000 to 0111:1111:1111:1111:0111:1111:1111:1111
3:25:20.732 L 10 S-CC/05/: isup_resume_ind - state from 0000:0000:0000:0000:0000:0000:0000:0000 to 0111:1111:1111:1111:0111:1111:1111:1111
3:25:20.732 L 10 S-CC/06/: isup_resume_ind - state from 0000:0000:0000:0000:0000:0000:0000:0000 to 0111:1111:1111:1111:1111:1111:1111:1111
3:25:20.732 L 10 S-CC/07/: isup_resume_ind - state from 0000:0000:0000:0000:0000:0000:0000:0000 to 0111:1111:1111:1111:1111:1111:1111:1111
3:25:20.732 L 10 S-CC/08/: isup_resume_ind - state from 0000:0000:0000:0000:0000:0000:0000:0000 to 0111:1111:1111:1111:0111:1111:1111:1111
```



## CHAPTER 6

### Tracing

Trace information will be written via the standard Dialogic® Diva® trace utilities. To enable tracing for the Dialogic® Diva® softSS7 software, you have to make sure that the following entries are included in the "divaSS7.cfg" file:

```
ISUP_CC_DEBUG_MASK    0x00000007 # set to STATUS|ERROR|WARN
MTP3_MTP2_DEBUG_MASK 0x00000007 # set to STATUS|ERROR|WARN
```

To enable a complete trace for the Diva softSS7 software, you can change your trace mask to:

```
ISUP_CC_DEBUG_MASK    0x000003FF
MTP3_MTP2_DEBUG_MASK 0x000003FF
```

Please see the [Appendix](#) on page 32 for a complete description of the debug mask. If you need to make changes to the "divaSS7.cfg" file, you need to stop the Diva softSS7 software and start it again.

If you only want to trace on SS7 level, you need to disable the other categories. See also [Verify if Dialogic® Diva® softSS7 software is running](#) on page 23 for more information.

The following sections describes the tracing with the Dialogic® Diva® Configuration web interface.

#### Tracing with the Dialogic® Diva® Configuration web interface

1. Start the Diva Configuration web interface and click **Trace/Debug** on the left hand side to open the Dialogic® Diva® Trace Wizard.
2. Keep the default settings and click **Start**.
3. To stop the tracing, click **Stop trace process and retrieve compressed trace file**.  
**Note:** If you use the Diva Trace Wizard at start-up, keep in mind that the whole start-up procedure for the Diva softSS7 software takes about 70 seconds. Therefore, wait at least 70 seconds before you click **Stop trace process and retrieve compressed trace file**.
4. You can also make traces when the stack is up and running, but the trace information depends on the settings you made in the trace mask in the divaSS7.cfg file. If you make changes to these trace settings, you need to restart Diva softSS7 software.

5. After you stopped the trace process, you can view and/or download the trace file and select with the trace viewer the components you want to see in your trace file. For the Dialogic® Diva® softSS7 software, set the MTP2/MTP3 and ISUP components to **Yes** and the rest to **No**.

## Dialogic

The screenshot shows the Dialogic web interface for selecting trace sources. The top navigation bar includes 'HOME' and 'View trace file'. The left sidebar contains a menu with categories: Configuration (Board configuration, System configuration, SIP control configuration, softSS7 configuration, Call Routing configuration), System (System control (driver start/stop), System environment, System messages), Status (Board monitor, View call history, View statistics, View report), Debugging (Support/Troubleshooting, Trace/Debug, View trace file, View recovered trace buffer, View adapter recovered trace buffer), and Licensing (License Management).

The main content area is titled 'Please select the sources of the trace information' and contains a table with the following data:

| Description               | Selection | Trace ID | Driver name/Device                              |
|---------------------------|-----------|----------|-------------------------------------------------|
| All messages              | Yes       |          |                                                 |
| Kernel mode IDI interface | Yes       | 1        | divadidd (DIDD, /proc/net/isdn/eicon/divadidd)  |
| Active adapter driver     | Yes       | 2        | divas (XDI, /proc/net/isdn/eicon/divas)         |
| Maintenance driver        | Yes       | 3        | diva_mnt (MAINT, /proc/net/isdn/eicon/maint)    |
| Diva Board Nr:1, Sn:1050  | Yes       | 4        | /proc/net/isdn/eicon/adapter1/info              |
| User mode IDI interface   | Yes       | 5        | diva_idi (IOCTL, /proc/net/isdn/eicon/diva_idi) |
| MTPX                      | Yes       | 6        |                                                 |
| CAP12.0 interface         | Yes       | 7        | divacapi (/dev/capi20 MAJOR 68, /proc/capi/)    |
| SS7MTP3CMTP2              | Yes       | 8        |                                                 |
| SS7ISUPCC                 | Yes       | 9        |                                                 |

Below the table is a section titled 'Select filter options' with the following settings:

| Description          | Selection         |
|----------------------|-------------------|
| Selected B-channels  | All               |
| Decode VSIG messages | No                |
| Decode PPP frames    | detect PPP frames |

At the bottom of the filter options section are two buttons: 'View/Download decoded trace file' and 'Download binary trace file'.

6. Click one of the buttons to view and/or download the trace file.

## Dynamic tracing

Below are some examples for the MTP process on how to enable/disable the Diva softSS7 software tracing dynamically. If you change the -c 1010 to -c 1011, you are setting the debug masks for the ISUP process. For a full description about the trace mask, see the description in the divaSS7.cfg configuration file. After setting the trace masks for the ISUP and MTP processes, you can then use the Dialogic® Diva® Trace tool as described in [Tracing with the Dialogic® Diva® Configuration web interface](#) on page 25 or use the command line interface as described in [Verify if Dialogic® Diva® softSS7 software is running](#) on page 23.

```
[root@tick divas]# ./divactrl mantool -L
6:{1,1004,101,1000,1010,1011}
```

```
[root@tick divas]# ./divactrl mantool -c 1010 -r"Debug"
I: adapter 1010 selected
Management Interface B-Channel State Trace utility for Diva cards
BUILD (108-22-Feb 26 2008-17:11:43)
Copyright (c) 1991-2008 Dialogic
```

```
-w-----hit-[debug_mask .....] = 0x3ff
-----fn -[DebugStop .....]
```

```
[root@tick divas]# ./divactrl mantool -c 1010 -w"Debug\debug_mask=0x0"
I: adapter 1010 selected
Management Interface B-Channel State Trace utility for Diva cards
```

BUILD (108-22-Feb 26 2008-17:11:43)  
Copyright (c) 1991-2008 Dialogic

```
[root@tick divas]# ./divactrl mantool -c 1010 -r"Debug"
I: adapter 1010 selected
Management Interface B-Channel State Trace utility for Diva cards
BUILD (108-22-Feb 26 2008-17:11:43)
Copyright (c) 1991-2008 Dialogic
```

```
-w-----hit-[debug_mask .....] = 0x0
-----fn -[DebugStop .....]
```

```
[root@tick divas]# ./divactrl mantool -c 1010 -w"Debug\debug_mask=3ff"
I: adapter 1010 selected
Management Interface B-Channel State Trace utility for Diva cards
BUILD (108-22-Feb 26 2008-17:11:43)
Copyright (c) 1991-2008 Dialogic
```

```
[root@tick divas]# ./divactrl mantool -c 1010 -r"Debug"
I: adapter 1010 selected
Management Interface B-Channel State Trace utility for Diva cards
BUILD (108-22-Feb 26 2008-17:11:43)
Copyright (c) 1991-2008 Dialogic
```

```
-w-----hit-[debug_mask .....] = 0x3ff
-----fn -[DebugStop .....]
```

## CHAPTER 7

### Uninstalling

**Note:** There is no separate Dialogic® Diva® softSS7 software uninstaller provided. The software is uninstalled together with the Dialogic® Diva® System Release software.

To uninstall the Dialogic® Diva® softSS7 software, do the following:

1. Open a terminal and go to `/usr/lib/opensdiva/divas` and change the file `Diva4Linux_uninstaller.sh` to an executable  
`# chmod a+x Diva4Linux_uninstaller.sh.`
2. Stop the Dialogic® Diva® driver with `# ./Stop`
3. Execute the script `Diva4Linux_uninstaller.sh`. While executing the script you will be asked:
  - If you would like to uninstall the Dialogic® Diva® SoftIP software, the Dialogic® Diva® SIPcontrol™ software (when these products are installed). Answer **No** if you do not want to uninstall these products or press **Yes** to confirm that you want to remove these software products.
  - If you want to uninstall the Diva softSS7 software, press **Yes** to confirm.
  - For the Dialogic® Diva® System Release software, answer **NO** if you do not want to uninstall or press **Yes** to confirm that you want to remove this software product.
4. The license files and configuration files are saved:
  - Diva softSS7 software binaries are removed and license and the configuration files are copied to:  
`/usr/lib/opensdiva/divas.ss7`  
`DSC71000_*****_*****.lic`  
`divaSS7.cfg.rpmsave`
  - Dialogic® Diva® Media Board licenses are saved in  
`/usr/lib/opensdiva/licenses.saved.by.divas4linux`
  - Dialogic® Diva® Media Board configuration is copied to  
`/usr/lib/opensdiva/divas_cfg.rc.saved.by.divas4linux`
  - Dialogic® Diva® softIP software configuration and licenses are saved in `/usr/lib/opensdiva/diva.softip`
  - Dialogic® Diva® SIPcontrol™ software configuration and licenses are saved in  
`/usr/lib/opensdiva/diva.sipcontrol`
5. If you decide to reinstall the software, these files will be restored.

Your Diva softSS7 software is now removed.

You can also use the above procedure for upgrades. When you install your new Diva softSS7 software, the backup license file and the Dialogic® Diva® softSS7 configuration files are automatically copied back as shown in the graphic below.

A terminal window titled 'root@tick:/home/ss7' showing the execution of the Diva Linux installer. The installer displays a list of components to be installed, followed by a series of steps from 1 to 11, including extracting archives, unpacking, checking the license, determining the system type, searching for previous versions, and installing the Diva software and its components. The process concludes with a successful installation and cleanup.

```
root@tick:/home/ss7
[root@tick ss7]# ./DivaLinux_installer_8.5-108-51.bin

-----
Installing Diva Service Release 8.5 LIN
incl.
- softIP 2.2
- SIPcontrol 1.6
- softSS7 1.5
-----

1) Extracting archive to /tmp/divas ...
   OK

2) Unpacking archive ...
   OK

3) Checking License ...
   License Agreement accepted.

4) determining system type ...
   rpm found

5) searching previous versions
   no previous versions found. Proceeding with installation.

6) installing Diva for Linux
   success.

7) installing Diva softIP 2.2
   success.

8) installing Diva SIPcontrol 1.6
   success.

9) installing Diva softSS7 1.5 ...
   - mtp3/mtp2
   - isup
   - additional files and docs
   - restoring configuration backup
   success.

10) installing additional components

11) cleaning up ...
```

## **CHAPTER 8**

### **Issues While Running The Dialogic® Diva® softSS7 Software**

If you have any issues with the Diva softSS7 software, please contact Dialogic Customer support at:  
<http://www.dialogic.com/support/contact/>.

**Note:** When contacting support, you will be asked to provide traces of your Dialogic® Diva® softSS7 software application as well as of the CAPI and the Dialogic® Diva® Media Board. For more information, see [Tracing](#) on page 25.

## Glossary

|       |                                                 |
|-------|-------------------------------------------------|
| APC   | Adjacent Point Code                             |
| CAPI  | COMMON-ISDN-API: CAPI - the ISDN interface      |
| CIC   | Circuit Identification Code                     |
| DPC   | Destination Point Code                          |
| ETSI  | European Telecommunications Standards Institute |
| ISUP  | ISDN User Part                                  |
| ITU-T | International Telecommunication Union           |
| LPC   | Local Point Code this is the same as the OPC    |
| MTP2  | Message Transfer Part level 2                   |
| MTP3  | Message Transfer Part level 3                   |
| OPC   | Originator Point Code                           |
| SDK   | Software Development Kit                        |
| SEP   | Signaling End Point                             |
| SLC   | Signaling Link Code                             |
| SLS   | Signaling Link Selection                        |
| SS7   | Signaling System Number 7                       |
| STP   | Signal Transfer Point                           |

## Appendix

The Appendix provides examples and explanations of the default Dialogic® Diva® softSS7 software configuration file (divaSS7.cfg).

```
#-----
# STACK_STANDARD_TYPE : Specifies the variant of the stack
# ITU= 1, ETSI=2
#-----
STACK_STANDARD_TYPE          1
#-----
# NETWORK_INDICATOR : Specifies the network indicator of ISUP and MTP3
# International 0 = 0, International 1 / SPARE = 1,
# National 0 = 2, National 1 (Reserved for national use) = 3
#-----
NETWORK_INDICATOR           2
#-----
# MTP3 and ISUP are communicating via (local) sockets with each other
# -> therefore the below paragraph is required
# MTP3_IP_ADDRESS            - IP of MTP3
# ISUP_IP_ADDRESS            - IP of ISUP
# MTP3_SERVER_PORT           - MTP3 server port to which the ISUP client is connecting
# ISUP_SERVER_PORT           - ISUP server port to which the MTP3 client is connecting
# MTP3_CLIENT_TO_ISUP_PORT    - MTP3 client port which connects to the ISUP server
# ISUP_CLIENT_TO_MTP3_PORT    - ISUP client port which connects to the MTP3 server
# all entries are required
#-----
MTP3_IP_ADDRESS              127.0.0.1
MTP3_SERVER_PORT             13000
MTP3_CLIENT_TO_ISUP_PORT     13100
ISUP_IP_ADDRESS              127.0.0.1
ISUP_SERVER_PORT             14000
ISUP_CLIENT_TO_MTP3_PORT     14100
#-----
# DEBUG MASKS
# set debug mask according to the definitions below
# debug information is written via standard log mechanism
# STATUS 0x00000001 - output STATUS (marked with 'S-')
# ERROR  0x00000002 - output ERRORS (marked with 'E-')
# WARN   0x00000004 - output WARNINGS (marked with 'W-')
# INFO   0x00000008 - output info (marked with 'I-')
# WRAPPER 0x00000010 - output details of the stack encapsulation (marked with 'A-')
# DETAIL  0x00000020 - output detail (creates a lot of output) (marked with 'V-')
# DATA   0x00000040 - output data (for data messages) (marked with 'D-')
# PERROR  0x00000080 - output pointer errors (marked with 'R-')
# NCCI_STM 0x00000100 - output Capi NCCI statemachine (marked with 'N-')
# PLCI_STM 0x00000200 - output Capi PLCI statemachine (marked with 'P-')
# CONT_STM 0x00000400 - output Capi Controller statemachine (marked with 'C-')
# MALLOC  0x00000800 - output memory allocation errors
#                      (creates a lot of output, do not use if not requested)
#                      (marked with 'M-')
# TIMER   0x00001000 - output timer handling
#                      (creates a lot of output, do not use if not requested)
#                      (marked with 'T-')
# in general a debug mask set to 0x00000007 should be sufficient
#-----
ISUP_CC_DEBUG_MASK 0x00000007 # set to STATUS|ERROR|WARN
MTP3_MTP2_DEBUG_MASK 0x00000007 # set to STATUS|ERROR|WARN
#-----

#-----
# Controller configuration
# This paragraphs were changed from 1.2 to 1.5
# The 'old' style configuration will still work
# Using the 'old' style will cause the following Warning on startup:
# W-CONFIGURATION: cc_prov: no Controller Configuration found - assuming old format
# W- This may cause fatal errors if your DIVA server adapter
# W- numbering changes
# W- (e.g. adapter was not found while rebooting)
#

# Reason for the change:
# The 'old' configuration may cause fatal errors.
```



```

# In the 'old' configuration the CAPI adapter number was used to
# identify the DIVA server controller/trunk.
# The mapping between the CAPI adapter number and the physical
# DIVA server controller/trunk is not hard wired.
# When adding an additional, removing or crash of a DIVA server
# controller/trunk the mapping between CAPI adapter number
# DIVA server controllers/trunks may change.
# Even on startup the DIVA server controllers/trunks may be detected
# in a different sequence and therefore the mapping may change.
# The only secure way to identify a DIVA server controller/trunk is
# via serial number.
#
#       There are different formats for the serial numbers:
#       1234      - single controller
#                  or first controller of a multispan DIVA server card
#                  running on LINUX
#
#       1234-1    - serial numbers of controllers on a multispan card
#       1234-2    LINUX would not display 1234-1 but 1234
#       1234-3    -> the serial numbers in the configuration of Linux
#       1234-4    would be 1234, 1234-2, 1234-3, 1234-4
#
#       Windows adds an additional number identifying the DIVA server
#       card type: 1234-72 -> PRI v3.0 E1/T1 8M
#                  1234-1-85 -> first controller on Diva Server 4PRI/E1/T1
#       The cardtype is ignored -> please do not add the type to the
#       configuration of the serial
#
# How to obtain the serial number of your adapters:
#   Windows: - open the Diva Server Configuration Manager
#             - click onto the corresponding adapter symbol
#             - in the properties You will find the serial number
#             - for multispan adapters you have to append the 'Lines'
#               after the serial '-1', '-2', ...
#   Linux:   run the tool adapter_info.sh and the serial numbers of the
#             DIVA Server controllers will be displayed
#
# Note: to enable the handling of the serials (windows/linux), serial
#       numbers without the 'port'-number (sub adapter number) will have appended
#       automatically the '-1'
#-----
NUM_CONTROLLER 1
#-----
#LogControllerNum local law SerialN
CONTROLLER_CONFIG_START
1 local A 1300
CONTROLLER_CONFIG_END
#-----

#-----
#CC_PROVISIONING
#-----
# number of terminals configured/used
CC_NUM_TERMINALS 30
#-----
# length called party number
CC_LENGTH_CALLED_PARTY_NUMBER_START
0
CC_LENGTH_CALLED_PARTY_NUMBER_END
#-----
# initial state 0-PAUSE 1-ACTIVE
CC_INITIAL_STATE 0
#-----
# Due to the increased functionality of the blocking, the configuration of
# the blocking is enhanced
#
# LSB - bit 0 0x01 local maintenance blocking (by operator) (Note1)
#       bit 1 0x02 local hardware blocking (by operator) (Note2)
#       bit 2 reserved
#       bit 3 reserved
#       bit 4 0x10 follow remote blocking (Note3)
#       bit 5 reserved
#       bit 6 0x40 inbound calls disabled (Note4)
# MSB bit 7 0x80 outbound calls disabled (Note4)

```

```

#
# All theses values may be superseded by management when
# ISUP/CallControl is started
# Note1: local maintenance blocking may be set/reset additionally via
#       DIVA server adapter management and when follow remote is set
# Note2: local hardware blocking is as well set/reset when Layer 1 of
#       DIVA server adapter is Down OR the CAPI connection to the
#       DIVA server adapter is lost (no path to the applications)
# Note3: When follow remote is set, local maintenance blocking will be
#       set/reset when blocking/unblocking is received from the
#       remote peer
# Note4: The disabling of in-/outbound calls can NOT be signaled to
#       the remote peer.
#       Therefore be sure, that the administrator of the peer is
#       aware if the disabling is set.
#       Even if those values can be set/reset when started, but
#       it does not make sense to do it, other than for testing purpose.
#
# These bits may be combined
# Examples: 0x11 - local maintenance blocking is set,
#           follow remote is set
#           0xC0 - inbound and outbound calls are disabled
#
# You may set those values as well decimal:
# Examples: 0x11 corresponds to 17
#           0xC0 corresponds to 192
#-----
#CIC OPC DPC LogContrNum Timeslot Blocked
CC_TERMINAL_CONFIG_START
1 129 130 1 1 0
2 129 130 1 2 0
3 129 130 1 3 0
4 129 130 1 4 0
5 129 130 1 5 0
6 129 130 1 6 0
7 129 130 1 7 0
8 129 130 1 8 0
9 129 130 1 9 0
10 129 130 1 10 0
11 129 130 1 11 0
12 129 130 1 12 0
13 129 130 1 13 0
14 129 130 1 14 0
15 129 130 1 15 0
17 129 130 1 17 0
18 129 130 1 18 0
19 129 130 1 19 0
20 129 130 1 20 0
21 129 130 1 21 0
22 129 130 1 22 0
23 129 130 1 23 0
24 129 130 1 24 0
25 129 130 1 25 0
26 129 130 1 26 0
27 129 130 1 27 0
28 129 130 1 28 0
29 129 130 1 29 0
30 129 130 1 30 0
31 129 130 1 31 0
CC_TERMINAL_CONFIG_END
#-----
#CC_PROVISIONING_END
#-----

```

```

#-----
#ISUP_PROVISIONING
#-----
ISUP_CIC_CONFIG_START
#   Status:  Delete  = 0, Add = 1
ISUP_CIC_CONFIG
      OPC      DPC      START_CIC      NUM_OF_CICS
      129      130      1      15
      129      130      17      15
ISUP_CIC_CONFIG_END
#-----
# Network Protection timer (ITU-T Q.764 T7)
# Started after the transmission of an IAM. Stopped when ACM is received.
# On expiry the connection is released.
# ITU-T Q.764 - Standard: 20-30 sec
# Implementation default: 20 sec
# If You require a different value, uncomment line and change value according
# ISUP_T7 20
#-----
#ISUP_PROVISIONING_END
#-----

#-----
#MTP3_PROVISIONING
#-----
MTP3_SELF_POINT_CODE_START
# PC: Self Point Code
# Type:  Primary PC = 81, SECONDARY = 82 CAPABILITY CODE =83
# Point code of MTP3
# PC Nodecap Status
MTP3_SELF_POINT_CODE
#OPC      SPC_TYPE
129      81
MTP3_SELF_POINT_CODE_END
#-----
MTP3_DEST_POINT_CODE_START
# Destination Type Bitwise Usage:
#   Bit      Value      Definition
# Most Significant Bit 0Destination is DPC
#   1st Bit      1(0x01)      Adj DPC
#   2nd Bit      1(0x02)      Rem DPC
#   3rd Bit      0/1(0/0x04)      Brdcast_opt enable/disable
#   4th Bit      0/1(0/0x08)      dpc is mated_stp/non mated
# Status:  Delete  = 0, Add = 1
# DPC      Type  Sls  Status
#-----
MTP3_DEST_POINT_CODE
DPC      Type  sls
130      1      1
MTP3_DEST_POINT_CODE_END
#-----
MTP3_LINK_START
# LINK_TYPE : Link Type A ...F , Value 1,2 ...6
MTP3_LINK
OPC  DPC  SLC  MTP2_ID  LOG_DATA_LINK_ID  LINK_TYPE  ROUTE_PARAM_LOG_LINK_ID
129  130  0    0        1                1          1
MTP3_LINK_END
#-----
MTP3_LINK_SET_START
#Put the information in following order
# (1)OPC (2)DPC (3)Num_Links (4)Num_Normal_Links
# (5)Broadcast_Option (6)Linkset_Option
# (7){Log_Link_Id, Link_State, Link_Priority} for each link
# (8) Log_Link_Set_Id
# Priority : 1 to XX
# LinkState : Active = 0, Inactive = 1
# Status:  Delete  = 0, Add = 1
# BRDCAST_OPT:  enable: 0, disable: 1
MTP3_LINK_SET
opc dpc nlks nrml_lks bd_opt lset_opt lset_id lk_id lk_state lk_prio
129 130 1 1 0 0 1 1 0 0
MTP3_LINK_SET_END

```

```

#-----
MTP3_ROUTE_START
# ROUTE_TYPE Bitwise Usage:
#   Bit      Value      Definition
# Most Significant Bit 0/1 Destination is Route/CLUSTER Route
#   Ist Bit      1/2      Direct/Indirect Route
# DPC is a cluster if the route is a cluster route

MTP3_ROUTE
OPC  DPC  ROUTE_TYPE  LOG_LINKSET_ID  PRIORITY ROUTE_PARAM_LOG_ROUTE_ID
129 130   1           1               1         1
MTP3_ROUTE_END
#-----
# Overall MTP restart timer (ITU-T Q.704 T20)
# Started when first link of linkset is available.
# Time required to do the routing update.
# On expiry TRA message (traffic restart allowed) will be transmitted
# ITU-T Q.704 - Standard: 59-61 sec
# Implementation default: 59 sec
# If You require a different value, uncomment line and change value according
# MTP3_T20 59
#-----
#MTP3_PROVISIONING_END
#-----

#-----
#MTP2_PROVISIONING
#-----
# number of MTP2 signaling links
MTP2_NUM_LINKS 1
#-----
# Configuration of MTP2 links:
#
# MTP2_LOG_LINK_ID - MTP2 Link Id
# MTP2_ID          - MTP2 Id
# MTP2_CONTROLLER  - identifies the controller on which the link is set up
#                   (log-controller number)
# MTP2_TIMESLOT    - defines the timeslot of the link
# MTP2_MODE        - defines the MTP2 mode
#                   0 - normal mode
#                   1 - preventive mode
#-----
#MTP2_LOG_LINK_ID  MTP2_ID  MTP2_CONTROLLER  MTP2_TIMESLOT  MTP2_MODE
MTP2_LINK_CONFIG_START
1          0          1          16          0
MTP2_LINK_CONFIG_END
#-----
#MTP2_PROVISIONING_END
#-----

```

### Back to Back test

For the back-to-back test, you need two systems. Below you will find two divaSS7.cfg configuration files for a back-to-back test. It has 1 SS7 link and 30 CICs.

### First divaSS7.cfg file

```

#-----
# STACK_STANDARD_TYPE : Specifies the variant of the stack
# ITU= 1, ETSI=2
#-----
STACK_STANDARD_TYPE 1
#-----
# NETWORK_INDICATOR : Specifies the network indicator of ISUP and MTP3
# International 0 = 0, International 1 / SPARE = 1,
# National 0 = 2, National 1 (Reserved for national use) = 3
#-----
NETWORK_INDICATOR 2
#-----
# MTP3 and ISUP are communicating via (local) sockets with each other
# -> therefore the below paragraph is required

```

```

# MTP3_IP_ADDRESS          - IP of MTP3
# ISUP_IP_ADDRESS          - IP of ISUP
# MTP3_SERVER_PORT         - MTP3 server port to which the ISUP client is connecting
# ISUP_SERVER_PORT         - ISUP server port to which the MTP3 client is connecting
# MTP3_CLIENT_TO_ISUP_PORT - MTP3 client port which connects to the ISUP server
# ISUP_CLIENT_TO_MTP3_PORT - ISUP client port which connects to the MTP3 server
# all entries are required
#-----

MTP3_IP_ADDRESS          127.0.0.1
MTP3_SERVER_PORT        13000
MTP3_CLIENT_TO_ISUP_PORT 13100
ISUP_IP_ADDRESS         127.0.0.1
ISUP_SERVER_PORT        14000
ISUP_CLIENT_TO_MTP3_PORT 14100
#-----

# DEBUG MASKS
# set debug mask according to the definitions below
# debug information is written via standard log mechanism
# STATUS      0x00000001 - output STATUS (marked with 'S-')
# ERROR       0x00000002 - output ERRORS (marked with 'E-')
# WARN        0x00000004 - output WARNINGS (marked with 'W-')
# INFO        0x00000008 - output info (marked with 'I-')
# WRAPPER     0x00000010 - output details of the stack encapsulation (marked with 'A-')
# DETAIL      0x00000020 - output detail (creates a lot of output) (marked with 'V-')
# DATA       0x00000040 - output data (for data messages) (marked with 'D-')
# PERROR      0x00000080 - output pointer errors (marked with 'R-')
# NCCI_STM    0x00000100 - output Capi NCCI statemachine (marked with 'N-')
# PLCI_STM    0x00000200 - output Capi PLCI statemachine (marked with 'P-')
# CONT_STM    0x00000400 - output Capi Controller statemachine (marked with 'C-')
# MALLOC      0x00000800 - output memory allocation errors
#               (creates a lot of output, do not use if not requested)
#               (marked with 'M-')
# TIMER       0x00001000 - output timer handling
#               (creates a lot of output, do not use if not requested)
#               (marked with 'T-')
# in general a debug mask set to 0x00000007 should be sufficient
#-----

ISUP_CC_DEBUG_MASK      0x00000007 # set to STATUS|ERROR|WARN
MTP3_MTP2_DEBUG_MASK    0x00000007 # set to STATUS|ERROR|WARN
#-----

#-----
# Controller configuration
#-----
NUM_CONTROLLER 1
#LogControllerNum local law SerialN
#-----
CONTROLLER_CONFIG_START
1 local A 1300
CONTROLLER_CONFIG_END
#-----

#-----
#CC_PROVISIONING
#-----
# number of terminals configured/used
CC_NUM_TERMINALS 30
#-----
# length called party number
CC_LENGTH_CALLED_PARTY_NUMBER_START
0
CC_LENGTH_CALLED_PARTY_NUMBER_END
#-----
# initial state 0-PAUSE 1-ACTIVE
CC_INITIAL_STATE 0
#-----
#CIC OPC DPC LogContrNum Timeslot Blocked
CC_TERMINAL_CONFIG_START
1 129 130 1 1 0
2 129 130 1 2 0
3 129 130 1 3 0
4 129 130 1 4 0

```

```

5      129 130      1      5      0
6      129 130      1      6      0
7      129 130      1      7      0
8      129 130      1      8      0
9      129 130      1      9      0
10     129 130      1     10      0
11     129 130      1     11      0
12     129 130      1     12      0
13     129 130      1     13      0
14     129 130      1     14      0
15     129 130      1     15      0
17     129 130      1     17      0
18     129 130      1     18      0
19     129 130      1     19      0
20     129 130      1     20      0
21     129 130      1     21      0
22     129 130      1     22      0
23     129 130      1     23      0
24     129 130      1     24      0
25     129 130      1     25      0
26     129 130      1     26      0
27     129 130      1     27      0
28     129 130      1     28      0
29     129 130      1     29      0
30     129 130      1     30      0
31     129 130      1     31      0
CC_TERMINAL_CONFIG_END
#-----
#CC_PROVISIONING_END
#-----

#-----
#ISUP_PROVISIONING
#-----
ISUP_CIC_CONFIG_START
#   Status:  Delete  = 0, Add = 1
ISUP_CIC_CONFIG
      OPC      DPC      START_CIC      NUM_OF_CICS
      129      130      1      15
      129      130      17      15
ISUP_CIC_CONFIG_END
#-----
#ISUP_PROVISIONING_END
#-----

#-----
#MTP3_PROVISIONING
#-----
MTP3_SELF_POINT_CODE_START
# PC: Self Point Code
# Type: Primary PC = 81, SECONDARY = 82 CAPABILITY CODE =83
# Point code of MTP3
# PC Nodecap Status
MTP3_SELF_POINT_CODE
#OPC      SPC_TYPE
129      81
MTP3_SELF_POINT_CODE_END
#-----
MTP3_DEST_POINT_CODE_START
# Destination Type Bitwise Usage:
#   Bit      Value      Definition
# Most Significant Bit 0      Destination is DPC
#   1st Bit      1(0x01)      Adj DPC
#   2nd Bit      1(0x02)      Rem DPC
#   3rd Bit      0/1(0/0x04)      Brdcast_opt enable/disable
#   4th Bit      0/1(0/0x08)      dpc is mated_stp/non mated
# Status: Delete = 0, Add = 1
# DPC      Type      Sls      Status
#-----
MTP3_DEST_POINT_CODE
DPC      Type      sls
130      1      1
MTP3_DEST_POINT_CODE_END
#-----

```

```

MTP3_LINK_START
# LINK_TYPE : Link Type A ...F , Value 1,2 ...6
MTP3_LINK
OPC  DPC  SLC  MTP2_ID  LOG_DATA_LINK_ID  LINK_TYPE  ROUTE_PARAM_LOG_LINK_ID
129 130   0    0         1             1             1
MTP3_LINK_END
#-----
MTP3_LINK_SET_START
#Put the information in following order
# (1)OPC (2)DPC (3)Num_Links (4)Num_Normal_Links
# (5)Broadcast_Option (6)Linkset_Option
# (7){Log_Link_Id, Link_State, Link_Priority} for each link
# (8) Log_Link_Set_Id
#   Priority : 1 to XX
#   LinkState : Active = 0, Inactive = 1
#   Status:   Delete  = 0, Add = 1
#   BRDCAST_OPT: enable: 0, disable: 1
MTP3_LINK_SET
opc dpc nlks nrml_lks bd_opt lset_opt lset_id lk_id lk_state lk_prio
129 130 1 1 1 0 0 1 1 0 0
MTP3_LINK_SET_END
#-----
MTP3_ROUTE_START
# ROUTE_TYPE Bitwise Usage:
#   Bit          Value          Definition
# Most Significant Bit 0/1 Destination is Route/CLUSTER Route
# Ist Bit             1/2 Direct/Indirect Route
# DPC is a cluster if the route is a cluster route
MTP3_ROUTE
OPC  DPC  ROUTE_TYPE  LOG_LINKSET_ID  PRIORITY  ROUTE_PARAM_LOG_ROUTE_ID
129 130 1 1 1 1 1
MTP3_ROUTE_END
#-----
#MTP3_PROVISIONING_END
#-----
#-----
#MTP2_PROVISIONING
#-----
# number of MTP2 signaling links
MTP2_NUM_LINKS 1
#-----
# Configuration of MTP2 links:
#
# MTP2_LOG_LINK_ID - MTP2 Link Id
# MTP2_ID           - MTP2 Id
# MTP2_CONTROLLER   - identifies the controller on which the link is set up
#                   (log-controller number)
# MTP2_TIMESLOT     - defines the timeslot of the link
# MTP2_MODE         - defines the MTP2 mode
#                   0 - normal mode
#                   1 - preventive mode
#-----
#MTP2_LOG_LINK_ID  MTP2_ID  MTP2_CONTROLLER  MTP2_TIMESLOT  MTP2_MODE
MTP2_LINK_CONFIG_START
1 0 1 16 0
MTP2_LINK_CONFIG_END
#-----
#MTP2_PROVISIONING_END
#-----

```

**Second divaSS7.cfg file**

```

#-----
# STACK_STANDARD_TYPE : Specifies the variant of the stack
# ITU= 1, ETSI=2
#-----
STACK_STANDARD_TYPE          1
#-----
# NETWORK_INDICATOR : Specifies the network indicator of ISUP and MTP3
# International 0 = 0, International 1 / SPARE = 1,
# National 0 = 2, National 1 (Reserved for national use) = 3
#-----
NETWORK_INDICATOR            2
#-----
# MTP3 and ISUP are communicating via (local) sockets with each other
# -> therefore the below paragraph is required
# MTP3_IP_ADDRESS             - IP of MTP3
# ISUP_IP_ADDRESS             - IP of ISUP
# MTP3_SERVER_PORT            - MTP3 server port to which the ISUP client is connecting
# ISUP_SERVER_PORT            - ISUP server port to which the MTP3 client is connecting
# MTP3_CLIENT_TO_ISUP_PORT    - MTP3 client port which connects to the ISUP server
# ISUP_CLIENT_TO_MTP3_PORT    - ISUP client port which connects to the MTP3 server
# all entries are required
#-----
MTP3_IP_ADDRESS               127.0.0.1
MTP3_SERVER_PORT              13000
MTP3_CLIENT_TO_ISUP_PORT      13100
ISUP_IP_ADDRESS               127.0.0.1
ISUP_SERVER_PORT              14000
ISUP_CLIENT_TO_MTP3_PORT      14100
#-----
# DEBUG MASKS
# set debug mask according to the definitions below
# debug information is written via standard log mechanism
# STATUS      0x00000001 - output STATUS (marked with 'S-')
# ERROR       0x00000002 - output ERRORS (marked with 'E-')
# WARN        0x00000004 - output WARNINGS (marked with 'W-')
# INFO        0x00000008 - output info (marked with 'I-')
# WRAPPER     0x00000010 - output details of the stack encapsulation (marked with 'A-')
# DETAIL      0x00000020 - output detail (creates a lot of output) (marked with 'V-')
# DATA       0x00000040 - output data (for data messages) (marked with 'D-')
# PERROR      0x00000080 - output pointer errors (marked with 'R-')
# NCCI_STM    0x00000100 - output Capi NCCI statemachine (marked with 'N-')
# PLCI_STM    0x00000200 - output Capi PLCI statemachine (marked with 'P-')
# CONT_STM    0x00000400 - output Capi Controller statemachine (marked with 'C-')
# MALLOC      0x00000800 - output memory allocation errors
#                (creates a lot of output, do not use if not requested)
#                (marked with 'M-')
# TIMER       0x00001000 - output timer handling
#                (creates a lot of output, do not use if not requested)
#                (marked with 'T-')
# in general a debug mask set to 0x00000007 should be sufficient
#-----
ISUP_CC_DEBUG_MASK 0x000003FF # set to STATUS|ERROR|WARN|INFO
MTP3_MTP2_DEBUG_MASK 0x000003FF # set to STATUS|ERROR|WARN
#-----

#-----
# Controller configuration
#-----
NUM_CONTROLLER 1
#-----
#LogControllerNum local law SerialN
CONTROLLER_CONFIG_START
1 local A 1455
CONTROLLER_CONFIG_END
#-----

#-----
#CC_PROVISIONING
#-----
# number of terminals configured/used
CC_NUM_TERMINALS 30
#-----

```



```

# length called party number
CC_LENGTH_CALLED_PARTY_NUMBER_START
0
CC_LENGTH_CALLED_PARTY_NUMBER_END
#-----
# initial state 0-PAUSE 1-ACTIVE
CC_INITIAL_STATE 0
#-----

# Note: the order of the CIC definition is changed to avoid collisions
#CIC OPC DPC LogContrNum Timeslot Blocked
CC_TERMINAL_CONFIG_START
31 130 129 1 31 0
30 130 129 1 30 0
29 130 129 1 29 0
28 130 129 1 28 0
27 130 129 1 27 0
26 130 129 1 26 0
25 130 129 1 25 0
24 130 129 1 24 0
23 130 129 1 23 0
22 130 129 1 22 0
21 130 129 1 21 0
20 130 129 1 20 0
19 130 129 1 19 0
18 130 129 1 18 0
17 130 129 1 17 0
15 130 129 1 15 0
14 130 129 1 14 0
13 130 129 1 13 0
12 130 129 1 12 0
11 130 129 1 11 0
10 130 129 1 10 0
9 130 129 1 9 0
8 130 129 1 8 0
7 130 129 1 7 0
6 130 129 1 6 0
5 130 129 1 5 0
4 130 129 1 4 0
3 130 129 1 3 0
2 130 129 1 2 0
1 130 129 1 1 0
CC_TERMINAL_CONFIG_END
#-----
#CC_PROVISIONING_END
#-----

#-----
#ISUP_PROVISIONING
#-----
ISUP_CIC_CONFIG_START
# Status: Delete = 0, Add = 1
ISUP_CIC_CONFIG
      OPC      DPC      START_CIC      NUM_OF_CICS
      130      129      1      15
      130      129      17      15
ISUP_CIC_CONFIG_END
#-----
#ISUP_PROVISIONING_END
#-----

#-----
#MTP3_PROVISIONING
#-----
MTP3_SELF_POINT_CODE_START
# PC: Self Point Code
# Type: Primary PC = 81, SECONDARY = 82 CAPABILITY CODE =83
# Point code of MTP3
# PC Nodecap Status
MTP3_SELF_POINT_CODE
PC      SPC_TYPE
130      81
MTP3_SELF_POINT_CODE_END

```

```

#-----
MTP3_DEST_POINT_CODE_START
# Destination Type Bitwise Usage:
# Bit Value Definition
# Most Significant Bit 0 Destination is DPC
# 1st Bit 1(0x01) Adj DPC
# 2nd Bit 1(0x02) Rem DPC
# 3rd Bit 0/1(0/0x04)Brdcast_opt enable/disable
# 4th Bit 0/1(0/0x08)dpc is mated_stp/non mated

# Status: Delete = 0, Add = 1
# DPC Type sls Status
#-----
MTP3_DEST_POINT_CODE
DPC Type sls
129 1 1
MTP3_DEST_POINT_CODE_END
#-----

MTP3_LINK_START
# LINK_TYPE : Link Type A ...F , Value 1,2 ...6
MTP3_LINK
OPC DPC SLC MTP2_ID LOG_DATA_LINK_ID LINK_TYPE ROUTE_PARAM_LOG_LINK_ID
130 129 0 0 1 1 1
MTP3_LINK_END
#-----
MTP3_LINK_SET_START
#Put the information in following order
# (1)OPC (2)DPC (3)Num_Links (4)Num_Normal_Links
# (5)Broadcast_Option (6)Linkset_Option
# (7){Log_Link_Id, Link_State, Link_Priority} for each link
# (8) Log_Link_Set_Id
# Priority : 1 to XX
# LinkState : Active = 0, Inactive = 1
# Status: Delete = 0, Add = 1
# BRDCAST_OPT: enable: 0, disable: 1
MTP3_LINK_SET
opc dpc nlks nrml_lks bd_opt lset_opt lset_id lk_id lk_state lk_prio
130 129 1 1 0 0 1 1 0 0
MTP3_LINK_SET_END
#-----
MTP3_ROUTE_START
# ROUTE_TYPE Bitwise Usage:
# Bit Value Definition
# Most Significant Bit 0/1 Destination is Route/CLUSTER Route
# 1st Bit 1/2 Direct/Indirect Route
# DPC is a cluster if the route is a cluster route
MTP3_ROUTE
OPC DPC ROUTE_TYPE LOG_LINKSET_ID PRIORITY ROUTE_PARAM_LOG_ROUTE_ID
130 129 1 1 1 1
MTP3_ROUTE_END
#-----
#MTP3_PROVISIONING_END
#-----

#-----
#MTP2_PROVISIONING
#-----
# number of MTP2 signaling links
MTP2_NUM_LINKS 1
#-----
# Configuration of MTP2 links:
#
# MTP2_LOG_LINK_ID - MTP2 Link Id
# MTP2_ID - MTP2 Id
# MTP2_CONTROLLER - identifies the controller on which the link is set up
# (log-controller number)
# MTP2_TIMESLOT - defines the timeslot of the link
# MTP2_MODE - defines the MTP2 mode
# 0 - normal mode
# 1 - preventive mode
#-----
#MTP2_LOG_LINK_ID MTP2_ID MTP2_CONTROLLER MTP2_TIMESLOT MTP2_MODE

```

```

MTP2_LINK_CONFIG_START
1          0          1          16          0
MTP2_LINK_CONFIG_END
#-----
#MTP2_PROVISIONING_END
#-----

```

### Example: One SS7 link on one controller and 31 CICs on another controller

In this example, there are two 2MB trunks connected to the SS7 network. On the first trunk, one SS7 link is configured (controller 1) towards DPC=4119 and on the second trunk 31 CICs are configured (controller 2) towards DPC=3031:

```

#-----
# STACK_STANDARD_TYPE : Specifies the variant of the stack
# ITU= 1, ETSI=2
#-----
STACK_STANDARD_TYPE          1
#-----
# NETWORK_INDICATOR : Specifies the network indicator of ISUP and MTP3
# International 0 = 0, International 1 / SPARE = 1,
# National 0 = 2, National 1 (Reserved for national use) = 3
#-----
NETWORK_INDICATOR          2
#-----
# MTP3 and ISUP are communicating via (local) sockets with each other
# -> therefore the below paragraph is required
# MTP3_IP_ADDRESS             - IP of MTP3
# ISUP_IP_ADDRESS             - IP of ISUP
# MTP3_SERVER_PORT            - MTP3 server port to which the ISUP client is connecting
# ISUP_SERVER_PORT            - ISUP server port to which the MTP3 client is connecting
# MTP3_CLIENT_TO_ISUP_PORT    - MTP3 client port which connects to the ISUP server
# ISUP_CLIENT_TO_MTP3_PORT    - ISUP client port which connects to the MTP3 server
# all entries are required
#-----
MTP3_IP_ADDRESS              127.0.0.1
MTP3_SERVER_PORT             13000
MTP3_CLIENT_TO_ISUP_PORT     13100
ISUP_IP_ADDRESS              127.0.0.1
ISUP_SERVER_PORT             14000
ISUP_CLIENT_TO_MTP3_PORT     14100
#-----
# DEBUG MASKS
# set debug mask according to the definitions below
# debug information is written via standard log mechanism
# STATUS 0x00000001 - output STATUS (marked with 'S-')
# ERROR  0x00000002 - output ERRORS (marked with 'E-')
# WARN   0x00000004 - output WARNINGS (marked with 'W-')
# INFO   0x00000008 - output info (marked with 'I-')
# WRAPPER 0x00000010 - output details of the stack encapsulation (marked with 'A-')
# DETAIL  0x00000020 - output detail (creates a lot of output) (marked with 'V-')
# DATA   0x00000040 - output data (for data messages) (marked with 'D-')
# PERROR  0x00000080 - output pointer errors (marked with 'R-')
# NCCI_STM 0x00000100 - output Capi NCCI statemachine (marked with 'N-')
# PLCI_STM 0x00000200 - output Capi PLCI statemachine (marked with 'P-')
# CONT_STM 0x00000400 - output Capi Controller statemachine (marked with 'C-')
# MALLOC  0x00000800 - output memory allocation errors
#              (creates a lot of output, do not use if not requested)
#              (marked with 'M-')
# TIMER   0x00001000 - output timer handling
#              (creates a lot of output, do not use if not requested)
#              (marked with 'T-')
# in general a debug mask set to 0x00000007 should be sufficient
#-----
ISUP_CC_DEBUG_MASK 0x000003FF # set to STATUS|ERROR|WARN|INFO
MTP3_MTP2_DEBUG_MASK 0x000003FF # set to STATUS|ERROR|WARN
#-----
# Controller configuration
#-----
NUM_CONTROLLER 2
#-----
#LogControllerNum local law SerialN

```

```

CONTROLLER_CONFIG_START
1          local      A      1001
2          local      A      1084
CONTROLLER_CONFIG_END

#-----
#CC_PROVISIONING
#-----
CC_NUM_VIRTUAL_SIG_CONTROLLER 2
#LogControllerNum local law
CC_CONTROLLER_CONFIG_START
1          local      A
2          local      A
CC_CONTROLLER_CONFIG_END
#-----
CC_NUM_TERMINALS      31
#-----
CC_LENGTH_CALLED_PARTY_NUMBER_START
0
CC_LENGTH_CALLED_PARTY_NUMBER_END
#-----
# initial state 0-PAUSE 1-ACTIVE
CC_INITIAL_STATE 0
#-----
#CIC OPC DPC LogContrNum Timeslot   Blocked
CC_TERMINAL_CONFIG_START
1  7072 3031      2          1      0
2  7072 3031      2          2      0
3  7072 3031      2          3      0
4  7072 3031      2          4      0
5  7072 3031      2          5      0
6  7072 3031      2          6      0
7  7072 3031      2          7      0
8  7072 3031      2          8      0
9  7072 3031      2          9      0
10 7072 3031      2         10      0
11 7072 3031      2         11      0
12 7072 3031      2         12      0
13 7072 3031      2         13      0
14 7072 3031      2         14      0
15 7072 3031      2         15      0
16 7072 3031      2         16      0
17 7072 3031      2         17      0
18 7072 3031      2         18      0
19 7072 3031      2         19      0
20 7072 3031      2         20      0
21 7072 3031      2         21      0
22 7072 3031      2         22      0
23 7072 3031      2         23      0
24 7072 3031      2         24      0
25 7072 3031      2         25      0
26 7072 3031      2         26      0
27 7072 3031      2         27      0
28 7072 3031      2         28      0
29 7072 3031      2         29      0
30 7072 3031      2         30      0
31 7072 3031      2         31      0
CC_TERMINAL_CONFIG_END
#-----
#CC_PROVISIONING_END
#-----

#-----
#ISUP_PROVISIONING
#-----
ISUP_CIC_CONFIG_START
#   Status:  Delete  = 0, Add = 1
ISUP_CIC_CONFIG
OPC      DPC      START_CIC      NUM_OF_CICS
7072     3031      1             31
ISUP_CIC_CONFIG_END
#-----
#ISUP_PROVISIONING_END
#-----

```

```



#-----
#MTP3_PROVISIONING
#-----
MTP3_SELF_POINT_CODE_START
# PC: Self Point Code
# Type: Primary PC = 81, SECONDARY = 82 CAPABILITY CODE =83
# Point code of MTP3
# PC Nodecap Status
MTP3_SELF_POINT_CODE
PC      SPC_TYPE
7072    81
MTP3_SELF_POINT_CODE_END
#-----
MTP3_DEST_POINT_CODE_START
# Destination Type Bitwise Usage:
#      Bit      Value      Definition
# Most Significant Bit      0      Destination is DPC
# 1st Bit      1(0x01)      Adj DPC
# 2nd Bit      1(0x02)      Rem DPC
# 3rd Bit      0/1(0/0x04)Brdcst_opt enable/disable
# 4th Bit      0/1(0/0x08)dpc is mated_stp/non mated
# Status: Delete = 0, Add = 1
# DPC      Type      Sls      Status
#-----
MTP3_DEST_POINT_CODE
DPC      Type      sls
4119     1          1
3031     2          1
MTP3_DEST_POINT_CODE_END
#-----
MTP3_LINK_START
# LINK_TYPE : Link Type A ...F , Value 1,2 ...6
MTP3_LINK
OPC      DPC      SLC      MTP2_ID      LOG_DATA_LINK_ID      LINK_TYPE      ROUTE_PARAM_LOG_LINK_ID
7072     4119     0        0            1                    1                    1
MTP3_LINK_END
#-----
MTP3_LINK_SET_START
#Put the information in following order
# (1)OPC (2)DPC (3)Num_Links (4)Num_Normal_Links
# (5)Broadcast_Option (6)Linkset_Option
# (7){Log_Link_Id, Link_State, Link_Priority} for each link
# (8) Log_Link_Set_Id
# Priority : 1 to XX
# LinkState : Active = 0, Inactive = 1
# Status: Delete = 0, Add = 1
# BRDCAST_OPT: enable: 0, disable: 1
MTP3_LINK_SET
opc dpc nlks nrml_lks bd_opt lset_opt lset_id lk_id lk_state lk_prio
7072 4119 1 1 0 0 1 1 0 1
MTP3_LINK_SET_END
#-----
MTP3_ROUTE_START
# ROUTE_TYPE Bitwise Usage:
#      Bit      Value      Definition
# Most Significant Bit      0/1      Destination is Route/CLUSTER Route
# 1st Bit      1/2      Direct/Indirect Route
# DPC is a cluster if the route is a cluster route
MTP3_ROUTE
OPC      DPC      ROUTE_TYPE      LOG_LINKSET_ID      PRIORITY      ROUTE_PARAM_LOG_ROUTE_ID
7072     4119     1            1            1            1
7072     3031     2            1            2            2
MTP3_ROUTE_END
#-----
#MTP3_PROVISIONING_END
#-----




#-----
#MTP2_PROVISIONING
#-----
# number of MTP2 signaling links
MTP2_NUM_LINKS 1
#-----



```

```
# Configuration of MTP2 links:
#
# MTP2_LOG_LINK_ID - MTP2 Link Id
# MTP2_ID           - MTP2 Id
# MTP2_CONTROLLER   - identifies the controller on which the link is set up
#                   (log-controller number)
# MTP2_TIMESLOT     - defines the timeslot of the link
# MTP2_MODE         - defines the MTP2 mode
#                   0 - normal mode
#                   1 - preventive mode
#-----
#MTP2_LOG_LINK_ID   MTP2_ID       MTP2_CONTROLLER   MTP2_TIMESLOT   MTP2_MODE
MTP2_LINK_CONFIG_START
1                   0             1               1               0
MTP2_LINK_CONFIG_END
#-----
#MTP2_PROVISIONING_END
#-----
```



### Dialogic® Diva® Configuration Wizard settings for the Dialogic® Diva® softSS7 software




































```
Update CFGLib information ... succeeded
Load Diva MAINT debug/trace driver ... OK
Check Diva configuration ... succeeded, look for changes now

    Successfully updated configuration of Diva M-Adapter driver
Please RESTART Dialogic Diva PRI/E1/T1-CTI PCI v3 SN:1455 to activate new configuration
    Successfully updated configuration of Diva TTY driver
    Successfully updated configuration of Diva CAPI driver
```

**ISUP: list of messages**

| Type | Code | ISUP Message Type                        |
|------|------|------------------------------------------|
| ACM  | 06   | Address Complete                         |
| ANM  | 09   | Answer                                   |
| BLA  | 15   | Blocking Acknowledgement                 |
| BLO  | 13   | Blocking                                 |
| CCR  | 11   | Continuity Check Request                 |
| CFN  | 2F   | Confusion                                |
| CGB  | 18   | Circuit Group Blocking                   |
| CGBA | 1A   | Circuit Group Blocking Acknowledgement   |
| CGU  | 19   | Circuit Group Unblocking                 |
| CGUA | 1B   | Circuit Group Unblocking Acknowledgement |
| CMC  | 1D   | Call Modification Completed              |
| CMR  | 1C   | Call Modification Request                |
| CMRJ | 1E   | Call Modification Reject                 |
| CON  | 07   | Connect                                  |
| COT  | 05   | Continuity                               |
| CPG  | 2C   | Call Progress                            |
| CQM  | 2A   | Circuit Group Query                      |
| CQR  | 2B   | Circuit Group Query Response             |
| CRG  | 31   | Charge Information                       |
| DRS  | 27   | Delayed Information                      |
| FAA  | 21   | Facility Accepted                        |
| FAR  | 21   | Facility Request                         |
| FOT  | 08   | Forward Transfer                         |
| FRJ  | 1F   | Facility Reject                          |
| GRA  | 17   | Circuit Group Reset Acknowledgement      |
| GRS  | 29   | Circuit Group Reset                      |
| IAM  | 01   | Initial Address Message                  |
| INF  | 04   | Information                              |
| INR  | 03   | Information Request                      |
| LPA  | 24   | Loop Back Acknowledgement                |
| OLM  | 30   | Overload                                 |
| PAM  | 28   | Pass Along                               |
| REL  | 0C   | Release                                  |
| RES  | 0E   | Resume                                   |
| RLC  | 10   | Release Complete                         |
| RSC  | 12   | Reset Circuit                            |
| SAM  | 02   | Subsequent Address message               |
| SUS  | 0D   | Suspend                                  |
| UBA  | 16   | Unblocking Acknowledgement               |
| UBL  | 14   | Unblocking                               |
| UCIC | 2E   | Unequipped Circuit Identification Code   |
| USR  | 2D   | User to User Information                 |
|      | 0A   | Reserved                                 |
| Type | Code | ISUP Message Type                        |
|      | 0B   | Reserved                                 |
|      | 0F   | Reserved                                 |
|      | 22   | Reserved                                 |
|      | 23   | Reserved                                 |
|      | 25   | Reserved                                 |
|      | 26   | Reserved                                 |