

Dialogic[®] SS7 Software for Dialogic[®] Diva[®] Interfaces

Reference Guide

Copyright And Legal Notice

Copyright © 2008-2009 Dialogic Corporation. All Rights Reserved. You may not reproduce this document in whole or in part without permission in writing from Dialogic Corporation at the address provided below.

All contents of this document are furnished for informational use only and are subject to change without notice and do not represent a commitment on the part of Dialogic Corporation or its subsidiaries ("Dialogic"). Reasonable effort is made to ensure the accuracy of the information contained in the document. However, Dialogic does not warrant the accuracy of this information and cannot accept responsibility for errors, inaccuracies or omissions that may be contained in this document.

INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH DIALOGIC® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN A SIGNED AGREEMENT BETWEEN YOU AND DIALOGIC, DIALOGIC ASSUMES NO LIABILITY WHATSOEVER, AND DIALOGIC DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF DIALOGIC PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY INTELLECTUAL PROPERTY RIGHT OF A THIRD PARTY.

Dialogic products are not intended for use in medical, life saving, life sustaining, critical control or safety systems, or in nuclear facility applications.

Due to differing national regulations and approval requirements, certain Dialogic products may be suitable for use only in specific countries, and thus may not function properly in other countries. You are responsible for ensuring that your use of such products occurs only in the countries where such use is suitable. For information on specific products, contact Dialogic Corporation at the address indicated below or on the web at www.dialogic.com.

It is possible that the use or implementation of any one of the concepts, applications, or ideas described in this document, in marketing collateral produced by or on web pages maintained by Dialogic may infringe one or more patents or other intellectual property rights owned by third parties. Dialogic does not provide any intellectual property licenses with the sale of Dialogic products other than a license to use such product in accordance with intellectual property owned or validly licensed by Dialogic and no such licenses are provided except pursuant to a signed agreement with Dialogic. More detailed information about such intellectual property is available from Dialogic's legal department at 9800 Cavendish Blvd., 5th Floor, Montreal, Quebec, Canada H4M 2V9. **Dialogic encourages all users of its products to procure all necessary intellectual property licenses required to implement any concepts or applications and does not condone or encourage any intellectual property infringement and disclaims any responsibility related thereto. These intellectual property licenses may differ from country to country and it is the responsibility of those who develop the concepts or applications to be aware of and comply with different national license requirements.**

Dialogic, Dialogic Pro, Brooktrout, Diva, Cantata, SnowShore, Eicon, Eicon Networks, NMS Communications, NMS (stylized), Eiconcard, SIPcontrol, Diva ISDN, TruFax, Exnet, EXS, SwitchKit, N20, Making Innovation Thrive, Connecting to Growth, Video is the New Voice, Fusion, Vision, PacketMedia, NaturalAccess, NaturalCallControl, NaturalConference, NaturalFax and Shiva, among others as well as related logos, are either registered trademarks or trademarks of Dialogic Corporation or its subsidiaries. Dialogic's trademarks may be used publicly only with permission from Dialogic. Such permission may only be granted by Dialogic's legal department at 9800 Cavendish Blvd., 5th Floor, Montreal, Quebec, Canada H4M 2V9. Any authorized use of Dialogic's trademarks will be subject to full respect of the trademark guidelines published by Dialogic from time to time and any use of Dialogic's trademarks requires proper acknowledgement.

The names of actual companies and products mentioned herein are the trademarks of their respective owners.

This document discusses one or more open source products, systems and/or releases. Dialogic is not responsible for your decision to use open source in connection with Dialogic products (including without limitation those referred to herein), nor is Dialogic responsible for any present or future effects such usage might have, including without limitation effects on your products, your business, or your intellectual property rights.

Software License Agreement

This Software License Agreement ("Agreement") is a legal Agreement for the conditional use of the software provided herein ("Program") between you, the end-user, and Dialogic Corporation ("Dialogic"). By downloading, copying or otherwise using the Program, you agree to be bound by the terms of the foregoing license.

YOU ASSUME RESPONSIBILITY FOR THE SELECTION OF THE PROGRAM TO ACHIEVE YOUR INTENDED RESULTS, AND FOR THE INSTALLATION, USE, AND RESULTS OBTAINED FROM THE PROGRAM.

YOU SHOULD CAREFULLY READ THE SOFTWARE LICENSE AGREEMENT ("AGREEMENT") ON THIS SEALED PACKAGE BEFORE OPENING THE PACKAGE. BY OPENING THE PACKAGE, YOU ACCEPT THE TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT AGREE WITH OR ARE UNWILLING TO ACCEPT THESE

TERMS AND CONDITIONS, YOU MAY RETURN THE PACKAGE IN UNOPENED "AS NEW" CONDITION (INCLUDING ALL DOCUMENTATION AND BINDERS OR OTHER CONTAINERS) FOR A FULL REFUND. BY DOWNLOADING, INSTALLING, COPYING OR OTHERWISE USING THE ENCLOSED SOFTWARE ("PROGRAM"), YOU FURTHER AGREE AND ACKNOWLEDGE THAT YOU HAVE READ THIS AGREEMENT AND UNDERSTAND IT, AND THAT BY TAKING ANY ONE OR MORE OF SUCH STEPS/ACTIONS YOU AGREE TO BE BOUND BY SUCH TERMS AND CONDITIONS. DIALOGIC IS UNWILLING TO LICENSE THE SOFTWARE TO YOU IF YOU DO NOT ACCEPT AND AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF THIS AGREEMENT.

Intellectual Property

The enclosed Software ("Program") and all accompanying documentation are individually and collectively owned by Dialogic Corporation ("Dialogic"), its subsidiaries and/or its suppliers and are protected by all applicable intellectual property laws and international treaty provisions. Therefore, You and Your Authorized Users must treat the Program and documentation like any other material so protected, except as expressly permitted in this Agreement. In particular, but without limitation, You acknowledge that the Program and its accompanying documentation constitute valuable intellectual property rights, including without limitation trade secrets and copyrights, and confidential information of Dialogic. The Program and all programs developed thereunder and all copies thereof (including without limitation translations, compilations, partial copies with modifications and updated works) are proprietary to Dialogic and title to all applicable copyrights, trade secrets, patents and other intellectual property rights therein remains in Dialogic, its subsidiaries, and/or its suppliers. Except as expressly permitted in this Agreement, You shall not sell, transfer, publish, disclose, display or otherwise make available the Program or copies thereof to others. You agree to secure and protect the Program, its accompanying documentation and copies thereof in a manner consistent with the maintenance of Dialogic's rights therein and to take appropriate action by instruction or agreement with Your employees and/or consultants who are permitted access to the Program to satisfy Your obligations hereunder. Violation of any provision of this paragraph shall be the basis for immediate termination of this Agreement. Because unauthorized use or transfer of the Software or documentation may diminish substantially the value of such materials and irrevocably harm Dialogic, if You breach the provisions of this Section of this Agreement, Dialogic shall be entitled to injunctive and/or other equitable relief, in addition to other remedies afforded by law, to prevent a breach of this Section of this Agreement.

Grant of License

Subject to the terms and conditions of this Agreement Dialogic grants to You a non-exclusive, personal, non-transferable license to use the Program in object code form only and solely in accordance with the following terms and conditions:

- You may make, install and use only one (1) copy of the Program on a single-user computer, file server, or on a workstation of a local area network, and only in conjunction with a legally acquired Dialogic® hardware or software product You may also make one copy solely for backup or archive purposes;
- The primary Authorized User on the computer on which the Program is installed may make a second copy for his/her exclusive use on either a home or portable computer;
- You may copy the Program into any machine readable or printed form for backup or modification purposes in support of Your use of one copy of the Program;
- You may distribute the Program in object code only and only as part of, or integrated by You into, a computer system that (i) contains a Dialogic hardware product, (ii) includes a substantial amount of other software and/or hardware manufactured or marketed by You and (iii) is marketed and sublicensed to an end user for the end user's own internal use in the regular course of business (a "Licensed System");
- Each end user to whom a Licensed System is distributed must agree to license terms with respect to the Program that are at least as protective of Dialogic's rights in the Program as those set forth in this Agreement;
- You shall receive one (1) Program master disk, and shall be solely responsible for copying the Program into the Licensed Systems and for warranting the physical media on which it is copied
- You may make one (1) copy of the documentation accompanying the Program, provided that all copyright notices contained within the documentation are retained;
- You may modify the Program and/or merge it into another Program for Your use in one computer; (any portion of this Program will continue to be subject to the terms and conditions of this Agreement);

- You may transfer the Program, documentation and the license to another eligible party within Your Company if the other party agrees to accept the terms and conditions of this Agreement. If You transfer the Program and documentation, You must at the same time either transfer all copies whether in printed or machine readable form to the same party or destroy any copies not transferred; this includes all modifications and portions of the Program contained in or merged into other Programs;
- You shall not remove, and each copy of the Program shall contain, the same copyright, proprietary, patent and/or other applicable intellectual property or other ownership notices, plus any restricted rights legends that appear in the Program and/or this Agreement and, if You copy the Program onto media to which a label may be attached, You shall attach a label to the media that includes all such notices and legends that appear on the Program master disk and envelope;
- You may not rent or lease the Program. You may not reverse engineer, decompile or disassemble the Program. Except as is strictly necessary for You to integrate the Program with other software and/or hardware to produce the Licensed Systems, You shall not copy, modify or reproduce the Program or documentation in any way. You shall use Your best efforts to ensure that any user of the Program does not reverse engineer, decompile or disassemble the Program to derive a source code equivalent of the Program;
- If You transfer possession of any copy, modification or merged portion of the Program or documentation to another party in any way other than as expressly permitted in this Agreement, this license is immediately and automatically terminated;
- The Program may be used only in conjunction with Dialogic hardware;
- The Program shall not be exported or re-exported in violation of any export provisions of the United States or any other applicable jurisdiction.

Upgrades

If the Program is provided as an upgrade and the upgrade is an upgrade from another product licensed to You and Your Authorized Users by Dialogic, the upgrade is governed by the license agreement earlier provided with that software product package and the present Agreement does not grant You additional license(s). If You and Your Authorized Users choose to upgrade this Program or the product used together with the Program and such upgrade requires the license of additional software (whether a charge is associated with such software or not), the license agreement associated with such additional software shall govern the license of such additional software to the exclusion of this Agreement.

Term

The Agreement is effective until terminated. You may terminate it at any time by notifying Dialogic and/or by destroying the Program and all accompanying documentation together with all copies, modifications and merged portions in any form. The Agreement will also terminate automatically upon the occurrence or lack of occurrence of certain terms and/or conditions set forth in this Agreement, or if You fail to comply with any term or condition of this Agreement. You agree that upon any such termination You shall destroy or return to Dialogic the Program and all accompanying documentation supplied by Dialogic, together with any and all copies, modifications and merged portions in any form. All provisions of this Agreement relating to disclaimers of warranties, limitation of liability, remedies, or damages, and licensor's proprietary rights shall survive termination.

Limited Warranty

Dialogic solely warrants the media on which the Program is furnished to You to be free from defects in materials and workmanship under normal use for a period of ninety (90) days from the date of purchase by You as evidenced by a copy of Your receipt. If such a defect appears within the warranty period, You may return the defective media to Dialogic for replacement without charge provided Dialogic, in good faith, determines that it was defective in materials or workmanship. Replacement is Your sole remedy with respect to such a defect. Dialogic offers no warranty for Your reproduction of the Program. This Limited Warranty is void if failure of the Program has resulted from accident, misuse, abuse or misapplication.

Disclaimers, Limitations of Liability and Customer Remedies

Except as set forth in the "Limited Warranty" Section of this Agreement, the Program and accompanying documentation are provided to You "as is." Neither Dialogic, its subsidiaries, its suppliers, nor its licensor(s) (if any) warrants that the Program will meet Your requirements or that its use will be uninterrupted or error-free. Except as set forth in the "Limited Warranty" Section, EACH OF DIALOGIC, ITS SUBSIDIARIES, ITS SUPPLIERS AND ITS LICENSOR(S) (IF ANY) DISCLAIMS ANY AND ALL REPRESENTATIONS AND WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THE PROGRAM AND ACCOMPANYING DOCUMENTATION, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR AGAINST LATENT DEFECTS. Except as set forth in the "Limited Warranty" Section, neither Dialogic, its subsidiaries, its suppliers, nor its licensor(s) (if any) shall have any liability to You or any third party for any claim, loss or damage of any kind, including but not limited to lost business profits, business interruption, loss of information, or other pecuniary loss and indirect, punitive, incidental, economic, consequential or special damages, arising out of or in connection with this Agreement and/or the use, inability to use the Program and/or the Program's performance or inability to perform nor from or in connection with the Program's accompanying documentation, or any data or equipment related thereto or used in connection therewith. In no event shall Dialogic's, its subsidiaries', its suppliers' or its licensor(s)'s liability for damages, whether arising out of contract, negligence, warranty, or patent or copyright infringement, exceed the fees You paid for the Program. No representation or warranty regarding the Program may be made without Dialogic's, its

subsidiaries', its suppliers', or its licensor(s)'s (if any) prior written consent, and any warranty or representation made by You or Your customers regarding the Program shall not constitute an obligation of Dialogic, its subsidiaries, its suppliers, or other licensor(s) (if any). This limited warranty gives You specific legal rights. You may have other rights, which may vary from jurisdiction to jurisdiction. Also, as some jurisdictions do not allow the exclusion or limitation for certain damages, some of the above limitations may not apply to You.

Right to Audit

If this Program is licensed for use in a Company, Your Company and You individually and collectively agree to keep all usual and proper records and books of accounts and all usual proper entries relating to each installation of the Program during the term of this Agreement and for a period of three (3) years thereafter. During this period, Dialogic may cause an audit to be made of the applicable records in order to verify Your compliance with this Agreement and prompt adjustment shall be made to compensate for any errors or omissions disclosed by such audit. Any such audit shall be conducted by an independent certified public accountant selected by Dialogic and shall be conducted during the regular business hours at Your offices and in such a manner as not to interfere with Your normal business activities. Any such audit shall be paid for by Dialogic unless material discrepancies are disclosed. For such purposes, "material discrepancies" shall mean three percent (3%) or more of the Authorized Users within the Company. If material discrepancies are disclosed,

Your Company agrees to pay Dialogic for the costs associated with the audit as well as the license fees for the additional licensed channels or additional authorized users. In no event shall audits be made more frequently than semi-annually unless the immediately preceding audit disclosed a material discrepancy.

Supplementary Software

Any Supplementary Software provided with the Program and/or referred to in this Agreement is provided "as is" with no warranty of any kind.

Miscellaneous

You acknowledge that You have read this Agreement, that You understand it, and that You agree to be bound by its terms and conditions, and You further agree that this is the complete and exclusive statement of the Agreement between the Dialogic and You ("the Parties"), which supersedes and merges all prior proposals, understandings and all other agreements, oral and written, between the Parties relating to the Program. You agree to indemnify and hold harmless Dialogic and its subsidiaries, affiliates, suppliers, officers, directors and employees from and against any claim, injury, loss or expense, including reasonable attorneys' fees, arising out of (i) Your failure to comply with the provisions of this Agreement, or (ii) any other wrongful conduct by or on behalf of You. This Agreement applies to all updates, future releases, modifications and portions of the Program contained in or merged into other programs. This Agreement may not be modified or altered except by written instrument duly executed by Dialogic. No action, regardless of form, arising out of this Agreement or the use of the Program may be brought by You more than two (2) years after the cause of action has first arisen. Except as provided herein, neither this Agreement nor any rights granted are assignable or transferable, and any assignment or transfer will be null and void. If You authorize any other person to copy the Program, You shall obligate that person in writing to comply with all conditions of this Agreement. Dialogic shall have the right to collect from You its reasonable expenses incurred in enforcing this agreement, including attorney's fees. The waiver or failure of Dialogic to exercise in any respect any right provided for herein shall not be deemed a waiver of any further right hereunder. All rights and remedies, whether conferred hereunder or by any other instrument or law, will be cumulative and may be exercised singularly or concurrently. Failure by either Dialogic or You to enforce any term or condition of the Agreement will not be deemed a waiver of future enforcement of that or any other term or conditions. The terms and conditions stated herein are declared to be severable. Should any term(s) or condition(s) of this Agreement be held to be invalid or unenforceable the validity, construction and enforceability of the remaining terms and conditions of this Agreement shall not be affected. It is expressly agreed that Dialogic and You are acting as independent contractors under this Agreement. These terms and conditions will prevail notwithstanding any different, conflicting or additional terms and conditions that may appear on any other agreement between Dialogic and You. Deviations from these terms and conditions are not valid unless agreed to in writing in advance by an authorized representative of Dialogic. Any notices sent to Dialogic under this Agreement must be sent by registered mail or courier to the attention of Dialogic's legal department at the address below or such other address as may be listed on www.dialogic.com from time to time as being Dialogic's Montreal headquarters.

U.S. Government Restricted Rights

The Program and all accompanying documentation are provided with RESTRICTED RIGHTS. Use, duplication or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(iii) of The Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 or subparagraph (c) (1) and (2) of the Commercial Computer Software-Restricted Rights at 48 CFR52.227-19, both as applicable.

Governing Law

Any and all claims arising under this Agreement shall be construed and controlled by the laws in force in the Province of Quebec, Canada, excluding its principles of conflict of laws and the United Nations Convention on Contracts for the Sale of Goods. Dialogic is not obligated under any other agreements unless they are in writing and signed by an authorized representative of Dialogic.

Contractor/ manufacturer is:

Dialogic CORPORATION.

9800 Cavendish Blvd., Montreal, Quebec, Canada H4M 2V9

This Agreement has been drafted in English at the express wish of the parties. Ce contrat a été rédigé en anglais à la demande expresse des parties.

Contents

Copyright And Legal Notice	2
Software License Agreement	3
About This Publication	9
How to use this online guide	9
Structure of this guide	9
1 About The Dialogic® SS7 Software for Dialogic® Diva® Interfaces	10
1.1 Dialogic® SS7 Software for Dialogic® Diva® Interfaces	10
1.2 Supported hardware	11
2 Preparing The Dialogic® Diva® Media Boards	12
3 Installing The Dialogic® SS7 Software for Dialogic® Diva® Interfaces.	13
4 Dialogic® Diva® System Release Software Configuration	16
4.1 License activation	16
4.2 Regulatory and Geographic Considerations	17
4.3 Configuration in the Dialogic® Diva® Configuration web interface	17
4.4 Configuration with the Dialogic® Diva® Configuration Wizard	24
4.5 Test the Dialogic® Diva® Media Board	29
5 Dialogic® SS7 Software Configuration	30
5.1 Dialogic® SS7 Software system configuration	30
5.2 Dialogic® SS7 protocol configuration	34
6 Starting The Dialogic® SS7 Software for Dialogic® Diva® Interfaces ...	46
7 Tracing	47
7.1 Verify if Dialogic® SS7 Software for Dialogic® Diva® Interfaces software is running	47
7.2 Tracing with the Dialogic® Diva® Configuration web interface	49
7.3 Dynamic tracing	50
8 Uninstalling	52
9 Troubleshooting	53
10 Management Interface of the SSDD Process	54
10.1 Config Directory	55
10.2 State Directory	58
10.3 Statistics Directory	60
10.4 License Directory	64
10.5 Debug Directory	65

11 Management Interface of the DVSCC Process	66
11.1 Config directory	67
11.2 State directory	71
11.3 Statistics directory	78
11.4 Debug Directory	84
12 Examples of the Default Configuration Files.....	85
Glossary	88

About This Publication

How to use this online guide

- To view a section, click the corresponding bookmark located on the left.
- To view a topic that contains further information, click the corresponding blue underlined phrase.
- You may wish to print out the pages required for installing the drivers.

Structure of this guide

This guide provides a detailed description of how to install and configure the Dialogic® SS7 Software for Dialogic® Diva® Interfaces.

This guide is structured as follows:

Section	Contents
About The Dialogic® SS7 Software for Dialogic® Diva® Interfaces	The SS7 Software for Diva Interfaces features and supported Dialogic® Diva® Media Boards.
Preparing The Dialogic® Diva® Media Boards	Preparations before using the SS7 Software for Diva Interfaces.
Installing The Dialogic® SS7 Software for Dialogic® Diva® Interfaces	Installation of the SS7 Software for Diva Interfaces.
Dialogic® Diva® System Release Software Configuration	Modifications in the Dialogic® Diva® Configuration Wizard, activation and installation of the license file.
Starting The Dialogic® SS7 Software for Dialogic® Diva® Interfaces	Start and verification of the SS7 Software for Diva Interfaces.
Tracing	Creation of traces with the Diva Configuration Wizard.
Uninstalling	Uninstallation of the SS7 Software for Diva Interfaces.
Troubleshooting	How to solve problems with the SS7 Software for Diva Interfaces.
Management Interface of the SSDD Process	Parameters of the ssdd management interface.
Management Interface of the DVSCC Process	Parameters of the Diva Virtual Signaling Call Control management interface.
Glossary	Common terms in the SS7 environment.
Examples of the Default Configuration Files	Examples and explanation of the default SS7 for Diva Interfaces configuration file.

Chapter 1: About The Dialogic® SS7 Software for Dialogic® Diva® Interfaces

The SS7 Software for Diva Interfaces is an add-on for the Dialogic® Diva® System Release software. It enables you to have connectivity over the SS7 signaling network and still be able to use applications with standard programming interfaces like CAPI and the Dialogic® Diva® SDK.

This reference guide describes the basic Linux configuration for the SS7 Software for Diva Interfaces. It is intended to provide advice and instructions on how to install the SS7 for Diva Interfaces modules as add-on software for the Diva System Release software.

1.1 Dialogic® SS7 Software for Dialogic® Diva® Interfaces

- Basic inbound and outbound calls
- Support for SS7 MTP/ISUP protocols
- SS7 Signaling End Point (SEP) functionality
- Connection to other SEP or Signaling Transfer Point (STP)
- Associated signaling mode (SS7 link and bearer channels on same trunk)
- Quasi-associated signaling mode via STP (one or more SS7 link(s) on one or more trunk(s), bearer channels on different trunks)
- User-defined trunk number(s) and 64 kbps timeslot(s) for signaling link(s)
- Up to 16 E1 trunks per installation
- Up to 496 bearer channels per installation
- Up to 4 signaling links and up to 4 linksets
- Support of B-channel types (speech, 3.1 kHz audio, 64 kbps transparent, Data, 3G Video GW)
- Configuration for MTP 2 and 3, ISUP and call control parameters per text file
- Blocking/unblocking according to ITU-T ISUP
- User mode management interface for SSDD and DVSCC
- Dialogic® Diva® DSI management for MTP3 and ISUP
- Enable dynamic change of:
 - blocking states
 - debug mask
 - via user mode management interface
- Representation of layer 1 state on ISUP via blocking, e.g., if Layer 1 goes down on a trunk, the related interface is blocked
- Event disabling signaling is represented on ISUP via blocking, e.g., if the signaling connection between the trunk card and the SS7 system service is down, the related interface is blocked
- Representation of blocking state on specific channels via the Dialogic® Diva® Management software.

1.2 Supported hardware

The Dialogic® Diva® Media Board product family includes PCI and PCI Express (PCIe) form factor boards described in the Dialogic® Diva® Media Board Installation Guide, which is available for download at: www.dialogic.com/manuals.

The Dialogic® SS7 Software for Dialogic® Diva® Interfaces software supports the following Diva Media Boards:

Diva PRI:

- Diva PRI/E1/T1-CTI PCI
- Diva PRI/E1/T1-8 PCI and PCIe
- Diva PRI/T1-24 PCI and PCIe
- Diva PRI/E1-30 PCI and PCIe

Diva V-PRI:

- Diva V-PRI/T1-24 PCI and PCIe
- Diva V-PRI/E1-30 PCI and PCIe

Diva UM-PRI:

- Diva UM-PRI/T1-24 PCI and PCIe
- Diva UM-PRI/E1-30 PCI and PCIe

Diva Multiport PRI:

- Diva V-2PRI/T1-48 PCI
- Diva V-2PRI/E1-60 PCI
- Diva V-4PRI/T1-96 PCI
- Diva V-4PRI/E1-120 PCI
- Diva V-1PRI/E1/T1-30 PCIe HS
- Diva V-2PRI/E1/T1-60 PCIe HS
- Diva V-4PRI/E1/T1-120 PCIe HS
- Diva V-4PRI/E1/T1-120 PCIe FS
- Diva V-8PRI/E1/T1-240 PCIe FS

Note: "HS" stands for the half size and "FS" for the full size board format.

Chapter 2: Preparing The Dialogic® Diva® Media Boards

The Dialogic® SS7 Software for Diva® Interfaces software is included in the Dialogic® Diva® System Release software. You can download the files for installing the software from the Dialogic web site at:

http://www.dialogic.com/products/tdm_boards/system_release_software/Diva_for_Linux.htm

The online Dialogic® Diva® System Release LIN Reference Guide provides help for the installation of the software. You can download it from the Dialogic web site at:

<http://www.dialogic.com/manuals.htm>

The drivers of the SS7 Software for Diva Interfaces are installed together with the Diva System Release.

Chapter 3: Installing The Dialogic® SS7 Software for Dialogic® Diva® Interfaces

The SS7 Software for Diva Interfaces drivers are provided together with the Dialogic® Diva® System Release software. If you upgrade from an former SS7 Software for Diva Interfaces version and have not changed the folder structure, the configuration of the previous version is used.


Notes:

- If you want to replace an existing Dialogic® Diva® softSS7 software installation with the SS7 software for Diva Interfaces, the existing Diva softSS7 software installation will not be removed.
- If you have the Diva softSS7 software previously installed and you want to install the SS7 Software for Diva Interfaces, you need to manually rename the directory 'usr/lib/opendiva/divas.ss7'.

To install the Diva System Release software, do the following:

1. Login to the Linux system with root permissions.
2. Download the Diva System Release software from: http://www.dialogic.com/products/tdm_boards/system_release_software/Diva_for_Linux.htm and store it on your hard disk, e.g., under /tmp/.
3. Change to the directory in which the installer-.bin file is located, e.g., `cd /tmp`.
4. Start the installation: `./Diva4Linux_installer-<build number>.bin`

During the installation, you will be asked to accept the End-User License Agreement and to confirm the installation.



```
root@frog# ./Diva4Linux_installer_9.0-108-15.bin
-----
Installing Diva Service Release 9.0 LIN
Build 108-15

incl.
- softIP 2.2
- SIPcontrol 2.0
- DSI SS7
-----

1) Extracting archive to /tmp/divas ...
   OK

2) Unpacking archive ...
   OK

3) Checking License ...
   License Agreement accepted.

4) determining system type ...
   rpm found

5) searching previous versions
   no previous versions found. Proceeding with installation.

6) installing Diva for Linux
   success.

7) installing Diva softIP 2.2
   success.

8) installing Diva SIPcontrol
   success.


9) installing Dialogic DSI SS7 for Diva Media Boards for Linux ...
   success.

10) installing additional components

11) cleaning up ...
```

5. After the installation is complete, press the **Return** button to finish the installation.

6. Follow the instructions shown in the graphic below:



- Start the Dialogic® Diva® Build Wizard to build and install the drivers for Diva Media Boards:
`cd /usr/lib/opensdiva/divas/src; ./Build`
- To configure the Diva Media Boards, either
 - start the Dialogic® Diva® Configuration Wizard to detect and configure the installed Diva Media Boards: `/usr/lib/opensdiva/divas/Config`
or
 - start the Dialogic® Diva® web Configuration Server at port 10005. To enable the web interface access, change the password in the following file: `/usr/lib/opensdiva/divas/httpd/login/login`.

Use an editor of your choice, delete the first line "XX" characters and replace them with your password. The password needs to be at least 7 digits long.

The table below shows the files that are copied into the installation directory `/usr/lib/opensdiva/dlgss7` for the SS7 Software for Diva Interfaces.

File	Purpose
ssdd	Dialogic® SS7 Software for Dialogic® Diva® Interfaces board management and interface process for Diva Media Boards (Signalling Service Device Driver).
mtp_lnx6	SS7 for Diva Interfaces MTP3 is the layer 3 (network layer) of an SS7 stack.
isp_lnx6	SS7 for Diva Interfaces ISUP is the ISDN User Part of SS7 it abstracts ISDN signaling and adds additional functionality to it.
dvscc	Diva Virtual Signaling Call ControlSS7, it translates ISUP primitives into Diva signaling primitives forwarded to and received from the virtual signaling protocol running on the Diva Media Board. Component of SS7 for Diva Interfaces for Linux.
gctlib.lib	Library to be linked with user's application.
system.txt	Example system configuration file
config.txt	Example protocol configuration file
versions.txt	Hold version information of components

File	Purpose
gctload	Task that initializes the Dialogic® DSI SS7 host system environment and starts up all other processes (such as ssdd and dvsc), deriving the process and message queue configuration from the system.txt file.
tick_lnx tim_lnx s7_mgt s7_log s7_play actlinks mtpsl	Executables for use as described in the Dialogic® DSI SS7 Software for Dialogic® Diva® Media Boards Programmer's Manual (Linux version).

To enable the dynamic linking of gctlib.lib (libgctlib.so), the following symbolic links are created by the installation:

```
/usr/lib/libgctlib.so -> /usr/lib/opensdiva/dlgss7/libgctlib.so.1.0.0
```

```
/usr/lib/libgctlib.so.1 -> /usr/lib/opensdiva/dlgss7/libgctlib.so.1.0.0
```

```
/usr/lib/libgctlib.so.1.0.0 -> /usr/lib/opensdiva/dlgss7/libgctlib.so.1.0.0
```

After you installed the software, continue with the [Dialogic® Diva® System Release Software Configuration](#) on page 16.

Chapter 4: Dialogic® Diva® System Release Software Configuration

After you have installed the Dialogic® Diva® System Release software as described in [Installing The Dialogic® SS7 Software for Dialogic® Diva® Interfaces](#) on page 13, configure the SS7-related Dialogic® Diva® Media Board parameters. You can either use:

- the Dialogic® Diva® Configuration web interface as described on page 17, or
- the Dialogic® Diva® Configuration Wizard as described page 24.

Before you start to configure the Diva Media Board parameters, activate the license file as described below.

4.1 License activation

Depending on the signaling requirements, you will need the following host licenses in conjunction with the Dialogic® DSI SS7 Software for Dialogic® Diva® Media Boards software.

Product Name	Protocol
	MTP2 Protocol Layer host license
SS7SBMTP2D1	1 link
SS7SBMTP2D2	2 links
SS7SBMTP2D4	4 links
SS7SBHSTMTP3	MTP3 Protocol Layer host license
SS7SBHSTISUP	ISUP Protocol Layer host license

Note: As specified above, MTP2 host licensed are available for 1, 2, or 4 links. One license file per protocol (e.g., MTP2) is supported.

These licenses are bound to a specific host, identified by a host ID. The host ID can be queried by calling:

```
cd /usr/lib/opensdiva/dlgss7
./ssdd -v
```

In the install directory of DSI SS7 for Diva Media Boards software, the host ID will be displayed as follows:

```
The Licensing Host ID for this machine is: 0123456789ab.
```

Note, that there are different classes of licenses depending on the performance requirements which need to be satisfied. For further information on the Dialogic® SS7 Software for Dialogic® Diva® Interfaces host licensing, refer to Dialogic® DSI Protocol Stacks - Host Protocol Licensing User Guide - U32SSS.

Following the instruction in the Dialogic® DSI Protocol Stacks - Host Protocol Licensing User Guide - U32SS you will receive one or more license files via e-mail. Please copy the attached .lic files to a directory on the host, e.g., /usr/lib/opensdiva/dlgss7/ (default license path). Copying the license files to this directory will include them automatically into the SS7 environment. In case you want to store the license in another directory, you need to extend your system.txt file with the correct license path (-Lp option) for the `ssdd`, `mtp_lnx6`, and `isp_lnx6` commands as described in [Command Description](#) on page 32.

For test purposes there is a possibility to run SS7 for Diva without a valid license key. For more information, see [Testmode](#) on page 31.

4.2 Regulatory and Geographic Considerations

Certain functions of Dialogic® Diva® Media Boards, although implemented in the hardware, have selectable options that are configured by the Dialogic® Diva® System Release LIN software. A user or integrator needs to consider the requirements of the application when choosing these settings, but must also consider any local regulatory requirements for the intended deployment location to ensure a compliant overall system. As an aid to this process, the table below details some of the areas where the correct selection of configuration options may be required.

Configuration Area		Dialogic® Diva® Media Board
T1/E1 Ports	Interface type	<ul style="list-style-type: none"> Selected via D-channel protocol E1/T1¹⁾ (120 Ω balanced) 75 Ω unbalanced requires an external unbalanced to balanced transformer
	Puls shape	Selected via D-channel protocol E1/T1
	Line code	Selected via D-channel protocol: <ul style="list-style-type: none"> E1:HDB3 T1:B8ZS
	Frame format	Selected via layer 1 framing <ul style="list-style-type: none"> E1:multiframe (default) or double framing, no CRC T1:ESF
	CRC/E-bit operation	Selected via layer 1 framing <ul style="list-style-type: none"> E1:CRC4 T1:CRC6

¹⁾ T1 includes J1

4.3 Configuration in the Dialogic® Diva® Configuration web interface

You can configure the necessary settings in the Diva Configuration web interface. To access the configuration via the web interface, you need to set an administration password as described on page 14. You can open the web interface either from the computer on which the Dialogic® SS7 Software for Dialogic® Diva® Interfaces software is installed or from a remote computer.

To open the web interface from the local computer, enter: `http://localhost:10005`.

To access the web interface from a remote computer, enter: `http://<IP-address>:10005`.

After you entered the URL, the login page appears, where you need to type the administration password.




Please login to the Dialogic® Diva® Configuration

Password:

Enter >>

If the server is not able to resolve the URL, make sure the inet services are started on the computer on which the Dialogic® Diva® System Release LIN software is installed, as shown in the graphic below.



After successful login, the main configuration page opens.



For the SS7 Software for Diva Interfaces, you need to configure the settings under:

- [System configuration](#),
- [Board configuration](#), and
- [DSI SS7 configuration](#).

4.3.1 System configuration

Click **System configuration** on the left hand side. The following page appears:

Note: If you have the Dialogic® Diva® softSS7 software installed, the option **DSI SS7 for Diva** is replaced by **softSS7**.

The screenshot shows the 'System Configuration' web interface. The left sidebar contains navigation links for Configuration, System, Status, Debugging, and Licensing. The main content area is divided into two sections: 'System Settings' and 'Startup Options'.

System Settings

Parameter	Value
	<input checked="" type="checkbox"/> TTY interface
	<input type="checkbox"/> PIAFS support for TTY
	<input type="checkbox"/> fax/voice support for TTY
Applications/Interfaces:	<input checked="" type="checkbox"/> DIVA API / CAPI 2.0 interface
	<input type="checkbox"/> SIP-PSTN gateway (SIPcontrol 2.0)
	<input type="checkbox"/> SIP enabled CAPI (softIP 2.2)
	<input checked="" type="checkbox"/> DSI SS7 for Diva
	(Mode: <input type="radio"/> SS7 Diva Interfaces <input checked="" type="radio"/> DSI SS7 Interfaces)
	<input type="checkbox"/> Dialogic HMP GC/R4/MM mode
FAX CLASS 2 options:	Enable ECM, Compression and V.34 (33600) ▼
FAX CLASS 2 V.34 options:	off ▼
FAX CLASS 2 resolutions:	Normal/Fine ▼
Extended FAX CLASS 2 options:	off ▼
PIAFS link RTP:	15 frames [default] ▼
CAPI Call distribution:	Group Optimization ▼
Call Rate Limit	off [default] ▼

Startup Options

Parameter	Value
Verify serial number:	Yes ▼
Debug mode for microcode load:	No ▼
Forced (insmod -f) driver load:	No ▼
Write call history to /var/log/divalog:	Yes ▼
Activate Diva SNMP support:	No ▼
Start driver on system boot:	Yes ▼
Automatic reboot after system error:	No ▼
Load MAINT debug/trace driver:	No ▼

At the bottom of the 'Startup Options' section, there are 'Save' and 'Cancel' buttons.

The system configuration consists of two sections:

- **System Settings:** For Dialogic® DSI SS7 Software for Dialogic® Diva® Media Boards settings. Enable the **DivA API / CAPI 2.0 interface** and the **DSI SS7 for Diva** option with the **DSI SS7 Interfaces** mode.
- **Startup Options:** To set up the necessary settings for the system behavior on startup. The following parameters are set to **Yes** by default: **Verify serial number**, **Start driver on system boot**, and **Load Maint/debug driver on system start**.

4.3.2 Board configuration

1. Click **Board configuration** on the left hand side. The following page opens:

Click the Dialogic® Diva® Media Board icon of the board you want to configure.

2. A page displaying the Diva Media Board parameters opens:


Parameter	Value
D-Channel Protocol:	SS7_E1 - DSI SS7 for Diva E1
Interface mode/Resource board:	TE - mode
Direct Inward Dialing (DID):	No Configure Call Routing
Layer 1 Framing:	Doubleframing (no CRC4)
TX Attenuation:	0 dBm (default)
Voice Companding:	Force A-Law
View Extended Configuration	No

Configure the parameters according to your system configuration. For the Dialogic® SS7 Software for Dialogic® Diva® Interfaces software, you may choose between the values shown in the table below.

Parameter	Value
D-Channel Protocol	<ul style="list-style-type: none"> • SS7_E1 - DSI SS7 for E1 lines • SS7_T1 - DSI SS7 for T1 lines
Interface mode resource	<ul style="list-style-type: none"> • TE - mode • NT - mode
Direct Inward Dialing	Enable: <ul style="list-style-type: none"> • Yes • No
TX Attenuation	<ul style="list-style-type: none"> • 0 dbm (default) • -7.5 dbm • -15 dbm
Voice Companding	<ul style="list-style-type: none"> • Force A-Law • Force μ-Law

3. After you have made the changes, click **Save** to write the changes to the Diva Media Board configuration file.
usr/lib/opensdiva/divas/divas_cfg.rc

- 4. Restart your Diva Media Board for the changes to take effect. To do so, click **System control (driver start/stop)** on the left hand side and under **Driver status** click **Stop** and then **Start**.




4.3.3 DSI SS7 configuration

1. Click **DSI SS7 configuration** on the left hand side of the main configuration page. The following page opens:

The screenshot displays the 'SS7 Configuration' web interface. The top navigation bar includes 'HOME' and 'SS7 Configuration'. A left sidebar menu lists various configuration categories: Configuration (Board, Clock, System, SIPcontrol, DSI SS7, Call Routing), System (System control, System environment, System messages), Status (Board monitor, View call history, View statistics, View report), Debugging (Support/Troubleshooting, Trace/Debug, View trace file, View recovered trace buffer, View board recovered trace buffer), and Licensing (License management). The main content area, titled 'View/edit SS7 config file', shows two text editors. The top editor, 'config.txt', contains example configuration for DSI SS7, including board types like 'Diva Server PRI v.3 PCI (ADSP based)' and 'Diva Server 2/4PRI Cards (BF based)'. The bottom editor, 'system.txt', shows example system configuration with essential modules like 'MTP3 module', 'ISUP module', and 'ssdd - Board interface task'.

2. Change the configuration files according to your network setup as described under [Dialogic® SS7 Software Configuration](#) on page 30.
3. To save your settings, press the **change config** button.


- Restart your Diva Media Board for the changes to take effect. To do so, click **System control (driver start/stop)** on the left hand side and under **Driver status** click **Stop** and then **Start**.




4.4 Configuration with the Dialogic® Diva® Configuration Wizard

1. To start the Diva Configuration Wizard, execute the following command:

```
/usr/lib/opendiva/divas/Config
```



- To navigate in the wizard, use <up> and <down> keys.
 - To select a choice, use <space>.
2. Select **CAPI 2.0 interface** and **DSI SS7 for Diva**.



3. Install the License via the License Manager as described in [License activation](#) on page 16.
4. Select the board you want to configure and click **<OK>**.



5. Some information about the selected Diva Media Board is displayed.

```
Board 1 - Dialogic Diva PRI/E1/T1-8 PCI v3 SN:1300
Name       : Dialogic Diva PRI/E1/T1-8 PCI v3
DSP state  : 00000000
Channels   : 31
E. max/used : 256/000
Serial     : 1300
IRQ        : 16
CardIndex  : 3
CardOrdinal : 72
Controller : 1
Bus-Type   : PCI
Port-Name  : DIVA PRI 3.0 1300
PCI-bus    : 4
PCI-func   : 0
Mem / I/O 0 : 0xd487fc00 / mapped : 0xf8e88c00 ( 67%)
< EXIT >
```

Click **<EXIT>**.

6. If the network provides the clock for the signaling, set the interface mode to **Terminal Equipment (TE) mode, default** otherwise select **Network Termination (NT) mode**.

```
Board 1 - Dialogic Diva PRI/E1/T1-8 PCI v3 SN:1300
Please select interface mode (TE/NT/Resource board)
(X) 0 Terminal Equipment (TE) mode, default
( ) 1 Network Terminator (NT) mode
< OK > <Cancel> < Help >
```

Click **<OK>**.

7. Select as D-Channel protocol SS7 with the variant E1 or T1. For details about the configuration settings, refer to [Regulatory and Geographic Considerations](#) on page 17.

```
Board 1 - Dialogic Diva PRI/E1/T1-8 PCI v3 SN:1300
Please select D-channel protocol
^(--)
( ) 36 R2CAS - R2 signaling, Indonesia channelized E1
( ) 37 R2CAS - R2 signaling, Thailand channelized E1
( ) 38 R2CAS - R2 signaling, Philippines channelized E1
( ) 39 R2CAS - R2 signaling, Brazil channelized E1
( ) 40 R2CAS - R2 signaling, Mexico channelized E1
( ) 41 R2CAS - R2 signaling, ITU-T channelized E1
( ) 42 R2CAS - R2 signaling, Korean channelized E1
( ) 43 DSS1-JP - ETSI-DSS1 Japan
( ) 44 SERBIA - Serbia Euro-ISDN (ETSI-DSS1) with CRC4 off
( ) 45 LINESIDEE1 - Lineside E1
(X) 46 SS7_E1 - DSI SS7 E1
( ) 47 SS7_T1 - DSI SS7 T1
( ) 48 R2CAS - R2 signaling, Argentina channelized E1
( ) 49 R2CAS - R2 signaling, Venezuela channelized E1
< OK > <Cancel> < Help >
```


Click **<OK>**.

8. Select the redirecting number emulation settings.

```
Board 1 - Dialogic Diva PRI/E1/T1-8 PCI v3 SN:1300
Please select Redirecting Number Emulation
(X) 0 - Disabled (default)
( ) 1 - Use Called Number
< OK > <Cancel> < Help >
```


Click **<OK>**.

9. Select the layer 1 framing. Depending on the network, leave the default value **Multiframing (CRC4)** or select **Doubleframing (no CRC4)**.




Click **<OK>**.

10. Select voice companding options. The default value for E.1 is a-law and μ -law for T.1.




Click **<OK>**.

11. Select the fax speed limit. (Relevant for media applications using fax.)




Click **<OK>**.

12. Select the non-productive fax session time limit. (Relevant for media applications using fax.)




Click **<OK>**.

13. Select the global fax options for T.30 protocol. (Relevant for media applications using fax.)




Click **<OK>**.

14. Select the part 68 voice signal limiter settings. (Relevant for media applications using voice.)



Click **<OK>**.

15. Select the DTMF clamping settings. (Relevant for media applications using voice.)



Click **<OK>**.

16. Select the Audio Recording AGC settings. (Relevant for media applications using voice.)




Click **<OK>**.

17. Save the configuration and exit the configuration wizard or select another Diva Media Board for configuration.




Click **<OK>**.

18. If you selected **Save configuration and exit**, you have to select the Diva Board to M-Board assignment, where you should choose to **Preserve existing configuration** or to **Bind every Diva Board to own M-Board**.




Click **<OK>**.

19. Select the ECT emulation settings.




Click **<OK>**.

20. Select the global CAPI call distribution policy settings.




Click **<OK>**.

21. Select the call rate limit settings.



Click **<OK>**.

22. Select the card startup options. If you want to start the Diva driver on system boot, you need to select it here.



Click **<OK>**.

23. Now the configuration is complete, press <EXIT> to exit the wizard.

24. Change the configuration files of the SS7 Software for Diva Interfaces as described below.

4.5 Test the Dialogic® Diva® Media Board

After the restart of the system, plug the E.1/T.1 cable into one port of your Diva Media Board. If the red LED of this port is turned off, your configuration is working properly from the hardware point of view. If the red LED remains lit, make sure that the other end of the cable is properly connected to the end-point. If that is the case, verify the configuration with help of the Dialogic® Diva® Configuration web interface or the Dialogic® Diva® Configuration Wizard.

4.5.1 Loopback test

If your Diva Media Board has various ports or you have various Diva Media Boards installed, you can also do a loopback test. To do so, plug the loopback cable in the ports you want to test. If the red LED is turned off, your configuration is working properly on a hardware/electrical level. If it remains lit, you need to verify the configuration with help of the Diva Configuration web interface or the Diva Configuration Wizard.

Chapter 5: Dialogic® SS7 Software Configuration

A set of sample configuration files (system.txt.ss7, config.txt.ss7) is copied with the SS7 Software for Diva Interfaces package. These configuration files are text-based. You need to rename them to config.txt/system.txt and enter your own SS7 configuration parameters either in the Dialogic® Diva® Configuration web interface or in a text editor, e.g., vi. The complete path to the configuration files is:

```
/usr/lib/opendiva/dlgss7/system.txt
```

```
/usr/lib/opendiva/dlgss7/config.txt
```

5.1 Dialogic® SS7 Software system configuration

The system.txt configuration file is a text file used to configure the software environment. The file syntax permits the use of comments to improve the readability of the file. Comments are inserted into the file by using an asterisk (*). Numbers can be entered in either decimal or hexadecimal format. Hexadecimal numbers should be prefixed with 0x.

The system configuration file contains the following commands:

- LOCAL commands to allow the gctload program to generate message queues for modules running locally.
- REDIRECT commands to cause messages generated for modules not running locally to be redirected via a module that is running locally.
- FORK_PROCESS commands advising the gctload program of any processes that need to be started locally.

The full syntax of each command is listed in the Dialogic® DSI SS7 Protocols Software Environment Programmer's Manual.

An example system.txt configuration file for Dialogic® SS7 Software for Dialogic® Diva® Interfaces is shown here:

```
*****
*
* Example System Configuration File (system.txt) for use with
* Dialogic(R) SS7 for Diva(R) Interfaces
*
* Edit this file to reflect your configuration.
*
*****
*
* Essential modules running on host:
*
LOCAL 0x20 * ssdd - Board interface task
LOCAL 0x22 * MTP3 module
LOCAL 0x23 * ISUP module
LOCAL 0x4d * dvscc - Diva Virtual Signaling Call Control
*          transfers ISDN to ISUP and vice versa
LOCAL 0x00 * tim_lnx6 - Timer task
LOCAL 0xcf * s7_mgt - Management/config task
*
* Optional modules running on the host:
*
LOCAL 0xef * s7_log - Display and logging utility
*
* Essential modules running on the board (all redirected via ssd):
*
REDIRECT 0x71 0x20 * MTP2 module (except SS7HD boards)
REDIRECT 0x8e 0x20 * On-board management module
*
* Redirection of status indications:
*
REDIRECT 0xdf 0xef * LIU/MTP2 status messages -> s7_log
*
```

```
*
* Dimensioning the Message Passing Environment:
*
NUM_MSGS  10000      * Number of standard size
*                  messages in the environment
*
*
* Now start-up all local tasks:
FORK_PROCESS ./tim_lnx
FORK_PROCESS ./tick_lnx
FORK_PROCESS ./s7_log -o0xff1f
FORK_PROCESS ./s7_mgt -i0x4d -d
FORK_PROCESS ./ssdd
FORK_PROCESS ./mtp_lnx6
FORK_PROCESS ./isp_lnx6
FORK_PROCESS ./dvsc
*
*****
```

5.1.1 Adapting the system.txt configuration file

The default system.txt contains the correct settings of a standard SS7 Software for Diva Interfaces system. Therefore, you should change commands only if it is required by the used system implementation. The following commands may be adapted:

```
FORK_PROCESS ./ssdd
FORK_PROCESS ./dvsc
FORK_PROCESS ./s7_log
FORK_PROCESS ./mtp_lnx6
FORK_PROCESS ./isp_lnx6
```

For a detailed description of the mentioned processes see [Command Description](#) on page 32, for all others refer to the Dialogic® DSI SS7 Protocols Software Environment Programmer's Manual.

5.1.2 Testmode

To run Dialogic® SS7 Software for Dialogic® Diva® Interfaces, you need valid licenses for MTP2, MTP3 and ISUP.

Without a valid license file, you can start the according processes in a test mode. The option `-t` is available for the following process calls:

```
FORK_PROCESS ./ssdd -t      (MTP2 License)
FORK_PROCESS ./mtp_lnx6 -t  (MTP3 License)
FORK_PROCESS ./isp_lnx6 -t  (ISUP)
```

The testmode will expire after 10 hours.

5.1.3 Command Description

ssdd

Syntax:

```
ssdd [-m<module_id>] [-d<trace_mask>] [-v] [-lt] [-Lp<path>] [-t]
```

Command	Option	Description	Remark
ssdd	-m<module id>	Defines the module id of ssdd (default: 0x20)	
	-d<trace mask>	Enable diagnostic tracing and define the initial trace mask of ssdd as hexadecimal number (default:0x7)	For details, see table below.
	-v	Show version information and exit	command line only
	-lt	License Test displays MTP2 license information and exit	command line only
	-Lp<path>	Set the path to the license file (default:'.')	
	-t	Start ssdd in trail mode. (no MTP2 license required). It will terminate after 10 hours	

Trace mask definition:

Bit	Meaning
0	initialisation and state changes
1	Errors
2	Warnings
3	internal status change
4	protocol wrapper
5	internal verbose
6	messages/primitives
x	All other bits are reserved.

The debug information is written into the Dialogic® Diva® System Release standard tracing utilities, refer to the Dialogic® Diva® System Release LIN Reference Guide for more information.

Notes:

- The trace mask used on live systems, should not define more than bit 0,1, and 2 since it may significantly harm the overall system performance. The -d option is intended for use during fault finding on a system that has not been configured correctly.
- The trace mask can be changed while ssdd is up and running via the management interface, refer to [Management Interface of the SSDD Process](#) on page 54

dvsc

Syntax:

```
dvsc [-m<module_id>] [-d<trace_mask>] [-i<module_id>]
```

Command	Option	Description	Remark
dvsc	-m<module id>	Defines the module id of the Diva Virtual Signaling Call Control (default: 0x4d)	
	-d<trace mask>	Enable diagnostic tracing and define the initial trace mask of ssdd as hexadecimal number (default:0x7)	For details, see command ssdd on page 32.
	-i<module id>	Defines the destination module ID of ISUP (default:0x23)	

Trace mask definition: see [ssdd](#) on page 32

s7_log

Syntax:

```
s7_log [-m<module_id> -f<logfile> -o<options> -s<max_log_size [kilobytes]> -n<max_log_files> -c<max_messages> -t<timestamp> -p<pcap_file_name>
```

Command	Option	Description	Remark
s7_log	[-m<module_id>]	s7_log's module ID (default=0xef)	
	-f<logfile>	Optional file to write console output (default=none) Enable fixed length logfile by setting -f and -n and/or -s.	
	-o<options>	16 bit run-time options (default 0xaf0d) each bit set to 1 enables : 0 Text interpretation of MSGs 1 Display all MSG as binary 2 MGT trace event decoding 3 Display of trace event time 8 Display m.hdr.type 9 Display m.hdr.id 10 Display m.hdr.src 11 Display m.hdr.dst 12 Display m.hdr.rsp_req 13 Display m.hdr.status 14 Display m.hdr.err_info 15 Display m.param	
	-s<max_log_size>	Defines maximum logfile size (kbyte)	
	-n<max_log_files>	Defines maximum number of logfiles	
	-c<max_messages>	Defines maximum number of messages	
	-t<timestamp>	enable time stamp: • time only t [-tt] • time and date d [-td]	
	-p<pcap_file_name>	Optional file to write PCAP formatted logging (default=none)	

mtp_Inx6

Syntax:

```
mtp_lnx6 [-m<module_id>] [-v] [-Lt] [-Lp<path>] [-t]
```

Command	Option	Description	Remark
mtp_Inx6	-m<module id>	Defines the module id of mtp_Inx6 (default: 0x22)	
	-v	Show version information and exit	command line only
	-Lt	License Test displays MTP3 license information and exit	command line only
	-Lp<path>	Set the path to the license file (default:'.')	
	-t	Start mtp_Inx6 in trail mode. (no MTP3 license required). It will terminate after 10 hours.	

isp_Inx6

Syntax:

```
isp_lnx6 [-m<module_id>] [-v] -Lt[-Lp<path>] [-t]
```

Command	Option	Description	Remark
isp_Inx6	-m<module id>	Defines the module id of isp_Inx6 (default: 0x23)	
	-v	Show version information and exit	command line only
	-Lt	License Test displays MTP3 license information and exit	command line only
	-Lp<path>	Set the path to the license file (default:'.')	
	-t	Start mtp_Inx6 in trail mode. (no MTP3 license required). It will terminate after 10 hours.	

5.2 Dialogic® SS7 protocol configuration

This chapter describes the commands and parameters used in the config.txt protocol configuration file. These commands are used by the s7_mgt protocol configuration utility to perform one time configuration of the protocol stack at startup.

The commands are logically grouped in the following categories:

- [Physical Interface Configuration Command](#) on page 37
- [MTP Configuration Commands](#) on page 38
- [ISUP Configuration Commands](#) on page 42
- [DVSCC Command Reference](#) on page 44

This is an example of the config.txt protocol configuration file. The commands are described below the example.

```
*****
* Example SS7 Configuration File (config.txt) for use with
* Dialogic(R) Global Call for SS7 based on Dialogic(R) Diva(R) Media Boards
*
* This file needs to be modified to suit individual circumstances.
*
*****
*
* Board Definitions:
*
*****
* For Diva boards:
* DIVA_BOARD <board_id> <board_type> <flags> <serial>
* board_id: logical number to identify the board, starts at 0
* board_type: identifies the type of Diva board.
```

```

*
* Valid entries:
* Diva PRI v.3 PCI (ADSP based)
* 70 - Dialogic Diva PRI/E1-30 PCI v3
* 71 - Dialogic Diva PRI/T1-24 PCI v3
* 72 - Dialogic Diva PRI/E1/T1-8 PCI v3
* 73 - Dialogic Diva V-PRI/E1-30 PCI v3
* 74 - Dialogic Diva V-PRI/T1-24 PCI v3
* 75 - Dialogic Diva PRI/E1/T1-CTI PCI v3
* Diva 2/4PRI Boards (BF based)
* 79 - Dialogic Diva V-2PRI/E1/T1-60 PCI v1
* 81 - Dialogic Diva V-4PRI/E1/T1-120 PCI v1
* PCI Express version of Diva PRI v.3 boards (ADSP based)
* 94 - Dialogic Diva PRI/E1-30 PCIe v3
* 95 - Dialogic Diva PRI/T1-24 PCIe v3
* 96 - Dialogic Diva V-PRI/E1-30 PCIe v3
* 97 - Dialogic Diva V-PRI/T1-24 PCIe v3
* 98 - Dialogic Diva PRI/E1/T1-CTI PCIe v3
* PCI Express version of Diva 2/4PRI boards (BF based)
* 110 - Dialogic Diva V-4PRI PCIe HS v1
* 111 - Dialogic Diva V-2PRI PCIe HS v1
* 112 - Dialogic Diva V-1PRI PCIe HS v1
* PCI Express version of Diva 4/8PRI boards (BF based)
* 113 - Dialogic Diva V-4PRI PCIe FS v1
* 114 - Dialogic Diva V-8PRI PCIe FS v1
* Unified Messaging version of Diva PRI v.3 boards (ADSP based)
* 115 - Dialogic Diva UM-PRI/E1-30 PCI v3
* 116 - Dialogic Diva UM-PRI/T1-24 PCI v3
* 117 - Dialogic Diva UM-PRI/E1-30 PCIe v3
* 118 - Dialogic Diva UM-PRI/T1-24 PCIe v3
* flags: for future use, shall be set to 0
* serial: serial number of that board
* Note: The LIUs are implicit declared here
* E.g. Diva board type 81 (Dialogic Diva V-4PRI/E1/T1-120 PCI v1) consists
* of 4 LIUs.
* Diva 'InterfaceNr' 0 -> LIU Id 0
* 1 -> LIU Id 1
* 2 -> LIU Id 2
* 3 -> LIU Id 3
*
* <board_id> <board_type> <flags> <serial>
DIVA_BOARD 0 81 0x0 1234 * Dialogic Diva V-4PRI/E1/T1-120 PCI v1
* * serial number 1234
*
*
*****
*
* MTP parameters:
*
*****
* MTP_CONFIG <reserved1> <reserved2> <options>
* =====
MTP_CONFIG 0 0 0x00040004 * RPO handling according to ITU-T 1992 (and later)
* * 14 bit point codes
* * Host-based MTP3
*
*****
* MTP_LINKSET <linkset_id> <adjacent_spc> <num_links> <flags> <local_spc> <ssf>
* =====
MTP_LINKSET 0 129 2 0x0000 130 0x08 * APC: 129 as 14 bit PC (hex: 81, 4-3-4-3:0-1-0-1)
* * two links in this linkset
* * OPC: 130 as 14 bit PC (hex: 82, 4-3-4-3:0-1-0-2)
* * ssf: national 0
*
*****
* MTP_ROUTE <dpc> <norm_ls> <user_part_mask> <flags> <second_ls>
* =====
MTP_ROUTE 129 0 0x0020 * DPC: 129 as 14 bit PC (hex: 81, 4-3-4-3:0-1-0-1)
* * linkset Id: 0
* * user_part_mask: Bit 5 is set -> ISUP Service indicator
*
*****
* MTP_LINK <link_id><linkset_id><link_ref><slc><board_id><blink><stream>
* =====
MTP_LINK 0 0 0 0 0 0 0 16 0x0006 * link on board Id 0,
* * liu Id 0,timeslot 16
* * signalling link test
* * 64 kb/s
MTP_LINK 1 0 1 1 0 2 2 16 0x0006 * link on board Id 0,
* * liu Id 1,timeslot 16
* * signalling link test
* * 64 kb/s
*****
*

```

```

*****
*
* ISUP parameters:
*
*****
* ISUP_CONFIG <res1><res2><user_id><options><num_grps><num_cts>
* =====
ISUP_CONFIG 0 0 0x4d 0x0414 4 128 * gcss7 module ID: 0x4d (see system.txt)
* * call release procedures are supported by gcss7
* * errors are reported to gcss7
* * 4 Circuit groups are defined
* * Max. CID 128
*
*****
* Configure ISUP circuit groups:
* ISUP_CFG_CCTGRP <gid><dpc><base_cic><base_cid><cic_mask><options><user_inst>
* * <user_id><opc><ssf><variant><options2>
* =====
ISUP_CFG_CCTGRP 0 130 0x01 0x01 0x7FFF7FFF 0x249001e 0 0x4d 129 0x8 1 0x00d0
* * Circuit group = 0
* * DPC = 130 (HEX:0x82, 4-3-4-3:0-1-0-2)
* * Base CIC = 0x01 (dec:1)
* * Base CID = 0x01 (dec:1)
* * group consist of 30 CICs (0x1-0xF, 0x11-0x1F)
* * options:
* * - outgoing call priority:
* * Higher point code has priority on even cic s.
* * - T7, T9 (ACM, ANM) timers are used
* * - T2 or T6 are running in suspended state
* * - abnormal circuit group blocking procedures follows
* * Q.767, Q.764 (03/93) and ANSI T1.113 operation
* * - 'Confusion' (CFN) messages are enabled
* * - T34 for segmented messages will be enabled
* * - Q.764 (03/93) end node (i.e. exchange type A) message
* * and parameter compatibility handling will be
* * performed (passing on unrecognised information is
* * possible)
* * user instance = 0
* * gcss7 module ID: 0x4d (see system.txt)
* * OPC = 129 (HEX:0x81, 4-3-4-3:0-1-0-1)
* * Sub Service Field = 0x8 (national 0)
* * variant = 1 (Q.761 Q.764 (1992 and later editions)
* * options2:
* * - T39 (waiting for IRS after sending IDR) is used
* * - enable the user part unavailability procedure
ISUP_CFG_CCTGRP 1 130 0x20 0x21 0x7FFFFFFF 0x249001e 0 0x4d 129 0x8 1 0x00c0 *$ conform=ETSI_V2_V3
* * Circuit group = 1
* * Base CIC = 0x20 (dec:32)
* * Base CID = 0x21 (dec:33)
* * group consist of 31 CICs (0x20-0x3E)
* * other parameters as for group 0
ISUP_CFG_CCTGRP 2 130 0x3F 0x41 0x7FFF7FFF 0x249001e 0 0x4d 129 0x8 1 0x00c0 *$ conform=ETSI_V2_V3
* * Circuit group = 2
* * Base CIC = 0x3F (dec:63)
* * Base CID = 0x41 (dec:65)
* * group consist of 30 CICs (0x3F-0x4D, 0x4F-0x5D)
* * other parameters as for group 0
ISUP_CFG_CCTGRP 3 130 0x5E 0x61 0x7FFFFFFF 0x249001e 0 0x4d 129 0x8 1 0x00c0 *$ conform=ETSI_V2_V3
* * Circuit group = 3
* * Base CIC = 0x5E (dec:94)
* * Base CID = 0x61 (dec:97)
* * group consist of 31 CICs (0x5E-0x7D)
* * other parameters as for group 0
*
*****

```

5.2.1 Physical Interface Configuration Command

The physical interface configuration command is:

DIVA_BOARD - Configure Dialogic® Diva® Media Board

Synopsis

Command to configure an Dialogic® Diva® Media Board for the use in the Dialogic® SS7 Software for Dialogic® Diva® Interfaces environment.

Syntax

```
DIVA_BOARD <board_id> <board_type> <flags> <serial>
```

Example

```
DIVA_BOARD 0 81 0x0 1092
```

Parameters

The DIVA_BOARD command includes the following parameters:

- <board_id>
The logical identity of the board in the range of 0 to one less than the number of boards supported (starting at 0, range of 0 to 15).
- <board_type>
Dialogic® Diva® Media Board type.

Board Type	Diva Media Board
70	Diva PRI/E1-30 PCI v3
71	Diva PRI/T1-24 PCI v3
72	Diva PRI/E1/T1-8 PCI v3
73	Diva V-PRI/E1-30 PCI v3
74	Diva V-PRI/T1-24 PCI v3
75	Diva PRI/E1/T1-CTI PCI v3
79	Diva PRI/E1/T1-CTI PCI v3
81	Diva V-4PRI/E1/T1-120 PCI v1
83	Diva -V2PRI/E1/T1-60 PCI v1
85	Diva V-4PRI/E1/T1-120 PCI v1
94	Diva PRI/E1-30 PCIe v3
95	Diva PRI/T1-24 PCIe v3
96	Diva V-PRI/E1-30 PCIe v3
97	Diva V-PRI/T1-24 PCIe v3
98	Diva PRI/E1/T1-CTI PCIe v3
110	Diva V-4PRI PCIe HS v1
111	Diva V-2PRI PCIe HS v1
112	Diva V-1PRI PCIe HS v1
113	Diva V-4PRI PCIe FS v1
114	Diva V-8PRI PCIe FS v1
115	Diva UM-PRI/E1-30 PCI v3
116	Diva UM-PRI/T1-24 PCI v3

Board Type	Diva Media Board
117	Diva UM-PRI/E1-30 PCIe v3
118	Diva UM-PRI/T1-24 PCIe v3

- <flags>
Reserved for future use, set to 0x0
- <serial>
Serial number of the Diva Media Board

5.2.2 MTP Configuration Commands

The Message Transfer Part (MTP) configuration commands are:

- MTP_CONFIG - Configure MTP
- MTP_LINKSET - Configure a Linkset
- MTP_LINK - Configure a Link
- MTP_ROUTE - Configure a Route

MTP_CONFIG - Configure MTP

Synopsis

The global configuration parameters for the Message Transfer Part (MTP).

Syntax

```
MTP_CONFIG <reserved1> <reserved2> <options>
```

Example

```
MTP_CONFIG 0 0 0x00040000
```

Parameters

The MTP_CONFIG command includes the following parameters:

- <reserved1>, <reserved2>
These parameters are reserved for backwards compatibility only. For applications conforming to this release, these parameters should always be set to 0.
- <options>
A 32-bit value containing run-time options for the operation of MTP as follows:

- Bit 0 is set to 1 to disable the MTP3 message discrimination function and thus to allow the signaling point to receive all messages irrespective of the destination point code contained in the message or zero to allow the discrimination function to operate normally.
- Bit 1 is set to 1 to disable sub-service field (SSF) discrimination. If this bit is set to zero, each received MSU with an ssf value that does not match the configured ssf value for that link set is discarded.
- Bit 3 is set to 1 to cause MTP3 to generate a User Part Unavailable (UPU) message to the network on receipt of a message containing a Service Indicator (SI) value that has not been configured. If set to zero, the message will be discarded without sending the UPU message.
- Bit 8 is set to 1 to select ANSI operation; otherwise it should be set to zero.
- Bit 9 is set to 1 to select 24-bit point codes in the MTP routing label or zero to select 14-bit or 16-bit point codes. This bit should always be set to 1 when ANSI operation is required.
- Bit 10 is set to 1 for ANSI operation; otherwise it should be set to zero.
- Bit 11 is set to 1 for ANSI operation; otherwise it should be set to zero.
- Bit 18 is used to control MTP functionality in the event of detection of Remote Processor Outage (RPO). If set to 1, RPO is handled in accordance with the ITU-T 1992 (and later) recommendations. If set to zero, on detection of RPO, the signaling link is taken out of service and restoration commences. This bit should normally be set to 1.
- Bit 20 is set to 1 to select 16-bit point codes in the MTP routing label for use in Japanese networks or zero to allow the use of 24-bit or 14-bit point codes as set using bit 9 (see above).
- Bit 21 should be set to 1 for use in Japanese networks; otherwise it should be set to zero.

All other bits are reserved for future use and should be set to zero.

Note: For correct ANSI operation, bits 8, 9, 10, 11, and 18 must be set to 1. This gives a typical <options> field value of 0x00040f00 for ANSI configurations.

MTP_LINKSET - Configure a Linkset

Synopsis

Configuration of a linkset to an adjacent signaling point.

Syntax

```
MTP_LINKSET <linkset_id> <adjacent_spc> <num_links> <flags> <local_spc> <ssf>
```

Example

```
MTP_LINKSET 0 321 2 0x0000 456 0x8
```

Parameters

The MTP_LINKSET command includes the following parameters:

- <linkset_id>
The logical identity of the linkset, in the range of zero to one less than the number of linksets supported. The linkset_id is used in other commands for reference.
- <adjacent_spc>
The point code of the adjacent signaling point.
- <num_links>
The number of links to be allocated to the linkset.
- <flags>
This field is a 16-bit field containing run-time configuration options for the link set as follows:

- Bit 3 is set to 1 to enable MTP restart procedures for this link set.
- All other bits are reserved for future use and should be set to zero.
- <local_spc>
The point code of the signaling point itself.
- <ssf>

The value to be used in the Sub-Service Field (SSF) of all MTP3 messages and checked for by the discrimination function in all received messages. This is a 4-bit value. For ANSI operation, each of the two least significant bits should be set to 1.

Note: For correct operation, the adjacent point code must also appear in an MTP_ROUTE declaration.

MTP_LINK - Configure a Link

Synopsis

Configuration of a signaling link.

Syntax

```
MTP_LINK <link_id> <linkset_id> <link_ref> <slc> <board_id> <blink> <stream> <timeslot> <flags>
```

Example

```
MTP_LINK 0 0 2 2 0 1 1 16 0x0006
```

Parameters

The MTP_LINK command includes the following parameters:

- <link_id>
The unique logical identity of the link. It must be in the range of zero to one less than the total number of signaling links supported.
- <linkset_id>
The logical identity of the linkset to which the link belongs. The linkset must already have been configured using the MTP_LINKSET command.
- <link_ref>
The logical identity within the linkset of the signaling link. It should be in the range of zero to one less than the number of links in the linkset.
- <slc>
The signaling link code for the signaling link. This must be unique within the linkset and is typically the same as <link_ref>. The valid range is 0 to 15.
- <board_id>
The board ID of the signaling processor allocated for this signaling link.
- <blink>
This parameter indicates the channel of the link within the board. Each blink can be used only once per board. The parameter must be between zero and one less than the number of links supported.
- <stream>
When the <timeslot> parameter is set to a non-zero value, the <stream> parameter is the logical identity of the T1/E1 Line Interface Unit (LIU) (liu_id) containing the signaling link. It should be in the range of zero to one less than the number of LIUs. In these cases, the timeslot should be the signaling processor's signaling link in the range of 0 to 31.
- <timeslot>
The timeslot used for signaling in the range of 0 to 31. The valid ranges are:

- For an E1 interface: 1 to 31.
- For a T1 interface: 1 to 24.
- <flags>

A 16-bit value containing additional run-time options. The bit significance is as follows:

- Bit 0 is set to 1 to force the use of the emergency proving period during link alignment or zero to use the appropriate proving period according to the MTP3 recommendations.
- Bit 1 is set to 1 to cause a signaling link test (in accordance with ITU-T Q.707 / ANSI T1.111.7) to be carried out before a link is put into service, or zero if a test is not required.
- Bit 2 is set to 1 to cause a signaling link test (in accordance with ITU-T Q.707 / ANSI T1.111.7) to be carried out every 30 seconds. This bit is ignored unless bit 1 is set to 1.
- Bit 8 is used to select the MTP2 error correction mode. It is set to 1 to select PCR (Preventive Cyclic Retransmission) operation or zero for the Basic Method of Error Correction.
- Bits 10 and 11 together select the appropriate operating bit rate for the link. The table below specifies the appropriate values for 48, 56 or 64 kb/sec.

Bit 10	Bit 11	Data Rate (pattern)
0	0	64 kb/s (0xFF)
0	1	48 kb/s (0x7E)
1	0	56 kb/s (0xFE)
1	1	6 kb/s (0xFD)

- Bit 15 is set to 1 to disable the link. This bit should be set to zero to enable normal link operation. All other bits are reserved for future use and should be set to zero.

MTP_ROUTE - Configure a Route

Synopsis

Configuration of a route for use with one or more user parts.

Syntax

```
MTP_ROUTE <dpc> <norm_ls> <user_part_mask> <flags> <second_ls>
```

Example

```
MTP_ROUTE 567 0 0x0020 0x0000 0
```

Parameters

The MTP_ROUTE command includes the following parameters:

- <dpc>

The point code of the remote signaling point for which this command is configuring routing data. It may be either an adjacent point code or a point code accessible via an adjacent Signaling Transfer Point (STP).
- <norm_ls>

The linkset_id of the normal linkset used to reach the specified destination. This parameter must be a linkset_id that has already been configured using the MTP_LINKSET command. The normal linkset may be any of the following:

- The only linkset used to reach the destination.
- The preferred linkset used to reach the destination.
- One of a pair of links sets forming a combined linkset.

In the latter two cases, a second linkset, <second_ls>, must also be specified.

Within a linkset, messages are automatically load shared across links using the Signaling Link Selection (SLS) field in the message.

- <second_ls>

The linkset_id of an optional second linkset used to reach the specified destination. This may be either of the following options:

- The secondary linkset used to reach the destination only on failure of the preferred linkset.
- One of a pair of links sets forming a combined linkset over which load sharing takes place. In this case, bit 1 must also be set in the <flags> parameter of the command.

When a second linkset is specified, the user must also set bit 0 in the <flags> field of this command.

- <user_part_mask>

This is a 16-bit field used identify the user parts that are supported over this route. The bits are labelled 0 to 15. For each user part supported, the bit corresponding to the Service Indicator for that user part should be set. For example, to support just ISUP messages, the ISUP Service Indicator is 5. Bit 5 should be set, and therefore a value of 0x0020 is appropriate.

- <flags>

A 16-bit field containing run-time configuration options for the route as follows:

- Bit 0 is set to 1 to indicate that a second linkset is specified within the command. If set to zero, the <second_ls> parameter is ignored.
- Bit 1 is used to determine whether or not to load share messages across the two linksets. It is only used when two linksets are specified for the route. When set, the MTP3 module load shares messages for the destination equally across each of the two specified linksets. Otherwise, the MTP3 module considers the normal linkset to be the preferred linkset and only uses the second linkset in the event of failure of the normal linkset. The bit should be set to 1 to enable load sharing across the two linksets or zero to disable load sharing and use preferred and secondary linksets.

All other bits are reserved for future use and must be set to zero.

5.2.3 ISUP Configuration Commands

The ISUP configuration commands are:

- ISUP_CONFIG - Configure ISUP
- ISUP_CFG_CCTGRP - Configure an ISUP Circuit Group
- ISUP_TIMER - Configure ISUP Timers

ISUP_CONFIG - Configure ISUP

Synopsis

The global configuration parameters for the ISUP module.

Syntax

```
ISUP_CONFIG <res1> <res2> <user_id> <options> <num_grps> <num_ccts> [<partner_id>]
```

Example

```
ISUP_CONFIG 0 0 0x2d 0x0435 4 128
```

Parameters

The ISUP_CONFIG command includes the following parameters:

- <res1> , <res2>
Reserved for backwards compatibility. These fields should be set to 0.
- <user_id>
The module_id of the application running on the host that uses the ISUP module.
- <options>
A 16-bit value that contains global run-time options for the operation of the ISUP module. The meaning of each bit is as defined for the options parameter in the ISUP Configure Request message as detailed in the Dialogic® SS7 Protocols ISUP Programmer's Manual.
- <num_grps>
The maximum number of ISUP circuit groups that the user intends to use. This must not exceed the maximum number of circuit groups supported, otherwise module configuration fails. Typically, this parameter should be set to the maximum number of circuit groups supported.
- <num_ccts>
The maximum number of ISUP circuits that the user intends to use. This must not exceed the maximum number of circuits supported otherwise module configuration fails. Typically, this parameter is set to:
 - 32 times the number of groups for E1 operation
 - 24 times the number of circuit groups for T1 operation**Note:** The valid range for the circuit identifier (cid) is from zero to one less than the maximum cid value.
- <partner_id>
Optional parameter for use when operating in dual resilient configuration. This parameter is the module_id of the partner ISUP module (equivalent to the module_id field in the ISUP Configure Request message as documented in the Dialogic® SS7 Protocols ISUP Programmer's Manual).

ISUP_CFG_CCTGRP - Configure an ISUP Circuit Group

Synopsis

The configuration parameters for a group of ISUP circuits. Typically, a group is all the circuits in a single E1 or T1 interface.

Syntax

```
ISUP_CFG_CCTGRP <gid> <dpc> <base_cic> <base_cid> <cic_mask> <options> <user_inst> <user_id>  
<opc> <ssf> <variant> <options2>
```

Example

```
ISUP_CFG_CCTGRP 0 3 1 1 0x7fff7fff 0x00000003 0 0x2d 2 0x8 4 0x00000000
```

Parameters

The ISUP_CFG_CCTGRP command includes the following parameters:

- <gid>
The group id of the circuit group in the range of zero to one less than the number of groups supported.
- <dpc>
The destination point code for all circuits in the circuit group.
- <base_cic>
The Circuit Identification Code (CIC) that is allocated to the first circuit in the circuit group.

- <base_cid>
The logical id for the first circuit in the circuit group. It must lie in the range of zero to one less than the number of circuits supported.
- <cic_mask>
A 32-bit mask with bits set to indicate which circuits are to be allocated to the circuit group. Bit 0 must always be set since it represents the <base_cic> / <base_cid> . Subsequent bits represent the subsequent circuits. ANSI circuit groups are not permitted to contain more than 24 circuits.
- <options>
A 32-bit value containing run-time options for the ISUP circuit group. Refer to the Configure Circuit Group Request section of the ISUP Programmer's Manual). Bits 0 to 15 are equivalent to the options field and bits 16 to 31 represent the ext_options field as detailed in the Dialogic® SS7 Protocols ISUP Programmer's Manual.
- <user_inst>
The instance number of the user application. Typically, only a single user application exists, so this field should be set to zero.
- <user_id>
The module_id of the user application.
- <opc>
Originating Point Code. The local point code for all circuits in the group.
- <ssf>
The value to be used in the Sub-Service Field (SSF) of all ISUP messages for this circuit group.
- <variant>
The protocol variant for this circuit group. Refer to the Dialogic® SS7 Protocols ISUP Programmer's Manual for full details.
- <options2>
A 32-bit value containing additional run-time options for the ISUP circuit group. Refer to the Configure Circuit Group Request section of the Dialogic® SS7 Protocols ISUP Programmer's Manual. Bits 0 to 31 are equivalent to the ext_1_options parameter, as detailed in the Dialogic® SS7 Protocols ISUP Programmer's Manual.

5.2.4 DVSCC Command Reference

CCT_RESOURCE, CCTGRP_RESOURCE - map a CIC to a Diva trunk timeslot

Synopsis

Define the fix mapping of a CIC to a Diva trunk timeslot.

There are two possibilities to define the relation CIC to Board/liu/timeslot

1. Configure CIC to physical board/trunk/timeslot by a line for each CIC, this means, the CCT_RESOURCE has to be stated for each CIC defined by ISUP_CFG_CCTGRP.

Syntax

```
CCT_RESOURCE <gid> <cic> <board_id> <liu_id> <timeslot>
```

Example

```
CCT_RESOURCE 0 0x01 0 0 1
```

Parameters

The CCT_RESOURCE command includes the following parameters:

- <gid>
The group Id of circuit as defined in command ISUP_CFG_CCTGRP.

- <cic>
The CIC circuit identification code.
 - <board_id>
The board ID of the signaling processor allocated for this CIC.
 - <liu_id>
The logical identity of the T1/E1 Line Interface Unit (LIU) (liu_id) containing the signaling link.
 - <timeslot>
The trunk timeslot used for the according CIC (E1: 1 .. 31, T1: 1 .. 24).
2. Map a complete group of CICs to a related trunk. Therefore the CCTGRP_RESOURCE has to be stated for each CIC group defined by ISUP_CFG_CCTGRP.

Syntax

```
CCTGRP_RESOURCE <gid> <board_id> <liu_id> <tslot_mask> <tslot_s>
```

Example

```
CCTGRP_RESOURCE 0 0 0 0x7FFF7FFF 0
    gid          - 0
    board_id     - 0
    liu_id       - 0
    tslot_mask   - 0x7FFF7FFF
                 E1 timeslot 16 reserved (e.g. for signaling) all
                 other timeslot have to be assigned to a CIC.
    tslot_s      - 0
                 Start CIC on lowest timeslot Last CIC on highest
                 timeslot
```

Parameters

The CCT_RESOURCE command includes the following parameters:

- <gid>
The group Id of circuit as defined in command ISUP_CFG_CCTGRP.
- <board_id>
The board ID of the signaling processor allocated for this CIC.
- <liu_id>
The logical identity of the T1/E1 Line Interface Unit (LIU) (liu_id) containing the signaling link.
- <tslot_mask>
A bitmask which defines which timeslots are used

0 -	not used
1 -	used
bit 0 -	timeslot 1
bit 23 -	timeslot 24
bit 30 -	timeslot 31
- <tslot_start>
Timeslot, where the assignment is starting, identifies the first timeslot to which cic_start will be assigned.


0 -	Start CIC on lowest timeslot Last CIC on highest timeslot
1 -	Start CIC on highest timeslot Last CIC on lowest timeslot

Note: This type of CIC configuration will just work, if allocation is continuous (beside the CICs which are barred by the cic_mask of ISUP_CFG_CCTGRP).

Chapter 6: Starting The Dialogic® SS7 Software for Dialogic® Diva® Interfaces

After you installed the SS7 Software for Diva Interfaces, the license files and made the necessary changes to the "config.txt" and "system.txt" configuration files, you can start the Dialogic® SS7 Software for Diva® Interfaces.

1. Change to the divas directory: `cd /usr/lib/opendiva/divas.`
2. Start the Dialogic® Diva® Media Board with the command `./Start`



```


/usr/lib/opendiva/divas - Shell - Konsole
Session Edit View Bookmarks Settings Help

root@frog#cd /usr/lib/opendiva/divas
root@frog#./Start
Load Diva DIDD driver ... OK
Load Diva XDI driver ... OK
Check for saved MAINT debug/trace buffer ... idle
Write Diva configuration to CFGLib ... succeeded
Load Diva MAINT debug/trace driver ... OK
Parallel start of 2 Diva Boards:
Nr:1 - Dialogic Diva PRI/E1/T1-8 PCI v3 SN:1300
Nr:2 - Dialogic Diva PRI/E1/T1-CTI PCI v3 SN:2223
Wait ... OK
Verify state of Diva Boards:
Start adapter Nr:1 - 'Dialogic Diva PRI/E1/T1-8 PCI v3', SN: 1300 ... OK (already active)
Start adapter Nr:2 - 'Dialogic Diva PRI/E1/T1-CTI PCI v3', SN: 2223 ... OK (already active)
Start background retrieval of initial XLOG for:
  Dialogic Diva PRI/E1/T1-8 PCI v3 SN:1300 to /var/log/diva1.log
  Dialogic Diva PRI/E1/T1-CTI PCI v3 SN:2223 to /var/log/diva2.log
Wait until XLOG retrieval is completed ... OK
Load Diva IDI driver ... OK
Load Diva HSI driver ... OK
Load Diva M-Board driver ... OK
Load optimized Diva CAPI driver ... OK
Initialize Diva registry ... OK
Activate DSI SS7 for Diva ... OK

root@frog#

```

3. To stop the Diva Media Board and the related processes, use the `./Stop` command in the same directory as in step 2.



```

/usr/lib/opendiva/divas - Shell - Konsole
Session Edit View Bookmarks Settings Help

root@frog#./Stop
DIVAS4LINUX SHUTDOWN OK.
root@frog#

```

If you only want to stop the Diva SS7 processes and not the entire Diva Media Board, you can use the command `gctload`.

To shutdown all SS7 processes use:

```
cd /usr/lib/opendiva/dlgss7
./gctload -x
```

To start all SS7 processes use:

```
./gctload -d
```


Chapter 7: Tracing

Trace information will be written via the standard Dialogic® Diva® trace utilities. To enable tracing for the Dialogic® SS7 Software for Dialogic® Diva® Interfaces software, you have to make sure that the debug mask which can be added to the process call in the "system.txt" file are set to a comfortable level. See the [Examples of the Default Configuration Files](#) on page 85 for a complete description of the debug mask. If you need to make changes to the "system.txt" file, you need to stop the Diva DSI SS7 software and start it again as described in [Starting The Dialogic® SS7 Software for Dialogic® Diva® Interfaces](#) on page 46. MTP and ISUP tracing is done via the DSI SS7 trace mechanisms. See the Dialogic® SS7 Protocols Software Environment Programmer's Manual, for more information.

7.1 Verify if Dialogic® SS7 Software for Dialogic® Diva® Interfaces software is running


To verify if the SS7 Software for Diva Interfaces starts properly, you may use the following commands, to setup a trace message.

1. Enable Diva tracing with `cd /usr/lib/opensdiva/divas` and type `./Trace`.
2. Select **Load MAINT driver and exit**.



Click **<OK>**.

3. Display the available interfaces. For the SS7 software, the DVSCC and the SSDD interfaces are the most important ones.




```
root@frog# cd /usr/lib/opensdiva/divas
root@frog# ./divactrl ditrace -l

-----
ditrace, BUILD (108-1009[108-130]-Sep 19 2008-14:31:35)
-----
732:29:05.4130403 01 - DIDD(3.0)
732:29:05.4130403 02 - DIVAS(2.0)
732:29:05.4130403 03 - MAINT(3.1)
732:29:08.4133559 04 - ADAPTER:2 SN:2223
732:29:08.4133563 05 - ADAPTER:1 SN:1300
732:29:10.4135095 06 - User IDI(2.0)
732:29:10.4135119 07 - MTPX(108-359-SRC)
732:29:11.4136135 08 - CAPI20(2.0)
732:29:11.4136243 09 - DVSCC(1.0.0.55 )
732:29:11.4136243 10 - SSDD(1.0.0.78 )
-----

root@frog#
```

4. If only the information of the SSDD and DVSCC is relevant, you may disable the trace output of the other drivers by setting their trace mask to zero.



```
root@frog# ./divactrl ditrace -d 1,2,3,4,5,6,7,8 -m 0x0
root@frog#
```

5. The default trace masks for the SS7 Software for Diva Interfaces are saved in the system.txt configuration file. The default masks for tracing are set with -d option, e.g.,

```
FORK_PROCESS ./ssdd -d0x7
FORK_PROCESS ./dvsc -d0x7
```

- Start the trace. The output will be prompted to the default output. Alternatively, you can write the trace output into a file, therefore use the command shown in the picture below. The trace is written into the file `trace1.txt` in the current working directory. For more information about tracing of the Diva Media Board and Diva System Release Software, see the Dialogic® Diva® System Release LIN Reference Guide.

```

/usr/lib/opensdiva/divas - Shell - Konsole
Session Edit View Bookmarks Settings Help
root@frog# ./divactrl ditrace -p

-----
ditrace, BUILD (108-1009[108-130]-Sep 19 2008-14:31:35)
-----
732:48:51.1021304 01 - DIDD(3.0)
732:48:51.1021304 02 - DIVAS(2.0)
732:48:51.1021304 03 - MAINT(3.1)
732:48:54.1024484 04 - ADAPTER:2 SN:2223
732:48:54.1024496 05 - ADAPTER:1 SN:1300
732:48:55.1026028 06 - User IDI(2.0)
732:48:55.1026052 07 - MTPX(108-359-SRC)
732:48:57.1027084 08 - CAPI20(2.0)
-----
==> missing sequence 1 - 408
732:51:44.1194508 DIMAINT - drv # 9 = 'SSDD' registered
732:51:44.1194508 DIMAINT - drv # 10 = 'DVSCC' registered
732:51:44.1194508 L A B-DVSCC: Init dbg-mask:0x0007
732:51:44.1194508 L A B-DVSCC: New dbg-mask:0x0007
732:51:44.1194508 L A S-DVSCC: Dialogic Virtual SS7 Call Control service (1.0.0.55 ) started
732:51:44.1194516 L 9 S-SSDD: licHostId:0019b915e012
732:51:44.1194516 L 9 B-SSDD: Init dbg-mask:0x0007
732:51:44.1194516 L 9 S-SSDD: Dialogic Diva SS7 ssdd service (1.0.0.78 ) started test mode
732:51:44.1194516 L 9 S-SSDD: GCT thread created - handle:0x81bc298
732:51:44.1194520 L 9 S-SSDD: CAPI User Init - Controller 1, serial:1300
732:51:44.1194520 L 9 S-SSDD: CAPI User Init - Controller 2, serial:2223
732:51:44.1194624 L 9 S-SSDD: reset board serial:1300, type 70(Dialogic Diva PRI/E1-30 PCI v3) (1:31)
732:51:44.1194624 L 9 S-SSDD: set board run mode:2[0]
732:51:44.1194624 L 9 S-SSDD: gct_context:0x81994c4 capi_context:0x81bb974 - board_id:00, liu_id:0, Capi no:01,
serial:1300, type:70(Dialogic Diva PRI/E1-30 PCI v3)
732:51:44.1194624 L 9 S-SSDD: set board hstate:32[0]
732:51:44.1194624 L 9 S-SSDD: set board pstate:48[0]
732:51:44.1194624 L 9 S-SSDD: reset board serial:2223, type 70(Dialogic Diva PRI/E1-30 PCI v3) (1:31)
732:51:44.1194624 L 9 S-SSDD: set board run mode:2[1]
732:51:44.1194624 L 9 S-SSDD: gct_context:0x819957c capi_context:0x81c34fc - board_id:01, liu_id:0, Capi no:02,
serial:2223, type:70(Dialogic Diva PRI/E1-30 PCI v3)
732:51:44.1194624 L 9 S-SSDD: set board hstate:32[1]
732:51:44.1194624 L 9 S-SSDD: set board pstate:48[1]
732:51:44.1194624 L 9 S-SSDD: MGT_MSG_L1_CONFIG - stream:0 board_mgmt_id:0x8e, sliu->mtp2_module_id:0x71
732:51:44.1194624 L 9 S-SSDD: connecting link:0:0:0, 0 connections to be established
732:51:44.1194624 L 9 S-CAPI[0000] NOT_CONNECTED->CONNECTING
732:51:44.1194624 L 9 S-SSDD: MGT_MSG_L1_CONFIG - stream:0 board_mgmt_id:0x8e, sliu->mtp2_module_id:0x71
732:51:44.1194624 L 9 S-SSDD: connecting link:1:0:1, 0 connections to be established
732:51:44.1194624 L 9 S-CAPI[0001] NOT_CONNECTED->CONNECTING
732:51:44.1194632 L 9 S-CAPI[0001] CONNECTING->CONNECTED
732:51:44.1194632 L 9 S-SSDD: connected link:1:0:1, to 2(070,2223-0):0x00008000
732:51:44.1194632 L 9 S-CAPI[0000] CONNECTING->CONNECTED
732:51:44.1194632 L 9 S-SSDD: connected link:0:0:0, to 1(070,1300-0):0x00008000
732:51:45.1195112 L A S-CONFIGURATION - board_id:00, serial:1300, type:70(Dialogic Diva PRI/E1-30 PCI v3) found
732:51:45.1195112 L A S-CONFIGURATION - board_id:01, serial:2223, type:70(Dialogic Diva PRI/E1-30 PCI v3) found
732:51:45.1195112 L A S-DVSCC: CONFIGURATION:
732:51:45.1195112 L A S- No VSIg Controller: 0

```

7.2 Tracing with the Dialogic® Diva® Configuration web interface

- Start the Diva Configuration web interface and click **Trace/Debug** on the left hand side to open the Dialogic® Diva® Trace Wizard.
- Leave the settings at their default values and click **Start Trace**.
- To stop the tracing, click **Stop trace process and retrieve compressed trace file**.

If you use the Diva Trace Wizard at start-up, keep in mind that the whole start-up procedure for the Dialogic® Diva® DSI SS7 software takes about 70 seconds. Therefore, wait at least 70 seconds before you stop the trace.

You can also make traces when the stack is up and running, but the trace information depends on the settings you made in the trace mask in the `system.txt` file. If you make changes to these trace settings, you need to restart Diva DSI SS7 software.

4. After you stopped the trace process, you can view and/or download the trace file and select with the trace viewer the components you want to see in your trace file. For the Dialogic® SS7 Software for Dialogic® Diva® Interfaces, set the **SSDD** and **DVSCC** components to **Yes** and all others to **No**.

Please select the sources of the trace information

Description	Selection	Trace ID	Driver name/ Device
All messages	No		
Diva Board Nr:5, Sn:1627	Yes	1	/proc/net/isdn/eicon/adapter5/info
Diva Board Nr:1, Sn:1102	Yes	2	/proc/net/isdn/eicon/adapter1/info
Diva Board Nr:2, Sn:1102-2	No	3	/proc/net/isdn/eicon/adapter2/info
Diva Board Nr:3, Sn:1102-3	No	4	/proc/net/isdn/eicon/adapter3/info
Diva Board Nr:4, Sn:1102-4	No	5	/proc/net/isdn/eicon/adapter4/info
Kernel mode IDI interface	No	6	divadidd (DIDD, /proc/net/isdn/eicon/divadidd)
Active board driver	No	7	divas (XDI, /proc/net/isdn/eicon/divas)
Maintenance driver	No	8	diva_mnt (MAINT, /proc/net/isdn/eicon/maint)
User mode IDI interface	No	9	diva_idi (IOCTL, /proc/net/isdn/eicon/diva_idi)
MTPX	No	10	
CAPI2.0 interface	No	11	divacapi (/dev/capi20 MAJOR 68, /proc/capi/)
SSDD	Yes	12	
DVSCC	Yes	13	

Select filter options

Description	Selection
Selected B-channels	All
Decode VSIG messages	No
Decode PPP frames	detect PPP frames

View/Download decoded trace file

Download binary trace file

5. Choose whether to view or to download the trace file.

7.3 Dynamic tracing

Below are listed some examples for the MTP process on how to enable/disable the SS7 Software for Diva Interfaces tracing dynamically. If you change the -c 1021 to -c 1022, you are setting the debug masks for the ISUP processes. For information about the trace mask, see the description in the system.txt configuration file. After setting the trace masks for the SSDD and DVSCC processes, you can use the Dialogic® Diva® Trace tool as described in [Tracing with the Dialogic® Diva® Configuration web interface](#) on page 49 or use the command line interface as described in [Verify if Dialogic® SS7 Software for Dialogic® Diva® Interfaces software is running](#) on page 47. You can find more information about the [Management Interface of the SSDD Process](#) on page 54.

- Display the available adapters

```
/usr/lib/opensdivas/diva/divactrl mantool -F
14: {5, 1, 2, 3, 4, 1004, 101, 102, 103, 104, 105, 1000, 1021, 1022}
```

- Check current debug mask

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1021 -r"Debug"
```

Will cause to output the current state of the diva tracing for ssdd (1021).

```
I: adapter 1021 selected
```

```
Management Interface B-Channel State Trace utility for Diva cards
```

```
BUILD (108-1009-Sep 19 2008-14:31:35)
```

```
Copyright (c) 1991-2007 Dialogic
```

```
-w-----hit-[debug_mask .....] = 0x7
```

```
-----fn -[DebugStop .....]
```

- Set debug mask to 3FF

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1021 -w"Debug/debug_mask=0x3FF"
```

```
I: adapter 1021 selected
```

```
Management Interface B-Channel State Trace utility for Diva cards
```

```
BUILD (108-1009-Sep 19 2008-14:31:35)
```

```
Copyright (c) 1991-2007 Dialogic
```

- Set debug mask to 0

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1021 -w"Debug/debug_mask=0x0"
```

```
I: adapter 1021 selected
```

```
Management Interface B-Channel State Trace utility for Diva cards
```

```
BUILD (108-1009-Sep 19 2008-14:31:35)
```

```
Copyright (c) 1991-2007 Dialogic
```

Chapter 8: Uninstalling

Note: There is no separate uninstaller provided for the Dialogic® SS7 Software for Dialogic® Diva® Interfaces. The software is uninstalled with the Dialogic® Diva® System Release software.

To uninstall the SS7 Software for Diva Interfaces, do the following:

1. Open a terminal and go to `/usr/lib/opensdiva/divas` and change the file `Diva4Linux_uninstaller.sh` to an executable
`chmod a+x Diva4Linux_uninstaller.sh.`
2. Stop the Dialogic® Diva® driver with `./Stop`
3. Execute the script `Diva4Linux_uninstaller.sh`. While executing the script you will be asked:
 - If you would like to uninstall the Dialogic® Diva® softIP software, the Dialogic® Diva® SIPcontrol™ software (when these products are installed). Answer **No** if you do not want to uninstall these products or press **Yes** to confirm that you want to remove these software products.
 - If you want to uninstall the SS7 Software for Diva Interfaces, press **Yes** to confirm.
 - For the Dialogic® Diva® System Release software, answer **NO** if you do not want to uninstall or press **Yes** to confirm that you want to remove this software product.
4. The license files of the Dialogic® DSI SS7 software and the configuration files (`config.txt` and `system.txt`) are saved into `/usr/lib/opensdiva/dlgss7_backup.tgz`.
5. After the uninstall, the DSI SS7 software will not be started when starting the Diva System Release software.
6. When you reinstall or upgrade the DSI SS7 software, the configuration and license files will be restored.

Chapter 9: Troubleshooting

If you experience any issues with the SS7 Software for Diva Interfaces, please contact Dialogic Customer support at: <http://www.dialogic.com/support/contact/>.

Note: When contacting support, you will be asked to provide traces of your SS7 Software for Diva Interfaces application as well as of the CAPI and the Dialogic® Diva® Media Board. For more information, see [Tracing](#) on page 47 and see the corresponding chapter in the Dialogic® Diva® System Release LIN Reference Guide.

Chapter 10: Management Interface of the SSDD Process

The Dialogic® Diva® System Release LIN software provides a common management utility to access configuration, status, statistics and debugging information while running. The ssdd process has implemented a management interface which can be accessed with the standard Diva System Release method, see Dialogic® Diva® System Release LIN Reference Guide.

This chapter describes the parameters of the ssdd management interface.

- [Config Directory](#) on page 55
- [State Directory](#) on page 58
- [Statistics Directory](#) on page 60
- [License Directory](#) on page 64
- [Debug Directory](#) on page 65

The management interface of the ssdd has the logical board number 1021; this number is fixed on all systems. Accessing the management interface with the option `-c 1021` registers with the management interface of the ssdd.

Reading the root directory of the ssdd management interface:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"
```

will generate the following information:

```
-----hit-[MIF Version .....] = 0x117
-----asz-[Build .....] = 108-76 Sep  5 2008 12:59:13
-----asz-[StartUpTime .....] = Fri Sep  5 17:49:10 2008
-----dir-[Config .....]
-----dir-[State .....]
-----dir-[Statistics.....]
-----dir-[License .....]
-----dir-[Debug .....]
```

Values

- **MIF Version**
Identifies the version of the management information base
- **Build**
Displays available version information of the ssdd
- **StartUpTime**
Displays system time at start of the ssdd
- **Config**
Directory containing configuration information, see [Config Directory](#) on page 55
- **State**
Directory containing the current state of the ssdd, see [State Directory](#) on page 58
- **Statistics**
Directory containing available statistics of the ssdd, see [Statistics Directory](#) on page 60
- **License**
Directory containing extracted license information, see [License Directory](#) on page 64
- **Debug**
Directory containing and controlling the current debug state, see [Debug Directory](#) on page 65

10.1 Config Directory

Description

Via the config directory of the ssdd, you can retrieve configuration information received by the ssdd.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Config"
```

Output

```
-----dir-[Boards .....]
-----dir-[LIUs .....]
-----dir-[Links .....]
```

Values

- [Boards](#) on page 55
Directory containing board configuration information
- [LIUs](#) on page 56
Directory containing information about the line interface unit (LIU) configuration
- [Links](#) on page 57
Directory containing information about the signaling link configuration

10.1.1 Boards

Description

The boards directory lists configuration information about all configured boards.

When calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Config\Boards"
```

the boards that have been reset by the **SSD_MSG_RST_BOARD** or **DIVA_BOARD** command (see [Physical Interface Configuration Command](#) on page 44) are enumerated.

```
-----uit-[NumberBoards .....] = N
-----dir-[Board 1 .....]
...
-----dir-[Board N .....]
```

Where *N* is the number of boards reset.

Reading the configuration of a single board is described below.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Config\Boards\Board X"
```

where *X* is the Link management number.

Output (example)

```
-----int-[board_id .....] = 0
-----asz-[serial_number .....] = 1234
-----int-[board_type .....] = 81
-----int-[board_typeS .....] = Dialogic Diva V-4PRI/E1/T1-120 PCI v1
-----int-[number_of_LIUs .....] = 4
```

Values

- **board_id**
board_id as defined by the **SSD_BOARD_RESET** or **DIVA_BOARD** command.
- **serial_number**
serial_number as defined by the **SSD_BOARD_RESET** or **DIVA_BOARD** command.
- **board_type**
Dialogic® Diva® Media Board **board_type** as defined by **SSD_BOARD_RESET** or **DIVA_BOARD** command.
- **board_typeS**
Diva Media Board **board_type** as ASCII string.
- **number_of_LIUs**
Number of line interface unit(s) (LIU) of the board.

10.1.2 LIUs

Description

The LIUs directory lists configuration information about the configured line interface units (LIU).

When calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Config\LIUs"
```

the LIUs configured for signaling are enumerated:

```
-----uit-[NumberLIUs .....] = N
-----dir-[LIU 1 .....]
...
-----dir-[LIU N .....]
```

Where N is the number of LIUs.

Reading the configuration of a single LIU is described below.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Config\LIUs\LIU X"
```

where X is the LIU management number

Output (example)

```
-----int-[board_id .....] = 0
-----asz-[serial_number .....] = 1234
-----int-[liu_id .....] = 0
-----hit-[board_mgmt_id .....] = 0x8e
-----hit-[mtp2_module_id .....] = 0xff
```

Values

- **board_id**
Board ID of the Diva Media Board.
- **serial_number**
Serial number of the Diva Media Board.
- **liu_id**
LIU ID of this LIU.

- **board_mgmt_id**
Module ID of board management module.
- **mtp2_module_id**
Module ID of MTP2 module.

10.1.3 Links

Description

The links directory lists configuration information about all MTP2 links.

When calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Config\Links"
```

all configured links which were received in a **MGT_L1_CONFIG** request message are enumerated:

```
-----uit-[NumberOfLinks .....] = N
-----dir-[Link 1 .....]
...
-----dir-[Link N .....]
```

Where N is the number of links.

Reading the configuration of a single link is described below.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Config\Links\Link X"
```

where X is the LIU management number

```
Output (example)
-----int-[board_id .....] = 0
-----asz-[serial_number .....] = 1234
-----int-[liu_id .....] = 0
-----int-[llid .....] = 0
-----bit-[timeslotmask .....] = 0000:0000:0000:0000:1000:0000:0000:0000
-----bit-[channelBitMask .....] = 1111:1111
-----hit-[mtp2_module_id .....] = 0x71
-----asz-[mgt_msg_L1_config .....] =
I0000-t7f17-i0000-fcf-d8e-r8000-c00-s00-e00000000-p(040)000000000000000000000000
```

Values

- **board_id**
Board ID of the Diva Media Board.
- **serial_number**
Serial number of the Diva Media Board.
- **liu_id**
LIU ID of the Diva Media Board.
- **llid**
Logical link ID (llid) of the link.
- **timeslotmask**
Shows channel used for this link (example shows timeslot 16).
- **channelBitMask**
Shows bits utilized for this link (example shows all bits - 64k).

- **mtp2_module_id**
Module ID of MTP2 module.
- **mgt_msg_L1_config**
Displays **MGT_L1_CONFIG** request message.

10.2 State Directory

Description

The state directory gives hints when the stack is not working properly (e.g., CAPI link down).
Via the **State** directory, state information of the ssdd can be retrieved.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"State"
```

Output

```
-----dir-[Links .....]
```

Value

[Links](#) below

Directory containing information about the signaling link states

10.2.1 Links

Description

The links directory lists state information about all MTP2 links.

When calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"State\Links"
```

All configured links, the ssdd is maintaining, are enumerated:

```
-----uit-[NumberOfLinks .....] = N  
-----dir-[Link 1 .....]  
...  
-----dir-[Link N .....]
```

Where **N** is the number of links.

Reading the state of a single link is described below.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"State\Links\Link X"
```

where **x** is the link management number

Output (example)

```

-----int-[board_id .....] = 0
-----int-[liu_id .....] = 0
-----int-[llid .....] = 0
-----hit-[LastPrimitiveRX .....] = 0x8f01
-----hit-[LastPrimitiveTX .....] = 0xcf00
-----int-[MaxDataB3Req .....] = 2
-----int-[CurrentDataB3Req .....] = 0
-----int-[maxMsgCapiReq .....] = 0
-----int-[CurrentMsgCapiReq .....] = 0
-----int-[CapiState .....] = 2
-----asz-[CapiStateS .....] = CONNECTED
-----asz-[ChangeTime .....] = Mon Sep 8 09:27:03
    
```

Values

- **board_id**
Board ID of the Diva Media Board.
- **liu_id**
LIU ID of the Diva Media Board.
- **llid**
Logical link ID (llid) of the link.
- **LastPrimitiveRX**
Shows the message type of the last primitive received from the board.
In this example: 0x8f01 - **API_MSG_RX_IND**
- **LastPrimitiveTX**
Shows the message type of the last primitive sent to the board.
In this example: 0xcf00 - **API_MSG_TX_REQ**
- **MaxDataB3Req**
Maximum number of CAPI requests of the link queued towards the board.
- **CurrentDataB3Req**
Current number of CAPI requests of the link queued towards the board.
- **MaxMsgCapiReq**
Maximum number of Dialogic® DSI primitives in CAPI request of the link queued towards the board.
- **CurrentMsgCapiReq**
Current number of Dialogic® DSI primitives in CAPI request of the link queued towards the board.
- **CapiState**
Current CAPI state.
- **CapiStateS**
Current CAPI state as ASCII string.
- **ChangeTime**
System time when entered the above state.

10.3 Statistics Directory

Description

The statistics directory gives further hints when the stack is not working properly (load balancing, ...).

Via the statistics directory of the ssdd, information about the number of messages/octetets received or transmitted is retrieved. The values can be reset.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Statistics"
```

Output

```
-----dir-[All .....]
-----dir-[Boards .....]
-----dir-[LIUs .....]
-----dir-[Links .....]
```

Values

- [All on page 60](#)
The **All** directory lists the numbers of all links.
- [Boards on page 61](#)
The **Boards** directory lists the numbers of all links running on that board.
- [LIUs on page 62](#)
The **LIUs** directory lists the numbers of all links running on that line interface unit (LIU).
- [Links on page 63](#)
The **Links** directory lists the numbers of the corresponding links.

10.3.1 All

Description

The **All** directory lists the statistics numbers of all links maintained by ssdd.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Statistics\All"
```

Output (example)

```
-----int-[NumberPrimitivesRX .....] = 16
-----int-[NumberPrimitivesTX .....] = 28
-----int-[NumberOctetsRX .....] = 388
-----int-[NumberOctetsTX .....] = 388
-----fn -[Reset .....]
```

Values

- **NumberPrimitivesRX**
Total number of Dialogic® DSI primitives received from all link instances maintained by ssdd.
- **NumberPrimitivesTX**
Total number of Dialogic® DSI primitives sent to all link instances maintained by ssdd.

- **NumberOctetsRX**

Total number of octets in Dialogic® DSI primitives received from all link instances maintained by ssdd.

- **NumberOctetsTX**

Total number of octets in Dialogic® DSI primitives sent to all link instances maintained by ssdd.

- **Reset**

Function call to reset all statistics numbers of all link instances maintained by ssdd:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -e"Statistics\All\Reset"
```

10.3.2 Boards

Description

The **Boards** directory lists the total number of all links maintained by the ssdd running on that board.

When calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Statistics\Boards"
```

All boards are enumerated:

```
-----uit-[NumberBoards .....] = N
-----dir-[Board 1 .....]
...
-----dir-[Board N .....]
```

Where N is the number of boards.

Reading the statistics of a single board is described below.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Statistics\Boards\Board X"
```

where x is the board management number

Output (example)

```
-----int-[board_id .....] = 0
-----int-[NumberPrimitivesRX .....] = 16
-----int-[NumberPrimitivesTX .....] = 28
-----int-[NumberOctetsRX .....] = 388
-----int-[NumberOctetsTX .....] = 388
-----fn -[Reset .....]
```

Values

- **board_id**

Board ID as received in the **SSD_BOARD_RESET** request message.

- **NumberPrimitivesRX**

Total number of Dialogic® DSI primitives received from link instances assigned to the board and maintained by ssdd.

- **NumberPrimitivesTX**

Total number of Dialogic® DSI primitives sent to all link instances assigned to the board and maintained by ssdd.

- **NumberOctetsRX**

Total number of octets in Dialogic® DSI primitives received from all link instances assigned to the board and maintained by ssdd.

- **NumberOctetsTX**

Total number of octets in Dialogic® DSI primitives sent to all link instances assigned to the board and maintained by ssdd.

- **Reset**

Function call to reset all statistics numbers of all link instances assigned to the board and maintained by ssdd.

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -e"Statistic\Boards\Board X \Reset"
```

Note: The numbers of all link instances maintained by ssdd will be reset to 0.

10.3.3 LIUs

Description

The LIUs directory lists the total number of all links maintained by the ssdd running on that line interface unit (LIU).

When calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Statistics\LIUs"
```

The LIUs configured to be used for signaling are enumerated:

```
-----uit-[NumberLIUs .....] = N
-----dir-[LIU 1 .....]
...
-----dir-[LIU N .....]
```

Where N is the number of LIUs.

Reading the statistics of a single LIU is described below.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Statistics\LIUs\LIU X"
```

where X is the LIU management number.

Output (example)

```
-----int-[board_id .....] = 0
-----int-[liu_id .....] = 0
-----int-[NumberPrimitivesRX .....] = 6
-----int-[NumberPrimitivesTX .....] = 12
-----int-[NumberOctetsRX .....] = 172
-----int-[NumberOctetsTX .....] = 172
-----fn -[Reset .....]
```

Values

- **board_id**

board_id, reference to the board

- **liu_id**

LIU id of this LIU

- **NumberPrimitivesRX**

Total number of Dialogic® DSI primitives received from link instances assigned to that LIU and maintained by ssdd.

- **NumberPrimitivesTX**

Total number of Dialogic® DSI primitives sent to all link instances assigned to that LIU and maintained by ssdd.

- **NumberOctetsRX**

Total number of octets in Dialogic® DSI primitives received from all link instances assigned to that LIU and maintained by ssdd.

- **NumberOctetsTX**

Total number of octets in Dialogic® DSI primitives sent to all link instances assigned to that LIU and maintained by ssdd.

- **Reset**

Function call to reset all statistics numbers of all link instances assigned to that LIU and maintained by ssdd.

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -e"Statistics\LIUs\LIU X \Reset"
```

10.3.4 Links

Description

The links directory lists the statistics numbers of each MTP2 link maintained by ssdd.

When calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Statistics\Links"
```

all configured links which were received in a **MGT_L1_CONFIG** request message are enumerated:

```
-----uit-[NumberOfLinks .....] = N
-----dir-[Link 1 .....]
...
-----dir-[Link N .....]
```

Where N is the number of links.

Reading the statistics of a single link is described below.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Statistics\Links\Link X"
```

where x is the link management number.

Output (example)

```
-----int-[board_id .....] = 0
-----int-[liu_id .....] = 0
-----int-[llid .....] = 0
-----int-[NumberPrimitivesRX .....] = 3
-----int-[NumberPrimitivesTX .....] = 6
-----int-[NumberOctetsRX .....] = 86
-----int-[NumberOctetsTX .....] = 86
-----fn -[Reset .....]
```

Values

- **board_id**

Board ID referencing to the board.

- **liu_id**

LIU ID referencing to the LIU of the board.

- **llid**

Logical link ID (llid) of the link.

- **NumberPrimitivesRX**

Total number of Dialogic® DSI primitives received from this link instance.

- **NumberPrimitivesTX**

Total number of Dialogic® DSI primitives sent to this link instance.

- **NumberOctetsRX**

Total number of octets in Dialogic® DSI primitives received from this link instance.

- **NumberOctetsTX**

Total number of octets in Dialogic® DSI primitives sent to this link instance.

- **Reset**

Function call to reset the statistic numbers of this link instance.

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -e"Statistic\Links\Link X \Reset"
```

10.4 License Directory

Description

Via the license directory of the ssdd, the current license status can be obtained.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"License"
```

Output (example)

```
-----asz-[HostId .....] = 00123456789A
-----uit-[NumberOfLinks .....] = 4
-----uit-[NumberOfLinksInUse .....] = 4
-----asz-[LicensePath .....] = ./
-----bol-[TestMode .....] = FALSE
```

Values

- **HostId**

Displays the host ID of the system.

- **NumberOfLinks**

If a valid license is found, **NumberOfLinks** displays the number of licensed MTP2 links.

- **NumberOfLinksInUse**

Number of links currently configured.

- **LicensePath**

Path to license found.

- **TrialMode**

Indicates if running in test mode (ssdd -t).

10.5 Debug Directory

Description

Via the debug directory, the debug information of the ssdd written into the Dialogic® Diva® System Release standard tracing utilities (see the Dialogic® Diva® System Release Software Reference Guide) can be controlled.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Debug"
```

Output (example)

```
-w-----hit-[debug_mask .....] = 0x47
-----fn -[DebugStop .....]
```

Values

- **debug_mask**

Current debug mask.

Bit	Meaning
0	Initialisation and state changes
1	Errors
2	Warnings
3	Internal status changes
4	Protocol wrapper
5	Internal verbose
6	Messages/primitives
7	-
8	CAPI - NCCI state machine
9	CAPI - PLCI state machine
10	CAPI - controller state machine
11	Memory allocation
12	Timer handling

Note: The trace mask used on live systems, should not define more than bit 0, 1, and 2 since it may harm the overall system performance significantly. The -d option is intended for use during fault finding on a system that has not been configured correctly.

The value of the debug_mask can be changed during runtime:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -w"Debug\debug_mask=0x7"
```

will change the current debug mask to 0x7 (initialisation and state changes AND errors AND warnings)

- **DebugStop/DebugStart**

Enables or disables debugging.

When debugging is enabled, **DebugStop** will be displayed. By calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -e"Debug\DebugStop"
```

debugging may be disabled.

When debugging is disabled, **DebugStart** will be displayed. By calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -e"Debug\DebugStart"
```

debugging may be enabled.

Chapter 11: Management Interface of the DVSCC Process

The Dialogic® Diva® System Release LIN provides a common management utility to access the configuration, status, statistics, and debugging information while it is running. The Diva Virtual Signaling Call Control (DVSCC) has implemented a management interface that can be accessed with the standard Diva System Release method, see the Dialogic® Diva® System Release LIN Reference Guide for more information.

This chapter describes the parameters of the DVSCC management interface:

- [Config directory](#) on page 67
- [State directory](#) on page 71
- [Statistics directory](#) on page 78
- [Debug Directory](#) on page 84

The management interface of the DVSCC has the board number 1022, this number is fix on all systems. Accessing the management interface with the option "-c 1022" registers with the management interface of the DVSCC.

Reading the root directory of the DVSCC management interface:

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"
```

will generate the following information:

```
-----hit-[MIF Version .....] = 0x115
-----asz-[Build .....] = 108-67 Oct 29 2008 18:53:35
-----dir-[Config .....]
-----dir-[State .....]
-----dir-[Statistics .....]
-----dir-[Debug .....]
```

Values

- **MIF Version**
Identifies the version of the management information base.
- **Build**
Displays available version information of the DVSCC.
- **Config**
Directory containing configuration information, see page 67.
- **State**
Directory containing the current state of the DVSCC, see page 71.
- **Statistic**
Directory containing available statistics of the DVSCC, see page 78.
- **Debug**
Directory containing and controlling the current debug state, see page 84.

11.1 Config directory

Description

Via the Config directory, you can retrieve the configuration information of DVSCC.

DVSCC reads its configuration from the common config.txt file. Some specific values of the configuration are not configurable by the standard mechanism; the corresponding values are explicitly mentioned in the description.

Syntax

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"Config"
```

Output

```
-----dir-[Trunks .....]  
-----dir-[CICs .....]  
-w-----uit-[utilizeCHI .....] = 0  
-w-----uit-[BCI_ChargeInd .....] = 0  
-w-----uit-[BCI_CalledPartC .....] = 0
```

Values

- **Trunks**

Directory contains the configuration information of all trunks.

- **CICs**

Directory contains the configuration information of all CICs.

- **utilizeCHI**

When configured, it tries to fulfill the channel request from the user.

Values:

0 - Specific channel requests of the user are ignored (default).

1 - DVSCC tries to fulfill the channel request from the user.

When the channel is already taken or on dual seizure, the channel request is ignored and the next free bearer channel is utilized.

Note: The value can only be set by writing this variable.

- **BCI_ChargeInd**

The value of the Charge Indicator (bit 0,1 of the backward call indicator) in the ACM (address complete message).

Values:

0 - no indication (default)

1 - no charge

2 - charge

Note: The value can only be set by writing this variable.

- **BCI_CalledPartC**

The value of the Called Party's Category Indicator (bit 4, 5 of the backward call indicator) in the ACM (Address Complete Message).

Values:

0 – no indication (default)

1 – ordinary subscriber

2 – payphone (value can only be set by writing this variable)

11.1.1 Trunks directory

Description

The Trunks directory enumerates the configuration information about all configured trunks.

When calling:

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"Config\Trunks"
```

```
-----uit-[NumberTrunks .....] = N
```

```
-----dir-[Trunk 1 .....]
```

```
...
```

```
-----dir-[Trunk N .....]
```

Where *N* is the number of Trunks configured.

Reading the configuration of a single trunk is described below.

Syntax

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"Config\Trunks\Trunk X"
```

Where *x* is the board management number.

Output (example)

```
-----int-[CapiController .....] = 2
```

```
-----asz-[SerialNumber .....] = 1008-0
```

```
-----int-[BoardId .....] = 0
```

```
-----int-[LiuId .....] = 0
```

```
-----int-[GID .....] = 0
```

```
-----int-[OPC .....] = 129
```

```
-----int-[DPC .....] = 130
```

```
-----asz-[ProtocolVariantS .....] = 1-ITU92
```

```
-----asz-[ConformanceS .....] = ITU(03/93 and later)
```

```
-----asz-[NetworkIndicatorS .....] = 0x08-national network
```

```
-----asz-[L1CodingS .....] = a-law
```

Values

- **CapiController**

CAPI controller number of the trunk.

- **SerialNumber**

Serial number of the Dialogic® Diva® Media Board.

- **BoardId**

Board ID of the Diva Media Board.

- **LiuId**

Line Interface Unit Identifier of the trunk on the Diva Media Board.

- **GID**
Group ID of the circuit group (the circuits assigned to the trunk).
- **OPC**
Originating Point Code of the circuit group.
- **DPC**
Destination Point Code of the circuit group.
- **ProtocolVariants**
Protocol variant of the circuit group as string.
- **Conformances**
Conformance string, subvariant of the protocol of that circuit group.
- **NetworkIndicators**
Network Indicator string of the circuit group.
- **L1CodingS**
L1 coding string of the trunk (read from the Dialogic® Diva® System Release configuration).

11.1.2 CICs directory

Description

The CICs directory lists the configuration information about the configured CICs.

When calling:

```
/usr/lib/opendivas/diva/divactrl mantool -c 1022 -r"Config\CICs"
-----uit-[NumberCICs .....] = N
-----dir-[CIC 1 .....]
...
-----dir-[CIC N .....]
```

Where *N* is the number of CICs configured.

Reading the configuration of one CIC is described below.

Syntax

```
/usr/lib/opendivas/diva/divactrl mantool -c 1022 -r"Config\CICs\CIC X"
```

Where *x* is the board number.

Output (example)

```
-----int-[CIC .....] = 1
-----int-[GID .....] = 1
-----int-[CID .....] = 1
-----int-[OPC .....] = 129
-----int-[DPC .....] = 130
-----asz-[SerialNumber .....] = 1008-0
-----int-[BoardId .....] = 0
```

```
-----int-[LiuId .....] = 0
-----int-[Timeslot .....] = 1
```

Values

- **CIC**
Circuit Identification Code
- **GID**
Group ID to which the circuit belongs.
- **CID**
Circuit identifier of the circuit.
- **OPC**
Originating Point Code of the circuit.
- **DPC**
Destination Point Code of the circuit.
- **SerialNumber**
Serial number of the Dialogic® Diva® Media Board that administers the timeslot of the circuit.
- **BoardId**
Board ID of the Diva Media Board that administers the timeslot of the circuit.
- **LiuId**
Line Interface Unit Identifier of the trunk that administers the timeslot of the circuit.
- **Timeslot**
Timeslot of the circuit.

11.2 State directory

Description

The State directory shows the current state of the DVSCC; additionally it gives hints if the stack is not working properly (e.g., CAPI connection down).

Via the State directory, state information of the DVSCC can be retrieved.

Syntax

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"State"
```

Output

```
-----asz-[StartUpTime .....] = Fri Oct 31 10:02:00 2008
-----dir-[Trunks .....]
-----dir-[CICs .....]
```

Value

- **StartUpTime**

Displays system time at DVSCC start.

- **Trunks**

Directory containing information about the current state of all trunks.

- **CICs**

Directory containing information about the current state of all CICs.

11.2.1 Trunks directory

Description

The Trunks directory lists state information about all trunks.

When calling:

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"State\Trunks"
-----uit-[NumberTrunks .....] = N
-----dir-[Trunk 1 .....]
...
-----dir-[Trunk N .....]
```

Where N is the number of trunks configured.

Reading the state of a single trunk is described below.

Syntax

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"State\Trunks\Trunk X"
```

Where x is the board number.

Output (example)

```
-----int-[CapiController .....] = 2
-----asz-[SerialNumber .....] = 1008-0
-----int-[BoardId .....] = 0
-----int-[LiuId .....] = 0
-----int-[GID .....] = 1
-----dir-[CAPI .....]
-----bit-[TimeslotConfigured .....] =0111:1111:1111:1111:0111:1111:1111:1111
-w-----bit-[LocMaintBlockState .....] =0000:0000:0000:0000:0000:0000:0000:0000
-----bit-[LocHWBlockState .....] =0000:0000:0000:0000:0000:0000:0000:0000
-----dir-[SpecLocHWBlockState .....]
-----dir-[L1State .....]
-----dir-[ConnState .....]
-----fn -[GRS .....]
```

```
-w-----bit-[RSC_ByOperator .....] =0000:0000:0000:0000:0000:0000:0000:0000
-----bit-[RemoteMaintBlocked .....] =0000:0000:0000:0000:0000:0000:0000:0000
-----bit-[RemoteHWBlocked .....] =0000:0000:0000:0000:0000:0000:0000:0000
-----bit-[ActiveState .....] =0111:1111:1111:1111:0111:1111:1111:1111
-----bit-[WaitForGRA .....] =0000:0000:0000:0000:0000:0000:0000:0000
```

Values

- **CapiController**
 CAPI controller number of the trunk.
- **SerialNumber**
 Serial number of the Dialogic® Diva® Media Board.
- **BoardId**
 Board ID of the Diva Media Board.
- **LiuId**
 Line Interface Unit Identifier of the trunk on the Diva Media Board.
- **GID**
 Group ID of the circuit group (the circuits assigned to the trunk).
- **CAPI**
 The CAPI directory as described on page 74.
- **TimeslotConfigured**
 Bitmask representing the timeslots utilized by circuits administered by this trunk (bit 0 represents timeslot 1).
- **LocMaintBlockState**
 Bitmask representing the current local maintenance blocking state (bit 0 represents timeslot 1). The local maintenance blocking state may be changed by writing a new value. The following command will set all circuits administered by this trunk to local maintenance blocked:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1022 -w"State/Trunks/Trunk X/LocMaintBlockState=0x7fffffff".
```
- **LocHWBlockState**
 Bitmask representing the current local hardware blocking state (bit 0 represents timeslot 1).
- **SpecLocHWBlockState**
 The special local hardware blocking state directory. For more information, see page 71.
- **L1State**
 Directory details the L1 state as described on page 75.
- **ConnState**
 Directory containing the current state of the CAPI connection to the trunk.
- **GRS**
 Circuit group reset function. When called, the DVSCC will issue a GRS command to ISUP for the circuit group of the circuits assigned to the trunk.

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1022 -e"State/Trunks/Trunk 1/GRS".
```

- **RSC_ByOperator**

Bitmask to reset a single circuit. Setting one bit of this bitmask will issue an RSC command to ISUP for the circuit allocated to the timeslot (bit 0, represents timeslot 1).

The command:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1022 -w"State/Trunks/Trunk X/RSC_ByOperator=0x4"
```

will cause an RSC message to be generated for the circuit assigned to timeslot 3 of the corresponding trunk.

Note: Only one bit can be set.

- **RemoteMaintBlocked**

Bitmask representing the current remote maintenance blocking state (bit 0 represents timeslot 1).

- **RemoteHWBlocked**

Bitmask representing the current remote hardware blocking state (bit 0 represents timeslot 1).

- **ActiveState**

Bitmask representing the current signaling state (bit 0 represents timeslot 1).

0 - paused

1 - active

- **WaitForGRA**

Bitmask indicating that the circuit is not available for communication, because a GRA is awaited (bit 0 represents timeslot 1).

11.2.2 CAPI directory

Description

The CAPI directory shows the available CAPI information.

Syntax

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"State/Trunks/Trunk 1/CAPI"
```

shows CAPI state.

Output (example)

```
-----asz-[LastMsgRX .....] = IND_DATA_B3_IND
```

```
-----asz-[LastMsgTX .....] = REQ_NULL
```

```
-----int-[MaxDataB3Req .....] = 1
```

Values

- **LastMSGRX**

Shows the message type of the last message received from the CAPI.

In this example: 0x8f01 - API_MSG_RX_IND.

- **LastMSGTX**

Shows the message type of the last message sent to the CAPI.

In this example: 0xcf00 - API_MSG_TX_REQ.

- **MaxDataB3Req**

Maximum number of CAPI requests of the link that are queued towards the CAPI.

11.2.3 SpecLocHWBlockState directory

Description

The SpecLocHWBlockState directory shows the reason for the local hardware blocking state. It enables the setting of the local hardware blocking state.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1022 -r"State/Trunks/Trunk X/SpecLocHWBlockState"
```

Output (example)

```
-w-----bit-[ByOperator .....] =0000:0000:0000:0000:0000:0000:0000:0000
-----bit-[ByResourceUnavail .....] =0000:0000:0000:0000:0000:0000:0000:0000
```

Values

- **ByOperator**

Bitmask representing the current local hardware blocking state set by the operator (bit 0 represents timeslot 1).

The operator may change it by writing a new value.

The following command will set all circuits administered by this trunk to local hardware blocked (byOperator):

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1022 -w"State/Trunks/Trunk
X/SpecLocHWBlockState/ByOperator=0x7fffffff"
```

Note: A hardware blocking request for a single circuit cannot be communicated and is therefore ignored.

- **ByResourceUnavail**

Bitmask representing the current local hardware blocking state caused by Layer 1 errors (bit 0 represents timeslot 1).

11.2.4 L1State directory

Description

The L1State directory shows the available layer 1 information.

Syntax

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"State/Trunks/Trunk 1/L1State"
```

shows the CAPI state.

Output (example)

```
-----int-[EventReporting .....] = 0
-----asz-[StateS .....] = Activated
-----asz-[TimeOfLastStateChange .....] = Tue Nov 18 07:07:05 2008
```

Values

- **EventReporting**

Indicating if management reporting is enabled. When disabled, layer 1 events are not reported and the DVSCC assumes that layer 1 is always activated.

- **StateS**

Current layer 1 state as ASCII string.

- **TimeOfLastStateChange**

System time when layer 1 entered the above state.

11.2.5 ConnState directory

Description

The ConnState directory displays the state of the CAPI connection to the Dialogic® Diva® Media Board.

Syntax

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"State/Trunks/Trunk 1/ConnState"
```

Output (example)

```
-----int-[State .....] = 1
-----asz-[TimeOfLastStateChange .....] = Tue Nov 18 07:07:05 2008
```

Values

- **State**

Current state of the CAPI connection to the Diva Media Board.

Values:

0 - not connected

1 - connected

- **TimeOfLastStateChange**

System time when entered the above state.

11.2.6 CICs directory

Description

The CICs directory lists state information about the configured CICs.

When calling:

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"State\CICs"
```

```
-----uit-[NumberCICs .....] = N
```

```
-----dir-[CIC 1 .....]
```

...

```
-----dir-[CIC N .....]
```

Where N is the number of CICs configured.

Reading the configuration of a single CIC is described below.

Syntax

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"State\CICs\CIC X"
```

Where x is the CIC number.

Output (example)

```

-----int-[CIC .....] = 1
-----int-[GID .....] = 0
-----int-[CID .....] = 1
-----int-[OPC .....] = 130
-----int-[DPC .....] = 129
-----int-[BoardId .....] = 1
-----int-[LiuId .....] = 1
-----int-[Timeslot .....] = 1
-w-----int-[LocMaintBlockState .....] = 0
-----int-[LocHWBlockState .....] = 0
-----dir-[SpecLocHWBlockState .....]
-----int-[RemoteMaintBlocked .....] = 0
-----int-[RemoteHWBlocked .....] = 0
-----bol-[ActiveState .....] = TRUE
-----bol-[WaitForGRA .....] = FALSE
    
```

Values

- **CIC**
Circuit Identification Code
- **GID**
Group ID to which the circuit belongs.
- **CID**
Circuit ID of the circuit.
- **OPC**
Originating point code of that circuit.
- **DPC**
Destination point code of that circuit.
- **Timeslot**
Timeslot the circuit is assigned to on the corresponding trunk, which is hidden behind the GID.
- **LocMaintBlockState**
Current Local Maintenance blocking state of the circuit.
The state can be changed:
`/usr/lib/opensiva/divas/divactrl mantool -c 1022 -w"State/CICs/CIC X/LocMaintBlockState=1".`
This will set local maintenance blocking for that circuit.
- **LocHWBlockState**
Current local hardware blocking state of the circuit.
- **SpecLocHWBlockState**
The special local hardware blocking state directory gives more specific information on page 78.

- **RemoteMaintBlocked**

Current value of the remote maintenance blocking state of the circuit.

- **RemoteHWBlocked**

Current value of the remote hardware blocking state of the circuit.

- **ActiveState**

Current signaling state of that circuit (TRUE = active, FALSE = paused).

- **WaitForGRA**

Indicating that the circuit is not available for communication because a GRA is awaited.

11.2.7 SpecLocHWBlockState directory

Description

The SpecLocHWBlockState directory shows the reason of the local hardware blocking state.

Syntax

```
/usr/lib/opendiva/divas/divactrl mantool -c 1022 -r"State/CICs/CIC X/SpecLocHWBlockState"
```

Output (example)

```
-----int-[ByOperator .....] =0  
-----int-[ByResourceUnavail .....] =0
```

Values

- **ByOperator**

Current Local Hardware blocking state of the circuit caused by operator blocking.

- **ByResourceUnavail**

Current Local Hardware blocking state of the circuit caused by layer 1 not active.

11.3 Statistics directory

Description

The Statistics directory gives a quick overview of the throughput call success or failure since startup.

Syntax

```
/usr/lib/opendivas/diva/divactrl mantool -c 1022 -r"Statistics"
```

Output

```
-----dir-[All .....]  
-----dir-[Trunks .....]  
-----dir-[CICs .....]
```

Values

- **All**
Statistics of the system (see page 79).
- **Trunks**
The combined statistics of all circuits of the corresponding trunk (see page 80).
- **CICs**
Statistic information of the corresponding circuit (see page 81).

11.3.1 All

Description

The All directory lists the condensed statistic numbers.

Syntax

```
/usr/lib/opendivas/diva/divactrl mantool -c 1022 -r"Statistic\All"
```

Output (example)

```
-----int-[OutGoodCounter .....] = 0
-----int-[OutFailCounter .....] = 0
-----int-[InGoodCounter .....] = 0
-----int-[InFailCounter .....] = 0
-----int-[CauseE6Counter .....] = 0
-----int-[Cause9FCounter .....] = 0
-----int-[InCollisions .....] = 0
-----int-[OutFailNoTerm .....] = 0
-----fn -[ResetStatistics .....]
```

Values

- **OutGoodCounter**
Total number of outgoing good completed calls of all circuits.
- **OutFailCounter**
Total number of outgoing failed calls of all circuits.
- **InGoodCounter**
Total number of incoming good completed calls of all circuits.
- **InFailCounter**
Total number of incoming failed calls of all circuits.
- **CauseE6Counter**
Total number of failed calls with reason "recover on timer expiry" (0xE6) of all circuits.
- **Cause9FCounter**
Total number of failed calls with reason "normal, unspecified" (0x9F) of all circuits.

- **InCollisions**

Total number of call collisions indicated by ISUP of all circuits.

Note: Call collisions may be resolved (configuration see ISUP Programmers's Manual, "Configure Circuit Group Request", options bit0,1).

- **OutFailNoTerm**

Total number of outgoing calls failed when "circuit available/no channel available" (0xA2) or "no route to destination" (0x83) of all circuits.

- **ResetStatistics**

Reset all counters of all circuits.

11.3.2 Trunks

Description

The Trunks directory lists statistic information about all trunks.

When calling:

```
/usr/lib/opendivas/diva/divactrl mantool -c 1022 -r"Statistics\Trunks"
-----uit-[NumberTrunks .....] = N
-----dir-[Trunk 1 .....]
...
-----dir-[Trunk N .....]
```

Where N is the number of trunks configured.

Reading the statistics of a single trunk is described below.

Syntax

```
/usr/lib/opendivas/diva/divactrl mantool -c 1022 -r"Statistics\Trunks\Trunk X"
```

Where x is the trunk number.

Output (example)

```
-----asz-[SerialNumber .....] = 1008-2
-----int-[BoardId .....] = 0
-----int-[LiuId .....] = 1
-----int-[OutGoodCounter .....] = 2078375
-----int-[OutFailCounter .....] = 0
-----int-[InGoodCounter .....] = 2769376
-----int-[InFailCounter .....] = 0
-----int-[CauseE6Counter .....] = 0
-----int-[Cause9FCounter .....] = 0
-----int-[InCollisions .....] = 856
-----int-[OutFailNoTerm .....] = 87
-----fn -[ResetStatistics .....]
```

Values

- **SerialNumber**
Serial number of the Dialogic® Diva® Media Board.
- **BoardId**
Board ID of the Diva Media Board.
- **LiuId**
Line Interface Unit Identifier of the trunk on the Diva Media Board.
- **OutGoodCounter**
Total number of outgoing good completed calls of all circuits on that trunk.
- **OutFailCounter**
Total number of outgoing failed calls of all circuits on that trunk.
- **InGoodCounter**
Total number of incoming good completed calls of all circuits on that trunk.
- **InFailCounter**
Total number of incoming failed calls of all circuits on that trunk.
- **CauseE6Counter**
Total number of failed calls with reason "recover on timer expiry" (0xE6) of all circuits on that trunk.
- **Cause9FCounter**
Total number of failed calls with reason "normal, unspecified" (0x9F) of all circuits on that trunk.
- **InCollisions**
Total number of call collisions indicated by ISUP of all circuits on that trunk.
Note: Call collisions may be resolved (For the configuration, see the ISUP Programmers's Manual, "Configure Circuit Group Request", options bit 0,1).
- **OutFailNoTerm**
Total number of outgoing calls failed when "circuit available/no channel available" (0xA2) or "no route to destination" (0x83) of all circuits on that trunk.
- **ResetStatistics**
Reset all counters of all circuits on that trunk.

11.3.3 CICs

Description

The CICs directory lists statistic information of all CICs.

When calling:

```
/usr/lib/opencv/divas/diva/divactrl mantool -c 1022 -r"Statistics\CICs"  
-----uit-[NumberCICs .....] = N  
-----dir-[CIC 1 .....]  
...  
-----dir-[CIC N .....]
```

Where N is the number of CICs configured.

Reading the statistics of a single CIC is described below.

Syntax

```
/usr/lib/opensdivas/diva/divactrl mantool -c 1022 -r"Statistics\CICs\CIC X"
```

Where x is the Diva Media Board number.

Output (example)

```
-----int-[Timeslot .....] = 1
-----int-[CIC .....] = 1
-----int-[GID .....] = 0
-----int-[CID .....] = 1
-----uit-[SigState .....] = 0
-----hit-[LastMsgToCapi .....] = 0x4d
-----asz-[LastMsgToCapiS .....] = REL
-----hit-[LastMsgFromCapi .....] = 0x5a
-----asz-[LastMsgFromCapiS .....] = REL_COM|REL_ACK
-----int-[OutGoodCounter .....] = 80056
-----int-[OutFailCounter .....] = 0
-----int-[InGoodCounter .....] = 79567
-----int-[InFailCounter .....] = 0
-----int-[CauseCountE6 .....] = 0
-----int-[CauseCount9F .....] = 0
-----int-[InCollisions .....] = 0
-----hit-[Cause0 .....] = 0x0
-----hit-[Cause1 .....] = 0x0
-----hit-[Cause2 .....] = 0x0
-----hit-[Cause3 .....] = 0x0
-----hit-[Cause4 .....] = 0x0
-----hit-[Cause5 .....] = 0x0
-----hit-[Cause6 .....] = 0x0
-----hit-[Cause7 .....] = 0x0
-----hit-[Cause8 .....] = 0x0
-----hit-[Cause9 .....] = 0x0
-----fn -[ResetStatistics .....]
```

Values

- **Timeslot**

Timeslot of the circuit.

- **CIC**

Circuit Identification Code of the circuit.

- **GID**
Group ID to which the circuit belongs.
- **CID**
Circuit ID of the circuit.
- **SigState**
Current CAPI signaling state.
- **LastMsgToCapi**
Last message request to CAPI as hexadecimal value.
- **LastMsgToCapiS**
Last message request to CAPI as ASCII string.
- **LastMsgFromCapi**
Last message indication from CAPI as hexadecimal value.
- **LastMsgFromCapiS**
Last message indication from CAPI as ASCII string.
- **OutGoodCounter**
Total number of outgoing good calls completed for this circuit.
- **OutFailCounter**
Total number of outgoing failed calls from for this circuit.
- **InGoodCounter**
Total number of incoming good calls completed for this circuit.
- **InFailCounter**
Total number of incoming failed calls for this circuit.
- **CauseE6Counter**
Total number of failed calls with reason "recover on timer expiry" (0xE6) for this circuit.
- **Cause9FCounter**
Total number of failed calls with reason "normal, unspecified" (0x9F) for this circuit.
- **InCollisions**
Total number of call collisions indicated by ISUP for this circuit.
Note: Call collisions may be resolved (For configuration, see the ISUP Programmers's Manual, "Configure Circuit Group Request", options bit 0,1).
Cause0..9
Last 10 causes received other than normal call clearing for this circuit.
- **ResetStatistics**
Reset all counters of this CIC.

11.4 Debug Directory

Description

Via the Debug directory, the debug information of the DVSCC written into the Dialogic® Diva® System Release standard tracing utilities (see the Dialogic® Diva® System Release Software Reference Guide) can be controlled.

Syntax

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -r"Debug"
```

Output (example)

```
-w-----hit-[debug_mask .....] = 0x47
-----fn -[DebugStop .....]
```

Values

- **debug_mask**

Current debug mask.

Bit	Meaning
0	Initialisation and state changes
1	Errors
2	Warnings
3	Internal status changes
4	Protocol wrapper
5	Internal verbose
6	Messages/primitives
7	-
8	CAPI - NCCI state machine
9	CAPI - PLCI state machine
10	CAPI - controller state machine
11	Memory allocation
12	Timer handling

Note: The trace mask used on live systems, should not define more than bit 0, 1, and 2 since it may harm the overall system performance significantly. The -d option is intended for use during fault finding on a system that has not been configured correctly.

The value of the debug_mask can be changed during runtime:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -w"Debug\debug_mask=0x7"
```

will change the current debug mask to 0x7 (initialisation and state changes AND errors AND warnings)

- **DebugStop/DebugStart**

Enables or disables debugging.

When debugging is enabled, **DebugStop** will be displayed. By calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -e"Debug\DebugStop"
```

debugging may be disabled.

When debugging is disabled, **DebugStart** will be displayed. By calling:

```
/usr/lib/opensdiva/divas/divactrl mantool -c 1021 -e"Debug\DebugStart"
```

debugging may be enabled.

Chapter 12: Examples of the Default Configuration Files

This chapter provides examples and explanations of the default Dialogic® SS7 Software for Dialogic® Diva® Interfaces configuration files (system.txt, config.txt).

```

*****
*
* Example System Configuration File (system.txt) for use with
* Dialogic(R) Diva (R) SS7
*
* Edit this file to reflect your configuration.
*
*****
*
*
* Essential modules running on host:
*
LOCAL  0x22    * MTP3 module
LOCAL  0x23    * ISUP module
LOCAL  0x20    * ssdd - Board interface task
LOCAL  0x4d    * dvscc - Diva Virtual Signalling Call Control
*                transfers ISDN to ISUP and vice versa
LOCAL  0x00    * tim_lnx6 - Timer task
LOCAL  0xcf    * s7_mgt - Management/config task
*
* Optional modules running on the host:
*
LOCAL  0xef    * s7_log - Display and logging utility
*
* Essential modules running on the board (all redirected via ssd):
*
REDIRECT 0x71 0x20    * MTP2 module (except SS7HD boards)
REDIRECT 0x10 0x20    * CT bus/Clocking control module
REDIRECT 0x8e 0x20    * On-board management module
*
*
* Redirection of status indications:
*
REDIRECT 0xdf 0xef    * LIU/MTP2 status messages -> s7_log
*
*
* Dimensioning the Message Passing Environment:
*
NUM_MSGS 65000      * Number of standard size
*                messages in the environment
*
*
*Now start-up all local tasks:
FORK_PROCESS ./ssdd
FORK_PROCESS ./dvscc
FORK_PROCESS ./tim_lnx
FORK_PROCESS ./tick_lnx
FORK_PROCESS ./s7_log -o0xff1f
FORK_PROCESS ./s7_mgt -i0x4d -d
FORK_PROCESS ./mtp_lnx6
FORK_PROCESS ./isp_lnx6
*
*****

```

Back to Back configuration (Dialogic® Diva® V-4PRI/E1/T1, 16 Ports, 2 Linksets, 4 Links) Controller 1 & 2 - 3 & 4 are connected via a loop cable.

```

*****
* Example SS7 Configuration File (config.txt) for use with
* Dialogic(R) Diva (R) SS7
*
* This file needs to be modified to suit individual circumstances.
* Refer to the relevant Programmer's Manuals for further details.
*
*****
*
* DIVA_BOARD
*      <board_id> <board_type> <flags> <serial>
DIVA_BOARD 0      81      0x0      1412
DIVA_BOARD 1      81      0x0      1411
DIVA_BOARD 2      81      0x0      1418
DIVA_BOARD 3      81      0x0      1104
*
*
*****
*
* MTP_CONFIG
*      <reserved1> <reserved2> <options>
MTP_CONFIG 0      0      0x00040044
*
*****
*
* MTP_LINKSET
*      <linkset_id> <adjacent_spc> <num_links> <flags> <local_spc> <ssf>
MTP_LINKSET 0      129      2      0x0000 130      0x08
MTP_LINKSET 1      130      2      0x0000 129      0x08
*
*****
*
* MTP_ROUTE
*      <dpc> <norm_ls> <user_part_mask> <flags> <second_ls>
MTP_ROUTE 129  0      0x0020
MTP_ROUTE 130  1      0x0020
*
*
*****
*
* MTP_LINK
*      <link_id> <linkset_id> <link_ref> <slc> <board_id> <blink> <stream> <timeslot> <flags>
MTP_LINK 0      0      0      0      0      0      0      16      0x0000
MTP_LINK 1      1      0      1      1      0      0      16      0x0000
MTP_LINK 2      0      1      0      2      0      0      16      0x0000
MTP_LINK 3      1      1      1      3      0      0      16      0x0000
*****
*
*****
*
* ISUP_CONFIG
*      <reserved> <reserved> <user_id> <options> <num_grps> <num_ccts> [<partner_id>]
ISUP_CONFIG 0      0      0x4d      0x0414 17      511
*

```

Examples of the Default Configuration Files

```

*****
*
* ISUP_CFG_CCTGRP
*
*      <gid> <dpc> <base_cic> <base_cid> <cic_mask> <options> <user_inst> <user_id> <opc> <ssf>
<variant> <options2>
ISUP_CFG_CCTGRP 1 129 0x01 0x01 0x7fff7fff 0x0249001c 0 0x4d 130 0x8 1 0x00d0
ISUP_CFG_CCTGRP 2 129 0x21 0x20 0x7fffffff 0x0249001c 0 0x4d 130 0x8 1 0x00d0

ISUP_CFG_CCTGRP 3 129 0x41 0x40 0x7fffffff 0x0249001c 0 0x4d 130 0x8 1 0x00d0
ISUP_CFG_CCTGRP 4 129 0x61 0x60 0x7fffffff 0x0249001c 0 0x4d 130 0x8 1 0x00d0
*
ISUP_CFG_CCTGRP 5 130 0x01 0x80 0x7fff7fff 0x0249001c 0 0x4d 129 0x8 1 0x00d0
ISUP_CFG_CCTGRP 6 130 0x21 0xA0 0x7fffffff 0x0249001c 0 0x4d 129 0x8 1 0x00d0
ISUP_CFG_CCTGRP 7 130 0x41 0xC0 0x7fffffff 0x0249001c 0 0x4d 129 0x8 1 0x00d0
ISUP_CFG_CCTGRP 8 130 0x61 0xE0 0x7fffffff 0x0249001c 0 0x4d 129 0x8 1 0x00d0
*
ISUP_CFG_CCTGRP 9 129 0x81 0x101 0x7fff7fff 0x0249001c 0 0x4d 130 0x8 1 0x00d0
ISUP_CFG_CCTGRP 10 129 0xA1 0x120 0x7fffffff 0x0249001c 0 0x4d 130 0x8 1 0x00d0
ISUP_CFG_CCTGRP 11 129 0xC1 0x140 0x7fffffff 0x0249001c 0 0x4d 130 0x8 1 0x00d0
ISUP_CFG_CCTGRP 12 129 0xE1 0x160 0x7fffffff 0x0249001c 0 0x4d 130 0x8 1 0x00d0
*
ISUP_CFG_CCTGRP 13 130 0x81 0x180 0x7fff7fff 0x0249001c 0 0x4d 129 0x8 1 0x00d0
ISUP_CFG_CCTGRP 14 130 0xA1 0x1A0 0x7fffffff 0x0249001c 0 0x4d 129 0x8 1 0x00d0
ISUP_CFG_CCTGRP 15 130 0xC1 0x1C0 0x7fffffff 0x0249001c 0 0x4d 129 0x8 1 0x00d0
ISUP_CFG_CCTGRP 16 130 0xE1 0x1E0 0x7fffffff 0x0249001c 0 0x4d 129 0x8 1 0x00d0
*****
* CCTGRP_RESOURCE
*
*      <gid> <board_id> <liu_id> <tslot_mask> <tslot_s>
CCTGRP_RESOURCE 1 0 0 0x7FFF7FFF 0
CCTGRP_RESOURCE 2 0 1 0x7FFF7FFF 0
CCTGRP_RESOURCE 3 0 2 0x7FFF7FFF 0
CCTGRP_RESOURCE 4 0 3 0x7FFF7FFF 0
*
CCTGRP_RESOURCE 5 1 0 0x7FFF7FFF 0
CCTGRP_RESOURCE 6 1 1 0x7FFF7FFF 0
CCTGRP_RESOURCE 7 1 2 0x7FFF7FFF 0
CCTGRP_RESOURCE 8 1 3 0x7FFF7FFF 0
*
CCTGRP_RESOURCE 9 2 0 0x7FFF7FFF 0
CCTGRP_RESOURCE 10 2 1 0x7FFF7FFF 0
CCTGRP_RESOURCE 11 2 2 0x7FFF7FFF 0
CCTGRP_RESOURCE 12 2 3 0x7FFF7FFF 0
*
CCTGRP_RESOURCE 13 3 0 0x7FFF7FFF 0
CCTGRP_RESOURCE 14 3 1 0x7FFF7FFF 0
CCTGRP_RESOURCE 15 3 2 0x7FFF7FFF 0
CCTGRP_RESOURCE 16 3 3 0x7FFF7FFF 0
*
*****

```

Glossary

CAPI	COMMON-ISDN-API: CAPI - the ISDN interface
CIC	Circuit Identification Code
config.txt	A text file used for protocol configuration.
DPC	Destination Point Code. Identifies the address (point code) of the SS7 network node to which a Message Signal Unit (MSU) should be directed.
DSI	Distributed Signaling Interface
DVSCC	Diva Virtual Signaling Call Control
gctload	A program that handles the initialization sequence and creates inter-process communication.
ISUP	ISDN User Part. An SS7 stack layer that defines the messages and protocols used in the establishment and tear down of voice and data calls over the public switched network, and to manage the trunk network on which they rely.
Link	A physical and logical connection between two signaling points.
Linkset	One or more signaling links that are connected to adjacent signaling points.
LIU	Line Interface Unit
LPC	Local Point Code this is the same as the OPC
MSU	Message Signal Unit. A data unit that carries signaling information for call control, transaction processing, network management and maintenance. Typically, the MSU is carried in the Signaling Information Field (SIF) of SS7 messages.
MTP	Message Transfer Part. Layers 1 to 3 of the SS7 protocol stack broadly equivalent to the Physical, Data Link and Network layers in the OSI protocol stack. See also MTP1, MTP2, and MTP3 below.
MTP1	Message Transfer Part Level 1. An SS7 stack layer that defines the physical and electrical characteristics of the signaling links of the SS7 network. Signaling links use DS0 channels and carry raw signaling data at a rate of 48, 56, or 64 kbps.
MTP2	Message Transfer Part level 2. An SS7 stack layer that provides link-layer functionality. Ensures that two end points of a signaling link can reliably exchange signaling messages. It provides error checking, flow control, and sequence checking.
MTP3	Message Transfer Part level 3. An SS7 stack layer that provides network-layer functionality. Ensures that messages can be delivered between signaling points across the SS7 network regardless of whether the signaling points are directly connected. It provides node addressing, routing, alternate routing and congestion control.
mtpsl	An example utility that can also be used to activate and deactivate signaling links.
OPC	Originator Point Code
route	An MTP3 concept that determines how signaling is distributed over linksets. A route consists of a destination point code and the linkset ID of one or two linksets over which traffic to the destination node should be routed. When two linksets are provided, the user can choose to load share traffic or treat the linksets as primary and secondary.
s7_log	A utility that enables messages received from the protocol stack to be logged in a text file. Typically used for diagnostic purposes.
s7_mgt	A utility that performs one time protocol configuration of all protocol modules using configuration parameters from the config.txt file.
s7_play	A utility that can be used to generate messages from a text file and send them to the system. Typically used for diagnostic purposes.
SLS	Signaling Link Selection field. A field in the MTP3 routing label used to determine the selection of an outgoing link for messages being routed to another point code.

SS7	Signaling System Number 7
SS7 Protocol Stack	A set of software modules that implement the various layers of the SS7 protocol stack.
ssdd	Process to interface with the device driver of Dialogic® Diva® Media Boards for passing messages to and from the board(s) and for configuring the Dialogic® DSI SS7 part running on the board(s).
system.txt	A text file used for system configuration.