

Dialogic® Brooktrout® Fax Products SDK

Installation and Configuration Guide

Copyright and Legal Notice

Copyright © 1998-2020 Dialogic Corporation. All Rights Reserved. You may not reproduce this document in whole or in part without permission in writing from Dialogic Corporation at the address provided below.

All contents of this document are furnished for informational use only and are subject to change without notice and do not represent a commitment on the part of Dialogic Corporation and its affiliates or subsidiaries ("Dialogic"). Reasonable effort is made to ensure the accuracy of the information contained in the document. However, Dialogic does not warrant the accuracy of this information and cannot accept responsibility for errors, inaccuracies or omissions that may be contained in this document.

INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH DIALOGIC® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN A SIGNED AGREEMENT BETWEEN YOU AND DIALOGIC, DIALOGIC ASSUMES NO LIABILITY WHATSOEVER, AND DIALOGIC DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF DIALOGIC PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY INTELLECTUAL PROPERTY RIGHT OF A THIRD PARTY.

Dialogic products are not intended for use in certain safety-affecting situations. Please see <http://www.dialogic.com/company/terms-of-use.aspx> for more details.

Due to differing national regulations and approval requirements, certain Dialogic products may be suitable for use only in specific countries, and thus may not function properly in other countries. You are responsible for ensuring that your use of such products occurs only in the countries where such use is suitable. For information on specific products, contact Dialogic Corporation at the address indicated below or on the web at www.dialogic.com.

It is possible that the use or implementation of any one of the concepts, applications, or ideas described in this document, in marketing collateral produced by or on web pages maintained by Dialogic may infringe one or more patents or other intellectual property rights owned by third parties. Dialogic does not provide any intellectual property licenses with the sale of Dialogic products other than a license to use such product in accordance with intellectual property owned or validly licensed by Dialogic and no such licenses are provided except pursuant to a signed agreement with Dialogic. More detailed information about such intellectual property is available from Dialogic's legal department at 3300 Boulevard de la Côte-Vertu, Suite 112, Montreal, Quebec, Canada H4R 1P8. ***Dialogic encourages all users of its products to procure all necessary intellectual property licenses required to implement any concepts or applications and does not condone or encourage any intellectual property infringement and disclaims any responsibility related thereto. These intellectual property licenses may differ from country to country and it is the responsibility of those who develop the concepts or applications to be aware of and comply with different national license requirements.***

Dialogic, Dialogic Pro, DialogicOne, Dialogic Buzz, Brooktrout, BorderNet, PowerMedia, PowerVille, PowerNova, ControlSwitch, I-Gate, Veraz, Cantata, TruFax, and NMS Communications, among others as well as related logos, are either registered trademarks or trademarks of Dialogic Corporation and its affiliates or subsidiaries. Dialogic's trademarks may be used publicly only with permission from Dialogic. Such permission may only be granted by Dialogic's legal department at 3300 Boulevard de la Côte-Vertu, Suite 112, Montreal, Quebec, Canada H4R 1P8. Any authorized use of Dialogic's trademarks will be subject to full respect of the trademark guidelines published by Dialogic from time to time and any use of Dialogic's trademarks requires proper acknowledgement.

The names of actual companies and products mentioned herein are the trademarks of their respective owners.

Hardware Limited Warranty

Refer to the following Dialogic web site for information on hardware warranty information, which applies unless different terms have been agreed to in a signed agreement between yourself and Dialogic Corporation or its subsidiaries. The listed hardware warranty periods and terms are subject to change without notice. For purchases not made directly from Dialogic please contact your direct vendor in connection with the warranty period and terms that they offer.

<http://www.dialogic.com/warranties>

SOFTWARE DEVELOPER LICENSE AGREEMENT

*** IMPORTANT ***

PLEASE READ CAREFULLY BEFORE USING THE SOFTWARE.

This Software Developer License Agreement is a legal agreement between Dialogic Corporation, and its affiliates or subsidiaries (collectively, "Dialogic") and you (either an individual or an entity) ("Developer"). ***IF YOU HAVE A WRITTEN, SIGNED LICENSE AGREEMENT GOVERNING THE USE OF THE ACCOMPANYING SOFTWARE, THE TERMS AND CONDITIONS OF THAT AGREEMENT WILL APPLY TO YOUR USE OF THE SOFTWARE. IF YOU HAVE WRITTEN, SIGNED SPECIAL TERMS GOVERNING THE USE OF THE ACCOMPANYING SOFTWARE ("SPECIAL TERMS"), THOSE SPECIAL TERMS ARE HEREBY INCORPORATED INTO THIS AGREEMENT.*** Read the following terms and conditions carefully before using the accompanying software. They define your rights and obligations with respect to the enclosed Software. If you do not agree to the terms of this Software Developer License Agreement, promptly return the Developer License Key that you obtained for the Software or the Dialogic® Hardware that you purchased for use with the Software, if any, to the place you obtained it for a full refund. USING THE SOFTWARE INDICATES YOUR AGREEMENT WITH AND ACCEPTANCE OF THE FOLLOWING TERMS AND CONDITIONS. AN INDIVIDUAL WHO DOES NOT HAVE AUTHORITY TO BIND THE ENTITY USING THE SOFTWARE SHOULD NOT USE THE SOFTWARE WITHOUT OBTAINING APPROVAL OF THIS AGREEMENT FROM A PERSON HAVING SUCH AUTHORITY.

YOU UNDERSTAND THAT IF YOU PURCHASED THE PACKAGE FROM AN AUTHORIZED RESELLER OF DIALOGIC, THAT RESELLER IS NOT DIALOGIC'S AGENT AND IS NOT AUTHORIZED TO MAKE ANY REPRESENTATIONS, CONDITIONS OR WARRANTIES, STATUTORY OR OTHERWISE, ON DIALOGIC'S BEHALF NOR TO VARY ANY OF THE TERMS OR CONDITIONS OF THIS AGREEMENT. IN ADDITION, YOU ACKNOWLEDGE THAT, UNLESS OTHERWISE AGREED BY THAT RESELLER IN WRITING OR PROHIBITED BY LAW, THE LIMITATIONS OF CONDITIONS AND WARRANTIES, STATUTORY OR OTHERWISE, AND LIABILITY SET FORTH IN THIS AGREEMENT ALSO APPLY TO AND BENEFIT THAT RESELLER.

The Software may include object code versions of third party software packages, including one or more of the following, which are subject to the terms and conditions of the applicable license agreements found at the websites identified below. Please refer to the attached Exhibit A to find out which, if any, licenses are applicable.

- *ACE™ software and TAO™ software are copyrighted by Douglas C. Schmidt and his research group at Washington University, University of California, Irvine, and Vanderbilt University Copyright (c) 1993-2003, all rights reserved. More information is available at:
<http://www.cs.wustl.edu/~schmidt/ACE.html>*
- *wxWindows software is copyrighted by Julian Smart, Robert Roebing et al. Copyright (c) 1998 Julian Smart, Robert Roebing et al. More information is available at:
<http://www.wxWindows.org>*

1. Definitions

- 1.1. "Dialogic Hardware" means voice and/or fax processing hardware and/or any other computer hardware manufactured by or for Dialogic which may (without limitation) be marketed under the brands Dialogic, Brooktrout, Excel, and/or Snowshore and purchased by the End User from Dialogic or one of its authorized resellers.
- 1.2. "Developer License Key" means an access code or activation key provided by Dialogic to enable a Developer to use the Software for the purposes set forth herein.
- 1.3. "End User" means the ultimate user of the Software who has obtained such Software pursuant to an End User Agreement.
- 1.4. "End User Agreement" means a sublicense agreement granting an End User the right to use the Software internally but not to further distribute or sublicense such Software, which agreement meets the requirements of Section 2.8.
- 1.5. "Integrated Product" means the Software as integrated with one or more of Developer's products to provide enhanced functionality.
- 1.6. "License Key" means an access code or activation key provided by Dialogic to enable an End User to use the Software.
- 1.7. "Software" means the software provided to you in the enclosed package, or enabled by the enclosed Developer License Key together with any accompanying documentation.
- 1.8. "Sublicensee" means any reseller, dealer, distributor or other entity authorized by Developer pursuant to a Sublicense Agreement meeting the requirements of Section 2.9, to sublicense the use of and distribution of the Software to End Users or other intermediate parties, such as dealers, in the distribution chain to End Users.

2. License

- 2.1. Demonstration or Evaluation. If the Software is provided to Developer as a demonstration or evaluation unit, (a) the licenses granted in Section 2.2 shall not apply and (b) Dialogic grants the Developer, and the Developer accepts, a non-exclusive, non-transferable right and license (without the right to grant sublicenses) to use the Software for a period of ninety (90) days from the date of delivery of the Software to Developer for the sole purpose of evaluating the suitability of such Software. Under no circumstances shall the Software be used for any commercial purposes, and Developer is not being granted any rights to distribute the Software under this Agreement without the express written permission of Dialogic.
- 2.2. License Grant. Subject to the terms and conditions contained herein, Dialogic grants Developer a license to use and distribute the Software subject to and in accordance with the following provisions.
 - a. If the Software is distributed to Developer for use with Dialogic Hardware, Dialogic grants Developer a royalty-free, non-transferable license (without the right to grant sublicenses, except as set forth in Section 2.9) to (i) use the Software solely for the purposes of developing Integrated Products; (ii) make copies of the Software for distribution to End Users, whether as a stand-alone product or as part of an Integrated Product, solely for use by such End Users for their internal business purposes in connection with Dialogic Hardware; and (iii) distribute the Software to End Users, whether as a stand-alone product or as part of an Integrated Product, solely for use by such End Users for their internal business purposes in connection with Dialogic Hardware. The Software is used in connection with Dialogic Hardware if it is operated only on the central processing unit of a computer served by one or more items of Dialogic Hardware and, where appropriate in connection with such use, it is downloaded into memory located on Dialogic Hardware.
 - b. If the Software is distributed to Developer as host-based media processing software, Dialogic grants Developer a royalty-bearing, non-transferable license (without the right to grant sublicenses, except as set forth in Section 2.9) to (i) use the Software solely for the purpose of developing Integrated Products; (ii) make copies of the Software for distribution to End Users, whether as a stand-alone product or as part of an Integrated Product for the End Users' internal business purposes; and (iii) distribute copies of the Software to End Users, whether as a stand-alone product or as part of an Integrated Product for the End Users' internal business purposes, subject to the purchase by the End User of a License Key. Developer shall not distribute or otherwise transfer any Developer License Key for any purpose without Dialogic's prior written consent.
- 2.3. Copies. Developer shall not remove or alter any copyright or other proprietary notices that appear on the Software and shall include all such notices on all copies of the Software (including without limitation all copies of the Software that are incorporated into Integrated Products).
- 2.4. No Reverse Engineering. Developer shall have no rights to any source code for the Software. Developer agrees that it shall not cause or permit the disassembly, decompilation or reverse engineering of the Software or otherwise attempt to gain access to the source code to the Software. If applicable law requires access to source code for some purpose, such as inter-operability with other software, and Developer desires access for that required purpose, Developer shall notify Dialogic, and Dialogic shall have the option, in its discretion, to (i) perform the work to derive any required information at Dialogic's usual consulting rate, or (ii) allow Developer access to source code solely for the legally required purpose.
- 2.5. Additional Restrictions. Developer shall not, and shall not permit any third party to disclose the results of any benchmark test of the Software to a third party without the prior written approval of Dialogic.
- 2.6. Reservation of Rights. Dialogic and its licensors reserve all rights not otherwise expressly granted in this Section 2. Any use, modification, reproduction or distribution of the Software not expressly permitted under this Agreement is hereby expressly prohibited.
- 2.7. License Keys. The use of the Software may require a License Key. Developer shall not (a) use any access code or activation key other than the Developer License Key (if any) provided by Dialogic or (b) develop or alter any access code for the Software or otherwise circumvent or attempt to circumvent the License Key or Developer License Key.
- 2.8. End User Agreements. The Software shall be distributed to each End User under an End User Agreement entered into by such End User which may be a shrink-wrap, break-the-seal or click-wrap or executed written agreement which provides for the same level of protection of Dialogic's title, rights and defenses as this Agreement, and pursuant to which the End User agrees (a) to use the Software solely for its own internal business purposes, and not for further distribution or licensing; (b) not to copy the Software in whole or in part, except as permitted under applicable law, and then only with the inclusion of all copyright, proprietary and other notices; (c) not to permit any parent, subsidiaries, affiliated entities or third parties to use the Software; and (d) not rent, lease, loan or transfer the Software. Where the Software or Integrated Product is distributed to an End User pursuant to Section 2.2(a), the End User shall also agree to use the Software solely in connection with Dialogic Hardware. Developer may include in such End User Agreement, the terms of the limited warranty attached as Exhibit B hereto.

- 2.9. Sublicenses. Developer shall have the right to sublicense its rights under Sections 2.2(a)(iii) and 2.2(b)(iii) solely to allow Sublicensees to distribute the Software to End Users, whether as a stand-alone product or as part of Developer's Integrated Product, but in no event shall any Sublicensee have the right to (a) use the Software to develop its own integrated products or (b) make copies of the Software. Each Sublicensee shall execute a Sublicense Agreement that contains substantially similar terms and conditions as are contained in this Agreement and provides for the same level of protection of Dialogic's title, rights and defenses as this Agreement.
- 2.10. Protection of Rights. Developer will use the same efforts that it would use to protect its own rights, including its intellectual property rights, but not less than commercially reasonable efforts to ensure that Sublicensees and End Users comply with the terms of their respective agreements, and will notify Dialogic of any known violation. Upon Dialogic's request, Developer will supply Dialogic with a copy of any sublicense agreement by and between Developer and any Sublicensees or End Users.

3. Ownership

- 3.1. Dialogic or its licensors own and shall retain all proprietary rights, including all patent, copyright, trade secret, trademark and other intellectual property rights, in and to the Software and any modifications thereto made by any entity.
- 3.2. Except as set forth in a separate agreement between Dialogic and Developer, Developer shall have no right to receive any corrections, enhancements, upgrades or other modifications to the Software ("Changes"). Unless otherwise agreed to in such separate agreement, any Changes to the Software provided by Dialogic to Developer in accordance with the separate agreement shall be governed by the terms of this Agreement. If Developer does receive Changes from Dialogic, it shall incorporate those Changes into Software that it distributes to End Users under Section 2.2 for initial installation by End Users. Developer acknowledges that the license granted under this Agreement does not provide Developer with title to or ownership of the Software, but only a right of limited use under the terms and conditions of this Agreement. Developer shall keep the Software free and clear of all claims, liens and encumbrances.

4. Limited Warranty

4.1. Scope of Limited Warranty

- a. Dialogic warrants to Developer that for a period of ninety (90) days from delivery of the Software to Developer (the "Warranty Period"), the media on which the Software is delivered shall be free from defects in materials and workmanship. Dialogic's sole liability and Developer's exclusive remedy under this limited warranty shall be the replacement of the non-conforming media.
- b. The remedies set forth in Section 4.1(a) are available only if Dialogic is promptly notified in writing, within the Warranty period, upon discovery of the defect by Developer.

4.2. Disclaimer of Any Other Warranties

- a. NOTWITHSTANDING ANYTHING IN THIS AGREEMENT TO THE CONTRARY, ANY SOFTWARE PROVIDED UNDER SECTION 2.1 AS A DEMONSTRATION OR EVALUATION UNIT IS BEING PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND AND LICENSOR HEREBY DISCLAIMS ALL WARRANTIES, WHETHER EXPRESS OR IMPLIED, ORAL OR WRITTEN, WITH RESPECT TO THE LICENSED SOFTWARE INCLUDING, WITHOUT LIMITATION, ALL IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE AND NON-INFRINGEMENT.
- b. EXCEPT FOR THE EXPRESS, LIMITED WARRANTY PROVIDED IN SECTION 4.1, DIALOGIC MAKES NO WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH RESPECT TO THE SOFTWARE, AND DIALOGIC DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. DIALOGIC DOES NOT WARRANT THAT THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT IT WILL SATISFY DEVELOPER'S REQUIREMENTS.
- 4.3. Dialogic will not be responsible to any End User for any warranties made by Developer with respect to any Software beyond the limited warranty described in Exhibit B.

5. Limitation of Liability

- 5.1. IN NO EVENT SHALL DIALOGIC'S OR ITS LICENSORS' AGGREGATE LIABILITY UNDER THIS AGREEMENT EXCEED THE AMOUNTS PAID BY DEVELOPER TO DIALOGIC FOR THE SOFTWARE (as "Software" is defined above).
- 5.2. IN NO EVENT WILL DIALOGIC OR ITS LICENSORS BE LIABLE TO DEVELOPER OR ANY END USER OR OTHER THIRD PARTY FOR SPECIAL, INCIDENTAL, CONSEQUENTIAL, EXEMPLARY, PUNITIVE, MULTIPLE OR OTHER INDIRECT DAMAGES, OR FOR LOSS OF PROFITS, LOSS OF DATA OR LOSS OF USE DAMAGES, ARISING OUT OF THIS AGREEMENT, WHETHER BASED UPON WARRANTY, CONTRACT, TORT, STRICT LIABILITY OR OTHERWISE, EVEN IF DIALOGIC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSSES.

6. Term and Termination

- 6.1. Termination. Dialogic shall have the right to terminate this Agreement and the license granted herein in the event Developer fails to comply with any of the terms and conditions of this Agreement and such default has not been cured within thirty (30) days after written notice of such default.
- 6.2. Effect of Termination. Upon termination of this Agreement, all licenses and other rights granted to you under this Agreement will become null and void, except that the End User Licenses and any Sublicenses shall survive termination as long as the End Users and Sublicensees are in compliance with the terms of this Agreement. Within five (5) days after termination of this Agreement, you shall return to Dialogic or destroy, at Developer's expense, the Software, including all copies thereof. Sections 2.3-2.8, 2.10, 3, 4, 5, 6, 7, 8, and 9 of this Agreement shall survive termination of this Agreement.

7. U.S. Government Restricted Rights

If Software is acquired by or on behalf of a unit or agency of the United States government, the Software is provided as "commercial computer software" or "commercial computer software documentation" and, absent a written agreement to the contrary, the government's rights with respect to such Software are limited by the terms of this Agreement pursuant to FAR Paragraph 12.212(a) and/or DFARS Paragraph 227.7202-1(a), as applicable.

8. Export

Developer shall comply with all export and re-export restrictions, laws and regulations of the U.S. Commerce Department and other U.S. agencies and authorities.

9. General

- 9.1. Assignment. This Agreement shall be binding upon and inure to the benefit of the parties hereto, and their respective successors and permitted assigns. Developer shall not assign or otherwise transfer this Agreement or any rights or obligations hereunder, in whole or in part, whether by operation of law or otherwise, without Dialogic's prior written consent. Any purported transfer, assignment or delegation without such prior written consent will be null and void and of no force or effect.
- 9.2. Entire Agreement. This Agreement, together with any Special Terms, represents the entire agreement between the parties, and supersedes all prior agreements and understandings with respect to the matters covered by this Agreement. In the event of a conflict between this Agreement and the Special Terms, the Special Terms shall control. Developer agrees that it has not entered in this Agreement based on any representations other than those contained herein. No modification of or amendment to this Agreement, nor any waiver of any rights under this Agreement, shall be effective unless in writing signed by the party to be charged.
- 9.3. Governing Law. This Agreement shall in all respects be governed by the laws of the Commonwealth of Massachusetts, excluding: (i) its conflicts of laws principles; (ii) the United Nations Convention on Contracts for the International Sale of Goods; (iii) the 1974 Convention on the Limitation Period in the International Sale of Goods; and (iv) the Protocol amending the 1974 Convention, done at Vienna April 11, 1980.
- 9.4. Severability. If any of the provisions of this Agreement is held by a court of competent jurisdiction to be invalid under any applicable statute or rule of law, such provision shall, to that extent, be deemed omitted, and the remaining portions of this Agreement shall remain in full force and effect.
- 9.5. Waiver. The waiver of one breach or default or any delay in exercising any rights shall not constitute a waiver of any subsequent breach or default.
- 9.6. Notices. All notices permitted or required under this Agreement shall be in writing and shall be delivered in person or mailed by first class, registered or certified mail, postage prepaid, to the address of the party specified on the first page of this Agreement or such other address as either party may specify in writing. Such notice shall be deemed to have been given upon receipt.
- 9.7. Counterparts. This Agreement may be executed in counterparts, each of which shall be deemed an original and all of which together shall constitute one instrument.
- 9.8. Headings. The headings are for convenience and shall not be used to construe this Agreement.
- 9.9. No Agency; Independent Contractors. Nothing contained in this Agreement shall be deemed to imply or constitute that either party is the agent or representative of the other party, or that both parties are joint ventures or partners for any purpose.

EXHIBIT A

THIRD PARTY SOFTWARE LICENSES

The Software includes object code versions of the following third party software packages which are subject to the terms and conditions of the applicable license agreements found at the websites identified:

- *ACE™ software and TAO™ software are copyrighted by Douglas C. Schmidt and his research group at Washington University, University of California, Irvine, and Vanderbilt University. Copyright (c) 1993-2003, all rights reserved. More information is available at:
<http://www.cs.wustl.edu/~schmidt/ACE.html>*
- *wxWindows software is copyrighted by Julian Smart, Robert Roebling et al. Copyright (c) 1998 Julian Smart, Robert Roebling et al. More information is available at:
<http://www.wxWindows.org>*
- *Portions of the Software are licensed under the Apache License, Version 2.0 (the "Apache License"); you may not use this file except in compliance with the Apache License. You may obtain a copy of the Apache License at:
<http://www.apache.org/licenses/LICENSE-2.0>*

Unless required by applicable law or agreed to in writing, software distributed under the Apache License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied. See the Apache License for the specific language governing permissions and limitations under the Apache License.

Preface	15
Introduction	15
Operating System Support	16
Compile Compatibility	16
Manual Conventions	17
Related Documents	17
Hardware Documents	18

Contents

Chapter 1 – Quick Start Steps

This chapter provides a series of steps that you can perform to quickly set up and test your installation of the Dialogic® Brooktrout® software and hardware.

Determining the Board Module Number	24
Dialogic® Brooktrout® SR140 Fax Software	25
Quick Start for Windows Systems	26
Step 1: Install Dialogic® Brooktrout® Software and Hardware	26
Step 2: Configure the Dialogic® Brooktrout® Software and Hardware	27
Step 3: Compile and Run the Sample Application	27
Next Steps	27
Quick Start for Linux Systems	29
Step 1: Install Dialogic® Brooktrout® software and hardware	29
Step 2: Configure the Dialogic® Brooktrout® Software and Hardware	30
Create the Configuration files	30
Start Boston Host Service	30
Step 3: Compile and Run the Sample Application	30
Next Steps	30

Chapter 2 – Installing the SDK on Red Hat Linux

This chapter describes how one can install Dialogic® Brooktrout® software on Red Hat Linux operating systems.

Installation Steps	33
Installing the Software	34
Removing the Software	36

Starting or Stopping the Driver	37
Reinitializing the Driver	37
Configuring the Driver Manually	38
History Logging	39
Advanced Configuration Parameters	39
Linux Kernel Versions	40
Removing the Manually Configured Driver	41
Using Boston Host Service Under Linux	42
Root login for Linux	43
Special Considerations	44
PCI Considerations	44
Dialogic® Brooktrout® Bfv API Libraries and Makefiles	45
Writing Multithreaded Programs	45
Warning and Error Messages	46
Determining Installation Parameters	46
Command Line Configuration for dinstall	46
Driver File Locations	48
Reviewing Compiler and Linker Options	49
SELinux	50
Driver Rebuilding for Patch Linux Kernels	50
Bostsrv Port in Use Error	52
Additional Packages Required for Red Hat Linux 6.0 and Later x64	53
Ksoftirqd and System Load	54

Chapter 3 – Installing the SDK on Windows 55

This chapter describes how one can install Dialogic® Brooktrout® software on Windows operating systems.

System Requirements for Installation	56
Installation Packages	57
Installing the Dialogic® Brooktrout® SDK	58
Removing or Modifying the Software	66
64-bit Windows API Libraries	68
Brooktrout_x64	68
System Files	69

Chapter 4 – Installing the Device Driver on Windows 71

This chapter describes how one can install the device driver on Windows systems.

Installing and Configuring Options	72
Installing the Plug-and-Play Driver	73
Updating Computer Telephony and the Plug-and-Play Driver	78
Removing Dialogic® Brooktrout® Hardware	79
Updating Previous Versions of the Plug-and-Play Driver	80
Removing the Plug-and-Play Driver	81
Disabling Plug-and-Play Driver Installation	83
Reinitializing the Driver	83
Installing and Configuring the Driver using a Command (cmd) Prompt	84
History Logging	86
Advanced Configuration Parameters	86
Memory Resources	87
Removing the Driver with a Command (cmd) Prompt	88
Reinitializing the Driver	88
Using the Boston Host Service	89
Installing Bostsrv	90
Starting Bostsrv	90
Troubleshooting Bostsrv	91
System Error 59	91
Special Considerations	92
PCI Considerations	92
Dialogic® Brooktrout® Bfv API Libraries and Makefiles	93
Writing Multithreaded Programs	93
Using BOSTDLLD with Debugging Enabled	94
Determining Installation Parameters	94
Driver Startup	95
Global Variables	95
Limits on Open Files	95
Process Priority	96
Command Line Configuration for Install	96
Driver File Locations (install)	99
Build Requirements for install	99
Version Information	99
Reviewing Compiler and Linker Options	100

Chapter 5 – Configuring Software 101

This chapter describes how one can configure the Dialogic® Brooktrout® Fax Software for your Dialogic® Brooktrout® boards.

Using the Dialogic® Brooktrout® Configuration Tool on Windows Systems	103
Running the Dialogic® Brooktrout® Configuration Tool	106
Choosing the File Location	108
Setting File Locations Prior to First Execution	108
Example of settings.cfg File	109
Getting Help From the Dialogic® Brooktrout® Configuration Tool	111
Identifying the Model of the Board	113
Resolving the Configtool Error Message	114
Configuring in Wizard Mode	116
Advanced Mode	117
Offline Mode	118
Adding a Module	119
Removing a Module	121
SR140 Modules in Offline Mode	122
Silent Mode	123
Using a Call Control Configuration File	124
About the Call Control Configuration File	124
Call Control (callctrl.cfg) File Examples	125

Chapter 6 – Directory Structure 126

This chapter contains tables that show the directory structure used for all installed binary, firmware, and sample source files, both platform-independent and platform-specific for all operating system platforms.

Installed Files Directory Structures	127
--	-----

Chapter 7 – Using the Dialogic® Brooktrout® TECUpdate Utility 132

This chapter describes how one can use the Dialogic® Brooktrout® Technology Expansion Capability (TEC) utility to display and upgrade the configured feature set on an installed board.

Starting Dialogic® Brooktrout® TECUpdate	133
When Errors Occur	135

Driver Error	135
Firmware Error	135
Running the Dialogic® Brooktrout® TECUpdate Utility	136
Error Logging	138

Chapter 8 – Downloading Firmware 139

This chapter describes how one can download the firmware to the board.

Introduction	140
Firmware Files	141
Updating Boot ROM Flash	142
Manually Downloading the Firmware	143

Appendix A – Compliance Information 146

This appendix describes how the Dialogic® Brooktrout® boards conform to compliance standards.

Electromagnetic Compatibility Statements	147
United States of America	148
Mandatory Statements	148
Class A Statement (for “Class A” products)	148
Class B Statements (for “Class B” products)	149
Canada	150
Class A Statements (for “Class A” products)	150
Class B Statements (for “Class B” products)	150
European Union	150
Class A Statements (for “Class A” products)	150
Class B Statements (for “Class B” products)	150
Japan	151
VCCI Class Statements	151
Telecommunications Compliance Statements	152
United States of America	152
Equipment Approved After July 23, 2001	152
Ringer Equivalence Number (REN)	152
Connection to Telecommunications Networks	153
FCC Rules Regarding FAX Branding	153
FCC Regulations For Connecting to a T1 Interface	155

Canada	157
Australia	158
Safety Compliance Statements	159
United States of America and Canada	159

Appendix B – Configuration from a Custom Installation Program..... 161

This appendix describes how one can create a custom installation program for manual configuration of the driver.

Linux Operating System	162
Linux Installation	162
Checking the Installation	163
Defining Default Symbols	164
Removing the Driver	165
Windows Operating System	166
Installing the Windows Driver	167
Driver Parameters Structure	169
Checking the Installation	170
Defining Default Symbols	170
Removing the Driver	171

Appendix C – Reinitializing the Device Driver 172

This appendix describes the driver reinitialization utility. This utility is used to return the device driver to a state as close as possible to that of a fresh driver start without stopping the driver.

Introducing the Driver Reinitialization Utility	173
Using the driver_reinit Utility	173

Glossary 174

Index 177

Introduction

The Dialogic® Brooktrout® *Fax Products SDK Installation and Configuration Guide* explains how to install the software (firmware, Dialogic® Brooktrout® Bfv APIs, and driver for the Dialogic® Brooktrout® TR1034/SR140/TruFax® products) on your host system. It also describes how to configure the driver, configure call control, and download the firmware to a Brooktrout module.

- Chapter 1 provides a quick start for users experienced with API programming in general and the Dialogic® Brooktrout® Bfv APIs in particular.
- Chapter 2 explains how to install the Dialogic® Brooktrout® software and the device driver on a Red Hat Linux operating system.
- Chapter 3 explains how to install the Dialogic® Brooktrout® software on a Windows operating system.
- Chapter 4 describes how to install the Dialogic® Brooktrout® device driver on Windows operating systems.
- Chapter 5 describes how to configure your software and hardware on Windows systems.
- Chapter 6 lists the directories where files are installed.
- Chapter 7 describes how to use the Dialogic® Brooktrout® TECUpdate Utility.
- Chapter 8 describes the firmware files, how to load them, and how to update the boot ROM.
- Appendix A describes compliance with North American and European standards that includes general telecommunications and safety.
- Appendix B describes how to create a custom installation program for the manual configuration of the driver.
- Appendix C describes how to use the driver reinitialization utility.

-
- A glossary provides definitions for some of the terms used in the manual.

A copy of this manual in Adobe Acrobat PDF format is included in the *Documents* directory on the Dialogic® Brooktrout® Fax Products SDK CD-ROM.

Refer to *Dialogic® Brooktrout® SR140 Software Windows User Guide* and *Dialogic® Brooktrout® SR140 Software Linux User Guide* for instructions to activate the software using the License Manager.

Operating System Support

See the latest *Dialogic® Brooktrout® Release Notes* for the supported operating systems. A copy of the Dialogic® Brooktrout® Release Notes is found in the *Documents* directory on the Dialogic® Brooktrout® Fax Products SDK CD-ROM.

Compile Compatibility

Applications compiled with Brooktrout SDK 6.0 or newer work with the latest Brooktrout SDK without recompiling as long as the application called the `BT_API_SET_VER` macro. See the *Dialogic® Brooktrout® Bfv APIs Reference Manual, Volume 1*.

You might also require one of the following:

- Windows libraries, see [Special Considerations on page 92](#)
- Linux libraries, see [Special Considerations on page 44](#)

Manual Conventions

This manual uses the following conventions:

- *Italics* denote file names, directory names, and program names within the general text.
- The **Courier** font in bold indicates a command sequence entered by the user at the system prompt, for example:
cd /boston/bfv.api
- The Courier font not bolded indicates system output, for example:
C:>Files installed.
- The Courier font also denotes programming code, such as C and C++. Programming code appears in program examples.
- **Bold** indicates names of variables, Dialogic® Brooktrout® Bfv API functions, dialog boxes, dialog box controls, windows, and menu items.
- Square brackets [] indicate that the information to be typed is optional.
- Angle brackets < > indicate that you must supply a value with the parameter.



The Caution icon is used to indicate an action that could cause harm to the software or hardware.



The Warning icon is used to indicate an action that could cause harm to the user.

Related Documents

Hardware Documents

These installation cards come with their respective boards:

- *Brooktrout Digital Board (Multiple Spans) Installation* describes how to install the Brooktrout Digital Board (Multiple Spans).
- *Brooktrout TR1034 Analog Loop Start Full-sized PCI Fax Board Installation* describes how to install the Brooktrout TR1034 Analog Loop Start Full-sized PCI Fax Board.
- *Brooktrout TR1034 Analog Loop Start Full-sized PCI Express Fax Board Installation* describes how to install the Brooktrout TR1034 Analog Loop Start Full-sized PCI Express Fax Board.
- *Brooktrout TR1034 BRI Half-sized PCI Fax Board Installation* describes how to install the Brooktrout TR1034 BRI Half-sized PCI Fax Board.
- *Brooktrout TR1034 BRI Half-sized PCI Express Fax Board Installation* describes how to install the Brooktrout TR1034 BRI Half-sized PCI Express Fax Board.
- *Brooktrout TR1034 DID, Combo, & Loop Start Half-sized PCI Fax Board Installation* describes how to install the Brooktrout TR1034 DID, Combo, & Loop Start Half-sized PCI Fax Board.
- *Brooktrout TR1034 DID, Combo, & Loop Start Half-sized PCI Express Fax Board Installation* describes how to install the Brooktrout TR1034 DID, Combo, & Loop Start Half-sized PCI Express Fax Board.
- *Brooktrout TR1034 T1/E1/IP Full-sized PCI Fax Board Installation* describes how to install the Brooktrout TR1034 T1/E1/IP Full-sized PCI Fax Board.
- *Brooktrout TR1034 T1/E1/IP Full-sized PCI Express Fax Board Installation* describes how to install the Brooktrout TR1034 T1/E1/IP Full-sized PCI Express Fax Board.
- *Brooktrout TruFax Analog Loop Start Full-sized PCI Fax Board Installation* describes how to install the Brooktrout TruFax Analog Loop Start Full-sized PCI Fax Board.
- *Brooktrout TruFax Analog Loop Start Half-sized PCI Fax Board Installation* describes how to install the Brooktrout TruFax Analog Loop Start Half-sized PCI Fax Board.

-
- *Brooktrout TruFax Analog Loop Start Half-sized PCI Express Fax Board Installation* describes how to install the Brooktrout TruFax Analog Loop Start Half-sized PCI Express Fax Board.
 - *Brooktrout TruFax BRI Half-sized PCI Fax Board Installation* describes how to install the Brooktrout TruFax BRI Half-sized PCI Fax Board.
 - *Brooktrout TruFax BRI Half-sized PCI Express Fax Board Installation* describes how to install the Brooktrout TruFax BRI Half-sized PCI Express Fax Board.

Software Documents

For product information, white papers, FAQs, and more, access the Dialogic web site at www.dialogic.com.

These documents come with the Dialogic® Brooktrout® SDK:

- ◆ *Brooktrout Fax Products Linux End User Guide* is for users running either of the following in a Linux environment: Brooktrout SR140 Fax Software or Brooktrout TR1034 Series and Brooktrout TruFax Boards.
- ◆ *Brooktrout Fax Products Windows End User Guide* is for users running either of the following in a Windows environment: Brooktrout SR140 Fax Software or Brooktrout TR1034 Series and Brooktrout TruFax Boards.
- ◆ *Brooktrout Bfv APIs Reference Manual* provides reference information for Brooktrout Bfv APIs.
- ◆ *Brooktrout Fax Products SDK Developer Guide* describes the Bfv API used to create applications to control the Brooktrout Fax Products features.
- ◆ *Brooktrout TECUpdate Utility Guide* describes the Brooktrout Technology Expansion Capability (TECUpdate) utility that is used to display and upgrade the configured feature set on an installed Brooktrout board.

Getting Technical Support

Dialogic provides technical services and support for customers who have purchased hardware or software products from Dialogic. If you purchased products from a reseller, please contact that reseller for technical support.

To obtain technical support, please use the web site below:

[*www.dialogic.com/support*](http://www.dialogic.com/support)

Terminology

Updated Terminology

The current version of this document includes terminology that differs from previous versions. Please note the changes below:

Former Terminology	Replaced with...
Host-based fax	Dialogic® Brooktrout® SR140 Fax Software
Virtual modules	or
Virtual boards	Brooktrout SR140 Fax Software
Software modules	or
VoIP modules	SR140 Software
SR140 virtual modules	or SR140
TR1000 Series SDK	Dialogic® Brooktrout® SDK
TR1000 Series Product	Dialogic® Brooktrout® Fax Board
TR1000 Series Module	or
TR1000 Series Board	Brooktrout fax board or board
Brooktrout System Software	Dialogic® Brooktrout® Runtime Software

Dialogic® Brooktrout® TR1034 Fax Board Terminology

The Dialogic® Brooktrout® TR1034 Fax Board is also referred to herein by one or more of the following terms, or like terms including "TR1034":

- Brooktrout TR1034 Fax Board
- Brooktrout TR1034 Board
- TR1034 Fax Board
- TR1034 Board

1 - Quick Start Steps

This chapter provides a series of steps that you can perform to quickly set up and test your installation of the Dialogic® Brooktrout® software and hardware.

Because the installation and configuration procedures can be quite different for Windows systems from those for Linux systems, this chapter gives separate quick start instruction for Windows systems.

This chapter includes the following:

- *Determining the Board Module Number on page 24*
- *Dialogic® Brooktrout® SR140 Fax Software on page 25*
- *Quick Start for Windows Systems on page 26*
- *Quick Start for Linux Systems on page 29*

Determining the Board Module Number

You need to know the module numbers (IDs) and associated channel numbers of each Dialogic® Brooktrout® fax board (for example: TR1034, TruFax®, or Brooktrout SR140 Software) in your system for a variety of tasks, including:

- Installing and identifying multiple modules
- Firmware download
- Telephony and network configuration
- Using some utilities (refer to Sample Applications and Utilities in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide*)

A module is a unit that communicates on a Dialogic® Brooktrout® TR1034, TruFax®, or Brooktrout SR140 Software. In general, each module corresponds to a control processor on the board. Most Dialogic® Brooktrout® boards have one module. Dialogic® Brooktrout® boards have an exact module number on the TR1034 and TruFax® boards and is indicated on the rotary switch on the board, refer to the Hardware installation card that came with you board to locate the rotary switch. Module numbers are normally referred to and displayed in hex. The Dialogic® Brooktrout® board contain a rotary switch that allows selection of a module number in a range from 2 through F.

To find the module numbers of the Dialogic® Brooktrout® boards in your system, run the *modinfo* program. The *modinfo* program provides the number of channels on each module, refer to *Sample Applications and Utilities* in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide* for more information.

The driver assigns other module numbers in addition to those for hardware modules. These can often be seen when running *modinfo*, for example.

- Module 1 represents the driver.
- Module FE is shared by all applications.
- Module 0x41 is the default for Brooktrout SR140.

Dialogic® Brooktrout® SR140 Fax Software

The Dialogic® Brooktrout® SR140 Software is a software-based virtual module that allows you to use T.38 fax or Fax Pass-through without installing a physical board. It is supported on Windows and Linux systems only and uses IP-enabled call control through SIP and H.323 stacks.

If you have a Dialogic® Brooktrout® SR140 Software license, you must install the Dialogic® Brooktrout® software first. Then you can activate the Dialogic® Brooktrout® SR140 Software using the Dialogic® Brooktrout® License Manager. For more information, see:

- *Installing the SDK on Windows on page 55*
- *Activating Dialogic® Brooktrout®SR140 Fax Software in the Dialogic® Brooktrout® Fax Products Windows End User Guide*

Quick Start for Windows Systems

If you have Brooktrout SR140 Software, see [Dialogic® Brooktrout® SR140 Fax Software on page 25](#) for setup information, otherwise continue with Step 1.

Step 1: Install Dialogic® Brooktrout® Software and Hardware

➤ **Do the following to install the Dialogic® Brooktrout® software and hardware:**

1. Before you install a Dialogic® Brooktrout® board, install the Brooktrout SDK by inserting the Dialogic® Brooktrout® Fax Products SDK CD-ROM into the CD-ROM drive. Then follow the directions in [Installing the SDK on Windows on page 55](#).

This procedure places the contents of the CD into a directory on your hard drive. The directory is either one you specify or the default (`\Brooktrout\Boston`).

See [Directory Structure on page 126](#) for the list of directories and their contents in this structure.

2. Power down the computer and install the board.

For installation instructions, see the hardware installation card that came with your board.

Although you can install the hardware before you install the software, Dialogic recommends that you install the software first.

3. Power up the computer and log on.
 - ◆ When the status LED on the board is flashing yellow, the board is ready to have the firmware downloaded (see [Step 2: Configure the Dialogic® Brooktrout® Software and Hardware on page 27](#)).
 - ◆ When the system sees the TR1034/TruFax® board, install the driver on a Windows operating system (see [Installing the Plug-and-Play Driver on page 73](#)).

Step 2: Configure the Dialogic® Brooktrout® Software and Hardware

- **Follow the steps below to run the Dialogic® Brooktrout® software and hardware:**
 1. Run the Dialogic® Brooktrout® Configuration Tool to configure the driver and the call control parameters. See [Using the Dialogic® Brooktrout® Configuration Tool on Windows Systems on page 103](#).

The Brooktrout Configuration Tool also starts the driver and downloads the firmware to the module.

Note: For the Dialogic® Brooktrout® Configuration Tool to work with Windows, you must install Internet Explorer 6.0 or higher.
 2. Reboot the system after running Dialogic® Brooktrout® Configuration Tool to have the driver configuration take effect.

Step 3: Compile and Run the Sample Application

To test your board and its setup, you can run the voice sample application, found in the *Boston\bfv.api\app.src* directory. However, before you can run the sample application, you must compile it. To compile sample applications, refer to *Sample Applications and Utilities* in the For information on testing your configuration, refer to the *Dialogic® Brooktrout® Fax Products Windows End User Guide*.

To compile sample applications, refer to *Sample Applications and Utilities* in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide*. For information on testing your configuration, refer to the *Dialogic® Brooktrout® Fax Products Windows End User Guide*

Next Steps

After you have verified that your board is functioning properly and can record and play speech, you can run your existing application, test your new application, or create a new application.

For more information, see these chapters in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide*:

-
- *Introduction to the Bfv API* describes the Bfv API
 - *Debugging* describes how to debug your applications
 - *Sample Applications and Utilities* describes how to compile and use the sample applications

Quick Start for Linux Systems

Step 1: Install Dialogic® Brooktrout® software and hardware

- **Follow the steps below to install Dialogic® Brooktrout® software and hardware:**
 1. Power down the computer and install the Dialogic® Brooktrout® board in your computer chassis. For installation instructions, see the hardware installation card that came with your board.
 2. Power up the computer and log on.
 - ◆ When the status LED on the board is flashing yellow, it is ready to have the firmware downloaded. See [Step 2: Configure the Dialogic® Brooktrout® Software and Hardware on page 27](#).
 - ◆ Insert the Dialogic® Brooktrout® Fax Products SDK CD-ROM into a CD-ROM drive. Then refer to [Installing the SDK on Red Hat Linux on page 32](#) or [Installing the SDK on Solaris on page 57](#).
 - ◆ This procedure places the contents of the CD into a directory on your hard drive. The directory can be one you specify or the default, `/usr/sys/brooktrout/boston`. See [Directory Structure on page 126](#) for the list of directories and their contents in the `/boston` directory structure.
 3. Start the driver. Linux, if you want, can start the driver, but you can wait until the software is installed before you start the driver. See the appropriate chapter that applies to your operating system.

Step 2: Configure the Dialogic® Brooktrout® Software and Hardware

Create the Configuration files

Dialogic provides two text files to configure the Dialogic® Brooktrout® Products:

- User-Defined Configuration File (*btcall.cfg*)
- Call Control Configuration File (*callctrl.cfg*)

See [Using a Call Control Configuration File on page 124](#).

Start Boston Host Service

Boston Host Service (Bostsrv) is used to initialize the modules. Upon startup it detects Dialogic® Brooktrout® modules, loads FW and initializes the call control based on the configuration files. You must use Boston Host Service to run a multi-process application or to use SR140 Fax Software modules.

See [Using Boston Host Service Under Linux on page 42](#).

Step 3: Compile and Run the Sample Application

To test your board and its setup, you can run the voice sample application, found in the *bfv.api/app.src* directory. However, before you can run the sample application, you must compile it. To compile sample applications, refer to *Sample Applications* and *Utilities* in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide*.

For information on testing your configuration, refer to the *Dialogic® Brooktrout® Fax Products Linux End User Guide*.

Next Steps

After you have verified that your board is functioning properly and can record and play speech, you can run your existing application, test your new application, or create a new application.

For more information, see these chapters in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide*:

- *Introduction to the Bfv API* describes the Dialogic® Brooktrout® Bfv API.
- *Debugging* describes how to debug your applications.
- *Sample Applications and Utilities* describes how to compile and use the sample applications.

2 - Installing the SDK on Red Hat Linux

This chapter describes how one can install Dialogic® Brooktrout® software on Red Hat Linux operating systems.

This chapter contains the following:

- *Installation Steps on page 33*
- *Configuring the Driver Manually on page 38*
- *Removing the Manually Configured Driver on page 41*
- *Using Boston Host Service Under Linux on page 42*
- *Special Considerations on page 44*

Installation Steps

If you have a Dialogic® Brooktrout® SR140 license, you must install the Dialogic® Brooktrout® SDK software first.

Then you can turn on SR140 Software by either of the following:

- Use the interactive web method
- Create a request for email or fax

See *Activating Dialogic® Brooktrout® SR140 Fax Software* in the *Dialogic® Brooktrout® Fax Products Linux End User Guide*.

➤ **Follow the steps below to install the Dialogic® Brooktrout® software on Linux:**

When running driver installation programs, scripts, or functions, you must be logged in as `root` or have administrative privileges. Dialogic supports only the standard GNU C compiler that ships with Linux.

1. Install the firmware, driver, and Bfv API software onto your computer.
If you are reinstalling or upgrading software from a previous Brooktrout SDK, you must first remove the previously installed software before installing this software.
See [Removing the Software on page 36](#).
2. Compile the sample applications and utilities (optional).
See the chapter on sample applications and utilities in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide*.
3. Run the `dinstall` program to manually configure the driver (optional).
See [Configuring the Driver Manually on page 38](#).
4. Download the firmware, optionally configure the telephony parameters, see:
 - ◆ [Downloading Firmware on page 139](#)
 - ◆ [Using a Call Control Configuration File on page 124](#).

Installing the Software

The Dialogic® Brooktrout® Fax Products SDK CD-ROM comes with an installation program that uses *rpm* to install the files on your hard drive. To use the program, follow the directions below. You must be logged in as *root* or *su* to install/uninstall the software and configure the driver.

➤ **Use the following procedure to install software files:**

1. Mount the installation CD-ROM:

```
mount -t iso9660 -r /dev/cdrom /mnt/cdrom
```

2. Enter the command line to go to the *Linux* directory on the CD-ROM drive:

```
cd /mnt/cdrom/Software/Linux/Redhat
```

3. Run the setup program by entering the following at a command prompt:

```
sh ./setup.sh
```

On the *setup.sh* command line, the optional argument *-y* can be given. This directs *setup.sh* to proceed through all prompts, accepting the defaults (except for the licensing prompt display, which cannot be skipped).

The program displays a message if it does not detect an Intel microprocessor and terminates. If the processor is Intel, the program then displays a copyright notice and the following information:

```
Welcome to the Dialogic Brooktrout Setup Program
to install the Brooktrout Boston SDK Package
```

```
*****
*
*   WARNING:  This program is protected by copyright law   *
*   and international treaties.                             *
*
*   Unauthorized reproduction or distribution of this     *
*   program, or any portion thereof, may result in severe *
*   civil and criminal penalties, and will be prosecuted *
*   to the maximum extent possible under law.             *
*
*****
```

The program then displays:

Press ENTER to continue or 'q' then ENTER to quit setup.

4. If there is no Brooktrout Boston SDK package currently installed, the program then displays:

```
Proceed to install
      SDK package BRKTBOSetup version 6.7.3
?
```

If there is already a Brooktrout Boston SDK package installed, the program then displays:

```
SDK package BRKTBOSetup version 6.7.2 already installed.
Perform upgrade to
      SDK package BRKTBOSetup version 6.7.3
      (newer ver)
?
```

5. If a new installation is being performed, the program then displays:

```
Default install directory is /usr/sys/brooktrout
```

```
Please enter desired install directory or just press
ENTER to use default directory.
```

If an upgrade is being performed, the new SDK is installed in the same location as the old SDK.

The upgrade will attempt to migrate configuration files *btcall.cfg*, *callctrl.cfg*, and *BT_CPARM.CFG* from *boston/bfv.api/config* along with driver parameters from the old SDK installation to the new SDK installation.

6. Please read and accept the license agreement to continue: Press the spacebar to continue or **q** to quit. (The program named "less" displays the license agreement.)
7. After you choose **q** to quit out of license agreement you get the following message:

```
Do you accept the above agreement?
```

8. If you choose **y** or **yes**, your files will install correctly. If you choose any other character the installation script will terminate with an error.
9. If the Linux kernel being run is not the base kernel for the version of Linux in use, the program then asks:

```
A driver rebuild for patch kernel is required.
```

```
Would you like to perform the driver rebuild at this
time?
```

10. If Step 9 is not required or if the rebuild is performed, the program then asks:

Would you like to install and configure the driver?

If you choose the default directory, the directory `/usr/sys/brooktrout` contains the directories and files shown in [Directory Structure on page 126](#).

After installing the software, you must download the firmware. See [Downloading Firmware on page 139](#).

Removing the Software

➤ **Use the following procedure to remove software files:**

1. Run the setup program by entering the following at a command prompt:

```
sh ./setup.sh -remove
```

On the `setup.sh` command line, the optional argument `-y` can be given. This directs `setup.sh` to proceed through all prompts, accepting the defaults.

The program then displays a copyright notice and the following information:

```
Welcome to the Dialogic Brooktrout Setup Program
to install the Brooktrout Boston SDK Package
```

```
*****
*
*   WARNING:  This program is protected by copyright law
*   and international treaties.
*
*   Unauthorized reproduction or distribution of this
*   program, or any portion thereof, may result in severe
*   civil and criminal penalties, and will be prosecuted
*   to the maximum extent possible under law.
*
*****
```

2. The program then asks:

```
Remove currently installed SDK package?
```

This will remove the entire SDK installation directory and all of its contents.

Starting or Stopping the Driver

You must start or stop the driver as shown below. You can also add the command lines to system startup scripts, if needed.

- **To start the driver, enter:**

```
/etc/startbost
```

- **To stop or shut down the driver, enter:**

```
/etc/startbost -r
```

Reinitializing the Driver

You can reinitialize the driver to its starting state in terms of channels assigned to modules and module number assignments using the *driver_reinit* utility located in the *boston/driver/linux/user* directory (see [Reinitializing the Device Driver on page 172](#)).

Configuring the Driver Manually

To configure the driver manually, change to the `/usr/sys/brooktrout/boston/driver/linux/install` directory and run the `dinstall` program.

The configuration dialog is as follows:

```
Installing Brooktrout Boston Device Driver Version 6.7.0
Maximum number of PCI/cPCI hardware modules (default 16):
Physical buffer size (default 32768):
Application buffer size (default 10240):
Machine ID, in hex (default 1):
Do initial reset (default 1):
History enable (default 0):
```

If you enter `1`, `dinstall` asks the following questions:

```
History size (default 1024000):
Number of physical channel histories (default 0):
Number of application channel histories (default 0):
Restrict physical channel histories to admin channel 1
(default 1):
Configure advanced parameters (n)?
```

If you enter `y`, `dinstall` asks the following questions:

```
Stop history on module death (default 0):
Number of I2O frames per module (default 16):
Driver flow control interval (default 250):
Internal memory allocation minimum (default 152):
Internal memory allocation quanta (default 128):
To reserve module numbers, enter mod_id (serial number)
and mod_num, in hex. Mod_num will default as indicated:
mod_id mod_num[F0]:
```

```
Configure test parameters (n)?
```

If you enter `y`, two test options are listed:

```
Test2:
```

```
Test3:
```

Configuring Boston driver:

Phys buf size 32768

App buffer size 10240

Machine ID 1

History size 1024000

Num phys hist bufs 0

Num apl hist bufs 0

The maximum number of PCI hardware modules can be left at its default. However, if fewer modules are in use, to conserve memory, this value can be set to a smaller number. Each hardware module uses approximately 60K.

History Logging

When the Dialogic® Brooktrout® driver is installed, history logging is disabled by default. When you manually install the driver using *dinstall*, the default is set to disable history logging (you can choose to override this option). History logging is a powerful debugging tool, especially when working with Dialogic Technical Services and Support. However, it does consume a significant amount of CPU time when running very high call loads. Therefore, leave history logging off for systems that have high call loads and are CPU-bound. For low-load systems or when debugging, enable history logging.

Leave the number of physical and application channel histories at 0 unless you are directed to change this by Dialogic Technical Services and Support. If you change the physical or application buffer size, do not change the value to one smaller than the default.

Advanced Configuration Parameters

If you select advanced configuration parameters, the software prompts you for the number of I2O frames, driver flow control interval, internal memory allocation parameters, module reservations, and test parameters. Do not configure advanced parameters except under the advice of Dialogic Technical Services and Support.

Linux Kernel Versions

Different versions of Linux have different kernel version numbers, and patches to Linux can also change the kernel version number. The binary distribution comes with driver support for a number of kernel versions. Dialogic® Brooktrout® drivers will be installed for all the installed kernel versions that are supported. If the currently installed kernel version is not supported, driver installation aborts.

The driver is configured and ready to be started.

See [Starting or Stopping the Driver on page 37](#) and [Driver Rebuilding for Patch Linux Kernels on page 50](#).

The Dialogic® Brooktrout® SDK supports the Linux Physical Address Extension (PAE) kernels. This support allows greater memory utilization on systems with four gigabytes of memory.

Removing the Manually Configured Driver

- **Follow the steps below to uninstall the driver:**
 1. Change to the following directory:
/usr/sys/brooktrout/boston/driver/linux/install
 2. Enter the following at the command prompt:
`./dinstall -r.`

Using Boston Host Service Under Linux

Boston Host Service (Bostsrv) is used to initialize modules. Upon startup it detects Dialogic® Brooktrout® modules, loads FW and initializes the call control. You must use Boston Host Service to run a multi-process application or to use Brooktrout SR140 Software modules. Boston Host Service is optional for other Dialogic® Brooktrout® modules.

When you use the Boston Host Service (Bostsrv) with a Linux system the following syntax applies:

- Go to following directory:

```
cd /usr/sys/brooktrout/boston/bfv.api/linux/bin/x
```

x depends on the version of Linux in use:

- ◆ Red Hat Enterprise/CentOS Linux 8.0 (4.18.0-80.el8), 64-bit
- ◆ Red Hat Enterprise/CentOS Linux 7.0 (3.10.0-123.el7), 64-bit
- ◆ Red Hat Enterprise/CentOS Linux 6.0 (2.6.32-71.el6), 32-bit and 64-bit

- Use any of the following command line options:

Option	Meaning
-c <file>	Full path to the <i>btcall.cfg</i> file and name of the <i>btcall.cfg</i> file
-D	Run as daemon (in background)
-f <path>	Full path to board firmware
-k	Stops the daemon
-stop	Stops the daemon
-query	Queries whether the server is running
-debug	Console app/debugging
-v	Enable Bfv API debug mode
-l <file>	Log output to file (can be used with -debug and -D)

Note: **-c** and **-f** are required.

For example:

```
Bostsrv -c /usr/sys/brooktrout/boston/config/btcall.cfg  
-f /usr/sys/brooktrout/boston/fw
```

Root login for Linux

When using Linux, you must log in as root to run Bostsrv from the command line in debug mode. Bostsrv creates a process id file in the root `owned/var/run` directory. This prevents multiple copies from running at the same time. It also supports the kill, stop, and query operations.

Special Considerations

When you install the Software on a Red Hat Linux operating system, consider the following:

- [PCI Considerations on page 44](#)
- [Dialogic® Brooktrout® Bfv API Libraries and Makefiles on page 45](#)
- [Writing Multithreaded Programs on page 45](#)
- [Warning and Error Messages on page 46](#)
- [Determining Installation Parameters on page 46](#)
- [Command Line Configuration for dinstall on page 46](#)
- [Driver File Locations on page 48](#)
- [Reviewing Compiler and Linker Options on page 49](#)
- [SELinux on page 50](#)
- [SELinux on page 50](#)
- [Driver Rebuilding for Patch Linux Kernels on page 50](#)
- [Bostsrv Port in Use Error on page 52](#)
- [Additional Packages Required for Red Hat Linux 6.0 and Later x64 on page 53](#)
- [Ksoftirqd and System Load on page 54](#)

PCI Considerations

When configuring the device driver, you must select 0 when asked for the number of ISA boards.

The operating system and/or system BIOS assigns base addresses and interrupt numbers to the PCI boards, which can change when the system is rebooted, especially if devices are added or moved.

If multiple PCI boards are in use, it is often not apparent which boards correspond to which module numbers or contain which ordinal channel values. See [Determining the Board Module Number on page 24](#) for more information about modules and module number assignment.

Dialogic® Brooktrout® Bfv API Libraries and Makefiles

The Dialogic® Brooktrout® Bfv API libraries are supplied in several forms for the appropriate Linux versions. The primary libraries are shared (.so) libraries. In addition, there are static (.a) libraries; their use is deprecated and are supplied for compatibility only.

To run an application compiled with the .so libraries, the operating system needs to find the .so libraries at runtime. The installation procedure automatically installs these libraries into a known system location: */usr/lib* and */usr/lib64*. If you are performing installation manually, you can either copy the libraries there, or add the directory locations containing the .so libraries to the environment variable `LD_LIBRARY_PATH`.

Follow the makefiles supplied in the *app.src* or *bapp.src* directory for all applications. In particular, since all the supplied libraries were compiled as multithreaded, compile all your applications this way. See also, [Reviewing Compiler and Linker Options on page 49](#).

Writing Multithreaded Programs

The Bfv API supports multithreaded programs using the *pthread*s package. When developing a multithreaded program, be sure to follow the programming guidelines described in your system documentation.

When new threads are created, often a stack size can be specified. The stack size must be sufficiently large to store all local variables used both by the application and the Bfv API. If the stack size is not large enough, unpredictable behavior can result.

Dialogic usually finds a stack size of 64K to be sufficient but, depending on the application's stack allocation demands, more memory might be required.

Warning and Error Messages

If the driver has an error or warning to report (often related to driver startup problems), the report always appears on the system console, if such a device exists for that platform. Additionally, a limited amount of messages are sometimes available if you use the `crash` command and select the `panic` option. These messages are logged to the `/var/log/messages` text file.

Determining Installation Parameters

Any time after you install the driver (but not removed) you can determine what installation parameters were used by looking at the `/etc/startbost` file.

Command Line Configuration for `dinstall`

When configuring the device driver using `dinstall`, you can specify the command line option `-c` to cause the `dinstall` program to not prompt you for any parameters. Instead, the `dinstall` program uses the responses that you supply following the `-c` option on the command line.

If you use the `-c` option, you must include all the parameters described below, in order, regardless of whether or not the parameter has meaning on the system in question. If a parameter does not apply, it is ignored. The parameters are not checked for validity.

Note: Prompting for removal of old driver versions is not performed.

When configuring the driver using *dinstall*, you must include the following parameters:

Parameter	Defaults
Reserved	0
Reserved	-1
Max num PCI/cPCI hw modules	16
Physical buffer size	32768
Application buffer size	10240
Reserved	0
Machine ID	1
Reset option (1 or 0)	1
History Enable	0
History Size	1024000
Num physical histories	0
Num app histories	0
Restrict phys channels (1 or 0)	1
Number of I2O frames	*0
Flow control interval	*0
Memory alloc minimum	*0
Memory alloc quanta	*0
Reserved	0
Stop history on module death	*0
Test parameter 2	*0
Test parameter 3	*0
Reserved module info module id, module number, 0 to terminate	*0
Reserved	0

The advanced parameters, marked with * in the list above, can always be safely set to 0. This tells the driver to use the default values.

There are currently no parameters used with *-c* when removing the driver, but the option might still be given on the command line for future use.

For example, to configure the driver for 0 ISA hardware modules and up to 16 PCI hardware modules, use the following settings:

- physical buffer size 32768
- application buffer size 10240
- machine ID 1
- reset on
- history enabled
- history size 1024000
- physical histories 0
- application histories 0
- restrict physical channels
- all default advanced parameters

Enter the following at the command line:

```
./dinstall -c 0 -1 16 32768 10240 0 1 1 1 1024000 0 0 1 0 0 0 0 0 0 0 0 0
```

Driver File Locations

When using *dinstall* to configure the device driver, you need not have all files from the distribution. However, the locations of files used by the installation procedure relative to the directory from which *dinstall* is being run must be the same as that in the normal distribution.

Assuming a directory named *install* from which *dinstall* is being run, the following files must be present:

```
install/dinstall  
install/dinstlib  
kernel/kvers/*
```

These files and directories appear in the standard distribution under the directory *driver/linux*.

The *kvers* directory contains subdirectories named after each kernel version for which binaries are available. The software supports the standard uni and multiprocessor releases, as well as alternate releases. See the Dialogic® Brooktrout® Release Notes for the supported kernel versions.

Reviewing Compiler and Linker Options

The makefiles contained in the *app.src* and *bapp.src* directories provide a number of command line options to the compiler and linker. Using these options, the compiler and linker produce object files and executables compatible with the Bfv API library.

Dialogic strongly recommends that you use these options for all your Dialogic® Brooktrout® Bfv API applications. But for those who want to change the set of options the compiler and linker use, the following is a list of the nonstandard options and their functions. The options used for compilation are marked with **(C)** and those for linking are marked with **(L)**.

<code>-DBFAX_THREADS</code>	(C) Specifies a multithreaded program to the API.
<code>-lpthreads</code>	(L) Multithreaded library.
<code>-m32/-64</code>	(C, L) Specify whether to build for 32-bits or 64 bits

SELinux

SELinux prevents `bostlib_mt.so` and other Dialogic-supplied shared libraries from loading because they require text relocation, which is very common for third-party shared libraries.

Follow one of the methods below to allow shared libraries to load:

- Disable SELinux as follows:
 - ◆ In `/etc/selinux/config`, set `SELINUX` to `disabled` and reboot.
- Set the SELinux mode to `permissive` - which will still cause warnings to pop up and appear in the logs, but the programs will work.
 - ◆ In `/etc/selinux/config`, set `SELINUX` to `permissive`, and reboot.
- Allow the shared library to do text relocation. For each shared library (`.so`) file that fails to load, run the following program:

```
chcon -t textrel_shlib_t <library name>
```

Driver Rebuilding for Patch Linux Kernels

This section provides instructions for recompiling the Dialogic® Brooktrout® driver to support new kernel patches.

Use the instructions below to recompile the Dialogic® Brooktrout® driver on supported Linux platforms so that the driver can operate with any kernel patch for supported Linux versions. Dialogic only supports official kernel patches as released by Red Hat. After you follow the procedure, the driver supports only the exact version of the kernel currently running on your system, including architecture and variant.

Note: This feature only provides support for the Dialogic® Brooktrout® driver, the kernel mode code. Other parts of the Brooktrout SDK (the user mode code) might also need rebuilding and this feature will not help in these situations.

Supported versions include:

- Red Hat Enterprise/CentOS Linux 8.0 (4.18.0-80.el8), 64-bit
- Red Hat Enterprise/CentOS Linux 7.0 (3.10.0-123.el7), 64-bit version

-
- Red Hat Enterprise/CentOS Linux 6.0 (2.6.32-71.el6), 32-bit and 64-bit versions

The fully precompiled installable driver binaries reside under the *driver/linux/kernel/kvers* directory. This directory contains subdirectories corresponding to each kernel version, variant, and architecture, with a driver binary in each (named *boston.o* or *boston.ko*).

For each Linux OS version supported, the only precompiled driver supplied supports the original kernel that shipped with that version of Linux.

Each of these directories also contains a file named *bostbase.a*, which is a library containing precompiled object files compiled for that same kernel version, variant, and architecture.

The *driver/linux/kernel* directory contains files named *kerndep.c*, *kerndep.h*, and *makefile.kerndep*.

Before building a Dialogic® Brooktrout® driver for a patch version, install the kernel source, the compiler, and other standard development tools on the system.

- **To build a driver for a kernel patch version, enter the following at the command prompt:**

```
make -f Makefile.kerndep
```

This command performs several steps.

- ◆ Determines what the base Red Hat release is that the booted kernel is based on, what the kernel version is that corresponds to the base release, and what the variant and architecture are.
- ◆ Compiles the source file *kerndep.c* on the current booted kernel setup.
- ◆ Links the resulting object file with the *bostbase.a* file from the directory corresponding to the base kernel version for the current variant and architecture.
- ◆ Puts the resulting driver binary into an appropriate *kvers* subdirectory for the actual kernel version in use.

After compiling the driver, use the standard manual *dinstall* script provided on the CD to manually configure the driver.

If the kernel source is not installed in a standard location, use the optional `KERNEL_SOURCE=<dir>` command line option to specify the kernel source location to the *make* utility.

The kernel source itself is not required; instead, a *development kit* is required. This kit is in the package whose name is of the form *kernel-devel-<version>*, in the file *kernel-devel-<version>.i686.rpm* or *kernel-smp-devel-<version>.i686.rpm*. This kit is automatically installed if you tell the Linux installation program to install everything. In this case, `KERNEL_SOURCE` should point to the appropriate subdirectory of `/usr/src/kernels` which would normally be one of *<version>-i686* or *<version>-smp-i686*.

Bostsrv Port in Use Error

If Boston host service is started too soon after being stopped, a port remains in use preventing H.323 initialization. As a workaround, wait a few minutes before restarting. This affects applications running Brooktrout H.323 call control on Linux.

Shutting down the Boston host service while TCP connections are active will cause those connections to go into a TIME-WAIT state. The TIME-WAIT state is a period of time equal to double the maximum segment life (MSL) time. This gives enough time to ensure the ACK sent in response to a FIN is received by the remote end.

A problem will be encountered if the Boston Host service is started before all connections in the TIME-WAIT state have completed. In this case the Boston Host service will fail to initialize H.323 call control and the application will be unable to send or receive H.323 calls.

To determine the TIME-WAIT duration in seconds on your Linux system enter the following:

```
cat /proc/sys/net/ipv[46]/tcp_fin_timeout
```

Additional Packages Required for Red Hat Linux 6.0 and Later x64

The following packages are required for the Dialogic Brooktrout SDK to be used on Red Hat Linux 6.0 and later x64 systems. It does not affect any x86 systems, and it does not affect any versions earlier than 6.0. These packages are on your Linux installation media in the Packages directory.

Each of the packages listed has a version number associated with it following the name of the package before additional text about the Linux version and the architecture. The package version will depend on the exact version of Linux being used.

Below, the packages are listed without the exact version number, and "*" is used instead. The version number can be determined by examining the installation media.

	Runtime-only systems	Development systems
RH 6	libstdc++*.el6.i686	libstdc++-devel*.el6.i686 glibc-devel*.el6.i686
RH 7	libstdc++*.el7.i686	libstdc++-devel*.el7.i686 glibc-devel*.el7.i686
RH 8	libstdc++*.el8.i686	libstdc++-devel*.el8.i686 glibc-devel*.el8.i686
	Required for SR140 only:	
	perl-Digest-MD5*.el7.x86_64	perl-Digest-MD5*.el7.x86_64

Ksoftirqd and System Load

On some Linux systems, when examining the system load, a process named `ksoftirqd` can be seen, which, once the Brooktrout driver is started, may seem to use up a fair amount of CPU. This is most often seen when running 64-bit RH 6.x.

This is due to an artifact of a feature that Linux introduced in 6.0 called the tickless kernel that has been known to cause problems for many timing sensitive software packages. This feature can be disabled, as follows.

As root, edit `/boot/grub/grub.conf`. Locate the kernel line in the file corresponding to the kernel being run. Add the following to the end of this line.

```
nohz=off
```

On subsequent boots of the system, the tickless kernel will be disabled.

3 - Installing the SDK on Windows

This chapter describes how one can install Dialogic® Brooktrout® software on Windows operating systems.

This chapter contains the following sections:

- *System Requirements for Installation on page 56*
- *Installing the Dialogic® Brooktrout® SDK on page 58*
- *Removing or Modifying the Software on page 66*
- *64-bit Windows API Libraries on page 68*

System Requirements for Installation

When running the installation, you need the following:

- Administrator privileges
- Sufficient available disk space on the drive that contains the Windows temp directory to extract the *sdk_windows.exe* file.

By default the Windows operating system sets it to [WINDOWS_VOLUME]\temp, where WINDOWS_VOLUME is the drive where the operating system is installed. If you do not have enough space, you will need to adjust the TEMP environment variable to point to a drive that contains at least 200 MB of free space.

- An Intel computer that contains an Intel x86 or x64 (including Pentium) CPU only.

Installation Packages

There are two installation packages for Windows.

- Dialogic® Brooktrout® SDK (*sdk_windows.exe*)

This installation is intended for developers. It contains the runtime binaries and tools, API headers and libraries, and samples source code.

- Dialogic® Brooktrout® Runtime Software (*boston.msi*)

This installation package is intended for end users. It contains only the runtime binaries and tools. Refer to the *Dialogic® Brooktrout® Fax Products Windows End User Guide* for more information.

You can also integrate the components into your installation by using the merge modules, provided in the Dialogic® Brooktrout® SDK, to give the end user the experience of one installation package. Refer to the section *About the Merge Module Feature* in the Dialogic® *Brooktrout® Fax Products SDK Developer Guide* for more information.

This chapter explains how to install the Dialogic® Brooktrout® SDK.

The SDK contains support for x64 libraries which allow customers to build x64 applications that take full advantage of the Windows x64 performance. Refer to [64-bit Windows API Libraries on page 68](#).

Installing the Dialogic® Brooktrout® SDK

If you do not have the Dialogic® Brooktrout® Fax Products SDK, contact your sales associate.

Also, although Dialogic recommends that you install the Brooktrout SDK before you install your Computer Telephony, if you choose to install the boards first, the Found New Hardware Wizard searches for and launches the driver installation. If the Wizard cannot find suitable drivers, it prompts you to browse and locate of the drivers.

Note: This installs the drivers but not the runtime components. Dialogic recommends using the Dialogic® Brooktrout® Fax Products SDK CD-ROM installation.

If you have Dialogic® Brooktrout® SR140 Software, you must install the Dialogic® Brooktrout® SDK first. Then you can turn on Dialogic® Brooktrout® SR140 Software using the Dialogic® Brooktrout® License Manager. See the Dialogic® Brooktrout® Fax Products Windows End User Guide.

Note: If you have a previous version of the Dialogic® Brooktrout® SDK installed on your system, you must uninstall it before you can successfully install the latest Dialogic® Brooktrout® SDK. The InstallShield Wizard does not install the latest Dialogic® Brooktrout® SDK if there is a previous version on your system; however, it notifies you of the previous version and suggests corrective action. See [Removing or Modifying the Software on page 66](#) for more information.

➤ *Follow the steps below to install the Dialogic® Brooktrout® SDK from the CD-ROM:*

1. Insert the SDK CD-ROM into a CD drive.
The Autorun program starts automatically.
If the Autorun program does not start automatically:
 - a. Go to the CD root directory on the CD-ROM.
 - b. Launch *autorun.exe*.

Autorun Menu

The Autorun Menu appears:



2. Choose **Install SDK** from the list of options, which starts the setup procedure and runs *InstallShield* to extract the files needed to install the Brooktrout SDK on your system.
The splash screen followed by the **Welcome** window appears.
3. Click **Next**.
The **License Agreement** window appears.

4. Read the license agreement and, if you agree, select the appropriate option and click **Next**.



The **Destination Folder** dialog box appears.


-
5. Click **Change** to choose a folder or click **Next** for the default folder, *C:\Brooktrout\Boston*.

In the example, *C:\Brooktrout\Boston* is the destination folder where the application software installs the Brooktrout SDK contents.

If you choose **Next**, go to [Step 7](#).


If you choose **Change**, the **Change Current Destination Folder** dialog box appears.

6. Click **OK** after selecting a new location for the software, which takes you back to the **Destination Folder** dialog box.
7. Click **Next** on the **Destination Folder** dialog box.




The **Setup Type** dialog box appears.

8. Choose one of the setup types:
 - ◆ Select **Complete** for the full software development kit that includes the Bfv and other APIs used for writing your applications, the tool to configure your boards and software, the runtime system, and troubleshooting tools.
 - ◆ Select **Custom** for picking specific software elements that exactly match your development needs.




Custom Setup

If you choose **Custom**, the **Custom Setup** window appears.




Custom Setup Tips

For help, click **Help** to see the **Custom Setup Tips** window.




9. After reading the **Help**, click **OK** to return to the **Custom Setup** window.
10. Select the components you want to install and click **Next**.
If you choose **Complete** or if you select a custom installation, the **Ready to Install** window appears.



11. Click **Install** to install the software.

The Installing Dialogic Brooktrout SDK window appears.




After the software is installed, the **InstallShield Wizard Completed** windows appears.

The installation program reminds you to activate your Dialogic® Brooktrout® SR140 with the Brooktrout License Manager and to finish configuring using the Brooktrout Configuration Tool.


12. Click **Finish**.

InstallShield Wizard Completed

When the x32 Windows installation finishes, the following InstallShield Wizard Completed window appears:



When the x64 Windows installation finishes, the following InstallShield Wizard Completed window appears:



On Windows x64, install the Brooktrout x64 package if you are running a 64-bit applications. The Brooktrout x64.msi package installs all the x64 components required to run x64 applications that use 64-bit Brooktrout libraries. Refer to [Brooktrout_x64 on page 68](#). Shut down your computer and install the board using the instructions in the hardware installation card that came with the board.

Installation Directory

When the installation is complete, the resulting directory, *[INSTALLDIR]*: (*C:\Brooktrout\Boston* is the default), contains the directories according to the options you choose. See [Directory Structure on page 126](#) for the installed directories and files.

Installing Licenses (SR140 Only)

After rebooting your system, you can install your Dialogic® Brooktrout® license. See the *SR140 Fax Software Windows User Guide* for more information.

Sample Applications

You must compile the sample applications if you want to use them. See the chapter in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide* on compiling the sample applications.

Remove Previous Version

The InstallShield Wizard does not install the latest Brooktrout SDK if you have a previous version of the SDK. You must remove it before installing the latest SDK.

See [Removing or Modifying the Software on page 66](#) and [Removing the Plug-and-Play Driver on page 81](#).

Removing or Modifying the Software

After you install the Brooktrout SDK, you can modify, repair, or remove it by running *sdk_windows.exe* again. Modifying or removing the Brooktrout SDK means reinstalling the software to add or delete functionality.

You can also remove or change the Brooktrout SDK or a previous version of the Brooktrout SDK by using **Add/Remove Programs** from the **Control Panel**.

➤ *Follow the steps below to uninstall or modify the existing software from the Control Panel:*

- ◆ **Start** → **Settings** → **Control Panel** → **Programs and Features**.


Add/Remove Program

The **Add/Remove Programs** window appears.

Note: On 64-bit Windows OSes, if installed also remove the Dialogic Brooktrout x64 components. Refer to [Brooktrout_x64 on page 68](#).

1. Select **Dialogic Brooktrout Boston SDK** from the program list.

If you click **Remove**, the system asks you if you want to remove the software in the **Add/Remove Programs** dialog box.



2. Click **Yes**.
3. If you click **Change** in the **Add/Remove Program** window, the **Welcome** window appears.

-
4. Click **Install**.

The software installs the Dialogic® Brooktrout® SDK.

If you choose **Repair**, the **Ready to Repair** window appears.

5. Click **Install** to have the wizard install the Dialogic® Brooktrout® SDK again.

Then the **InstallShield Wizard Completed** window appears after the software is reinstalled to either modify or repair it.

If you choose **Remove**, the **Remove the Program** window appears.

6. Click **Remove**.

The **Uninstalling Dialogic® Brooktrout® SDK** window appears.

When the removal of the software is complete, the **InstallShield Wizard Complete** window appears.

7. Click **Finish** to complete the operation.

These procedures only remove the files and directories that the installation procedure placed on the system.

64-bit Windows API Libraries

The 64-bit API libraries allow customers to build 64-bit applications that take full advantage of Windows 64-bit performance on x64 systems.

64-bit system

On a 64-bit system, the Brooktrout package installs the 64-bit version of the libraries in the following directory:

```
windows\system32
```

The 32-bit libraries are installed in the following directory:

```
windows\syswow64
```

32-bit system

On a 32-bit system, the Brooktrout package installs the 32-bit version of the libraries in the following directory:

```
windows\system32
```

No 64-bit libraries are installed in the system directory.

All files are available in the Brooktrout folder.

Brooktrout_x64

The *Brooktrout_x64* package installs all of the 64-bit components required to run 64-bit applications that use Brooktrout libraries.

This package installs the following:

- Visual Studio 2015 x64 components
- 64-bit Brooktrout API libraries in system directories

You install this package separately after installing either *sdk_windows.exe* or *boston.msi*. You can remove this package separately as well.

This package is available in two locations:

- On the CD under the directory `Software\Windows`
- Inside of the *sdk_windows.exe* package in the directory `Boston\bin\x64` after the *sdk_windows.exe* package is installed.

System Files

You can install either combination of packages below:

- *sdk_windows.exe* and *Brooktrout_x64.msi*
- *boston.msi* and *Brooktrout_x64.msi*

After installing them, the following configuration will be on the 32- and 64-bit operating systems:

32-bit operating system

A 32-bit operating system will have the following files installed in the `system32` directory:

- `system32\bostdll.dll`
- `system32\bostsrv.exe`
- `system32\bostsrv.dll`
- `system32\bsmidlld.dll`
- `system32\brkth323.dll`
- `system32\brktsip.dll`
- `system32\osidlld.dll`

64-bit operating system

A 64-bit operating system will have the following files installed:

64-bit version of the API binaries:

- `system32\bostdll.dll`
- `system32\bsmidlld.dll`
- `system32\osidlld.dll`

32-bit version of the API binaries:

- `syswow64\bostdll.dll`
- `syswow64\bostsrv.exe`
- `syswow64\bostsrv.dll`
- `syswow64\bsmidlld.dll`
- `syswow64\brkth323.dll`
- `syswow64\brktsip.dll`
- `syswow64\osidlld.dll`

All the above files will also be available in the Brooktrout\boston directory.

Note: The system32 directory on a 64-bit system is visible only by using 64-bit applications like Explorer. The 32-bit applications are not able to access that location.

4 - Installing the Device Driver on Windows

This chapter describes how one can install the device driver on Windows systems.

This chapter contains the following:

- *Installing and Configuring Options on page 72*
- *Installing the Plug-and-Play Driver on page 73*
- *Installing and Configuring the Driver using a Command (cmd) Prompt on page 84*
- *Using the Boston Host Service on page 89*
- *Special Considerations on page 92*

Installing and Configuring Options

Once the computer telephony hardware and software are installed on your system, you must install and configure the device driver for the Dialogic® Brooktrout® boards. This chapter describes two methods for installing the device driver:

- Automatically by letting the operating system identify the device, find the driver, and install it. See *Installing the Plug-and-Play Driver on page 73*.
 - ◆ You must be running on Windows to install the driver automatically using the Plug-and-Play (PnP) feature of the operating system.
 - ◆ SR140 (virtual module) users can also use the Dialogic® Brooktrout® Configuration Tool to install the driver.
- Manually running the *install* program from the command line. See *Installing and Configuring the Driver using a Command (cmd) Prompt on page 84*.

You can install the PnP driver manually using the *install* program with Windows.

Note: For users of Windows 2008 and later: It is strongly recommended to run the driver installation program with Administrative Privileges. Otherwise a dialog box will appear requiring you to respond to continue the installation.

Installing the Plug-and-Play Driver

After you have installed your Dialogic® Brooktrout® board the operating system can automatically install the driver for your board.



Found New Hardware Wizard

➤ *Follow the steps below to install the driver for your board:*

1. Turn on your computer.

As the operating system finishes booting, the **Found New Hardware Wizard** window might appear.

This window does not appear if the hardware was already detected from a prior boot or if you are upgrading from an older installation.

See [Updating Computer Telephony and the Plug-and-Play Driver on page 78](#) for information about upgrading.

2. Click **Next** to continue the device driver installation.

Installing Hardware Device Driver


The **Install Hardware Device Driver** window appears.



3. Choose the **Search for a suitable driver for my device (recommended)** and click **Next**.

Locating Driver Files

The **Locate Driver Files** window appears so the wizard can search for a suitable driver.



Browsing for the .inf File


4. Check **Specify a Location** and click **Next**.
5. The following window appears where you can browse to select the *trxstream.inf* file located in the following folder:
C:\Brooktrout\Boston\driver\winnt\pnp



6. Click **OK**.

Finding the Driver File

The **Driver File Search Results** window appears.



7. The **Completing the Found New Hardware Wizard** window appears then click **Finish**.
The Plug-and-Play installation is complete.


Verifying Dialogic® Brooktrout® Board Integration

- *Follow the steps below to verify that the Dialogic® Brooktrout® board is successfully installed on your system:*

1. Click one of either:


- ◆ Control Panel →Administrative Tools →
Computer Management

The **Computer Management** window appears:



- ◆ Control Panel →System →Hardware →Device Manager

The **Device Manager** window appears:




2. To view the properties of the Dialogic® Brooktrout® board in your system, double-click the board name in one of the windows shown above.

Viewing Dialogic® Brooktrout® Board Properties

The **Brooktrout TRxStream Board Properties** dialog box appears.

3. Click the **Device Details** tab.



-
4. Click the **Configure** button to use the Dialogic® Brooktrout® Configuration Tool Wizard to configure the device driver as well as other facilities of the board (for example, telephony).

For extra help, see [Configuring Software on page 101](#) for information about configuring your system. The Brooktrout Configuration Tool starts in Wizard mode if the boards are identical, or Advanced Mode if the boards are different.

Updating Computer Telephony and the Plug-and-Play Driver

A Plug-and-Play-compliant device driver cannot be started unless the devices managed by the driver are physically installed in the host system *and* are in an enabled state.

Removing Dialogic® Brooktrout® Hardware

➤ *Follow the steps below to remove the previous version of the Computer Telephony and device driver:*

1. Click **Start** → **Settings** → **Control Panel**.
Select the **Add/Remove Hardware** option to remove the previously installed Dialogic® Brooktrout® boards.
The **Add/Remove Hardware Wizard** window appears.
2. Click **Next**.
The **Choose a Hardware Task** window appears.
3. Select **Uninstall/Unplug a device** and click **Next**.
The **Choose a Removal Task** window appears.
4. Select **Uninstall a device** and click **Next**.
The **Installed Devices** window appears.
5. Select the device labeled **PCI Device** (or possibly **Network Controller** for some older digital boards) and click **Next**.
Note: If you have more than one device named **PCI Device** listed under **Devices**, select the first one.
The **Uninstall a Device** window appears.
6. Select **Yes** and click **Next**.
The **Add/Remove Hardware Complete** window appears and informs you that the device was successfully removed.
7. Click **Finish**.
8. Follow Step 1 through Step 6 to remove each Dialogic® Brooktrout® board that is listed as **PCI Device** (or possibly **Network Controller**) in the **Devices** list in the **Installed Devices** window.

Once the Plug-and-Play installation process is completed, verify that the Computer Telephony category appears correctly in the **Device Manager** and contains all installed Dialogic® Brooktrout® hardware.

See [Verifying Dialogic® Brooktrout® Board Integration on page 76](#).

Updating Previous Versions of the Plug-and-Play Driver

After you update the driver, reboot your system to ensure that the new driver is used.

➤ *Follow the steps to update the device driver:*

1. Open the **Windows Device Manager**.
2. Select **Start** → **Settings** → **Control Panel** → **Administrative Tools** → **Computer Management**.
3. Select the **Device Manager** node.
4. Expand the **Computer Telephony** node.
5. Right-click a Dialogic® Brooktrout® board and select **Properties** to open the board properties window.
6. Select the **Driver** tab and look for the **Update Driver** button.
7. Click **Update Driver** to start the **Update Driver Wizard**.
8. Click **Next**.
9. After the **Install Hardware Device Drivers** window appears, select **Search for a suitable driver for my device**.
10. The **Locate Driver Files** window appears, select **Specify a location**.
11. On the next window, choose **Browse** and locate the *trxstream.inf* file located on the CD under the *Windows Plug-and-Play* folder, or if you have already installed the Brooktrout SDK, locate the file under *[INSTALLDIR]\driver\winnt\pnp*.

If the specified location for the new *trxstream.inf* file is different from the location for the old *trxsteam.inf* file, and if the file still exists in the old location on your system, the update does not work. The system uses the old file and location instead of the new one. Delete the old copy of the *trxstream.inf* file and its Plug-and-Play components before installing the new one.
12. Click **OK** and then **Next**.
13. Click **Next** and then **Finish**.

Removing the Plug-and-Play Driver

Installing a Dialogic® Brooktrout® device using the Plug-and-Play Manager (Found New Hardware Wizard) creates some backup files and registry entries. The Windows Plug-and-Play Manager uses this information to automatically install the device on rebooting.

To completely remove the Plug-and-Play driver from the system, you must perform a complete cleanup after you remove the device from the Device Manager.



Make sure you stop all your applications and the Boston Host Service before uninstalling the device driver.

➤ *Follow the steps below to remove the Plug-and-Play driver:*

1. Open **Windows Device Manager**.
2. Expand the **Computer Telephony** node.
3. Remove all the Brooktrout boards listed under the **Computer Telephony** node.
 - a. Expand the “Computer Telephony” node.
 - b. Right click the Brooktrout board node and select.
4. Open **Command Prompt** and type “net stop boston” to stop the driver that can still be running.
5. Delete the following files:

```
C:\WINNT\SYSTEM32\DRIVERS\boston.sys
```

```
C:\WINNT\SYSTEM32\brktBdevpp.dll
```

6. Examine the registry value `InfPath` located under:

```
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\Class\{8CF4CA66-A2CC-48FA-BC1D-6A64E47F6D27}
```

Search for the first key which contains the following values:

- ◆ `DriverDesc=Brooktrout TRxStream Board`

This key should contain the name of the backup copy of the *trxstream.inf* file that Windows created during the device installation under *C:\winnt\INF*.

-
7. Delete the *INF* file of this name from *C:\WINNT\INF* along with the corresponding *PNF* file. Except for the extension, the *INF* file and the *PNF* file have the same names. For example, if the *INF* file is *oem11.inf*, the name of the *PNF* file is *oem11.pnf*.

8. Delete the following registry keys:

For 32-bit operating system:

HKEY_LOCAL_MACHINE\SOFTWARE\Brooktrout Technology
\DevicePropertyPage

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services
\Boston

For 64-bit operating system:

HKEY_LOCAL_MACHINE\SOFTWARE\WOW6432Node
\Brooktrout Technology\DevicePropertyPage

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services
\Boston

9. Reboot the system and verify that the **Brooktrout TRxStream** node(s) is not listed under the **Computer Telephony** class node in the **Device Manager**.

Disabling Plug-and-Play Driver Installation

After you install a Dialogic® Brooktrout® board, the Windows operating system might display a window stating that a new PCI device was found and offer to detect/install a driver for it. Proceed with the automatic detection. The operating system will not find a matching driver. Do not attempt to supply a driver when asked.

➤ *The detection of new hardware occurs after each reboot unless you perform the following procedure:*

1. When **Welcome to Found New Hardware Wizard** appears, click **Next**.
2. Select **Search for a suitable driver for my device (recommended)**.
3. Click **Next**, uncheck all choices, then click **Next** again.
4. Select **Disable device**
5. Click **Finish**.

➤ *Another approach is to:*

1. Click **Cancel** for ALL new devices that are found.
2. Right-click **My Computer**.
3. Right-click **Properties**.
4. Right-click **Hardware**
5. Right-click **Device Manager**.
6. Look for: **Other Devices**.
7. Right-click all devices with: **?**.
8. Select **Disable**.

Reinitializing the Driver

You can reinitialize the driver to its starting state in terms of channels assigned to modules and module number assignments using the *driver_reinit.exe* utility located in the *boston\driver\winnt\user* directory (see [Reinitializing the Device Driver on page 172](#)).

Installing and Configuring the Driver using a Command (cmd) Prompt

To install and configure the driver manually, change to the *[InstallDir]\driver\winnt\install* directory and run the *install* program. You can use this application to install Plug-and-Play drivers.

The configuration dialog is as follows:

```
Installing Brooktrout Boston Device Driver Version 6.7.0
Maximum number of PCI/cPCI hardware modules (default 16):
Physical buffer size (default 32768):
Application buffer size (default 10240):
Machine ID, in hex (default 1):
Do initial reset (default 1):
History enable (default 0):
```

If you enter *1*, *install* asks the following questions:

```
History size (default 1024000):
Number of physical channel histories (default 0):
Number of application channel histories (default 0):
Restrict physical channel histories to admin channel 1
(default 1):
Configure advanced parameters (n)?
```

If you enter *y*, *install* asks the following questions:

```
Stop history on module death (default 0):
Number of I2O frames per module (default 16):
Driver flow control interval (default 250):
Internal memory allocation minimum (default 152):
Internal memory allocation quanta (default 128):
To reserve module numbers, enter mod_id (serial number)
and mod_num, in hex. Mod_num will default as indicated:
mod_id mod_num[f0]:
Configure test parameters (n)?
```

If you enter `y`, two test options are listed:

Test2:

Test3:

Configuring Boston driver:

Phys buf size 32768

App buffer size 10240

Machine ID 1

History size 1024000

Num phys hist bufs 0

Num apl hist bufs 0

Load driver with no devices present? (y or n, default y):

When using Boston PCI hardware modules, a system memory adjustment may be required in order to properly access the modules. For a small number of modules this is often not required, but many factors, including other devices that are or will be in the system, affect this. After this adjustment is made, the system must be rebooted.

Do you wish to perform this adjustment? (default n):

After installing the Plug-and-Play driver, the following message appears:

Installing Plug and Play driver.

The Plug and Play driver was successfully installed.

The maximum number of PCI hardware modules can be left at its default. However, if fewer modules are in use, this value can be set to a smaller number to conserve memory. Each hardware module uses approximately 60K.

The following exit codes from the install program, either for driver installation or removal, can be used to determine if there was an error and/or if a reboot is required.

0 - No error and no reboot required

1 - No error and reboot required

-1 - Error and no reboot required

-2 - Error and reboot required

For more information, see:

- [Command Line Configuration for Install on page 96](#)
- [Windows Operating System on page 166](#)

See notes within [Installing the Plug-and-Play Driver](#) for information about pop-ups that may appear after installing the driver.

History Logging

When the *install* program installs the driver, history logging is disabled by default (0). When you manually install the driver using *install*, the default is set to disable history logging (which you can choose to override). History logging is a powerful debugging tool, especially when working with Dialogic Technical Services and Support. However, it does consume a significant amount of CPU time when running very high call loads. Therefore, leave history logging off for systems that have high call loads and are CPU bound. For low-load systems or when debugging, enable history logging (1).

Leave the number of physical and application channel histories at 0 unless you are directed to change this by Dialogic Technical Services and Support. If you change the physical or application buffer size, do not change the value to one smaller than the default.

Advanced Configuration Parameters

If you select advanced configuration parameters, the software prompts you for the number of I2O frames, driver flow control interval, internal memory allocation parameters, module reservations, and test parameters. Do not configure advanced parameters except under the advice of Dialogic Technical Services and Support.

Memory Resources

When Dialogic® Brooktrout® PCI hardware modules are installed in the system, a certain type of memory resource might be exhausted or dangerously low if you do not perform a memory adjustment. For small numbers of modules, the adjustment is often not required, but there is no way to predict the point at which it becomes necessary, since each system is different. Need for the adjustment depends on the system configuration, whether other drivers or devices are using this type of memory or will in the future, and possibly other factors. If you choose to perform the system memory adjustment, *install* prompts you for the system memory size.

```
Enter the number of MB of memory in the system[32]?
```

If a memory adjustment has been performed by another program, *install* prompts you as to how to proceed.

```
Do you wish to   (1) skip adjusting,  
                 (2) replace adjustment, or  
                 (3) add to the adjustment
```

Proceeding with any of the adjustments in this case might not properly succeed or be reversible later, but the *install* program does the best it can to make the adjustment safely.

The program then advises you to reboot.

```
You must reboot the system for the memory  
configuration changes to take effect.
```

```
A reboot is recommended. Do you wish to reboot now? [n]
```

The *install* application also prompts you to reboot the system if Windows requires a system restart to complete the Plug-and-Play installation.

Removing the Driver with a Command (cmd) Prompt

To remove the driver, enter the following at the Command Prompt:

```
install -r
```

You must include the following parameter (see [Command Line Configuration for Install on page 96](#)):

```
Reboot (if needed) after memory readjustment (1 or 0)
```

This option successfully removes all the Dialogic® Brooktrout® PnP devices that are installed using the *trxstream.inf* file that came with your Brooktrout SDK. If you installed the Dialogic® Brooktrout® PnP hardware using some other INF file that registers the Dialogic® Brooktrout® boards under a class other than Computer Telephony, the *-r* option can fail to completely uninstall this device.

Reinitializing the Driver

You can reinitialize the driver to its starting state in terms of channels assigned to modules and module number assignments using the *driver_reinit.exe* utility located in the *Boston\driver\winnt\user* directory (see [Reinitializing the Device Driver on page 172](#)).

Using the Boston Host Service

The Boston Host Service (Bostsrv) is used to initialize modules. Upon startup it detects Dialogic® Brooktrout® modules, loads FW and initializes the call control. You must use the Boston Host Service to run a multi-process application or to use Dialogic® Brooktrout® SR140 Fax Software. The Boston Host Service is optional for other Dialogic® Brooktrout® modules.

The Boston Host Service is installed and started automatically by the Brooktrout Configuration Tool when you click the Apply button. The command line process is not required.

To run the Boston Host Service with the driver, use any of these commands.

What you can do with Bostsrv	Command Line
To start the service	net start bostservice
To stop the service	net stop bostservice
To install the service	bostsrv -install
To remove the service	bostsrv -remove
To run as a console application for debugging	bostsrv -debug
To enable Bfv API debug mode	bostsrv -v
To log output to file (can be used with -debug and -install)	bostsrv -l <file>

Note: You must have administrative privileges to install, remove, start, or stop the Boston Host Service.

Installing Bostsrv

➤ *Follow the steps below to install the Boston Host Service, in a Command Prompt window:*

1. Enter the following at the a command prompt:

```
bostsrv -install
```

2. Enter name and location of the btcall configuration file. (default shown)

```
C:\Brooktrout\Boston\bfv.api\winnt\bin\btcall.cfg
```

3. Enter the location of the firmware files. (default shown)

```
C:\Brooktrout\Boston\fw
```

Starting Bostsrv

➤ *Follow the steps below to start the Boston Host Service, in a Command Prompt window:*

Enter the following at the a command prompt:

```
net start bostservice
```

```
The Brooktrout Technology Boston Host Service is starting...
```

To set the Boston Host Service to start automatically, set startup mode to **Automatic** using Windows Services window. This initializes the Dialogic® Brooktrout® modules upon machine starter reboot. You can also perform this step through the **Options, Preferences....Boston Host Service in Start Mode** in the Brooktrout Configuration Tool.

Troubleshooting Bostsrv

System Error 59

When the Boston Host Service fails to start as a service with a system error 59, verify that you correctly entered the configuration file name and path location, as shown in [Installing Bostsrv on page 90](#) for the *btcall.cfg* file.

If you do not specify the full path to the protocol for the *callctrl.cfg* file, within the *btcall.cfg* file, a system error 59 can also occur.

Special Considerations

When you install the device driver on a Windows operating system, consider the following topics:

- [PCI Considerations on page 92](#)
- [Dialogic® Brooktrout® Bfv API Libraries and Makefiles on page 93](#)
- [Writing Multithreaded Programs on page 93](#)
- [Using BOSTDLLD with Debugging Enabled on page 94](#)
- [Determining Installation Parameters on page 94](#)
- [Driver Startup on page 95](#)
- [Global Variables on page 95](#)
- [Limits on Open Files on page 95](#)
- [Process Priority on page 96](#)
- [Command Line Configuration for Install on page 96](#)
- [Driver File Locations \(install\) on page 99](#)

PCI Considerations

The operating system and/or system BIOS assigns base addresses and interrupt numbers to the PCI boards, that might change when the system is rebooted, especially if devices are added or moved.

If multiple PCI boards are in use, see [Determining the Board Module Number on page 24](#) to determine the module numbers of boards or ordinal channel values.

Dialogic® Brooktrout® Bfv API Libraries and Makefiles

Dialogic only supplies dynamically linked C runtime libraries (BOSTDLLD).

The *app.src* and *bapp.src* directories contain makefiles that compile using BOSTDLLD.DLL version of the Bfv API libraries. All applications should try to follow the makefiles supplied in the *app.src* or *bapp.src* directory. In particular, since all the supplied libraries were compiled as multi threaded, compile all your applications this way. See also, [Reviewing Compiler and Linker Options on page 73](#).

When using a dynamically linked version of the library, either add the directory name containing the DLL to your PATH environment variable, or copy the DLL into a directory already in PATH. For example:

```
\Brooktrout\Boston\bfv.api\winnt\lib
```

Writing Multithreaded Programs

When new threads are created, often a stack size can or must be specified. The stack size must be sufficiently large to store all local variables used both by the application and the Bfv API. If the stack size is not large enough, unpredictable behavior can result.

Dialogic usually finds a stack size of 64k to be sufficient but, depending on the application stack allocation demands, more memory might be required.

Using BOSTDLLD with Debugging Enabled

When using the DLL version of the Bfv API library with a debug version of your application, take special care when handling FILE * file pointers or dynamically allocated memory.

Some functions use FILE * pointers that the application must open. Applications can also access FILE * pointers that the Bfv API has opened (with the `TIFF_FP` macro). There are also some instances where memory is allocated by the Bfv API that must be freed by the application, for example, *BfvLinesAvail* and `PAGE_RES` structures.

The runtime libraries used by BOSTDLLD are separate from the debug ones used by the application. The meanings and applicability of the file pointers and allocated memory differ and are incompatible between the two copies of the runtime libraries. To avoid these kinds of pointer problems, the Bfv API provides a set of `_dll_...` functions. See *Volume 1 of the Dialogic® Brooktrout® Bfv APIs Reference Manual*.

Determining Installation Parameters

Any time after the driver has been installed (but not removed), you can determine what installation parameters were used.

➤ *Follow the steps below to determine the installation parameters:*

1. Run *regedit* or *regedit32*.
2. Locate the key:

```
HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Services  
\Boston\Parameters
```

3. Look at the values under this key.

Driver Startup

After you install the driver, it has a service associated with it named *boston*, a kernel-mode driver.

If driver startup fails, the error message that appears is almost always unrelated to the actual cause of failure. The Event Log contains an error message supplied by the driver. Using the Event Viewer, look for the most recent entries in the System section labeled *boston*. Occasionally the Event Log fills up. If this happens, set *Action->Properties->Overwrite* events as needed.

Under kernel debugging environments, the debugger also contains a message. Under other conditions, entries can also appear in the Event Log or debugger. If you encounter unusual behavior, check the Event Log or debugger.

Global Variables

If you plan to compile your application for use with the Dialogic® Brooktrout® Bfv API library, do not use local variable names that match any of the names of the global variables defined by the Bfv API library. Such duplications will prevent the application from compiling.

The Bfv API global variables include:

- the variables used by *getopt* (for example, *optind*)
- the *_mill_priority* variable, specific to Windows

Limits on Open Files

The Microsoft Visual C++ compiler library limits the number of files that can be opened. Developers often encounter this limit when developing multithreaded Dialogic® Brooktrout® Bfv API applications. Microsoft has updated their libraries, greatly increasing this limit. For Visual C++ 4.1+, the limit is 512 files. You can increase this limit using the *_setmaxstdio* function from the compiler library.

Process Priority

The Bfv API automatically raises the priority of any process that calls *BfvLineAttach* to `HIGH_PRIORITY_CLASS`. Dialogic recommends using this priority to keep delays to application processes performing fax or speech functions to a minimum. Priority raising occurs the first time the application calls *BfvLineAttach* only, and is controlled by the global variable `_mill_priority`, which contains the new priority for the process.

Command Line Configuration for *Install*

When configuring the device driver using *install* or removing it using *install -r*, you can specify the command line option `-c` to cause the *install* program to not prompt you for any parameters. Instead, the *install* program uses the responses that you supply following the `-c` option on the command line.

If you use the `-c` option, you must include all the parameters described below, in order, regardless of whether or not the parameter has meaning on the system in question. If a parameter does not apply, it is ignored. The parameters are not checked for validity.

Note: The software does not prompt for removal of old driver versions.

When configuring the driver using *install*, you must include the following parameters:

Parameter	Defaults
Reserved	p
Reserved	0
Reserved	-1
Max num PCI hardware modules	16
Physical buffer size	32768
Application buffer size	10240
Reserved	0
Machine ID	1
Reset option (1 or 0)	1
History Enable	0

History Size	1024000
Num physical histories	0
Num app histories	0
Restrict phys channels (1 or 0)	1
Number of I2O frames	*0
Flow control interval	*0
Memory alloc minimum	*0
Memory alloc quanta	*0
Reserved	0
Stop history on module death	*0
Test parameter 2	*0
Test parameter 3	*0
Reserved module info	*0
module id, module number	
0 to terminate	
Load driver with no devices present (y or n) - (n = pnp, y = software only solution)	n
Do mem adjustments (y or n)	n
What to do if already adjusted (1, 2, or 3)	1
Memory in system	0
Reserved	0
Reboot after mem adjustment (1 or 0)	0

The advanced parameters, marked with * in the list above, can always be safely set to 0. This setting tells the driver to use the default values.

For example, to configure the driver for up to 16 PCI hardware modules use the following settings:

physical buffer size 32768
application buffer size 10240
machine ID 1
reset on
history enabled
history size 1024000
physical histories 0
application histories 0
restrict physical channels 0
all default advanced parameters 0
not to start at boot 0
no memory adjustments 0
not reboot 0

Enter the following at the command line:

```
install -c p 0 -1 16 32768 10240 0 1 1 1 1024000 0 0 1 0 0 0 0 0 0 0 0 0 y n  
1 0 0 0
```

For more information, see [Windows Operating System on page 166](#).

Driver File Locations (install)

When using *install* to configure the device driver, you do not need all files from the distribution. However, the file locations used by the configuration procedure relative to the directory where *install* is run must be the same as that in the normal distribution.

Assuming a directory named *install* where *install* is being run, the following files must be present:

install\install.exe

pnp\brooktrout.cat

pnp\trxstream.inf

pnp\TRxStream\x86 (directory for the following 32-bit OS files)

boston.pdb

boston.sys

brktBdevpp.dll

brktBdevpp.pdb

pnp\TRxStream\x64 (directory for the following 64-bit OS files)

boston.pdb

boston.sys

brktBdevpp.dll

brktBdevpp.pdb

These files and directories appear in the standard distribution under the directory *driver\winnt*.

Build Requirements for install

You need the Windows DDK installed to compile the *install.exe* application. For more information about the Microsoft Windows Device Driver Kit, see *microsoft.com*. *install.exe* links to the DDK libraries: *setupapi.lib* and *newdev.lib*. It also links to the *shlwapi.lib* system library.

Version Information

The driver file, *boston.sys*, and the DLL library file, *bostdlld.dll*, contain version resource information. Use the system File Manager or Explorer to view this information.

Reviewing Compiler and Linker Options

The makefiles contained in the *app.src* and *bapp.src* directories provide a number of command line options to the compiler and linker. Using these options, the compiler and linker produce object files and executables compatible with the Bfv API library.

Dialogic strongly recommends that you use these options for all your Bfv API applications. But for those who want to change the set of options the compiler and linker use, the following is a list of the nonstandard options and their functions. The options used for compilation are marked with (C) and those for linking are marked with (L).

The makefile uses the standard \$(cflags) from *ntwin32.mak* and \$(cvarsdll) for the dynamically-linked C runtime libraries. It uses the standard \$(conlflags) for linking.

\$(cflags)	(C) Options for CFLAGS.
\$(cvarsdll)	(C) Options defining dynamic runtime library.
\$(conlflags)	(L) Options for linking console mode program.
-nologo	(C) Do not print logos.
-DWINNT	(C) Defines a symbol that identifies the environment.
-UMSDOS, -U_MSDOS	(C) Undefines symbols that the compiler might define that can cause problems at compilation.
-DMILL_DLL	(C) Defines a symbol that is required when using the DLL Bfv API library.
libcpmt.lib	(L) C++ libraries. Required when new call control is used.
NODEBUG=1	Note: This is a makefile line, not a compilation or link flag.

This line is needed in the makefile when compiling with certain versions of Visual Studio to prevent it from automatically compiling for debugging and producing inappropriate warning messages.

5 - Configuring Software

This chapter describes how one can configure the Dialogic® Brooktrout® Fax Software for your Dialogic® Brooktrout® boards.

Dialogic has created ways to configure the Dialogic® Brooktrout® software including:

- *Using the Dialogic® Brooktrout® Configuration Tool on Windows Systems on page 103*
- *Running the Dialogic® Brooktrout® Configuration Tool on page 106*

For Windows operating systems, you can use the Brooktrout Configuration Tool in one of several modes:

- ◆ *Configuring in Wizard Mode on page 116*
- ◆ *Advanced Mode on page 117*
- ◆ *Offline Mode on page 118*
- ◆ *Silent Mode on page 123*
- *Using a Call Control Configuration File on page 124*

For all operating systems, you can configure the call control by creating a call control configuration file that is read by the *BfvLineReset* function.

For more information, see:

- *Volume 6, Appendix A* in the *Dialogic® Brooktrout® Bfv API Reference Manual*
- The Bfv API Function Locator in the *Dialogic® Brooktrout® Bfv API Reference Manual*

Using the Dialogic® Brooktrout® Configuration Tool on Windows Systems

When you use one of the Windows operating systems, you can configure your module with the Dialogic® Brooktrout® Configuration Tool for Windows (*configtool.exe*).

The Dialogic® Brooktrout® Configuration Tool is a graphical user interface program that you can use to create and modify the configuration files, edit and update the driver parameters, and configure and initialize the module. The Brooktrout Configuration Tool also installs the Plug-and-Play driver, if not already installed.

It can be launched in the following modes.

- [Wizard Mode on page 103](#)
- [Advanced Mode on page 104](#)
- [Offline Mode on page 104](#)
- [Timer Mode on page 105](#)
- [Silent Mode on page 105](#)

A brief summary of each mode function is highlighted here:

Wizard Mode

Guides you in configuring Dialogic® Brooktrout® software and hardware. To use Wizard mode, all Dialogic® Brooktrout® modules in your system must be of the same type and the Brooktrout Configuration Tool must recognize the modules as Dialogic® Brooktrout® boards.

When the system contains different types of modules or the Brooktrout Configuration Tool does not recognize a module, the Brooktrout Configuration Tool selects Advanced Mode automatically.

See [Configuring in Wizard Mode on page 116](#).

Advanced Mode

Requires that you have some knowledge of computer telephony, communications protocols, and Computer Telephony. The Brooktrout Configuration Tool automatically selects Advanced Mode when there are different types of modules installed or when you explicitly indicate Advanced Mode by using a command line switch to start, possibly to configure each module differently (even if the modules are the same kind).

A toolbar provides the following options:

- The **Save** button:
 - Saves the configuration.
- The **Apply** button:
 - ◆ Saves your configuration to the appropriate configuration file.
 - ◆ If driver parameters were modified, it dynamically reconfigures the drivers on a PnP operating system.
 - ◆ If the Boston Host Service is not installed, installs the Boston Host Service.
 - ◆ If the Boston Host Service is running, stops the Boston Host Service.
 - ◆ Starts the Boston Host Service.

See [Advanced Mode on page 117](#).

Offline Mode

Allows you to create/edit configuration files when no boards are installed. In Offline Mode, the toolbar option **Apply** is not present and no checks are performed on the existence of the modules specified in the configuration.

The toolbar enables two options that are disabled in Advanced Mode: **Add** and **Remove**. These buttons allow you to modify the configuration files to add or remove modules.

See [Offline Mode on page 118](#).

Silent Mode

Reads configuration files from the location specified at installation (usually *C:\Brooktrout\Boston\config*), starts the device driver (if necessary). The graphical user interface is not displayed.

The Brooktrout Configuration Tool creates a log file (*configuration.log*) that contains all the actions that it executed and the results of these actions. This log file is located in the current working directory.

See [Silent Mode on page 123](#).

Timer Mode

Sets a timer that launches the Brooktrout Configuration Tool after a specified amount of time. You can override the time and launch the Brooktrout Configuration Tool immediately. You might want to override the timer when you do not need to check on the existence of modules.

Running the Dialogic® Brooktrout® Configuration Tool

You can run the Brooktrout Configuration Tool from:

- The program menu:

Start →All Program →Brooktrout →Brooktrout Configuration Tool

- The command line:

C:\Brooktrout\Boston\utils\winnt\bin\configtool.exe

- ◆ To specify the mode on the command line, use one of the following:

/a - Advanced Mode
/o - Offline Mode
/s - Silent Mode
/t - Timer Mode
/w - Wizard Mode

- ◆ Other command line arguments include:

/c (configip)

Displays the following note:

Note: /c option brings up the **Configure IP Stack** dialog box only if there are IP enabled devices installed.

/d (debug)

Enable the debug flag, which initiates writing of the debug information to the *configuration.log* file.

/e (expert)

Show all hidden parameters. Use this mode only under the guidance of Dialogic Technical Services and Support personnel. See [Getting Technical Support on page 20](#).

/i <INF file location>

Use the specified INF file to install the PnP driver when it is not installed or installed but not started.

You must uninstall any previous version of the plug and play driver INF file. See [Removing the Plug-and-Play Driver on page 81](#) or [Removing the Driver with a Command \(cmd\) Prompt on page 88](#).

`/f <cfgfile>`

Specify the name and location of the user-defined configuration file <cfgfile> while launching the Brooktrout Configuration Tool. For example:

`/f C:\Brooktrout\Boston\custom\btcall.cfg`

`/p`

Show the **Brooktrout Configuration Tool - Preferences** dialog box

`/q`

Do not display the **Brooktrout Configuration Tool - Preferences** dialog box.


You can use any options in combination with a mode when launching the Brooktrout Configuration Tool. When ran from any mode, including the command line without a mode option switch, the Brooktrout Configuration Tool starts in Wizard Mode, if the modules are of the same type. Otherwise, the Brooktrout Configuration Tool starts in Advanced Mode.

Choosing the File Location

When you start the Brooktrout Configuration Tool for the first time, you can choose the locations for various files using the **Brooktrout Configuration Tool - Preferences** dialog box.

Note: You might want to set these file locations before you start the Brooktrout Configuration Tool. See [Setting File Locations Prior to First Execution on page 108](#).

Preferences Dialog Box



Setting File Locations Prior to First Execution

- **To suppress the Preference dialog box with specified configuration files locations other than the defaults, before the first use of the application, follow these steps:**
1. Modify the following fields in the *settings.cfg* file (see [Example of settings.cfg File on page 109](#)):
 - ◆ `btcall_cfg_path`
 - ◆ `cc_cfg_path`
 - ◆ `log_cfg_path`
 - ◆ `firmware_dir`

The *settings.cfg* file must be placed in the same directory as the Brooktrout Configuration Tool program (*configtool.exe*):

C:\Brooktrout\Boston\utils\winnt\bin

-
2. Launch the Brooktrout Configuration Tool with the /q command line option:

C:\Brooktrout\Boston\utils\winnt\bin\configtool.exe /q

After launching the Brooktrout Configuration Tool for the first time, you can access the **Preferences** dialog box only through Advanced Mode by launching the Brooktrout Configuration Tool using /p command line option:

C:\Brooktrout\Boston\utils\winnt\bin\configtool.exe /p


Example of settings.cfg File

```
ip_stack_config=sip
home_dir=C:\Brooktrout\Boston
boston_source_path=C:\Brooktrout\Boston\driver\winnt\kernel\compile\i386
    \boston.sys
inf_source_path=C:\Brooktrout\Boston\driver\winnt\pnp\trxstream.inf
bostsrv_source_path=C:\Brooktrout\Boston\bfv.api\winnt\bin\bostsrv.exe
firmware_dir=C:\Brooktrout\Boston\fw
protocol_dir=C:\Brooktrout\Boston\config
btcall_cfg_path=C:\Brooktrout\Boston\config\btcall.cfg
cc_cfg_path=C:\Brooktrout\Boston\config\callctrl.cfg
log_cfg_path=C:\Brooktrout\Boston\bin\configuration.log
lic_mgr_path=C:\Brooktrout\Boston\bin\brktlicmgr.exe
modules_are_connected=false
vb_fname=C:\Brooktrout\Boston\fw\bostvb.dll
```

Configure IP Stack Dialog Box

When the Brooktrout Configuration Tool detects an IP-enabled device for the first time, it displays the **Configure IP Stack** dialog box:

Choose the IP stack you want to configure:



- **None:** IP stack not installed
- **SIP:** SIP stack installed (default)
- **H.323:** H.323 stack installed
- **Both (SIP and H.323):** Both SIP and H.323 stacks installed. (Not supported on SDK Versions 5.2.0 - 6.2.0).


When any option is selected, all previously added host modules are removed.

The settings for the IP stack can also be made in the *settings.cfg* file, see [Example of settings.cfg File on page 109](#).

Trace Connection Settings Dialog Box

You use the Trace Connection Setting dialog to configure the connection parameters for the Brktcctrace (server) application, and your end user application (client). See the *Debugging* chapter in your *Dialogic® Brooktrout® Fax Products SDK Developer Guide* for details about the *Brktcctrace* application.


Server Port:	Specifies the server port number.
First Client Port:	Specifies the client port that the server will first try to connect to.
Number of Client Ports:	Specifies the maximum number of clients.



Getting Help From the Dialogic® Brooktrout® Configuration Tool


The Brooktrout Configuration Tool provides context sensitive online help for parameters. The Help displays the purpose and description of the parameter including the default value and range, if applicable.

- Hold the cursor over the parameter input area to see a brief parameter definition:




- Right-click the parameter drop-down box to get a more complete definition for Brooktrout Configuration Tool parameters.

The **What's This?** popup menu appears:




- Left-click the **What's This?** popup menu for a definition like the following. You can resize this text box, if necessary.



Identifying the Model of the Board


- **When you launch the Brooktrout Configuration Tool and it is unable to automatically identify the board:**
 1. The Brooktrout Configuration Tool displays a dialog box similar to the following.



2. Choose an **Interface Type** and highlight the board model, then click **OK**.
3. If the Brooktrout Configuration Tool is not able to detect the board, then it launches the tool in Advanced Mode even if you included the `/w` parameter on the command line.

Resolving the Configtool Error Message

When you launch the Brooktrout Configuration Tool and the tool displays the **Configtool Error** screen, use the following instructions to eliminate this licensing conflict.



This error message displays when you have licenses from other vendors installed in a generic location and not in a vendor specific location. This conflict is possible with other products that use Macrovision licensing, and occurs when a Macrovision-protected application uses the `LM_LICENSE_FILE` environment variable rather than a vendor-specific name.

The Macrovision FlexNET licensing module queries for SR140 licenses. The query fails for the licenses that are installed in the generic location due to absence of the necessary vendor information.

This error message can only occur when a Brooktrout SR140 Software license is not installed.

➤ **To resolve this conflict and eliminate the Brooktrout Configuration Tool error message screen:**

1. On the **Desktop**, right-click on **My Computer**
2. Select:
Properties → **Advanced** → **Environment Variables**
3. Click **New** and create an environment variable `<VENDOR_NAME>_LICENSE_FILE`, replacing `<VENDOR_NAME>` with the application or vendor name. For example, `ACME_DLS_LICENSE_FILE`
4. Set the value of the `<VENDOR_NAME>_LICENSE_FILE` variable to the same value as `LM_LICENSE_FILE`.
For example:
If `LM_LICENSE_FILE = C:\acme\lmgr\system\license.dat`, then set

`ACME_DLS_LICENSE_FILE = C:\acme\lmgr\system\license.dat`
5. To delete the `LM_LICENSE_FILE` environment variable, highlight the current value with the mouse and click on **Delete**.
6. Click **Start** → **Run**.
7. Enter **regedit**, and click **OK**.
8. Expand:
`HKEY_LOCAL_MACHINE\SOFTWARE\FLEXlm License Manager` key and verify that there is a registry entry named `LM_LICENSE_FILE` under this key.
9. If the `LM_LICENSE_FILE` registry entry exists, rename the entry to `<VENDOR_NAME>_LM_LICENSE_FILE`. Replace `<VENDOR_NAME>` with the application or vendor name. For example, `ACME_DLS_LICENSE_FILE`
10. Verify:
 - a. The Brooktrout Configuration Tool no longer displays the error message box.
 - b. The other application using Macrovision licensing still runs.

Configuring in Wizard Mode

This section describes how to use the Wizard Mode to configure Dialogic® Brooktrout® Fax Software. You can use Wizard Mode to get most typical systems up and running with minimal effort.

In Wizard Mode, after you answer the basic questions, the Brooktrout Configuration Tool does the following.

- Automatically creates the necessary configuration file
- Installs and starts the drivers, if required
- Starts the Boston Host Service

Wizard Mode requires that all the modules be of the same kind. All modules are configured identically, that is, the modifications to the configuration apply uniformly to all the modules.

You can use Wizard Mode in a homogeneous configuration where:

- all the boards are of an identical type

or

- the system contains only SR140 virtual boards.

In a non-homogeneous configuration, the Brooktrout Configuration Tool will automatically start in Advanced Mode.

Note: To use Wizard Mode refer to *Dialogic® Brooktrout® Fax Products Windows End User Guide*.

Advanced Mode

If you have different types of Dialogic® Brooktrout® modules in your system or you want to configure your identical modules differently, you must use Advanced Mode:

- When the Dialogic® Brooktrout® Configuration Tool detects that you have different modules, it starts in Advanced Mode.
- When you start the Brooktrout Configuration Tool in Wizard Mode, you can move to Advanced Mode immediately by clicking the **Advanced Mode** button.

The Advanced Settings parameters for all module types are presented in logical groups. The ordering of the groups is alphabetical. The ordering of parameters within a group is according to their relative importance.

Most parameters are hidden unless you click **Show Advanced**. Generally, a user does not need to change the advanced parameters.

Note: To use Wizard Mode refer to the *Dialogic® Brooktrout® Fax Products Windows End User Guide*.

Offline Mode

With Offline Mode you can:

- Create or edit configuration files such as *btcall.cfg* and *callctrl.cfg*.
- Edit the device driver parameters.
- Add or remove, modules (boards).

Offline Mode allows you to create/edit configuration files when no boards are installed.


To specify Offline Mode, use command line option /o, for example:

```
C:\Brooktrout\Boston\utils\winnt\bin\configtool.exe /o
```

Offline Mode Window

When you enter Offline Mode, the **Brooktrout Configuration Tool - Offline Mode** window appears.

To navigate in Offline Mode, use the menus and buttons on the tool bar and the left panel tree view. The buttons are similar to **Advanced Mode** (see [Advanced Mode on page 117](#)) except that the **Apply** button is not present and **Add** and **Remove** buttons are available. These buttons allow you to add/remove items to and from the configuration files or add/remove modules from the configuration.




Adding a Module

➤ **Use the right mouse button to add and remove modules.**

1. Right-click on **Call Control Parameters** to add a module.


The following right panel information appears when no modules are installed.




2. The **Add Module** dialog box appears.

Select the **Module Number** and **Board Type**, then click **OK**. See [Determining the Board Module Number on page 24](#) for more information


Note: Always set the module number for the SR140 to start with 0x41, because the Brooktrout Configuration Tool Advanced Mode initializes the SR140 module as that default.



3. Enter the correct **Number of Channels** when a SR140 module type is selected, then click **OK**:



4. Click the **General Information** tab to see the added information. This example shows information for a SR140 module:




Note: For SR140 modules, you can edit the **Number of Channels** parameter entry of the call control configuration file.

Removing a Module

- **Right-click on a module name to remove it from the configuration.**

In the left panel, select the **Remove Module** option to remove the module from the configuration.




SR140 Modules in Offline Mode

When a SR140 module is detected in Offline Mode, the feature information is unavailable.


General Information Tab for SR140

The following information is displayed in the **General Information** panel for SR140 modules:



Parameters Tab for SR140

The **Parameters** tab displays the editable parameters for the SR140 module.



Silent Mode

With Silent Mode you can create the configuration files such as *btcall.cfg* and *callctrl.cfg* with defaults with no graphical user interface.

To specify Silent Mode, use command line option `/s`, for example:

```
C:\Brooktrout\Boston\utils\winnt\bin\configtool.exe /s
```

You have no interaction once you start the Brooktrout Configuration Tool. However, you can find information on the actions that were carried out during Silent Mode by referring to the *configuration.log* file that is located in the current working directory.

To manually configure the configuration file locations without using the **Preferences** dialog box (see [Preferences Dialog Box on page 108](#)) in Silent Mode, use the command line `/q` option, for example:

```
C:\Brooktrout\Boston\utils\winnt\bin\configtool.exe /q
```

When SR140 modules are present in Silent Mode, this mode does not display any windows or dialog boxes; however, the following occurs:

- Reads the configuration file
- Boston device driver starts, if stopped
- Validates data
- Writes information to the configuration file
- Boston Host Service starts

See *Volume 6* in the *Dialogic® Brooktrout® Bfv API Reference Manual* for information about the configuration files.

Using a Call Control Configuration File

The call control configuration file (*callctrl.cfg*) contains parameters that define how to configure your Dialogic® Brooktrout® boards for call control. The *callctrl.cfg* file replaces the *teleph.cfg* and *ecc.cfg* files previously used to define the call control configuration.

If you want to configure call control on your Dialogic® Brooktrout® boards, you can create a *callctrl.cfg* file on all supported operating systems (Linux and Windows). On Windows operating systems, you have the option of using the Dialogic® Brooktrout® Configuration Tool to configure the call control, or you can create or edit a call control configuration file that is read by the Brooktrout Configuration Tool. See [Using the Dialogic® Brooktrout® Configuration Tool on Windows Systems on page 103](#) and *Volume 6, Appendix A* of the *Bfv API Reference Manual*.

About the Call Control Configuration File

The call control configuration file is an ASCII file that contains general configuration parameters for all telephony hardware modules and static telephony connections to be formed for all modules. You can create your own file or edit one of the sample files supplied with the Brooktrout SDK in the *Brooktrout\Boston\config\samples.cfg* directory.

A complete description of the parameters in the call control configuration file along with examples of analog LS, analog DID, BRI, E1 ISDN (PRI), E1 CAS, E1 R2 CAS, T1 ISDN, T1 RBS, and IP call control configuration files is provided in *Volume 6, Appendix A* of the *Bfv API Reference Manual*.

The *call_control* parameter in the user-defined configuration (*btcall.cfg*) file specifies the path and filename of the call control configuration file. The Bfv API and the Brooktrout Configuration Tool use *callctrl.cfg* as the default value. The application passes the *btcall.cfg* file to the *BfvLineReset* function. *BfvLineReset* uses this information to reset and initialize the system.

The call control configuration (*callctrl.cfg*) file is divided into the following sections:

- Global parameters for call control that select trace options such as the name and size of the trace file and whether to turn tracing on or off.
- Global module parameters that define connections, specify A-law or μ -law, and specify *autoconnect* for the entire module.
- Generic clock configuration parameters that specify clock mode and source and H.100-specific parameters for the entire module.
- Port configuration parameters that describes the signaling protocol of a port and the specific parameters for the port based on the signaling protocol.
- IP call control configuration parameters that describe IP-enabled boards on the system.
- Ethernet interface parameters where you can configure modules with multiple interfaces.

Call Control (*callctrl.cfg*) File Examples

See *Volume 6, Appendix A*, in the *Dialogic® Brooktrout® Bfv API Reference Manual* for configuration file (*callctrl.cfg*) examples, including (but not limited to) the following port-specific configurations:

- Analog ports (loop start (LS) and direct inward dialing DID))
- ISDN BRI ports
- E1 CAS, E1 R2 CAS, and E1 ISDN ports
- T1 ISDN and T1 RBS ports
- SIP ports
- H.323 ports
- T1/E1 QSIG ports

6 - Directory Structure

This chapter contains tables that show the directory structure used for all installed binary, firmware, and sample source files, both platform-independent and platform-specific for all operating system platforms.

Some facilities might not be used with your Brooktrout SDK.

For information on how to compile sample applications using Windows Developer Studio Project files, Dialogic® Brooktrout® files, and makefiles, refer to the *Dialogic® Brooktrout® Fax Products SDK Developer Guide*.

Installed Files Directory Structures

The directory structures created when you install the Bfv API are dependent on the operating system platform that you are using:

- [Table 1 - Platform-Independent Files on page 127](#)
- [Table 2 - Linux-Specific Files on page 129](#)
- [Table 3 - Windows-Specific Files on page 130](#)

See one of the following for the default directory:

- ◆ Windows: \Brooktrout\Boston
- ◆ Linux: /usr/sys/brooktrout/boston

Table 1. Platform-Independent Files

Directory	Contents
<i>bfv.api</i>	Sub-directory for the Bfv API files
<i>bfv.api/app.src</i>	Configuration files and sample application source files
<i>bfv.api/app.src/ivr_msg</i>	Specific infopkt files for the IVR sample application
<i>bfv.api/app.src/params</i>	Country parameter file
<i>bfv.api/bapp.src</i>	Configuration files and BOSTON-specific sample application source files
<i>bfv.api/fonts</i>	Fonts for ASCII fax transmission
<i>bfv.api/inc</i>	Bfv API library header files
<i>bfv.api/misc</i>	High-level sample files
<i>bfv.api/samples</i>	Low-level sample files
<i>bfv.api/utills/fonts</i>	Font files
<i>bin</i>	Runtime executable, libraries, IP call control and Dialogic® Brooktrout® License Manager
<i>bin/x64</i>	64-bit libraries and Dialogic Brooktrout x64 components installation package
<i>bsmi.api</i>	Sub-directory for BOSTON Simple Message Interface files

Table 1. Platform-Independent Files (Continued)

Directory	Contents
<i>bsmi.api/bapp.src</i>	BSMI sample source files
<i>bsmi.api/inc</i>	BSMI library header files including country-specific R2 CAS protocol files
<i>config</i>	Sub-directory for call control configuration files and protocol variants
<i>config/samples.cfg</i>	Sample configuration files
<i>driver</i>	Driver directories
<i>driver/common</i>	Files used by low level applications to communicate with driver
<i>driver/inc</i>	Header files used by both driver and low level applications
<i>driver/fw/cmndset</i>	Firmware command set header files
<i>fw</i>	Firmware files
<i>utils/oslib</i>	Sub-directory for operating system independent files
<i>utils/osilib/inc</i>	Operating system independent library header file
<i>utils/oslib/osi.src</i>	Operating system independent source files

Table 2. Linux-Specific Files

Directory	Contents
<i>bfv.api/linux</i>	Sub-directory for Linux-specific compilation areas and utilities for Bfv API
<i>bfv.api/linux/app.src</i>	Makefile and configuration files for sample applications
<i>bfv.api/linux/bapp.src</i>	Makefile, configuration files, and compiled executables for BOSTON-specific sample applications
<i>bfv.api/linux/bin/4.4</i>	Bfv API binary files for Enterprise Linux 6.0
<i>bfv.api/linux/bin/4.8</i>	Bfv API binary files for Enterprise Linux 7.0
<i>bfv.api/linux/bin/8.2</i>	Bfv API binary files for Enterprise Linux 8.0
<i>bfv.api/linux/lib/4.4</i>	32-bit Bfv API libraries for Enterprise Linux 6.0
<i>bfv.api/linux/lib/4.4/64</i>	64-bit Bfv API libraries for Enterprise Linux 6.0
<i>bfv.api/linux/lib/4.8</i>	32-bit Bfv API libraries for Enterprise Linux 7.0
<i>bfv.api/linux/lib/4.8/64</i>	64-bit Bfv API libraries for Enterprise Linux 7.0
<i>bfv.api/linux/lib/8.2</i>	32-bit Bfv API libraries for Enterprise Linux 8.0
<i>bfv.api/linux/lib/8.2/64</i>	64-bit Bfv API libraries for Enterprise Linux 8.0
<i>bfv.api/linux/utils/bin</i>	Compiled G3 utilities
<i>bsmi.api/linux</i>	Sub-directory for Linux-specific BOSTON Simple Message Interface files
<i>bsmi.api/linux/bapp.src</i>	Makefile
<i>bsmi.api/linux/lib/4.4</i>	32-bit library files for BSMI for Enterprise Linux 6.0
<i>bsmi.api/linux/lib/4.4/64</i>	64-bit library files for BSMI for Enterprise Linux 6.0
<i>bsmi.api/linux/lib/4.8</i>	32-bit library files for BSMI for Enterprise Linux 7.0
<i>bsmi.api/linux/lib/4.8/64</i>	64-bit library files for BSMI for Enterprise Linux 7.0
<i>bsmi.api/linux/lib/8.2</i>	32-bit library files for BSMI for Enterprise Linux 8.0
<i>bsmi.api/linux/lib/8.2/64</i>	64-bit library files for BSMI for Enterprise Linux 8.0

Table 2. Linux-Specific Files (Continued)

Directory	Contents
<i>driver/linux</i>	Sub-directory for Linux-specific driver compilation areas and utilities
<i>driver/linux/install</i>	Installation program and library
<i>driver/linux/kernel</i>	Compiled binaries for the driver
<i>driver/linux/user</i>	Compiled binaries for the driver utility programs
<i>utils/linux</i>	Sub-directory for Linux-specific tracing utilities and configuration files
<i>utils/osilib/linux/lib</i>	Sub-directory for compiled OSI libraries for Linux
<i>utils/osilib/linux/lib/4.4</i>	32-bit OSI libraries for Enterprise Linux 6.0
<i>utils/osilib/linux/lib/4.4/64</i>	64-bit OSI libraries for Enterprise Linux 6.0
<i>utils/osilib/linux/lib/4.8</i>	32-bit OSI libraries for Enterprise Linux 7.0
<i>utils/osilib/linux/lib/4.8/64</i>	64-bit OSI libraries for Enterprise Linux 7.0
<i>utils/osilib/linux/lib/8.2</i>	32-bit OSI libraries for Enterprise Linux 8.0
<i>utils/osilib/linux/lib/8.2/64</i>	64-bit OSI libraries for Enterprise Linux 8.0
<i>utils/osilib/linux/osi.src</i>	Makefiles for OSI libraries

Table 3. Windows-Specific Files

Directory	Contents
<i>bfv.api\winnt</i>	Sub-directory for Windows-specific compilation areas and utilities
<i>bfv.api\winnt\app.src</i>	Makefile, configuration files, and sample application files
<i>bfv.api\winnt\bapp.src</i>	Makefile, configuration files, and compiled executables for BOSTON-specific sample applications
<i>bfv.api\winnt\bin</i>	Boston Host Service executable and library
<i>bfv.api\winnt\lib</i>	Compiled 32-bit Bfv API libraries

Table 3. Windows-Specific Files (Continued)

Directory	Contents
<i>bfv.api\winnt\lib\x64</i>	Compiled 64-bit Bfv API libraries
<i>bfv.api\winnt\utils</i>	Sub-directory for G3 utilities
<i>bfv.api\winnt\utils\bin</i>	Compiled G3 utilities
<i>bsmi.api\winnt</i>	Sub-directory for Windows-specific BOSTON Simple Message Interface files
<i>bsmi.api\winnt\lib</i>	Compiled library files for BSMI
<i>bsmi.api\winnt\bapp.src</i>	Makefile
<i>bsmi.api\winnt\bin</i>	Debugging program and configuration file
<i>driver\winnt</i>	Sub-directory for Windows platform-specific compilation areas and utilities
<i>driver\winnt\install</i>	Installation program and associated files for 32- and 64-bit operating systems
<i>driver\winnt\user</i>	Compiled binaries for the driver utility programs
<i>driver\winnt\pnp</i>	Plug-and-Play <i>.inf</i> file
<i>driver\winnt\pnp\TRxStream</i>	PnP driver, device property pages, and symbol files for 32- and 64-bit operating systems
<i>utils\winnt\bin</i>	Dialogic® Brooktrout® Configuration Tool, AccuCall, and Call Tracer executables, help and configuration files
<i>utils\osilib\winnt\lib</i>	Compiled 32-bit OSI libraries
<i>utils\osilib\winnt\lib\x64</i>	Compiled 64-bit OSI libraries
<i>utils\osilib\winnt\osi.src</i>	Makefiles for OSI library
<i>%SYSTEMROOT%\system32\</i>	64-bit system: 64-bit version of the libraries 32-bit system: 32-bit version of the libraries
<i>%SYSTEMROOT%\syswow64\</i>	64-bit system only: 32-bit version of the libraries
<i>bin</i>	Runtime executable, libraries, IP call control and Dialogic® Brooktrout® License Manager

Table 3. Windows-Specific Files (Continued)

Directory	Contents
<i>bin/x64</i>	64-bit libraries and Dialogic Brooktrout x64 components installation package
Note: <i>%SYSTEMROOT%</i> is usually <i>C:\windows</i> or <i>C:\winnt</i> .	

7 - Using the Dialogic® Brooktrout® TECUpdate Utility

This chapter describes how one can use the Dialogic® Brooktrout® Technology Expansion Capability (TEC) utility to display and upgrade the configured feature set on an installed board.

This chapter includes the following:

- *Starting Dialogic® Brooktrout® TECUpdate on page 133*
- *When Errors Occur on page 135*
- *Running the Dialogic® Brooktrout® TECUpdate Utility on page 136*
- *Error Logging on page 138*

To successfully perform an upgrade, you need to know the serial number of your board and have an appropriate license key provided by Dialogic.

Use the Dialogic® Brooktrout® TECUpdate utility to record the serial number of your board before you contact Dialogic to order the license file. When you receive an email with your updated license file, you can again use the TECUpdate utility to download the license file and expand the functionality of your board.

Starting Dialogic® Brooktrout® TECUpdate

The Dialogic® Brooktrout® TECUpdate utility is installed as a separate software package. For more information:

- See the chapter on packaging your application in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide*.
- Contact your authorized Dialogic reseller or application partner.

Distribute the TECUpdate utility to your end users even if you do not plan to distribute the Dialogic® Brooktrout® Configuration Tool, so that your customers can update their systems as needed.

The TECUpdate utility assumes that the:

- Firmware is downloaded to the board.
- Dialogic® Brooktrout® driver is started.

You can run the TECUpdate utility from the file system (for example, Windows Explorer), Start Menu or the command line:

- File System:

[InstallDIR] \TECUpdate.exe

where: InstallDIR is the directory where you installed the utility.

- Start Menu:


Start →All Programs →Brooktrout →TECUpdate License Upgrade Tool

- Command Line:

C:\Brooktrout\Boston\bin\TECUpdate.exe

The TECUpdate utility queries and displays information for the selected module. TECUpdate operates with Dialogic® Brooktrout® drivers from Brooktrout SDK 2.1.0 and above.

Following a successful start, the **Brooktrout TECUpdate** window appears. See *Running the Dialogic® Brooktrout® TECUpdate Utility on page 136* for specific steps to obtain module information.




When Errors Occur

If an error occurs, it is recorded in the error log file (see [Error Logging on page 138](#)). Contact Dialogic Technical Services and Support with the error log information if you cannot resolve the problem. If there are firmware or driver errors, the following **Error** dialogs are possible:

Driver Error

- Click **Yes** to retry after loading the driver. Before trying to run TECUpdate again, an **Error** dialog asks you to load the driver:



Yes


Tries to determine if the driver is started, then proceeds with the TECUpdate initialization process. If an error occurs, the dialog reappears.

No

TECUpdate utility exits.

Firmware Error

- Click **Yes** to retry after downloading the firmware. Before trying to run TECUpdate again, an **Error** dialog asks you to load the driver:



Yes


Tries to determine if the firmware is loaded, then proceeds with the TECUpdate initialization process. If an error occurs, the dialog reappears.

No


TECUpdate utility exits.

Running the Dialogic® Brooktrout® TECUpdate Utility

- *To display and update information for each module in your system, do the following:*
 1. Click on a specific module to display its information:
 - ◆ The left panel contains the tree for Dialogic® Brooktrout® hardware. All modules installed in your system are shown.
 - ◆ The lower left panel contains the **TECUpdate Version** and **Driver Version** information.
 - ◆ The right panel displays the feature set for the selected module.
 - ◆ The lower right panel contains an online **Help** and **Update License** buttons. **Update License** allows you to update the feature configuration for a selected module using a specified license file.




-
- Click **Update License** to load the license file updates.
The **Update Module** dialog appears:




- Click **Browse** to locate the license file (*.lic), then click **Update** to begin the updating process.
- Click **Yes** to begin the download of the license file.


A **Question** confirmation dialog appears before the update continues.



Click **OK** when an **Error** dialog appears to return to the Browse process (Step 3) and locate the correct file.



- Click **OK** if boards were updated with the new license information. The **Feature Table** on the right panel reflects the most current information about the module.



- Reboot your computer.

Error Logging

If TECUpdate encounters an error, an **Error** dialog box is displayed. Please see the error log file for more information. The error log file includes:

- ◆ TECUpdate version
- ◆ Driver version
- ◆ Diagnostic information

Provide the log file to Dialogic Technical Services and Support for more information on solving this error. The ASCII text file is called *TECUpdate.log* and is stored in the current application working directory. Subsequent errors are appended to this log file.

8 - Downloading Firmware

This chapter describes how one can download the firmware to the board.

The chapter includes the following:

- *Introduction on page 140*
- *Firmware Files on page 141*
- *Updating Boot ROM Flash on page 142*
- *Manually Downloading the Firmware on page 143*

Introduction

To install the software, you can download the firmware files and optionally configure call control.

For Linux operating systems, the procedures for downloading firmware are described here.

If your operating system is Windows, you can use the Dialogic® Brooktrout® Configuration Tool to download the firmware and configure the call control parameters.

To configure call control, see [Using a Call Control Configuration File on page 124](#) and *Volume 6, Appendix A* of the Dialogic® Brooktrout® *Bfv APIs Reference Manual*.

Firmware Files

Table 4 lists the firmware files. See the Dialogic® Brooktrout® Release Notes that came with your software CD for further information.

Table 4. Firmware and Flash Update Files

File	Use
<i>bostvb.dll</i>	Firmware for the SR140 virtual module
<i>cp.bin</i>	Control processor (PPC) firmware for all platforms
<i>dsp1000.hex</i>	High density DSP firmware for voice and fax modules without V.34 fax (includes V.17 fax)
<i>dsp1000_ld.hex</i>	Low density DSP firmware for TR1034 analog and BRI modules or TruFax® analog and BRI boards (includes V.17 and V.34 fax)
<i>dsp1000_ud.hex</i>	Ultra high density DSP firmware for multi-span voice and fax modules (non-V34)
<i>dsp1000_v34.hex</i>	High density DSP firmware for TR1034 voice and fax with V.34 fax and T.38 fax
<i>dsp1034_ud.hex</i>	Ultra high density DSP firmware for multi-span TR1034 voice and fax modules with V.34 fax and T.38 fax

Updating Boot ROM Flash



Typically, it is not necessary to update your Boot ROM. Use the following procedure to update your Boot ROM Flash firmware only when told to do so by a Dialogic Technical Services and Support Representative. The Dialogic® Brooktrout® driver must be running when you update the boot ROM flash.

➤ *Use the following procedure to update your Boot ROM Flash firmware.*

1. Ensure that each board has a unique module number. Maintain a current list. See [Determining the Board Module Number on page 24](#) for more information about modules and module number assignment. You can obtain a list of modules using the *modinfo* program.
2. Use the *firm* program to perform a flash update (do not interrupt the update process):

```
firm -m <module> -t 2 flashupd.bin
```

where: <module> is the hardware module number.

Note: This process takes less than a minute to complete. It is important not to interrupt the update process. If you interrupt the update process, you cannot reboot your board.

Manually Downloading the Firmware

You must download the firmware each time you boot the machine or restart the device driver.

To download the firmware to a module, you must run the *firmload* or *firm* program, both of which are located in the *brooktrout/boston/bfv.api/<platform>/bapp.src* directory.

The *firmload* program loads the control processor and DSP firmware on all Dialogic® Brooktrout® modules found in the system.

The *-c* option for the *firm* and *firmload* commands or the *config_spec_value* field of *BfvFirmwareDownload* sets the actual number of channels supported on the module.

First, start the driver if it is not already started, and if your operating system platform requires it.

Then, change to the *<install_root>/bfv.api/<platform>/bapp.src* directory and run the *firmload* or *firm* program.

To run the *firmload* program:

```
firmload -c num_channels brooktrout/boston/fw
```

Where *num_channels* is the number of channels configured to receive a firmware download.

For example:

```
firmload -c 48 brooktrout/boston/fw
```

The firmware consists of two types, by number, which must be downloaded in the proper sequence. The *firmload* program automatically takes care of identifying the proper files and downloading them in the correct sequence. If you wish to download the firmware using the *firm* program, you must download each module separately and specify the number of channels (*-c*) in the first *firm* command:

```
firm -m <module> -c <num_channels> -t <firmtype>  
<firmname>
```

➤ *The sequence is as follows:*

1. Type 2 (PROC_APP) = Control processor firmware (cp.bin)
2. Type 1 (DSP_APP) = DSP firmware, use one of the following DSP firmware files:

bostvb.dll	SR140 Software
dsp1000.hex	Brooktrout boards in T1 robbed-bit, T1 or E1 ISDN
dsp1000_ld.hex	Analog and BRI boards and TruFax® analog and BRI boards
dsp1000_ud.hex	Multi-span Series ISDN boards (non-V.34)
dsp1000_v34.hex	TR1034 boards with V.34 fax and T.38 fax
dsp1034_ud.hex	Multi-span TR1034 boards and single-span PCIe T1/E1 TR1034 boards with V.34 and T.38 fax.

For example:

```
firm -m 2 -c 30 -t 2 cp.bin
```

```
firm -m 2 -t 1 dsp1000.hex
```

It takes about 10 seconds per module for the firmware to download and for the module to begin operating. Proper operation is indicated by the module status LED slowly flashing green.

See the descriptions of these programs in the *Dialogic® Brooktrout® Fax Products SDK Developer Guide* chapter about sample applications and utilities.

When the firmware is downloaded to a module for the first time, the assigned ordinal channel numbers start wherever the assignment left off on the previous module. As the system initializes the modules, this numbering process creates a continuous ordering of the channel assignments across all the modules in the system. On later downloads, each module's ordinals begin at the same location, regardless of any decrease or increase in the channel count of a lower-numbered module. Therefore, if you decrease the channel count for a lower numbered module, the process creates gaps in the channel numbering assignments, possibly affecting your application. If you attempt to increase the channel count above any module's initial channel count, the system ignores the added channels.

➤ *For the following situations, restart the driver whenever you want to:*

1. Get a continuous assignment of channel numbers after decreasing the channel count on any module.
2. Increase the number of channels above a module's initial channel count.

Note: You must reboot the system to restart the driver.

Appendix A

Compliance Information

This appendix describes how the Dialogic® Brooktrout® boards conform to compliance standards.

It has the following sections:

- *Electromagnetic Compatibility Statements on page 147*
- *Telecommunications Compliance Statements on page 152*
- *Safety Compliance Statements on page 159*

Note to developers and system integrators: The following compliance information and statements must be provided to your customer or end user as part of your system documentation.

Electromagnetic Compatibility Statements

Electromagnetic compliance requirements include country specific statements for:

- *United States of America on page 148*
- *Canada on page 150*
- *European Union on page 150*
- *Japan on page 151*

The Federal Communications Commission (FCC) in the United States and Industry Canada (IC) in Canada regulate all electronic devices that connect to the telephone system and/or generate radio frequency signals. Additionally, all computing devices utilizing clock frequencies in excess of 10 kHz must be tested for compliance with RF emission limits set by the FCC and IC. The Dialogic® Brooktrout® board is such a device and must comply with the Class A or Class B regulations as specified below.

The following statements should be conspicuously located in bold letters in the end user system documentation.

United States of America

Mandatory Statements



Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

You must also add the following paragraph if shielded cables were used when testing your product:

In order to maintain compliance with FCC limits, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio & television reception.

Class A Statement (for "Class A" products)

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Class B Statements (for “Class B” products)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this is equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You might also find the following booklet helpful, prepared by the FCC: “*How to Identify and Resolve Radio-TV Interference Problems.*” This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402

Canada

Class A Statements (for “Class A” products)

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la class A est conforme à la norme NMB-003 du Canada.

Class B Statements (for “Class B” products)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la class B est conforme à la norme NMB-003 du Canada.

European Union

Class A Statements (for “Class A” products)

This equipment complies with the requirements of CISPR 22 (EN 55022) for Class A Information Technology Equipment (ITE).

Warning: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user is required to take adequate measures.

Class B Statements (for “Class B” products)

This equipment complies with the requirements of CISPR 22 (EN 55022) for Class B Information Technology Equipment (ITE).

VCCI Class Statements

Class A ITE

Class A Statement (For Class A Products).

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Translation:

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may occur, in which case, the user may be required to take corrective actions.

Class B ITE

Class B Statement (For Class B Products).

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。
取扱説明書に従って正しい取り扱いをして下さい。

Translation:

This is a Class B product based on the standard of the Voluntary Control Council for Interference from Information Technology Equipment (VCCI). If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

Telecommunications Compliance Statements

The following customer information must be provided to customers with each unit of approved terminal equipment.

The statements provided below should be conspicuously located in the end user system documentation:

United States of America

Equipment Approved After July 23, 2001

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the circuit side (bottom side) of this equipment is a label that contains, among other information, a product identifier in the format USAAAEQ##TXXXX. If requested, this information must be provided to the telephone company.

Ringer Equivalence Number (REN)

The REN is used to determine the number of devices that might be connected to a telephone line. Excessive RENs on a telephone line can result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that can be connected to a line, as determined by the total RENs, contact the local telephone company.

For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

Connection to Telecommunications Networks

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. Please refer to the installation instructions provided with this equipment for details.

Please refer to the installation instructions provided with this equipment for details concerning the Universal Service Order Codes (“USOC”) that are applicable to this equipment.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service might be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company can make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

There are no user replaceable or serviceable components in this equipment. If trouble is experienced with this equipment, for repair or warranty information, please refer to the appropriate section of the general customer instructions for this equipment. If the equipment is causing harm to the telephone network, the telephone company can request that you disconnect the equipment until the problem is resolved.

This equipment must not be used on party lines. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for further information.

FCC Rules Regarding FAX Branding

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device, including FAX machines, to send any message unless such message clearly contains in a margin at the top or bottom of each transmitted page or

on the first page of the transmission, the date and time it is sent and an identification of the business or other entity, or other individual sending the message and the telephone number of the sending machine or such business, other entity, or individual. (The telephone number provided cannot be a 900 number or any other number for which charges exceed local or long-distance transmission charges.)

To program this information into your FAX machine, you should complete the following steps:

- Users:** To program this information into your fax machine, follow the procedure described in your user manual.
- Developers:** You must include facilities in your application to enable the user to enter the required information. Use the ***BfvFaxHeader*** function with the Dialogic® Brooktrout® board to place this information on each transmitted page as required. You must also include, in your user manual, instructions for entering this information into your system.

Note to OEM Partners (final equipment assemblers):

For information related to power supply source requirements, signal levels, etc., please refer to the installation instructions and general specifications provided with this equipment.

The mounting of the approved unit in the final assembly must be made so that:

- The approved unit is isolated from exposure to any hazardous voltages within the assembly.
- Adequate separation and restraint of cables and cords must be provided.
- The circuitry from the approved unit to the telephone line must be provided in wiring that carries no other circuitry (such as PC or PR leads) unless specifically allowed by the rules.
- PC board traces carrying tip and ring leads shall have sufficient spacing to avoid surge breakdown.
- The final assembler shall provide in the consumer instructions all applicable customer information.
- The approval label shall be placed on the exterior of the cabinet for each type of approved device contained therein if the approved device is enclosed in an assembly, and not readily accessible.

-
- Modular plugs or jacks shall be provided which comply with TIA-968-A Chapter 6 requirements for dimensions, tolerances and metallic plating.

FCC Regulations For Connecting to a T1 Interface

The Federal Communications Commission (FCC) has established rules that permit a Dialogic® Brooktrout® board to be directly connected to the telephone network:

Standardized jacks are used for connections.

This equipment can not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs. (Contact your state public utility commission or corporation commission for information).

A malfunctioning circuit can harm the telephone network.

Disconnect a malfunctioning Dialogic® Brooktrout® board from the telephone network until you determine the cause of the malfunction and repair it. If a malfunctioning Dialogic® Brooktrout® board remains connected, the telephone company can temporarily disconnect service.

The Dialogic® Brooktrout® board is approved as a DSX-1 device. Federal regulations (FCC Part 68) prohibit connection of a DSX-1 device to the network without an FCC approved Channel Service Unit (CSU). Customers connecting this device to the network shall, upon request of the telephone company, inform the telephone company of the particular lines to which such connections are made and the FCC registration of the protection device (CSU).

The CSU has been designed to prevent harm to the T1 network. If the telephone company finds that the equipment is exceeding tolerable parameters, the telephone company can temporarily disconnect service, although they will attempt to give you advance notice if possible.

If the telephone company alters their equipment in a manner that will affect use of this device, they must give you advance warning so as to give you the opportunity for uninterrupted service. You will be advised of your right to file a complaint with the FCC.

Under the FCC rules, no customer is authorized to repair this equipment. This restriction applies regardless of whether the equipment is in or out of warranty.

Before connecting the Dialogic® Brooktrout® board to telephone service, you must give a representative of the local telephone company the following information:

- The telephone numbers (Port ID) to which the Dialogic® Brooktrout® board is connected.
- SOC: 6.0P HP02
 6.0Y HP03
- FIC: 04DU9-BN 1.544 Mbps SF
 04DU9-DN 1.544 Mbps SF+B8ZS
 04DU9-1KN 1.544 Mbps ESF
 04DU9-1SN 1.544 Mbps ESF+B8ZS
- The type of wall jack required: USOC-RJ-48C
- The FCC Registration number: Labeled on back of board
- FCC registration of the protection device (CSU)

Canada

NOTICE: This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. On certain products, the abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

AVIS: Le présent matériel est conforme aux spécifications techniques d'Industrie Canada applicables au matériel terminal. Cette conformité est confirmée par le numéro d'enregistrement. Le sigle IC, placé devant le numéro d'enregistrement, signifie que l'enregistrement s'est effectué conformément à une déclaration de conformité et indique que les spécifications techniques d'Industrie Canada ont été respectées. Il n'implique pas qu'Industrie Canada a approuvé le matériel.

NOTICE: The Ringer Equivalence Number (REN) for this terminal equipment is 0.4. The REN is an indication of the number of devices allowed to be connected to a telephone interface. The termination on an interface can consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices do not exceed 5.

AVIS: L'indice d'équivalence de la sonnerie (IES) du présent matériel est de 0.4. L'IES assigné à chaque dispositif terminal indique le nombre maximal de terminaux qui peuvent être raccordés à une interface téléphonique. La terminaison d'une interface peut consister en une combinaison quelconque de dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions might not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.



Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

Australia

Fail-Safe Operation (AS/ACIF S038-2001).

This equipment will be inoperable when mains power fails.



This equipment will not continue to support emergency dialing after loss of mains power.

Safety Compliance Statements

The following customer information must be provided to customers with each product.

The statements provided below should be conspicuously located in the end user system documentation:

United States of America and Canada

This product is listed by Underwriters Laboratories, a Nationally Recognized Test Laboratory (NRTL). The Listing Mark is located on the bottom surface of the board. The Dialogic® Brooktrout® board has been tested and complies with UL 60950 and CAN/CSA-C22.2 No. 60950, Safety of Information Technology Equipment, Including Electrical Business Equipment.

Install this card only in UL Listed equipment that has instructions stating that the user may install and remove accessory cards.

This product must be mounted in the final assembly so that it is isolated from exposure to any hazardous voltages (voltages greater than 42.4V peak or 60Vdc) within the assembly. Adequate separation and restraint of cables and cords must be provided.



To maintain the safety certification of the system, ensure that the power drawn from the power supply does not exceed its capacity. Please refer to the power usage table on the hardware installation card applicable to your board for information on the voltages and currents required for proper operation.

Models of this card that contain DID interfaces are for use only in equipment that has a permanent connection to protective earth and is installed in a restricted access location.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.



Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

Disconnect any TNV circuit connectors (telephone line cords) from this card before removing the cover of the equipment.

Appendix B

Configuration from a Custom Installation Program

This appendix describes how one can create a custom installation program for manual configuration of the driver.

You can find installation structure and functions for the following operating systems:

- *[Linux Operating System on page 162](#)*
- *[Windows Operating System on page 166](#)*
- *[Windows Operating System on page 166](#)*

Linux Operating System

You can perform configuration from a custom installation program by writing a program that runs *dinstall* with the `-c` option, or by writing a Bourne shell script that calls the provided installation functions described below.

Only write custom installation programs using one of these two mechanisms. Do not write them by directly including and/or modifying any of the supplied source or by writing new code to perform the same underlying system actions. Compatibility with installation functions for later versions cannot be guaranteed, but the up-to-date usage of the functions will always be documented.

The Bourne shell script containing the installation functions is *dinstlib*, located in `usr/sys/brooktrout/boston/driver/linux/install`. The *dinstall* is a particular example of a shell script that makes use of *dinstlib*.

The functions generally use shell variables to pass values in and out. An exhaustive description of these variables is not supplied here. Use the Linux driver installation and the *dinstall* script as guides (see [Installing the SDK on Red Hat Linux on page 32](#)).

Linux Installation

`mill_driver_install`

Required Input Variables

<code>Reserved</code>	
<code>Reserved</code>	
<code>Reserved</code>	
<code>max_pci_hw_modules</code>	Maximum number of PCI/cPCI hardware modules.
<code>physbufsize</code>	Physical buffer size.
<code>appbufsize</code>	Application buffer size.
<code>machine_id</code>	Machine ID, in hex (no leading 0x).
<code>do_reset</code>	Reset on driver startup.
<code>history_enable</code>	Whether to enable history.
<code>dhsize</code>	History size.

<code>num_hists_phy</code>	Number of physical histories.
<code>num_hists_apl</code>	Number of application histories.
<code>hist_phy_admin_only</code>	Whether to restrict physical histories to admin channels only.
<code>num_I2O_frames_per_module</code>	Number of I2O frames per module.
<code>fc_interval</code>	Driver flow control interval, in ms.
<code>mem_drv_alloc_min</code>	Min memory allocated per allocation.
<code>mem_drv_alloc_quanta</code>	Unit of allocation increment above min.
<code>num_reserved_modules</code>	Number of reserved modules.
<code>init_mod_vals</code>	A string consisting of the hex representation of pairs of module IDs and module numbers, each with the 0x prefix. Each pair is listed with a comma in between, and commas between each pair. If none, should be set to 0.
<code>mill_test1</code>	Driver test value 1
<code>mill_test2</code>	Driver test value 2
<code>mill_test3</code>	Driver test value 3
<code>driv_kvers_dir</code>	Location of all the <i>boston.o</i> binaries. This is normally the directory <i>driver/linux/kernel/kvers</i> .

Output Variable

`err_msg` Contains displayable error message.
Note: If echo is used to display the contents, it might require the `-e` option to properly display some of the messages.

This variable is not modified except to set to 1 or error message.

Exit Code

0 = success
 1 = error

Checking the Installation

`_mill_driver_install_check`

Exit Code

0 = not installed
 non-0 = installed

Defining Default Symbols

`_mill_driver_defaults`

Defines the symbols that provide defaults for use with getting parameter values.

<code>DEFAULT_MOD_NUM</code>	Default starting reserved module number.
<code>DEFAULTAPPBUFSIZE</code>	Default application buffer size.
<code>Reserved</code>	Default ISA interrupt line. Reserved, no longer in use.
<code>DEFAULTMACHINEID</code>	Default machine ID.
<code>DEFAULTMAXHWMOD</code>	Default maximum number of PCI/cPCI modules.
<code>Reserved</code>	Default number of ISA modules. Reserved, no longer in use.
<code>DEFAULTPHYBUFSIZE</code>	Default physical buffer size.
<code>DHSIZEDEF</code>	Default history size.
<code>HIST_PHY_ADMIN_ONLY_DEF</code>	Default for physical histories admin only.
<code>MAX_RESERVED_MODULE_NUMS</code>	Maximum number of module reservations.
<code>MAXAPPBUFSIZE</code>	Maximum application buffer size.
<code>MAXMACHINEID</code>	Maximum allowable machine ID.
<code>Reserved</code>	Maximum number of ISA modules. Reserved, no longer in use.
<code>MAXPHYBUFSIZE</code>	Maximum physical buffer size.
<code>MINAPPBUFSIZE</code>	Minimum application buffer size.
<code>MINMACHINEID</code>	Minimum allowable machine ID.
<code>MINPHYBUFSIZE</code>	Minimum physical buffer size.
<code>NUM_HISTS_APL_DEF</code>	Default number of application histories.
<code>NUM_HISTS_PHY_DEF</code>	Default number of physical histories.

Removing the Driver

`_mill_driver_remove`

Input Argument

`partial` (Optional) The function only performs a partial removal. Also used for removal prior to reinstallation.

Output Variable

`err_msg` Contains displayable error message.

Note: If `echo` is used to display the contents, it might require the `-e` option to properly display some of the messages.

This variable is not modified except to set to 1 or error message.

Exit Code

0 = success

1 = error

Windows Operating System

You can perform configuration from a custom installation program by writing a program that runs *install* with the `-c` option, or by writing a program that calls the Dialogic-provided installation functions, described below, that can be compiled and linked into the program.

Only write custom installation programs using one of these two mechanisms. Do not write them by directly including and/or modifying any of the supplied source or by writing new code to perform the same underlying system actions. Compatibility with installation functions for later versions cannot be guaranteed, but the up-to-date usage of the functions will always be documented.

All files referred to are in the *brooktrout\boston\driver\winnt\install* directory. To use these functions, the custom program must include *instlib.obj* and *pnplib.obj*. The object files must be linked with the custom program. *Install.c* is a particular example of a program that is compiled and linked in this way.

Note: To build a custom program with these object files requires the Windows DDK (2008 or higher).

An exhaustive description of the function parameters is not supplied here. Use the Windows driver configuration and the *install.c* program as guides (see [Installing the Device Driver on Windows on page 71](#)).

Installing the Windows Driver

Use the following function to install the Windows PnP driver:

```
int _mill_pnp_driver_install(  
    struct driver_parameters *drv_parm,  
    int do_adjustments,  
    int already_option,  
    int meg_in_system,  
    int *mem_adjust_stat,  
    char *inf_file,  
    int load_uncond,  
    int *reboot_required,  
    char **failed_win32_call,  
    DWORD *win32_err_val,  
    char **other_msg  
);
```

Input Variables

<code>already_option</code>	Action to take if already adjusted.
<code>appbufsize</code>	Application buffer size.
<code>dest_dir_name</code>	Pointer to <code>char *</code> variable to contain the directory name in which the driver files were installed.
<code>dhsize</code>	History size.
<code>do_adjustments</code>	Whether to do PCI memory adjustments.
<code>do_reset</code>	Reset on driver startup.
<code>driver_fname</code>	Name of driver binary <i>boston.sys</i> file to install.
<code>drv_parm</code>	Pointer to a structure containing driver parameters.
<code>failed_win32_call</code>	Pointer to <code>char *</code> variable to contain the name of a Windows function that failed.
<code>fc_interval</code>	Driver flow control interval, in ms.
<code>hist_phy_admin_only</code>	Whether to restrict physical histories to administrative channels only.
<code>history_enable</code>	Whether to enable history.
<code>inf_file</code>	Name of driver <i>.inf</i> file.
<code>Reserved</code>	ISA interrupt line is no longer used.
<code>load_uncond</code>	Indicates that driver should load regardless of devices being present in the system.
<code>machine_id</code>	Machine ID.
<code>max_pci_hw_modules</code>	Maximum number of PCI/cPCI hardware modules.

<code>meg_in_system</code>	Amount of memory in system.
<code>mem_adjust_stat</code>	Pointer to <code>int</code> variable to contain result of memory adjustment attempt 0 = Memory adjustment not performed 1 = Memory adjustment performed 2 = Previous adjustment detected, action dependent on <code>already_option</code>
<code>mem_drv_alloc_min</code>	Min memory allocated per allocation.
<code>mem_drv_alloc_quanta</code>	Unit of allocation increment above min.
<code>Reserved</code>	Pointer to array of ISA addresses is no longer used.
<code>Reserved</code>	Size of <code>mill_isa_addrs</code> array is no longer used.
<code>mill_test1</code>	Driver test value 1.
<code>mill_test2</code>	Driver test value 2.
<code>mill_test3</code>	Driver test value 3.
<code>num_hists_apl</code>	Number of application histories.
<code>num_hists_phy</code>	Number of physical histories.
<code>num_I2O_frames_per_module</code>	Number of I2O frames per module.
<code>Reserved</code>	Number of ISA modules is no longer used.
<code>num_reserved_modules</code>	Number of reserved modules.
<code>other_msg</code>	Pointer to <code>char *</code> variable to contain a possible error message.
<code>phybufsize</code>	Physical buffer size.
<code>pkt_version</code>	Reserved, must be 0.
<code>reboot_required</code>	Pointer to <code>int</code> variable to contain indication of whether a reboot is required.
<code>reserved_modules</code>	Pointer to array of reserved module information.
<code>reserved_modules_size</code>	Size of <code>reserved_modules</code> array.
<code>win32_err_val</code>	Win32 error code returned by failing Windows function.

Return Value 0 = success
 1 = error

Driver Parameters Structure

Use the `driver_parameters` structure to install the PnP driver (see [Installing the Windows Driver on page 167](#)).

For input variable definitions, see [Input Variables on page 167](#).

```
struct driver_parameters
{
    int         reserved;
    int         reserved;
    unsigned    reserved;
    unsigned    reserved;
    unsigned    max_pci_hw_modules;
    unsigned    phybugsize;
    unsigned    appbufsize;
    unsigned    machine_id;
    unsigned    do_reset;
    unsigned    history_enable;
    unsigned    dhsize;
    unsigned    num_hists_phy;
    unsigned    num_hists_apl;
    unsigned    hist_phy_admin_only;
    unsigned    num_I20_frames_per_module;
    unsigned    fc_interval;
    unsigned    mem_drv_alloc_min;
    unsigned    mem_drv_alloc_quanta;
    unsigned    pkt_version;
    unsigned    num_reserved_modules;
    struct reserved_module_num *reserved_modules;
    unsigned    reserved_modules_size;
    unsigned    mill_test1;
    unsigned    mill_test2;
    unsigned    mill_test3;
};
```

Checking the Installation

Verifies that the driver is installed.

```
int _mill_pnp_driver_install_check(void);
```

Return Value

0 = not installed

1 = installed

Defining Default Symbols

The *instlib.h* file defines the following symbols that provide defaults for use with getting parameter values.

You can find the *instlib.h* file at the following location:

```
C:\Brooktrout\Boston\driver\winnt\install\
```

DEFAULT_MOD_NUM	Default starting reserved module number.
DEFAULTAPPBUFSIZE	Default application buffer size.
DEFAULTINTRLINE	Default ISA interrupt line. Reserved, no longer in use.
DEFAULTMACHINEID	Default machine ID.
DEFAULTMAXHWMOD	Default maximum number of PCI/cPCI modules.
DEFAULTNMILL	Default number of ISA modules. Reserved, no longer in use.
DEFAULTPHYBUFSIZE	Default physical buffer size.
DFLT_FC_INTERVAL	Default number of FC intervals.
DFLT_I2O_FRAMES_PER_MODULE	Default number of I2O frames per module.
DHSIZEDEF	Default history size.
DHSIZEMIN	Minimum history size.
HIST_PHY_ADMIN_ONLY_DEF	Default for physical histories admin only.
I2O_FRAMES_PER_MODULE	Number of I2O frames per module.
MAX_RESERVED_MODULE_NUMS	Maximum number of module reservations.
MAXAPPBUFSIZE	Maximum application buffer size.
MAXMACHINEID	Maximum allowable machine ID.
MAXNMILL	Maximum number of ISA modules. Reserved, no longer in use.
MAXPHYBUFSIZE	Maximum physical buffer size.

MEM_DRV_ALLOC_MIN	Minimum allocation of memory.
MEM_DRV_ALLOC_QUANTA	Number of allocation of memory.
MIN_FC_INTERVAL	Minimum number of FC intervals.
MINAPPBUFSIZE	Minimum application buffer size.
MINMACHINEID	Minimum allowable machine ID.
MINPHYBUFSIZE	Minimum physical buffer size.
NUM_HISTS_APL_DEF	Default number of application histories.
NUM_HISTS_PHY_DEF	Default number of physical histories.

This file also defines `SYSDIR`, a string that represents the type of platform being compiled on, and a component of the subdirectory path needed to find the compiled driver binary.

It also provides the `struct reserved_module_num` definition, used by `_mill_pnp_driver_install`.

Removing the Driver

Uninstalls the driver service and removes files. For input variable definitions, see [Input Variables on page 167](#).

```
int _mill_pnp_driver_remove(
    int    *mem_adjust_stat,
    int    *reboot_required,
    char   **failed_win32_call,
    DWORD  *win32_err_val,
    char   **other_msg
);
```

Return Value

0 = success
1 = error

Appendix C

Reinitializing the Device Driver

This appendix describes the driver reinitialization utility. This utility is used to return the device driver to a state as close as possible to that of a fresh driver start without stopping the driver.

Introducing the Driver Reinitialization Utility

The driver can be reinitialized close to its starting state in terms of channels assigned to modules and module number assignments using the *driver_reinit* program located in the *boston/driver/<platform>/user* directory.

Use of this program may avoid the need to stop and restart the driver. This is especially useful for a Windows PnP system as the driver cannot be easily started and stopped.

Using the *driver_reinit* Utility

When you execute the *driver_reinit* program, this utility will return the driver to a state as close as possible to that of a fresh driver start without stopping the driver.

The utility will:

- Clear all ordinal channel assignments
- Remove all stored information about the modules
- Reset all the hardware modules

The utility fails if any application sessions currently exist.

Glossary

API	Application Programming Interface
ASR	Automatic Speech Recognition
Channel	A logical channel of operations provided by a Boston module. See <i>logical channel number</i> , <i>ordinal channel number</i> , <i>work channel</i> .
EC	Echo cancellation
Facility	A software entity responsible for a set of related functions that provide services to the host, e.g., fax facility and voice facility.
ISDN	Integrated Services Digital Network
IVR	Interactive Voice Response
lapdid	The term <i>lapdid</i> has its origins with the LAP-D protocol used for call control, but has an extended meaning for Dialogic products. For call control with the ISDN protocol (Q.931), <i>lapdid</i> refers to a trunk-specific HDLC controller (trunk 1 = lapdid 0, trunk 2 = lapdid 2, trunk 3 = lapdid 4 and trunk 4 = lapdid 6). For call control with the LEC protocols (RBS, etc.), <i>lapdid</i> refers to a specific 0-based trunk number (trunk 0 = lapdid 0, trunk 1 = lapdid 1, ..., trunk 6 = lapdid 6 and trunk 7 = lapdid 7).
Line	A T1/E1 slot or a single analog slot. Lines are numbered starting at 1.
Logical channel number	A number used with the hardware module number to reference a channel in a system. Channel 0 is reserved and channel 1 is the administrative channel. Other channels are numbered from 2 to n+1 (where n is the number of work channels defined for the module).

Millennium Address	An address of a communicating BOSTON or Millennium entity, a facility and channel on a BOSTON module, or the driver. Each address consists of 4 components, the facility, the channel, the module, and the machine. It is possible to make use of most features of the firmware and the APIs without requiring direct use of these addresses.
Module	A communicating Boston entity that usually represents a CPU on a Dialogic® Brooktrout® board, a host application, a software telephony module (SR140) or the driver. See Determining the Board Module Number on page 24 for more information about modules and module number assignment.
NVRAM	Non-Volatile RAM. Random Access Memory that is not erased when the board is powered off or when the firmware is downloaded again.
Ordinal channel number	A number in the range 0 to n-1 where n is the total number of work channels on all the boards in the system.
Packet	In the BOSTON architecture, a sequence of bytes containing a BOSTON destination address, source address, and one or more commands.
PCI	Peripheral Component Interconnect
PDF	Portable Document Format
Plug-and-Play	Hardware or software that, after installation, can be used immediately without configuration. Also PnP.
Port	A TDM bus (for example: MVIP, H110), DS-1 (T1/E1), BRI or analog interface.
Stream	A logical data entity that corresponds to a physical data line on a TDM bus
T1/E1 span	The set of slots that comprises one T1 (24) or one E1 (30) line. The spans are numbered starting at 1.
TCP	Transmission Control Protocol
Time slot	A logical entity that corresponds to one telephone call.
Unit number	1. In telephony configuration files and functions, a unit is a hardware port on a Dialogic® Brooktrout® board and is numbered starting at 0 (to denote a TDM bus); from 1 to n (for a specific T1/E1 interface).

2. In some Bfv functions (for example, *BfvLineAttach*), an ordinal channel number. Its range is 0...n-1, where n is the number of channels in a system.

VAD

Voice Activity Detection

Work channel

One of the channels on a module that is available for non-administrative purposes as a result of downloading firmware. A module configured for 48 channels when firmware download is performed has 48 work channels and one administrative channel. Logical work channel numbers start at 2 on each module.

Symbols

.bin file [162](#)
.cfg file [127](#)
.exe file [118](#), [122](#)
.inf file [92](#), [108](#), [125](#)
.log file [142](#), [159](#)
.pnf file [101](#), [102](#)

Brooktrout Configuration Tool, see Configuration Tool
BSMI API files
 Linux-specific [148](#)
 operating system-independent [147](#)
 Windows-specific [151](#)
btcall.cfg file
 choosing the location [127](#)
 edit [137](#)

Index

Advanced configuration parameters
 Technical Support [106](#)
Advanced Mode
 command line option [125](#)
 Configuration Tool [136](#)
 See also Configuration Tool
Autorun program [77](#)

B

Bfv API files
 Linux-specific [148](#)
 operating system-independent [146](#)
 Windows-specific [151](#)
Bfv API libraries and makefiles
 Linux [47](#)
 Windows [112](#)
Board
 model type [138](#)
 model, identifying [132](#)
 module ID [28](#)
 status LED [30](#)
Boston Host Service
 command line [109](#)
 installing [109](#)
 Red Hat Linux [44](#)
 troubleshooting [110](#)
 Linux login [45](#)
 Windows [109](#)
BOSTSRV
 see Boston Host Service
Bourne shell script [183](#), [187](#)
Brooktrout board
 verifying integration [95](#)

C

-c option [69](#)
Call control
 choosing file location [127](#)
 configuration file [120](#), [143](#)
 configuring (Windows) [31](#)
 configuring boards [143](#)
callctrl.cfg file
 edit [137](#)
 examples [144](#)
 troubleshooting [110](#)
 using [143](#)
Channel
 actual number supported [164](#)
 definition [199](#)
 ordinal channel numbers [165](#)
Channel density, upgrading [153](#)
Channel Service Unit (CSU) [176](#)
Class A products
 compliance, Canada [171](#)
 compliance, European Union [171](#)
 compliance, USA [169](#)
Class B products
 compliance, Canada [171](#)
 compliance, European Union [171](#)
 compliance, USA [170](#)
cmd prompt, driver install [104](#)
Command line
 Boston Host Service [109](#)
 Configuration Tool options [125](#)
 driver manual install [104](#)
 Linux dinstall [48](#)
 Windows install [115](#)
Compiler

-
- Linux issues [50](#)
 - Linux options [50](#)
 - Windows options [119](#)
 - Compliance
 - Class A products, Canada [171](#)
 - Class A products, European Union [171](#)
 - Class A products, USA [169](#)
 - Class B products [171](#)
 - Class B products, Canada [171](#)
 - Class B products, USA [170](#)
 - electromagnetic compatibility [168](#)
 - information [167](#)
 - Ringer Equivalence Number (REN), USA [173](#)
 - safety statements [180](#)
 - shielded cables [169](#)
 - telecommunications [173](#)
 - Configtool Error [133](#)
 - configtool.exe file [122](#)
 - Configuration files
 - creating [123](#), [137](#)
 - editing [123](#)
 - reading [124](#)
 - Configuration Tool
 - /a option [125](#)
 - /c option [125](#)
 - /d option [125](#)
 - /e option [125](#)
 - /f option [126](#)
 - /i option [125](#)
 - /o option [125](#)
 - /p option [126](#), [128](#)
 - /q option [126](#), [142](#)
 - /s option [125](#)
 - /t option [125](#)
 - /w option [125](#), [132](#)
 - Advanced Mode [136](#)
 - command line options [125](#)
 - file locations [127](#)
 - help [130](#)
 - INF file use [125](#)
 - installing driver for SR140 [89](#)
 - log files location [127](#)
 - Offline Mode [123](#)
 - parameter grouping [136](#)
 - running [31](#), [125](#)
 - setting file locations [128](#)
 - show Preferences dialog box [126](#)
 - showing hidden parameters [125](#)
 - Silent Mode [142](#)
 - Timer Mode [124](#)
 - Wizard Mode [135](#)
 - configuration.log file
 - debug command line option [125](#)
 - Silent Mode [142](#)
 - Configuring
 - Boston driver manually, Linux [41](#)
 - call control [31](#), [143](#)
 - IP stack command line option [125](#)
 - software [120](#)
 - Windows driver [31](#)
 - Windows driver manually [104](#)
 - Connecting to a T1 Interface, FCC rules [176](#)
 - Connecting to telecommunications networks [174](#)
 - Creating
 - configuration files [137](#)
 - Configuration Tool configuration files [123](#)
 - CSU (channel service unit) [176](#)
 - Custom installation
 - Linux [183](#)
 - Windows [191](#)
 - Custom setup, software [78](#)
- ## D
- Debugging
 - Configuration Tool [125](#)
 - Default folder, Windows [78](#)
 - Default symbols
 - Linux [185](#)
 - Windows [195](#)
 - Device details, Brooktrout board [96](#)
 - dinstall [69](#)
 - c option [48](#)
 - command line (Linux) [48](#)
 - configure Linux driver [41](#)
 - dinstlib
 - Linux custom installation [183](#)
 - location [183](#)
 - Directory structure defaults [145](#)
 - Downloading
 - firmware [164](#)
 - firmware (Windows) [31](#)
 - Driver
 - configuring Windows [31](#)
 - editing parameters [137](#)

- installing Windows [89](#)
- Linux file locations [50](#), [149](#)
- operating system-independent files [147](#)
- removing Linux [186](#)
- removing non_PnP [196](#)
- removing PnP [196](#)
- starting [124](#)
- starting and stopping, Linux [40](#)
- starting Windows [31](#)
- uninstalling current version of PnP [100](#)
- uninstalling Linux [43](#)
- uninstalling previous versions [97](#)
- uninstalling Windows [108](#)
- updating Plug-and-Play [97](#)
- updating previous versions of PnP [98](#)
- Windows file locations [151](#)
- Windows non-PnP file locations [118](#)
- Windows startup [114](#)

Driver reinitialization [197](#)

DSX-1 device [176](#)

E

- Editing
 - configuration files [123](#), [137](#)
 - driver parameters [137](#)
- Electromagnetic compatibility
 - compliance [168](#)
- Error, license [133](#)
- Example
 - callctrl.cfg [144](#)

F

- Facility definition [199](#)
- Fax branding, FCC rules [174](#)
- FCC rules
 - connecting to a T1 interface [176](#)
 - fax branding [174](#)
 - Part 15 [170](#)
- Files
 - firmware [147](#), [162](#)
 - limits on open (Windows) [114](#)
 - operating system-independent [146](#)
- firmload script [164](#)
- Firmware
 - choosing file locations [127](#)

- cp.bin file [162](#)
- downloading [164](#)
- downloading (Windows) [31](#)
- files [147](#), [162](#)

Found New Hardware Wizard [90](#)

G

- Global variables (Windows) [114](#)
- Grouping parameters, Advanced Mode [136](#)

H

- Help
 - Brooktrout Configuration Tool [130](#)
- History logging
 - installing driver [106](#)
 - installing the driver [42](#), [63](#)
- Host Based Fax
 - modules overview [29](#)
 - SR140 setup [37](#)

I

- Identifying board model [132](#)
- install.exe file [118](#)
- Installing
 - command line [115](#)
 - directory (Windows) [81](#)
 - driver (automatically) on Windows [89](#)
 - driver (manually) on Windows [89](#), [104](#)
 - driver for SR140 module [89](#)
 - interrupted (Windows) [82](#)
 - Linux custom program [183](#)
 - Linux parameters [48](#)
 - Linux steps [37](#)
 - software on Linux [37](#)
 - software on Windows [30](#)
 - Windows custom program [192](#)
 - Windows parameters [113](#)
 - Windows program [89](#)
- InstallShield
 - completed [82](#)
- instlib.obj file [191](#)
- Interrupted Windows installation [82](#)

K

- Kernel patches for Linux
 - recompiling for new patches [53](#)
- Kernel version numbers, Linux [43](#)

L

- Library files
 - Linux-specific [149](#)
 - operating system-independent [147](#)
 - Windows-specific [152](#)
- License
 - Configtool Error message [133](#)
- License update
 - TECUpdate utility [153](#)
- Line definition [199](#)
- Linker options
 - Linux [50](#)
 - Windows [119](#)
- Linux
 - Bfv API libraries and makefiles [47](#)
 - compiler issues [50](#)
 - compiler options [50](#)
 - configuring the driver manually [41](#)
 - dinstall program [41](#)
 - driver file locations [50](#)
 - installation parameters [48](#), [68](#)
 - installation steps [37](#)
 - installing API and driver [38](#)
 - installing software [37](#)
 - kernel version numbers [43](#)
 - linker options [50](#)
 - patches, recompiling for [53](#)
 - PCI considerations [46](#)
 - recompiling for new kernel patches [53](#)
 - removing the software [40](#)
 - rpm installation program [38](#)
 - starting and stopping the driver [40](#)
 - uninstalling the driver [43](#)
 - warning and error messages [47](#)
 - writing multithreaded programs [47](#)
- Logical channel number definition [200](#)

M

- modinfo program [163](#)

- Module
 - definition [200](#)
 - selecting number [138](#)
- Multithreaded programs
 - Linux [47](#)
 - Windows [112](#)

N

- Number [139](#)
- Number of Channels parameter [139](#)
- NVRAM definition [200](#)

O

- Offline Mode
 - command line option [125](#)
 - configuration tool [123](#)
- Operating system-independent files [145](#)
- Ordinal channel number
 - assignment [165](#)
 - definition [200](#)

P

- Packet definition [200](#)
- Parameter grouping
 - Configuration Tool [136](#)
- Part 15, FCC rules [170](#)
- PCI considerations
 - Linux [46](#)
 - Windows [111](#)
- Plug-and-Play
 - updating driver [97](#)
 - Windows systems [89](#)
- pnplib.obj file [191](#)
- Port definition [200](#)
- Preferences dialog box
 - not showing [126](#)
- Preferences dialog box, Configuration Tool [126](#)
- Process priority on Windows [115](#)
- Product identifier, compliance [173](#)

Q

- Quick start [27](#)

R

- Reinitializing driver [197](#)
- Removing
 - device driver [97](#)
 - Linux manually configured driver [43](#)
 - Linux software [40](#)
 - PnP driver using cmd [108](#)
 - Windows software [83](#)
- REN (Ringer Equivalence Number), Canada [178](#)
- REN (Ringer Equivalence Number), USA [173](#)
- Repairing software (Windows) [83](#)
- Ringer equivalence number (REN) [173](#)
- Ringer Equivalence Number (REN), Canada [178](#)
- rpm installation program, Linux [38](#)

S

- Safety compliance [180](#)
- Safety compliance statements [180](#)
- Sample applications
 - firmload [164](#)
 - modinfo [163](#)
 - voice [31](#), [34](#)
- settings.cfg file [127](#)
- settings.cfg file example [128](#)
- Shielded cables [169](#)
- Silent Mode
 - command line option [125](#)
 - configuraiton.log file [142](#)
 - Configuration Tool [142](#)
 - SR140 module [142](#)
- Software license key [153](#)
- SR140 module
 - installing driver [89](#)
 - overview [29](#)
 - Silent Mode [142](#)
- Starting the driver
 - Linux [40](#)
 - Windows [31](#), [109](#)
- Stopping the driver
 - Linux [40](#)
- Streams, definition [200](#)

T

- T1/E1 span definition [200](#)

- Technical Support
 - advanced configuration parameters [43](#), [64](#), [106](#)
 - API source version [71](#)
 - error logging [159](#)
 - history logging [42](#), [63](#), [106](#)
 - TECUpdate error log [156](#)
- Technology Expansion Capability, see TECUpdate utility
- TECUpdate utility
 - error logs [159](#)
 - running [157](#)
 - starting [154](#)
 - upgrade process [153](#)
- TECUpdate.log file [159](#)
- Telecommunications
 - network connection [174](#)
- Time slot definition [201](#)
- Timer dialog box, Configuration Tool [93](#), [94](#)
- Timer Mode
 - command line option [125](#)
- Timer Mode, Configuration Tool [124](#)
- TRxStream board
 - verifying integration [95](#)
- trxstream.inf file [92](#), [108](#)

U

- Uninstalling
 - device driver [97](#)
 - Linux manually configured driver [43](#)
 - Linux software [40](#)
 - PnP driver [108](#)
 - Windows software [83](#)
- Unit number definitions [201](#)
- Updating
 - hardware and PnP driver [97](#)
 - previous versions of PnP driver [98](#)
- User-defined configuration file
 - location [126](#)
- Utility, driver reinitialization [197](#)

V

- Verify TRxStream board integration [95](#)
- Version information, Windows [118](#)
- voice program [31](#), [34](#)

W

Warning and error messages

Linux [47](#)

Windows

Autorun program [77](#)

Bfv API libraries and makefiles [112](#)

compiler options [119](#)

driver startup [114](#)

install completed [80](#)

install software [73](#)

installation parameters [113](#)

installing driver manually [104](#)

installing SDK [76](#)

InstallShield installation program [77](#)

limits on open files [114](#)

linker options [119](#)

modifying the software [83](#)

non-Plug and Play file locations [118](#)

PCI considerations [111](#)

uninstalling driver [108](#)

uninstalling SDK software [83](#)

version information [118](#)

writing multithreaded programs [112](#)

Wizard Mode

command line option [125](#)

configuration tool [122](#)

Work channel, definition [201](#)