



IP Media Library API for Host Media Processing

Programming Guide

December 2005



INFORMATION IN THIS DOCUMENT IS PROVIDED IN CONNECTION WITH INTEL® PRODUCTS. NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHTS IS GRANTED BY THIS DOCUMENT. EXCEPT AS PROVIDED IN INTEL'S TERMS AND CONDITIONS OF SALE FOR SUCH PRODUCTS, INTEL ASSUMES NO LIABILITY WHATSOEVER, AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY, RELATING TO SALE AND/OR USE OF INTEL PRODUCTS INCLUDING LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT. Intel products are not intended for use in medical, life saving, life sustaining, critical control or safety systems, or nuclear facility applications.

Intel may make changes to specifications and product descriptions at any time, without notice.

This IP Media Library API for Host Media Processing Programming Guide as well as the software described in it is furnished under license and may only be used or copied in accordance with the terms of the license. The information in this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by Intel Corporation. Intel Corporation assumes no responsibility or liability for any errors or inaccuracies that may appear in this document or any software that may be provided in association with this document.

Except as permitted by such license, no part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means without the express written consent of Intel Corporation.

Copyright © 2002-2005 Intel Corporation. All Rights Reserved.

Celeron, Dialogic, Intel, Intel Centrino, Intel logo, Intel NetMerge, Intel NetStructure, Intel Xeon, Intel XScale, IPLink, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

* Other names and brands may be claimed as the property of others.

Publication Date: December 2005

Document Number: 05-2330-004

Intel Converged Communications, Inc.
1515 Route 10
Parsippany, NJ 07054

For **Technical Support**, visit the Intel Telecom Support Resources website at:
<http://developer.intel.com/design/telecom/support>

For **Products and Services Information**, visit the Intel Telecom and Compute Products website at:
<http://www.intel.com/design/network/products/telecom>

For **Sales Offices** and other contact information, visit the Buy Telecom Products page at:
<http://www.intel.com/buy/networking/telecom.htm>



Contents

	Revision History	7
	About This Publication	9
	Purpose	9
	Intended Audience	9
	How to Use This Publication	9
	Related Information	10
1	Product Description	11
	1.1 Features	11
	1.2 Architecture	11
	1.3 Introduction to the IP Media Library	12
	1.4 Relationship with Global Call Library	12
	1.5 Standard Runtime Library Support	13
	1.6 Media Channel Device Naming	13
2	Programming Models	15
3	State Models	17
4	Event Handling	19
	4.1 SRL Event Management Functions	19
	4.2 SRL Standard Attribute Functions	19
5	Error Handling	21
6	DTMF Handling	23
	6.1 Introduction to DTMF Handling	23
	6.2 Setting DTMF Parameters	24
	6.3 Notification of DTMF Detection	27
	6.4 Generating DTMF	28
7	T.38 Fax Server	29
	7.1 Using the T.38 Fax Server	29
	7.2 T.38 Fax Server Call Scenario	31
	7.3 T.38 Fax Server Example Code	31
8	Quality of Service (QoS) Alarms	37
	8.1 QoS Overview	37
	8.2 QoS Alarm Types	37
	8.3 QoS Threshold Attributes	38
	8.4 QoS Events	39
	8.5 Implementing QoS Alarms	40
	8.6 QoS Alarm and Alarm Recovery Mechanisms	41
	8.7 Example Code for QoS Alarm Handling	44

9	Volume Control	49
9.1	Volume Control Overview	49
9.2	Volume Control Parameters	49
9.3	Implementing Volume Control	50
9.4	Volume Control Hints and Tips	50
9.5	Volume Control Example Code	50
10	Configuring for Half- or Full-Duplex Media Streams	53
10.1	Overview of Half- and Full-Duplex Stream Support	53
10.2	Programming Interface for Half- and Full-Duplex Stream Configuration	54
10.3	Application Scenario	55
10.4	Code Example	56
11	Using Echo Cancellation	59
11.1	Overview of Echo Cancellation	59
11.2	Echo Cancellation Parameters	60
12	Building Applications	61
12.1	Compiling and Linking under Linux	61
12.2	Compiling and Linking under Windows	62
	Index	63

Figures

1	IP Media Architecture	12
2	IP Media Channel State Diagram	17
3	In-Band DTMF Mode Scenario Diagram	25
4	RFC 2833 Scenario Diagram.	26
5	Out-of-Band DTMF Mode Scenario Diagram	27
6	T.38 Fax Server Scenario	31
7	QoS Scenario 1: Brief Alarm Condition	42
8	QoS Scenario 2: True Alarm Condition	43
9	QoS Scenario 3: Alarm Condition Cleared	44
10	End Point Media Streaming State Transitions.	55
11	Half- and Full-Duplex Media Streaming Application Scenario	56
12	Echo Cancellation	59

Tables

1	Quality of Service Parameter Defaults for Host Media Processing	39
---	---	----



Revision History

This revision history summarizes the changes made in each published version of this document.

Document No.	Publication Date	Description of Revisions
05-2330-004	December 2005	Configuring for Half- or Full-Duplex Media Streams chapter: Added chapter on new feature. Using Echo Cancellation chapter: Added chapter on new feature.
05-2330-003	August 2005	T.38 Fax Server Scenario figure: Updated to show ipm_Stop() at correct time Quality of Service (QoS) Alarms chapter: Updated description of threshold and debounce settings (PTR#35692)
05-2330-002	July 2005	DTMF Handling chapter: Removed references to unsupported IPM_RFC2833MUTE_AUDIO parameter (PTR #33826) Generating DTMF section: Removed information relating to unsupported ipm_SendRFC2833SignalIDToIP() function QoS Alarm and Alarm Recovery Mechanisms section: Updated to illustrate jitter instead of lost packets
05-2230-001	April 2004	Initial version of document specific to the Intel NetStructure® Host Media Processing product published under this title and document ID number. Much of the information contained in this document was previously published in September 2003 as an HMP-specific document under document number 05-1834-003 and the misleading title <i>IP Media Library API for Linux and Windows Programming Guide</i> . Significant changes from that previous document version include: Application Development Guidelines chapter: Replaced by separate feature implementation chapters on DTMF Handling and T.38 Fax Server. Quality of Service (QoS) chapter: Added RTCP and RTP timeout alarm types. Removed DTMF discarded alarm type. Added new scenarios and graphics in QoS Alarm and Alarm Recovery Mechanisms section. Updated example code. Volume Control chapter: Added chapter on new feature.



About This Publication

The following topics provide information about this publication:

- [Purpose](#)
- [Intended Audience](#)
- [How to Use This Publication](#)
- [Related Information](#)

Purpose

This document provides programming guidelines for the IP Media Library API. It is a companion guide to the *IP Media Library API Library Reference*, which provides details on functions and parameters in the IP media software.

This document version is specific to the version of the IP Media Library that is provided with the Intel NetStructure® Host Media Processing Software product.

Intended Audience

This guide is intended for software developers who will access and utilize the IP media software. This may include any of the following:

- Distributors
- System Integrators
- Toolkit Developers
- Independent Software Vendors (ISVs)
- Value Added Resellers (VARs)
- Original Equipment Manufacturers (OEMs)

How to Use This Publication

Refer to this publication after you have installed the hardware and the system software which includes the IP media software. This publication assumes that you are familiar with the Linux* or Windows* operating system and the C programming language.

The information in this guide is organized as follows:

- [Chapter 1, “Product Description”](#), introduces the IP media software and its key features.

- [Chapter 2, “Programming Models”](#), describes methods of developing IP media-based applications.
- [Chapter 3, “State Models”](#), describes a simple state-based IP media application.
- [Chapter 4, “Event Handling”](#), defines an event and describes how to handle an event.
- [Chapter 5, “Error Handling”](#), presents information on how to obtain error codes and handle errors.
- [Chapter 6, “DTMF Handling”](#), provides information on how to send and receive DTMF digits.
- [Chapter 7, “T.38 Fax Server”](#), provides information on implementing a T.38 fax server.
- [Chapter 8, “Quality of Service \(QoS\) Alarms”](#), details how QoS may be used in an application.
- [Chapter 9, “Volume Control”](#), describes how to use volume level adjustment on a call.
- [Chapter 10, “Configuring for Half- or Full-Duplex Media Streams”](#), describes how to configure endpoints for half- and full-duplex media streaming.
- [Chapter 11, “Using Echo Cancellation”](#), describes how to enable echo cancellation on an IP channel.
- [Chapter 12, “Building Applications”](#), describes how to compile and link IP media-based applications.

Related Information

The following guides may also be used to develop IP technology-based applications:

- *IP Media Library API Library Reference*
- *Global Call IP Technology Guide*
- *Global Call API Programming Guide*
- *Global Call API Library Reference*
- *Standard Runtime Library API Library Reference*
- <http://developer.intel.com/design/telecom/support/> (for technical support)
- <http://www.intel.com/design/network/products/telecom/> (for product information)

This chapter provides an overview of the IP media software. It contains the following sections:

- Features 11
- Architecture 11
- Introduction to the IP Media Library 12
- Relationship with Global Call Library 12
- Standard Runtime Library Support 13
- Media Channel Device Naming 13

1.1 Features


Some of the features of the IP media software include:

- media resource management, such as open, close, and configure tasks
- media resource operations, such as start, stop, and detect digits
- Quality of Service (QoS) threshold alarm configuration and status reporting
- support of standard runtime library event management routines for error retrieval
- compatibility with Global Call or another call control stack to provide IP call control functionality

1.2 Architecture

Figure 1 shows the IP media library architecture when using an Intel NetStructure® DM/IP board or an Intel NetStructure® IPT board and a user-supplied call control stack.

Figure 1. IP Media Architecture



1.3 Introduction to the IP Media Library

The IP media library (IPML) provides an application programming interface to control the starting and stopping of RTP sessions, transmit and receive DTMF or signals, QoS alarms and their thresholds, and general-purpose device control functions. The library is only used to control media functions. It is not used to control the signaling stack. The application developer may choose to integrate any third party IP signaling stack (H.323, SIP, MGCP, etc.), or implement a proprietary signaling stack solution. The application developer uses the IP signaling stack to initiate or answer calls, and negotiate media characteristics such as coder, frames per packet, destination IP address, etc. Once media characteristics have been negotiated, the application uses IPML functions to start RTP streaming using the desired media characteristics.

1.4 Relationship with Global Call Library

The Global Call library provides a common call control interface that is independent of the underlying network interface technology. While the Global Call library is primarily used for call establishment and teardown, it also provides capabilities to support applications that use IP technology, such as:

- call control capabilities for establishing calls over an IP network, via the RADVISION* H.323 and SIP signaling stacks
- support for IP media control by providing the ability to open and close IP media channels for streaming, using the IP media software internally (under the hood)

Note: Applications should not mix Global Call and IP media library usage of the same ipm_ devices.

Refer to the following Global Call manuals for more details:

- *Global Call IP Technology Guide*

- *Global Call API Programming Guide*
- *Global Call API Library Reference*

1.5 Standard Runtime Library Support

The IP media library performs event management using the Standard Run-time Library (SRL), which provides a set of common system functions that are applicable to all devices. SRL functions, parameters, and data structures are described in the *Standard Runtime Library API Library Reference*. Use the SRL functions to simplify application development by writing common event handlers to be used by all devices.

1.6 Media Channel Device Naming

To determine available resources, call **ipm_Open()** on a board device, then call **ATDV_SUBDEVS** to get the available resources. (SRL operations are described in the *Standard Runtime Library API Library Reference*.)

To determine available resources in the Windows environment, use the **sr_getboardcnt()** function, which returns the number of boards of a particular type. (SRL operations are described in the *Standard Runtime Library API Library Reference*.)

Each IP media channel device follows the naming convention **ipmBxCy**; where:

- B is followed by the unique logical board number
- C is followed by the number of the media device channel

You may also use the **ipm_Open()** function to open a board device, **ipmBx**, where B is followed by the unique logical board number.

Before you can use any of the other IP media library functions on a device, that device must be opened. When the device is opened using **ipm_Open()**, the function returns a unique device handle. The handle is the only way the device can be identified once it has been opened. The **ipm_Close()** function closes a device.

This chapter describes the programming models supported by the IP media software.


The *Standard Runtime Library API Programming Guide* describes different programming models which can be used by applications. The IP media library supports all the programming models described therein.

Note: The synchronous programming model is recommended for low density systems only. For high density systems, asynchronous programming models provide increased throughput for the application.

This chapter describes a very simple IP media state-based application.

Figure 2 shows a simple IP media application using two channel device states, IDLE and STREAMING.

Figure 2. IP Media Channel State Diagram



All IP media events are retrieved using standard runtime library (SRL) event retrieval mechanisms, including event handlers. The SRL is a device-independent library containing Event Management functions and Standard Attribute functions. This chapter lists SRL functions that are typically used by IP media-based applications.

- [SRL Event Management Functions](#) 19
- [SRL Standard Attribute Functions](#) 19

4.1 SRL Event Management Functions

SRL Event Management functions retrieve and handle device termination events for certain library functions. Applications typically use the following functions:

sr_enbhdlr()
enables event handler

sr_dishdlr()
disables event handler

sr_getevtdev()
gets device handle

sr_getevttype()
gets event type

sr_waitevt()
wait for next event

sr_waitevtEx()
wait for events on certain devices

Note: See the *Standard Runtime Library API Library Reference* for function details.

4.2 SRL Standard Attribute Functions

SRL Standard Attribute functions return general device information, such as the device name or the last error that occurred on the device. Applications typically use the following functions:

ATDV_ERRMSGP()
pointer to string describing the error that occurred during the last function call on the specified device

ATDV_LASTERR()
error that occurred during the last function call on a specified device. See the function description for possible errors for the function.

ATDV_NAMEP()

pointer to device name, for example, ipmBxCy

ATDV_SUBDEVS()

number of subdevices

Note: See the *Standard Runtime Library API Library Reference* for function details.

This chapter describes error handling for the IP media software.

All IP media library functions return a value that indicates the success or failure of the function call. Success is indicated by a return value of zero or a non-negative number. Failure is indicated by a value of -1.

If a function fails, call the Standard Attribute functions **ATDV_LASTERR()** and **ATDV_ERRMSGP()** for the reason for failure. These functions are described in the *Standard Runtime Library API Library Reference*.

If an error occurs during execution of an asynchronous function, the **IPMEV_ERROR** event is sent to the application. No change of state is triggered by this event. Upon receiving the **IPMEV_ERROR** event, the application can retrieve the reason for the failure using the standard runtime library functions **ATDV_LASTERR()** and **ATDV_ERRMSGP()**.

This chapter contains guidelines for implementing DTMF handling using the IP media library. The following topics are discussed:

- [Introduction to DTMF Handling](#) 23
- [Setting DTMF Parameters](#) 24
- [Notification of DTMF Detection](#) 27
- [Generating DTMF](#) 28

6.1 Introduction to DTMF Handling

When a session is started on an IPM device, the IPM device receives data from its IP interface and transmits data towards the TDM bus. A DTI device receives data from its PSTN interface and transmits towards the TDM bus as well. In a gateway configuration, the DTI and IPM devices will be configured, via **gc_Listen()** and **ipm_Listen()** respectively, to listen to each other and thus create a full duplex communication path. The IPM device will forward DTMF that it receives on one interface to the other interface. [Figure 1, “IP Media Architecture”](#), on page 12 shows the data flow between the IP media library, the IP network, and the PSTN network.

When an IPM device receives DTMF from the TDM bus, there are several ways to forward it towards the IP interface. These include: forwarding it in the RTP stream (also called in-band), sending in the RTP stream via RFC 2833 packets, and using an application-controlled/defined method (also called out-of-band).

The IPM device can automatically forward the DTMF when either the in-band or RFC 2833 DTMF transfer mode has been selected. DTMF is **not** automatically forwarded when the application controlled/defined method, also known as out-of-band mode, has been selected. In the out-of-band case, the application must call **ipm_ReceiveDigits()** and have an IPM_DIGITS_RECEIVED event handler in place. Upon receiving the IPM_DIGITS_RECEIVED event, the DTMF information is contained in the IPM_DIGIT_INFO structure delivered with the event. The application has the responsibility to forward the DTMF via whatever mechanism, open or proprietary, it desires.

When using out-of-band mode, the DTMF is never transmitted in-band. As mentioned earlier, the application has the responsibility to forward the digits.

The setting for DTMF transfer mode also affects the handling of DTMF that is received from the IP interface. When the mode is set to in-band, the DTMF is automatically forwarded to the TDM bus.

When the mode is set to RFC 2833, DTMF is forwarded to the TDM bus as PCM data.

If out-of-band mode has been selected, then the application will use its own mechanism to be notified that a DTMF digit has been received. Then, **ipm_SendDigits()** is used when necessary to transmit a DTMF digit towards the TDM bus.

6.2 Setting DTMF Parameters

This section contains the following topics:

- [DTMF Modes](#)
- [Setting In-Band Mode](#)
- [Setting RFC 2833 Mode](#)
- [Setting Out-of-Band Mode](#)

6.2.1 DTMF Modes

The IP media library can be used to configure which DTMF mode (in-band, RFC 2833, or out-of-band) is used by the application. The DTMF mode is set on a per-channel basis using **ipm_SetParm()** and the **IPM_PARM_INFO** data structure.

The **eIPM_DTMFXFERMODE** enumeration identifies which DTMF mode to use. The following values are supported:

DTMFXFERMODE_INBAND

DTMF digits are sent and received in-band via standard RTP transcoding. This is the default mode when a channel is opened.

Note: In-band mode cannot be used when using low bit-rate (LBR) coders.

DTMFXFERMODE_RFC2833

DTMF digits are sent and received in the RTP stream as defined in RFC 2833.

DTMFXFERMODE_OUTOFBAND

DTMF digits are sent and received outside the RTP stream.

When using RFC2833, the payload type is specified by using the following parameter/value setting in a call to **ipm_SetParm()**:

PARMCH_RFC2833_EVT_TX_PLT

Identifies the transmit payload type. The value range for this field is 96 to 127.

PARMCH_RFC2833_EVT_RX_PLT

Identifies the receive payload type. The value range for this field is 96 to 127.

6.2.2 Setting In-Band Mode

In in-band mode, the DTMF audio is not clamped (not muted) and DTMF digits are sent in the RTP stream. When a channel is opened, the DTMF transfer mode is in-band by default.

Note: In-band mode cannot be used when using low bit-rate coders.


To set up a channel for in-band mode:

1. Open a channel using **ipm_Open("ipmB1C1",NULL,EV_SYNC)**
2. Set up the **IPM_PARM_INFO** structure and call **ipm_SetParm()** as shown below:

```
IPM_PARAM_INFO parmInfo;
unsigned long ulParmValue = DTMFXFERMODE_INBAND;
parmInfo.eParm = PARMCH_DTMFXFERMODE;
parmInfo.pvParmValue = &ulParmValue
ipm_SetParm(chdev, &parmInfo, EV_ASYNC)
```

Figure 3 shows a scenario diagram for setting in-band mode.

Figure 3. In-Band DTMF Mode Scenario Diagram



6.2.3 Setting RFC 2833 Mode

In RFC2833 mode, the DTMF audio is clamped (muted) and DTMF digits are sent in the RTP stream only as RFC2833 packets. To set up a channel for RFC 2833 mode, do the following:

1. Open a channel using **ipm_Open("ipmB1C1",NULL,EV_SYNC)**
2. Set the mode via the IPM_PARAM_INFO structure and **ipm_SetParm()** as shown below:

```
IPM_PARAM_INFO parmInfo;
unsigned long ulParmValue = DTMFXFERMODE_RFC2833;
parmInfo.eParm = PARMCH_DTMFXFERMODE;
parmInfo.pvParmValue = &ulParmValue
ipm_SetParm(chdev, &parmInfo, EV_ASYNC)
```

3. Set up the RFC 2833 event payload on the transmit side as shown below:


```
IPM_PARAM_INFO parmInfo;
unsigned long ulParmValue = 101;
parmInfo.eParm = PARMCH_RFC2833EVT_TX_PLT;
parmInfo.pvParmValue = &ulParmValue
ipm_SetParm(chdev, &parmInfo, EV_ASYNC)
```

4. Set up the RFC 2833 event payload on the receive side as shown below:

```
IPM_PARM_INFO parmInfo;
unsigned long ulParmValue = 101;
parmInfo.eParm = PARMCH_RFC2833EVT_RX_PLT;
parmInfo.pvParmValue = &ulParmValue;
ipm_SetParm(chdev, &parmInfo, EV_ASYNC)
```

Figure 4 shows a scenario diagram for setting RFC 2833 mode.

Figure 4. RFC 2833 Scenario Diagram



6.2.4 Setting Out-of-Band Mode

In out-of-band mode, the DTMF audio is automatically clamped (muted) and DTMF digits are not sent in the RTP packets. To set up a channel for out-of-band mode, do the following:

1. Open a channel using **ipm_Open**("ipmB1C1",NULL,EV_SYNC)
2. Set the mode via the IPM_PARM_INFO structure and **ipm_SetParm**() as shown below:


```
IPM_PARM_INFO parmInfo;
unsigned long ulParmValue = DTMFXFERMODE_OUTOFBAND;
parmInfo.eParm = PARMCH_DTMFXFERMODE;
parmInfo.pvParmValue = &ulParmValue;
ipm_SetParm(chdev, &parmInfo, EV_ASYNC)
```

3. Call **ipm_ReceiveDigits(chdev)** to have digits reported to the application and clamped from the RTP packets.

To change back to in-band mode, set the `PARMCH_DTMFXFERMODE` parameter to `DTMFXFERMODE_INBAND`.

Figure 5 shows a scenario diagram for setting out-of-band mode.

Figure 5. Out-of-Band DTMF Mode Scenario Diagram



6.3 Notification of DTMF Detection

Notification of DTMF detection depends on the DTMF mode being used. For out-of-band mode, when an incoming DTMF digit is detected (received from the TDM bus), the application receives an unsolicited `IPMEV_DIGITS_RECEIVED` event. The event data is contained in `IPM_DIGIT_INFO`. One event is returned for each digit that is received.

6.4 Generating DTMF

Once DTMF mode has been configured, the application can generate DTMF digits using the **ipm_SendDigits()** function.

Note: The only supported direction for DTMF digit generation is towards the TDM bus.

The IP media library for Host Media Processing supports T.38 fax server capability via the T.38 fax resource. The T.38 fax resource provides the host application the ability to initiate T.38 fax functionality, including modifying the codec from audio to T.38 and T.38 only.

7.1 Using the T.38 Fax Server

Note: The T.38 fax resource does not support the gateway mode nor does it support T.38 fax relay capability (T.38 packet to V.17/V.27/V.21 fax modem conversion and vice versa). Hence, the fax data cannot be shared on the CT Bus by multiple channels in this release.

Since the T.38 fax server resource has control of the UDP port, unlike the gateway model where the ipm channel controls the UDP port, two additional API functions, **dev_Connect()** and **dev_Disconnect()** are needed to associate or disassociate the voice media handle and the fax handle. When **dev_Connect()** is executed on an ipm channel and a T.38ServerFax resource, the IP media library API translates the ipm_(Get/Set)LocalMediaInfo() API call to a T38ServerFax_msg(Get/Set)Parm. As soon as **dev_Disconnect()** is issued, this translation is stopped and messages are forwarded to the ipm channel.

When using third party IP call control engines, specify the following sequence of calls in the application to make and break a T.38 session for sending fax. The IP media library provides the primitives to control media/session parameters.

1. Open an ipm channel using **ipm_Open()**. For example:

```
ipmDevH1 = ipm_open("ipmB1C1")
```
2. Open a dxxx channel to be used for fax using **dx_open()**. For example:

```
dxDevH1 = dx_open("dxxxB17C3")
```
3. Issue **dx_getfeaturelist()** on the dxxx channel to verify that this channel supports fax.
For example:

```
dx_getfeaturelist(dxDevH1, feature_tablep)
```
4. Verify that **dx_getfeaturelist()** returns FT_FAX for ft_fax bitmask in the FEATURE_TABLE structure. For example:

```
if (feature_tablep->ft_fax & FT_FAX)
```
5. Open the same dxxx channel using **fx_open()**. For example:

```
faxdevH1 = fx_open("dxxxB17C3")
```
6. Issue **dx_getfeaturelist()** to determine whether this fax resource supports T.38 fax. For example:

```
if (feature_tablep->ft_fax & FT_FAX_T38UDP)
```
7. To route the fax channel to the ipm channel, use **dev_Connect()**. For example:


```
ret = dev_Connect(ipmDevH1, faxdevH1, DM_FULLDUP, EV_ASYNC)
```
8. Process the DMEV_CONNECT completion event.

Note: DM_FULLDUP is the only mode supported when passing T.38 devices because the connection is made logically in both directions.

9. Issue **ipm_GetLocalMediaInfo()** to get the T.38 port and IP address information. The first media type in the IPM_MEDIA structure must be set to MEDIATYPE_LOCAL_UDPTL_T38_INFO. Process the IPMEV_GET_LOCAL_MEDIA_INFO completion event.
10. Get the remote end IP address and port information, achieved via signaling.
11. Issue **ipm_StartMedia()** to start media streaming. Specify the remote T.38 information obtained earlier. Process the IPMEV_START_MEDIA completion event.
12. To begin fax transmission, use **fx_sendfax()**. For example:
`fx_sendfax(faxdevH1, EV_ASYNC)`
13. Process the TFX_FAXSEND completion event.
14. When fax transmission is completed, use **ipm_Stop()** to stop operations on the ipm channel.

7.2 T.38 Fax Server Call Scenario

Figure 6. T.38 Fax Server Scenario



7.3 T.38 Fax Server Example Code

```

#include <stdio.h>
#include <stdlib.h>
#include <conio.h>
#include <string.h>
#include <fcntl.h>

```

```

#include <srllib.h>
#include <dxxlib.h>
#include <faxlib.h>
#include <ipmlib.h>
#include <devmgt.h>

static int ipm_handle = -1;
static int fax_handle = -1;

static DF_IOTT iott = {0};
static int fd = 0;
static IPM_MEDIA_INFO info;

static bool ipm_handle_disconnected = false;
static bool fax_handle_disconnected = false;

long IpmEventHandler( unsigned long evthandle )
{
    int evttype = sr_getevtttype();

    printf("Event=0x%x SRL handle=0x%x\n",evttype, evthandle);
    switch( evttype )
    {
        case DMEV_CONNECT:
            printf( "DMEV_CONNECT event received.\n" );
            {
                info.MediaData[0].eMediaType = MEDIATYPE_LOCAL_UDPTL_T38_INFO;
                if( ipm_GetLocalMediaInfo( ipm_handle, &info, EV_ASYNC ) == -1 )
                {
                    printf( "ipm_GetLocalMediaInfo() failed.\n" );
                    exit( 1 );
                }
            }
            break;
        case IPMEV_GET_LOCAL_MEDIA_INFO:
            printf( "IPMEV_GET_LOCAL_MEDIA_INFO event received.\n" );

            {
                info.unCount = 1;
                info.MediaData[0].eMediaType = MEDIATYPE_REMOTE_UDPTL_T38_INFO;
                info.MediaData[0].mediaInfo.PortInfo.unPortId = 2001; // remote IP port
                strcpy( info.MediaData[0].mediaInfo.PortInfo.cIPAddress, "146.152.84.56");
                info.MediaData[1].eMediaType = MEDIATYPE_FAX_SIGNAL;
                info.MediaData[1].mediaInfo.FaxSignal.eToneType = TONE_CED;
                printf("Press enter to continue (ipm_StartMedia)\n");
                //getchar();
                //printf( "calling ipm_StartMedia()\n" );
                if( ipm_StartMedia( ipm_handle, &info, DATA_IP_TDM_BIDIRECTIONAL, EV_ASYNC ) == -1 )
                {
                    printf( "ipm_StartMedia() failed.\n" );
                    exit( 1 );
                }
            }
            else
            {
                printf("[%s] ipm_StartMedia ok \n", ATDV_NAMEP(ipm_handle));
            }
            //getchar();
            //printf("Press enter to continue (ipm_StartMedia)\n");
        }
        break;
        case DMEV_DISCONNECT:
            printf( "DMEV_DISCONNECT event received.\n" );
            ipm_handle_disconnected = true;
    }
}

```

```

        if( fax_handle_disconnected )
        {
            return 0;
        }
        break;

case IPMEV_STARTMEDIA:
    printf( "IPMEV_STARTMEDIA event received.\n" );
    fd = dx_fileopen( "onepg_high.tif", O_RDONLY|O_BINARY );
    if( fd == -1 )
    {
        printf( "dx_fileopen() failed.\n" );
        exit( 1 );
    }
    fx_setiott(&iott, fd, DF_TIFF, DFC_EOM);
    iott.io_type |= IO_EOT;
    iott.io_firstpg = 0;
    iott.io_pgcount = -1;
    iott.io_phdcont = DFC_EOP;
    if( fx_initstat( fax_handle, DF_TX ) == -1 )
    {
        printf( "fx_initstat() failed.\n" );
        exit( 1 );
    }
    if( fx_sendfax( fax_handle, &iott, EV_ASYNC ) == -1 )
    {
        printf( "fx_sendfax() failed.\n" );
        exit( 1 );
    }
    break;

case IPMEV_STOPPED:
    printf( "IPMEV_STOPPED event received.\n" );
    if( dev_Disconnect( ipm_handle, EV_ASYNC ) == -1 )
    {
        printf( "dev_Disconnect() failed.\n" );
        exit( 1 );
    }

    if( dev_Disconnect( fax_handle, EV_ASYNC ) == -1 )
    {
        printf( "dev_Disconnect() failed.\n" );
        exit( 1 );
    }
    break;

case IPMEV_ERROR:
    printf( "IPMEV_ERROR event received on IPM channel.\n" );
    exit( -1 );
    break;

default:
    printf( "Unknown event %d received.\n", evttype );
    break;
}
return 0;
}

long FaxEventHandler( unsigned long evthandle )
{
    int evttype = sr_getevtttype();

    switch( evttype )
    {
    case TFX_FAXSEND:
        printf( "TFX_FAXSEND event received.\n" );
        if( ipm_Stop( ipm_handle, STOP_ALL, EV_ASYNC ) == -1 )

```

```

        {
            printf( "ipm_Stop() failed.\n" );
            exit( 1 );
        }
        break;

case TFX_FAXERROR:
    printf( "TFX_FAXERROR event received.\n" );
    exit( 1 );
    break;
default:
    printf( "Unknown event %d received on fax channel.\n", evttype );
    break;
}
return 0;
}

void main()
{
    ipm_handle = ipm_Open( "ipmB1C1", NULL, EV_SYNC );
    if( ipm_handle == -1 )
    {
        printf( "ipm_Open() failed.\n" );
        exit( 1 );
    }

    int vox_handle = dx_open( "dxxxB2C1", 0 );
    if( vox_handle == -1 )
    {
        printf( "dx_open() failed.\n" );
        exit( 1 );
    }

    FEATURE_TABLE feature_table;
    if( dx_getfeaturelist( vox_handle, &feature_table ) == -1 )
    {
        printf( "dx_getfeaturelist() failed.\n" );
        exit( 1 );
    }

    if( dx_close( vox_handle ) == -1 )
    {
        printf( "dx_close() failed.\n" );
        exit( 1 );
    }

    if( feature_table.ft_fax & FT_FAX )
    {
        if( feature_table.ft_fax & FT_FAX_T38UDP )
        {
            fax_handle = fx_open( "dxxxB2C1", 0 );
            if( fax_handle == -1 )
            {
                printf( "fx_open() failed.\n" );
                exit( 1 );
            }
        }
        else
        {
            printf( "Not a T.38 fax device.\n" );
            exit( 1 );
        }
    }
    else
    {
        printf( "Not a fax device.\n" );
        exit( 1 );
    }
}

```

```

    }
    if( sr_enbhdlr( ipm_handle, EV_ANYEVT, IpmEventHandler ) == -1 )
    {
        printf( "sr_enbhdlr() failed.\n" );
        exit( 1 );
    }

    if( sr_enbhdlr( fax_handle, EV_ANYEVT, FaxEventHandler ) == -1 )
    {
        printf( "sr_enbhdlr() failed.\n" );
        exit( 1 );
    }

    if( dev_Connect( ipm_handle, fax_handle, DM_FULLDUP, EV_ASYNC ) == -1 )
    {
        printf( "dev_Connect() failed.\n" );
        exit( 1 );
    }

    while(1)
    {
        sr_waitevt(-1);
        printf("Got an event\n");
    }

    if( sr_dishdlr( fax_handle, EV_ANYEVT, FaxEventHandler ) == -1 )
    {
        printf( "sr_dishdlr() failed.\n" );
        exit( 1 );
    }

    if( sr_dishdlr( ipm_handle, EV_ANYEVT, IpmEventHandler ) == -1 )
    {
        printf( "sr_dishdlr() failed.\n" );
        exit( 1 );
    }

    if( fx_close( fax_handle ) == -1 )
    {
        printf( "fx_close() failed.\n" );
        exit( 1 );
    }

    if( ipm_Close( ipm_handle, NULL ) == -1 )
    {
        printf( "ipm_Close() failed.\n" );
        exit( 1 );
    }
}

```


This chapter describes the QoS alarms that are supported by the IP media software. The following topics are discussed:

- [QoS Overview](#) 37
- [QoS Alarm Types](#) 37
- [QoS Threshold Attributes](#) 38
- [QoS Events](#) 39
- [Implementing QoS Alarms](#) 40
- [QoS Alarm and Alarm Recovery Mechanisms](#) 41
- [Example Code for QoS Alarm Handling](#) 44

8.1 QoS Overview

The public switched telephone network (PSTN) defines quality of service as a particular level of service, for example “toll-like” service. However, quality of service for voice or other media over the Internet Protocol is defined as a continuum of levels, which are affected by packet delay or loss, line congestion, and hardware quality such as microphone quality. The IP media software is designed to operate along the entire range of quality of service, enabling the application to retrieve information necessary for correct billing.

All QoS parameters supported by the IP media software are disabled by default. That is, QoS monitoring must be enabled by the application. If desired, the application can set threshold values to monitor the quality of service during sessions. The QoS parameters are measured during time intervals, starting when a session is established. A fault occurs when the measurement of a QoS parameter exceeds a predefined threshold. A recovery occurs when the measurement of a QoS parameter returns to a value that does not exceed the predefined threshold.

To enable and use QoS monitoring in your application, you must follow several steps. Some steps are optional; others are required. These steps are detailed in [Section 8.5, “Implementing QoS Alarms”](#), on page 40.

8.2 QoS Alarm Types

All QoS alarms operate on a per-channel basis. That is, a QoS alarm indicates the status of a particular channel during a particular session, not the status of an entire IP media resource board.

The following QoS alarm types are supported in the IP media software. These names are used in the `IPM_QOS_THRESHOLD_DATA` structure when setting parameters for the alarms, and in the `IPM_QOS_ALARM_DATA` structure that is associated with the `IPMEV_QOS_ALARM` event that is generated when an alarm state transition occurs.

QOSTYPE_JITTER

QoS alarm for excessive average jitter

QOSTYPE_LOSTPACKETS

QoS alarm for excessive percentage of lost packets

QOSTYPE_RTCPTIMEOUT

QoS alarm for RTCP timeout, indicating that RTCP packets are no longer being received. This alarm can also indicate that the network cable is disconnected.

QOSTYPE_RTPTIMEOUT

QoS alarm for RTP timeout, indicating that RTP packets are no longer being received. This alarm can also indicate that the network cable is disconnected.

For details on using QoS alarms in your application, see [Section 8.5, “Implementing QoS Alarms”](#), on page 40.

8.3 QoS Threshold Attributes

All QoS alarm types have one or more threshold attributes, such as time interval and fault threshold, which specify how the system determines when to generate a QoS alarm event.

The threshold attributes listed below are specified in `IPM_QOS_THRESHOLD_DATA` structures that are contained in an `IPM_QOS_THRESHOLD_INFO` structure that is passed to **`ipm_SetQoSThreshold()`**:

`unTimeInterval`

time interval between successive parameter measurements

`unDebounceOn`

polling interval for detecting potential alarm fault condition. This interval must be a multiple of `unTimeThreshold`.

`unDebounceOff`

polling interval for measuring potential alarm non-fault condition. This interval must be a multiple of `unTimeThreshold`.

`unFaultThreshold`

fault threshold value. The meaning and value range of this attribute depend on the alarm type.

`unPercentSuccessThreshold`

percentage of poll instances in `unDebounceOff` interval that the fault threshold must not be exceeded before an “alarm off” event is sent. The granularity for this attribute is the ratio of `unTimeInterval` to `unDebounceOff`, expressed as a percentage.

unPercentFailThreshold

percentage of poll instances in unDebounceOn interval that the fault threshold must be exceeded before an “alarm on” event is set. The granularity for this attribute is the ratio of unTimeInterval to unDebounceOff, expressed as a percentage.

Note: Not all attributes are supported for all alarm types and products. All attributes that are not supported should be set to 0.

The IP Media Library software provides default values for each threshold attribute that will be used if the application does not specify any threshold values via **ipm_SetQoSThreshold()**; the specific default values vary by alarm type. The following table provides details on the attributes supported and the default values for each QoS alarm type. Note that if the application needs to set an explicit value for any of the threshold values for a particular alarm, it must specify the values for *all* fields in the IPM_QOS_THRESHOLD_DATA structure, including those that remain at default values.

For details on the IPM_QOS_THRESHOLD_DATA structure, see the *IP Media Library API Library Reference*.

Table 1. Quality of Service Parameter Defaults for Host Media Processing

QoS Type	Time Interval (ms)	Debounce On (ms)	Debounce Off (ms)	Fault Threshold ¹	% Success Threshold	% Fail Threshold
Jitter	5000	20000	60000	60 (ms)	25	25
Lost Packets	1000	10000	10000	20 (%)	40	40
RTCP Timeout	1000	0	0	250 (x100ms = 25sec)	0	0
RTP Timeout	1000	0	0	1200 (x100ms = 120sec)	0	0
Notes: 1. Units for Fault Threshold are different for different QoS Types. See unit indications in table cells.						

8.4 QoS Events

The following QoS event types are used when calling the **ipm_EnableEvents()** and **ipm_DisableEvents()** functions to enable and disable the corresponding QoS alarms.

EVT_JITTER

event indicating excessive jitter

EVT_LOSTPACKETS

event indicating excessive percentage of lost packets

EVT_RTCPTIMEOUT

timeout event indicating RTCP packets are no longer being received

EVT_RTPTIMEOUT

timeout event indicating RTP packets are no longer being received

These QoS events correspond to the QoS alarms discussed in [Section 8.2, “QoS Alarm Types”](#), on page 37. For details on enabling QoS alarms in your application, see the following section, [“Implementing QoS Alarms”](#).

8.5 Implementing QoS Alarms

The following steps provide general guidelines for implementing QoS alarms in your application. For details on the IP Media Library functions and data structures that are mentioned, see the *IP Media Library API Library Reference*.

Note: These steps do not represent every task that must be performed to create a working application but are intended as general guidelines.

1. Optional steps before enabling a QoS alarm:

- a. Call `ipm_GetQoSThreshold()` to retrieve the current settings of QoS parameters on the specified IP channel. QoS parameter default values vary by alarm type and product. For information on QoS parameter default values, see the table in [Section 8.3, “QoS Threshold Attributes”](#), on page 38.
- b. If you need to change current QoS parameter values, set up the `IPM_QOS_THRESHOLD_INFO` structure with desired values. This structure contains one or more `IPM_QOS_THRESHOLD_DATA` structures. Note that you must explicitly specify the value for *every* parameter in the `IPM_QOS_THRESHOLD_DATA` structure, even if you want to use the default value for some of those parameters and non-default values for other parameters.
- c. Call `ipm_SetQoSThreshold()` to use the QoS parameter values set in step 1b.

2. Enable QoS alarms and start media streaming:

- a. Call `ipm_EnableEvents()` to enable QoS monitoring for a list of alarm types.
- b. Call `ipm_StartMedia()` to start media streaming and begin QoS monitoring.

3. Monitor QoS alarm notification events:

- a. When a QoS alarm has been triggered, an `IPMEV_QOS_ALARM` event is generated by the system. Call the Standard Runtime Library function `sr_getevtttype()` to return the event type.
- b. Use Standard Runtime Library API functions such as `sr_getevtdatap()` to query the `IPM_QOS_ALARM_DATA` structure to learn whether the alarm state is on or off.

Note: For the HMP software, the system sends a QoS alarm event containing `ALARM_STATE_ON` when the fault threshold is exceeded and sends a QoS alarm event containing `ALARM_STATE_OFF` when the threshold returns to the programmed level.

4. Perform clean-up activities:

- a. Call `ipm_Stop()` to stop media streaming.
- b. Call `ipm_DisableEvents()` to stop QoS parameter monitoring.

For example code that illustrates how to implement QoS alarms, see [Section 8.7, “Example Code for QoS Alarm Handling”](#), on page 44.

8.6 QoS Alarm and Alarm Recovery Mechanisms

The information in this section does not apply to the RTP timeout and RTCP timeout alarm types, which do not support the debounce parameters.

To explain how the system monitors, detects, and clears a QoS alarm condition, three scenarios will be presented. In the first scenario, a QoS fault condition is detected but an alarm-on event is not sent to the application. In the second scenario, the QoS fault condition meets all alarm criteria and an alarm-on event is sent. The third scenario expands on the second scenario and describes how the alarm-on condition is cleared.

These scenarios are intended to illustrate the concepts. For easier reference, in the figures, time is shown in seconds rather than in millisecond units. For details on the parameters, see the *IP Media Library API Library Reference*.

In the three scenarios, the jitter alarm type is being monitored. The QoS parameters (alarm threshold attribute values) used in these scenarios are:

- `unTimeInterval` = 1000 ms (1 second)
- `unDebounceOn` = 4000 ms (4 seconds)
- `unDebounceOff` = 4000 ms (4 seconds)
- `unFaultThreshold` = 60 milliseconds
- `unPercentFailThreshold` = 50 percent
- `unPercentSuccessThreshold` = 50 percent

From these parameters, the library calculates “count” values for alarm-on and alarm-off debouncing that represent the number of measurements that must fail (or succeed) within a `unTimeInterval` period before an alarm-on (or alarm-off) event is generated.

For alarm-on debouncing:

```
count = int((unDebounceOn/unTimeInterval) * (unPercentFailThreshold/100))
      = int((4000/1000) * (50/100))
      = int(4 * 0.5)
      = 2
```

For alarm-off debouncing:

```
count = int((unDebounceOff/unTimeInterval) * (unPercentSuccessThreshold/100))
      = int((4000/1000) * (50/100))
      = int(4 * 0.5)
      = 2
```

For example code that uses these QoS parameter values, see [Section 8.7, “Example Code for QoS Alarm Handling”](#), on page 44.

Scenario 1: Brief Alarm Condition

This scenario illustrates that a QoS alarm is triggered, but the alarm condition does not meet all of the specified alarm criteria. An alarm-on event is not sent to the application.

In Figure 7, the time line shows that QoS parameters are measured every time interval (**unTimeInterval** parameter), or every 1 second in this case. When the jitter exceeds the 60ms fault threshold (**unFaultThreshold** parameter), the debounce on timer is kicked off (**unDebounceOn** parameter). In this example, the fault threshold is exceeded at the 4th second.


To determine if this is a true alarm condition, the system continues to monitor the jitter in blocks of 4 seconds (**unDebounceOn** parameter), the debounce on window. If the jitter is below the 60ms fault threshold for more than 50 percent of the time (**unPercentFailThreshold** parameter) in a 4-second block, an alarm-on event is not sent to the application.

In this example, at the end of the 4-second debounce on window (at the 8th second), the percent failure threshold measured is 25 percent; that is, the fault threshold only exceeded the desired fault threshold of 60ms at the 5th second measurement within the 4-second debounce on window. Since the desired percentage failure threshold of 50 percent was not met or exceeded, no alarm-on event is sent to the application. At the end of the 8th second, the debounce on timer is reset.

Figure 7. QoS Scenario 1: Brief Alarm Condition

QoS parameters:

time interval = 1 sec
 debounce on = 4 sec
 debounce off = 4 sec
 fault threshold = 60ms
 % success threshold = 50 %
 % fail threshold = 50 %



Scenario 2: True Alarm Condition

This scenario illustrates that a QoS alarm is triggered, and the alarm condition meets all of the specified alarm criteria. Therefore, an alarm-on event is sent to the application.

In Figure 8, the time line shows that QoS parameters are measured every time interval (**unTimeInterval** parameter), or every 1 second in this case. When the jitter exceeds the 60ms fault threshold (**unFaultThreshold** parameter), the debounce on timer is kicked off (**unDebounceOn** parameter). In this example, the fault threshold is exceeded at the 4th second.


To determine if this is a true alarm condition, the system continues to monitor the jitter in blocks of 4 seconds, the debounce on window (**unDebounceOn** parameter). If the jitter exceeds the 60ms fault threshold for more than 50 percent of the time (**unPercentFailThreshold** parameter) in a 4-second block, an alarm-on event is sent to the application.

In this example, at the end of the 4-second debounce on window (at the 8th second), the percent failure threshold measured is 100 percent; that is, the fault threshold exceeded the desired fault threshold of 60ms at the 5th, 6th, 7th and 8th second measurement within the 4-second debounce on window. Since the desired percentage failure threshold of 50 percent was exceeded, an alarm-on event is sent to the application. At the end of the 8th second, the debounce on timer is reset. See [Scenario 3: Alarm Condition Cleared](#) to learn how the system continues to monitor the jitter QoS alarm.

Figure 8. QoS Scenario 2: True Alarm Condition

QoS parameters:

time interval = 1 sec
debounce on = 4 sec
debounce off = 4 sec
fault threshold = 60 ms
% success threshold = 50 %
% fail threshold = 50 %



Scenario 3: Alarm Condition Cleared

Scenario 3 builds on Scenario 2 to illustrate what happens after an alarm-on event is sent to the application and how the alarm-on condition is cleared.

In Figure 9, an alarm-on event was sent to the application at the 8th second, and the system is now in a QoS failure condition. To determine how long this condition will last, the system resumes monitoring the jitter every time interval (**unTimeInterval** parameter), or every 1 second in this case. When the jitter is less than the 60ms fault threshold (**unFaultThreshold** parameter), the debounce off timer kicks in (**unDebounceOff** parameter). In this example, this condition occurs at the 13th second.


To determine if this is a true success condition, the system monitors the jitter in blocks of 4 seconds, the debounce off window (**unDebounceOff** parameter). If the jitter is below the 60ms fault threshold for more than 50 percent of the time (**unPercentSuccessThreshold** parameter) in a 4-second block, an alarm-off event is sent to the application.

In this example, at the end of the 4-second debounce off window (at the 17th second), the percent success threshold measured is 100 percent; that is, the jitter level was below the desired fault threshold of 60ms at the 14th through 17th second measurement within the 4-second debounce off window. Since the desired percentage success threshold of 50 percent was exceeded, an alarm-off event is sent to the application. At the end of the 17th second, the debounce off timer is reset.

Figure 9. QoS Scenario 3: Alarm Condition Cleared

QoS parameters:

time interval = 1 sec
 debounce on = 4 sec
 debounce off = 4 sec
 fault threshold = 60 ms
 % success threshold = 50 %
 % fail threshold = 50 %



8.7 Example Code for QoS Alarm Handling

The following pseudocode illustrates how you might use QoS alarms in an application. The code enables the following QoS alarm types: . Because the `IPM_QOS_THRESHOLD_INFO` structure is not filled in for the lost packets alarm type, the default QoS parameter values are used for this alarm. The QoS parameter values for jitter are the same values used in the scenario descriptions in [Section 8.6, “QoS Alarm and Alarm Recovery Mechanisms”](#), on page 41.

```
#include <stdio.h>
#include <srllib.h>
#include <ipmlib.h>

typedef long int(*HDLR)(unsigned long);
void CheckEvent();
```

```

void main()
{
    int nDeviceHandle;
    IPM_QOS_THRESHOLD_INFO mySetQosThresholdInfo;

    const int nNumEvent = 4;
    eIPM_EVENT myEvents[nNumEvent] = {EVT_LOSTPACKETS,
                                       EVT_JITTER,
                                       EVT_RTPTIMEOUT,
                                       EVT_RTCPTIMEOUT};

    // Register event handler function with srl
    sr_enbhdr( EV_ANYDEV ,EV_ANYEVT , (HDLR) CheckEvent);
    /*
    .
    .
    Main Processing
    .
    .
    .
    */

    /*
    .
    .
    The application can call ipm_GetQoSThreshold() to check the current
    threshold levels for QoS parameters.
    .
    .
    */

    // Change alarm threshold settings for IP device handle, nDeviceHandle.
    // ASSUMPTION: A valid nDeviceHandle was obtained from prior call to ipm_Open().
    // Note:
    // 1. You don't have to change all QoS types. In the example below, the lost packet
    //    values are not changed.
    // 2. For RTP Timeout and RTCP Timeout, the values of all parameters EXCEPT
    //    unTimeInterval and unFaultThreshold must be set to ZERO
    mySetQosThresholdInfo.unCount = 3;
    mySetQosThresholdInfo.QoSThresholdData[0].eQoSType = QOSTYPE_JITTER;
    mySetQosThresholdInfo.QoSThresholdData[0].unTimeInterval = 1000; //1sec
    mySetQosThresholdInfo.QoSThresholdData[0].unDebounceOn = 4000; //4sec
    mySetQosThresholdInfo.QoSThresholdData[0].unDebounceOff = 4000; //4sec
    mySetQosThresholdInfo.QoSThresholdData[0].unFaultThreshold = 60; //60ms
    mySetQosThresholdInfo.QoSThresholdData[0].unPercentSuccessThreshold = 50; //50%
    mySetQosThresholdInfo.QoSThresholdData[0].unPercentFailThreshold = 50; //50%
    mySetQosThresholdInfo.QoSThresholdData[1].eQoSType = QOSTYPE_RTPTIMEOUT;
    mySetQosThresholdInfo.QoSThresholdData[1].unTimeInterval = 1000; //1sec
    mySetQosThresholdInfo.QoSThresholdData[1].unDebounceOn = 0;
    mySetQosThresholdInfo.QoSThresholdData[1].unDebounceOff = 0;
    mySetQosThresholdInfo.QoSThresholdData[1].unFaultThreshold = 600; //60sec timeout
    mySetQosThresholdInfo.QoSThresholdData[1].unPercentSuccessThreshold = 0;
    mySetQosThresholdInfo.QoSThresholdData[1].unPercentFailThreshold = 0;
    mySetQosThresholdInfo.QoSThresholdData[2].eQoSType = QOSTYPE_RTCPTIMEOUT;
    mySetQosThresholdInfo.QoSThresholdData[2].unTimeInterval = 1000; //1sec
    mySetQosThresholdInfo.QoSThresholdData[2].unDebounceOn = 0;
    mySetQosThresholdInfo.QoSThresholdData[2].unDebounceOff = 0;
    mySetQosThresholdInfo.QoSThresholdData[2].unFaultThreshold = 150; //15sec timeout
    mySetQosThresholdInfo.QoSThresholdData[2].unPercentSuccessThreshold = 0;
    mySetQosThresholdInfo.QoSThresholdData[2].unPercentFailThreshold = 0;

```

```

if(ipm_SetQoSThreshold(nDeviceHandle, &mySetQoSThresholdInfo, EV_SYNC) == -1)
{
    printf("ipm_SetQoSThreshold failed for device name = %s with error = %d\n",
           ATDV_NAMEP(nDeviceHandle), ATDV_LASTERR(nDeviceHandle));
    /*
     *
     * Perform Error Processing
     *
     */
}

// Call ipm_EnableEvent to be notified of possible alarm conditions.

if(ipm_EnableEvents(nDeviceHandle, myEvents, nNumEvent, EV_SYNC) == -1)
{
    printf("ipm_EnableEvents failed for device name %s with error = %d\n",
           ATDV_NAMEP(nDeviceHandle), ATDV_LASTERR(nDeviceHandle));
    /*
     *
     * Perform Error Processing
     *
     */
}

/*
 *
 * Continue Processing
 *
 */

// Application can disable events if it does not want to be notified.

if(ipm_DisableEvents(nDeviceHandle, myEvents, nNumEvent, EV_SYNC) == -1)
{
    printf("ipm_DisableEvents failed for device name %s with error = %d\n",
           ATDV_NAMEP(nDeviceHandle), ATDV_LASTERR(nDeviceHandle));
    /*
     *
     * Perform Error Processing
     *
     */
}

if(ipm_Close(nDeviceHandle, NULL) == -1)
{
    printf("----->ipm_Close() failed for handle = %d\n", nDeviceHandle);
    /*
     *
     * Perform Error Processing
     *
     */
}
}

```

```

void CheckEvent()
{
    int nEventType = sr_getevtttype();
    int nDeviceID = sr_getevtdev();
    void *pVoid = sr_getevtdata();

    switch(nEventType)
    {
        /*
        .
        . List of expected events
        .
        */

        /* When alarm occurs you get this event. */
        case IPMEV_QOS_ALARM:
        {
            printf("Received IPMEV_QOS_ALARM for device = %s\n",
                ATDV_NAMEP(nDeviceID));
            IPM_QOS_ALARM_DATA * l_pAlarm = (IPM_QOS_ALARM_DATA*)pVoid;
            switch(l_pAlarm->eQoSType)
            {
                case QOSTYPE_JITTER:
                    printf("Alarm Type = Jitter\n");
                    break;
                case QOSTYPE_LOSTPACKETS:
                    printf("Alarm Type = LostPackets\n");
                    break;
                case QOSTYPE_RTPTIMEOUT:
                    printf("Alarm Type = RTPTimeout\n");
                    break;
                case QOSTYPE_RTCPTIMEOUT:
                    printf("Alarm Type = RTCPTIMEOUT\n");
                    break;
            }
            printf("Alarm state = %s\n", (l_pAlarm->eAlarmState? "On": "Off"));
            break;
        }

        /*
        .
        .
        . process other cases.
        .
        .
        */

        default:
            printf("Received unknown event = %d for device = %s\n",
                nEventType, ATDV_NAMEP(nDeviceID));
            break;
    }
}

```


This chapter describes the volume adjustment feature which allows an application to adjust the volume level on an IP device. The following topics are covered:

- Volume Control Overview 49
- Volume Control Parameters 49
- Implementing Volume Control 50
- Volume Control Hints and Tips 50
- Volume Control Example Code 50

9.1 Volume Control Overview

The IP media library provides the ability to adjust the volume of an inbound and outbound call on an IP device. This volume adjustment value is specified for an IP channel device through the API; possible values are from -32 dB to +31 dB in increments of 1 dB.

The volume adjustment value is a relative change to the nominal value. For example, if the original volume level on a call is 20 dB, then to reduce the volume, you could specify an adjustment value of -6 dB; the volume level on the call would then be 14 dB. To increase the volume, you could specify an adjustment value of +8 dB; the volume level on the call would then be 28 dB. Subsequently, to readjust the volume to 26 dB, you must specify +6 dB. This adjustment is relative to the original nominal value of 20 dB.

9.2 Volume Control Parameters

The **ipm_SetParm()** function is used to specify the volume adjustment for an IP device in your application. The **ipm_GetParm()** function returns the value of the volume adjustment for a given IP device. If no volume adjustment has been made, this function returns a zero for the volume adjustment parameters. Both of these functions use the **IPM_PARM_INFO** structure.

The following parameter types (specified in the **IPM_PARM_INFO** structure **eParm** field) are used to adjust the volume level of a call on an IP device:

- **PARMCH_RX_ADJVOLUME** to adjust the volume level for the inbound side (from IP) of a call
- **PARMCH_TX_ADJVOLUME** to adjust the volume level for the outbound side (to IP) of a call

For details on these functions and data structure, see the *IP Media Library API Library Reference*.

9.3 Implementing Volume Control

To implement volume control for an IP device in your application, follow these steps:

Note: These steps do not represent every task that must be performed to create a working application but are intended as general guidelines.

1. Determine the volume adjustment necessary for the IP device; for example, based on your experience with equipment from a particular vendor.
2. Adjust the volume level for the inbound side (from IP) as needed using **ipm_SetParm()** and the **PARMCH_RX_ADJVOLUME** parameter in **IPM_PARM_INFO** structure.
3. Adjust the volume level for the outbound side (to IP) as needed using **ipm_SetParm()** and the **PARMCH_TX_ADJVOLUME** parameter in **IPM_PARM_INFO** structure.
4. Perform streaming activity using **ipm_StartMedia()**.

Note: Typically, you adjust the volume level *before* performing a streaming activity over the IP network. However, you can issue the **ipm_SetParm()** function to change the volume level during an active call.

5. If desired, check the current value of volume level adjustment for an IP device using **ipm_GetParm()**.
6. If desired, reset the volume to its original value (that is, no adjustment) at call termination using **ipm_SetParm()** and either **PARM_RX_ADJVOL_DEFAULT** or **PARM_TX_ADJVOL_DEFAULT**.

9.4 Volume Control Hints and Tips

The following hints and tips are provided to help you use the volume control feature in your application:

- The volume adjustment value (specified in **PARMCH_RX_ADJVOLUME** or **PARMCH_TX_ADJVOLUME**) is applied per IP channel device.
- The volume adjustment value for an IP device remains in effect until it is explicitly changed in the application. Terminating the call or closing the device will not reset the volume level to its default value.
- The adjustment levels specified are absolute values. Each invocation will change the adjustment level to its new value.

9.5 Volume Control Example Code

The following example illustrates the use of the **PARMCH_TX_ADJVOLUME** value to decrease the volume by 6 dB for the outbound side of an IP call.

```
#include <stdio.h>
#include <srllib.h>
#include <ipmlib.h>

typedef long int(*HDLR)(unsigned long);
```

```

void CheckEvent();

void main()
{
    int nDeviceHandle;
    // Register event handler function with the standard runtime library (SRL)
    sr_enbhdr( EV_ANYDEV, EV_ANYEVT, (HDLR)CheckEvent);

    /*
    .
    . main processing
    .
    */

    /*
    Need to enable three events for IP device handle, nDeviceHandle.
    ASSUMPTION: A valid nDeviceHandle was obtained from prior call to ipm_Open().
    */
    IPM_PARAM_INFO    parmInfo;
    int                parmValue = -6; // decrease nominal volume by 6 dB
    parmInfo.eParm = PARMCH_TX_ADJVOLUME;
    parmInfo.pvParmValue = &parmValue;
    if ipm_SetParm(nDeviceHandle, &parmInfo, EV_ASYNC) == -1)
    {
        /*
        .
        . Perform error processing
        .
        .
        */
    }

    /*
    .
    . Start media streaming with ipm_StartMedia( )
    .
    */

    // Reset Volume adjust to the channel
    IPM_PARAM_INFO    parmInfo;
    int                parmValue = PARM_TX_ADJVOL_DEFAULT;
    parmInfo.eParm = PARMCH_TX_ADJVOLUME;
    parmInfo.pvParmValue = &parmValue;
    if ( ipm_SetParm(nDeviceHandle, &parmInfo, EV_ASYNC) == -1)
        printf("%s: ipm_SetParm failed.\n", ATDV_NAMEP(nDeviceHandle));
    else
        printf("%s: Transmit Volume adjustment has been Reset successfully.\n",
            ATDV_NAMEP(nDeviceHandle));
    }

void CheckEvent()
{
    int nEventType = sr_getevtttype();
    int nDeviceID = sr_getevtdev();
    void* pVoid = sr_getevtdatap();

    switch(nEventType)
    {
        .
        .
        case IPMEV_SET_PARM:
            IPM_PARAM_INFO parmInfo;
            int parmValue = 0;
            parmInfo.eParm = PARMCH_TX_ADJVOLUME;
            parmInfo.pvParmValue = &parmValue;

```

```
        ipm_GetParm(nDeviceHandle, &parmInfo, EV_SYNC) ;
        printf("Outbound Volume for device = %s adjusted",
               "by = %d db.\n", ATDV_NAMEP(nDeviceID),
               parmInfo.ParmValue);
        break;

Default:
    Printf("Received unknown event = %d for device = %s\n",
           nEventType, ATDV_NAMEP(nDeviceID));
    break;
    }
}
```

Configuring for Half- or Full-Duplex Media Streams

10

This chapter describes the IP Media Library capability for setting up and reconfiguring end points for half-duplex and full-duplex media streams.

- Overview of Half- and Full-Duplex Stream Support. 53
- Programming Interface for Half- and Full-Duplex Stream Configuration 54
- Application Scenario 55
- Code Example 56

10.1 Overview of Half- and Full-Duplex Stream Support

When using IP technology, the ability to start a stream session at an end point for half-duplex (or full-duplex) media streaming and subsequently update the stream session for full-duplex (or half-duplex) media streaming is a useful capability.

One example that demonstrates this is when providing support for a call control feature known as “Early Media”. In IP technology, the establishment of RTP media streaming is normally one of the final steps in establishing and connecting a call. This is in contrast to the Public Switched Telephone Network (PSTN), where call progress signaling is commonly provided to the calling party via audible, in-band call progress tones, such as ringback, busy signal, and SIT tones. When implementing a VoIP gateway, it is often imperative to initiate media (RTP) streaming from the local endpoint to the calling party before the call is connected.

To achieve this functionality using the IP Media Library, the calling party end point can be configured for half-duplex streaming (in the receive direction) prior to call connection to receive call progress signaling. The end point can then be reconfigured for full-duplex streaming when the call is connected.

Another useful application of this feature is in the implementation of H.450.4 call hold message flows.

Note: Configuring half-duplex streaming for T.38 fax does not apply, since T.38 fax is inherently full-duplex.

10.2 Programming Interface for Half- and Full-Duplex Stream Configuration

The following IP Media Library functions are used to configure and reconfigure an end point for half-duplex or full-duplex media streaming:

ipm_StartMedia()

sets media properties and starts an RTP media streaming session

ipm_ModifyMedia()

modifies various properties of an active RTP media streaming session

Both functions contain an **eDirection** parameter that is used to specify if the media stream should be half-duplex or full-duplex. Possible values of the **eDirection** parameter are:

DATA_IP_RECEIVEONLY

receive RTP and RTCP packets from the IP network, but do not send packets

DATA_IP_SENDOONLY

send RTP and RTCP packets to the IP network, but do not receive packets

DATA_IP_TDM_BIDIRECTIONAL

full-duplex RTP and RTCP path between IP network and TDM

DATA_IP_INACTIVE

allow RTCP while blocking RTP or T.38 packets

DATA_IP_DIR_NONE

do not modify the direction of the current session; the previous direction remains in effect.

This value is used when changing the coder and/or IP address without changing the direction.


Note: The **DATA_IP_DIR_NONE** parameter applies only when using the **ipm_ModifyMedia()** function.

Both functions also have pointers to a media information structure through which coder attributes, such as the coder type, frame size, frames per packet setting etc. can also be configured.

See the *IP Media Library API for Host Media Processing Library Reference* for detailed information about these functions.

Figure 10 shows the possible end point states for media streaming and how the **ipm_StartMedia()** and **ipm_ModifyMedia()** functions are used to transition between those states.


Figure 10. End Point Media Streaming State Transitions



10.3 Application Scenario

Figure 11 shows a scenario in which the **ipm_StartMedia()** function is used to configure an end point for a half-duplex (receive-only) media stream early in the setup sequence. This media stream can be used to receive call setup information, for example call progress tones. Later, the **ipm_ModifyMedia()** function can be used to reconfigure the end point for full-duplex media streaming.

Figure 11. Half- and Full-Duplex Media Streaming Application Scenario



10.4 Code Example

The following sample code demonstrates how to reconfigure an end point from full-duplex media streaming to half-duplex (send only) media streaming. The coder is also changed from G.711 u-law to G.711 A-law.

```

#include <stdio.h>
#include <string>
#include <srllib.h>
#include <ipmlib.h>
typedef long int(*HDLR)(unsigned long);
void CheckEvent();
void main()
{
    /*
     *
     * Main Processing
     *
     */

    /*
     * Set the media properties for a remote party using IP device handle, nDeviceHandle.
     * ASSUMPTION: A valid nDeviceHandle was obtained from prior call to ipm_Open().
     */
}

```

```

IPM_MEDIA_INFO MediaInfo;
MediaInfo.unCount = 4;

MediaInfo.MediaData[0].eMediaType = MEDIATYPE_REMOTE_RTP_INFO;
MediaInfo.MediaData[0].mediaInfo.PortInfo.unPortId = 2328;
strcpy(MediaInfo.MediaData[0].mediaInfo.PortInfo.cIPAddress, "111.21.0.9\n");

MediaInfo.MediaData[1].eMediaType = MEDIATYPE_REMOTE_RTCP_INFO;
MediaInfo.MediaData[1].mediaInfo.PortInfo.unPortId = 2329;
strcpy(MediaInfo.MediaData[1].mediaInfo.PortInfo.cIPAddress, "111.41.0.9\n");

MediaInfo.MediaData[2].eMediaType = MEDIATYPE_REMOTE_CODER_INFO;
MediaInfo.MediaData[2].mediaInfo.CoderInfo.eCoderType = CODER_TYPE_G711ULAW64K;
MediaInfo.MediaData[2].mediaInfo.CoderInfo.eFrameSize = (eIPM_CODER_FRAMESIZE) 30;
MediaInfo.MediaData[2].mediaInfo.CoderInfo.unFramesPerPkt = 1;
MediaInfo.MediaData[2].mediaInfo.CoderInfo.eVadEnable = CODER_VAD_DISABLE;
MediaInfo.MediaData[2].mediaInfo.CoderInfo.unCoderPayloadType = 0;
MediaInfo.MediaData[2].mediaInfo.CoderInfo.unRedPayloadType = 0;

MediaInfo.MediaData[3].eMediaType = MEDIATYPE_LOCAL_CODER_INFO;
MediaInfo.MediaData[3].mediaInfo.CoderInfo.eCoderType = CODER_TYPE_G711ULAW64K;
MediaInfo.MediaData[3].mediaInfo.CoderInfo.eFrameSize = (eIPM_CODER_FRAMESIZE) 30;
MediaInfo.MediaData[3].mediaInfo.CoderInfo.unFramesPerPkt = 1;
MediaInfo.MediaData[3].mediaInfo.CoderInfo.eVadEnable = CODER_VAD_DISABLE;
MediaInfo.MediaData[3].mediaInfo.CoderInfo.unCoderPayloadType = 0;
MediaInfo.MediaData[3].mediaInfo.CoderInfo.unRedPayloadType = 0;

if (ipm_StartMedia(nDeviceHandle, &MediaInfo, DATA_IP_TDM_BIDIRECTIONAL, EV_SYNC) == -1)
{
    printf("ipm_StartMediaInfo failed for device name = %s with error = %d\n",
        ATDV_NAMEP(nDeviceHandle), ATDV_LASTERR(nDeviceHandle));
    /*
    .
    .
    Perform Error Processing
    */
}
/*
.
. Continue processing
.
*/

MediaInfo.unCount = 2;
MediaInfo.MediaData[0].eMediaType = MEDIATYPE_REMOTE_CODER_INFO;
MediaInfo.MediaData[0].mediaInfo.CoderInfo.eCoderType = CODER_TYPE_G711ALAW64K;
MediaInfo.MediaData[0].mediaInfo.CoderInfo.eFrameSize = (eIPM_CODER_FRAMESIZE) 30;
MediaInfo.MediaData[0].mediaInfo.CoderInfo.unFramesPerPkt = 1;
MediaInfo.MediaData[0].mediaInfo.CoderInfo.eVadEnable = CODER_VAD_DISABLE;
MediaInfo.MediaData[0].mediaInfo.CoderInfo.unCoderPayloadType = 0;
MediaInfo.MediaData[0].mediaInfo.CoderInfo.unRedPayloadType = 0;

MediaInfo.MediaData[1].eMediaType = MEDIATYPE_LOCAL_CODER_INFO;
MediaInfo.MediaData[1].mediaInfo.CoderInfo.eCoderType = CODER_TYPE_G711ALAW64K;
MediaInfo.MediaData[1].mediaInfo.CoderInfo.eFrameSize = (eIPM_CODER_FRAMESIZE) 30;
MediaInfo.MediaData[1].mediaInfo.CoderInfo.unFramesPerPkt = 1;
MediaInfo.MediaData[1].mediaInfo.CoderInfo.eVadEnable = CODER_VAD_DISABLE;
MediaInfo.MediaData[1].mediaInfo.CoderInfo.unCoderPayloadType = 0;
MediaInfo.MediaData[1].mediaInfo.CoderInfo.unRedPayloadType = 0;

if (ipm_ModifyMedia(nDeviceHandle, &MediaInfo, DATA_IP_SENDOONLY, EV_SYNC) == -1)
{
    printf("ipm_Modify failed for device name = %s with error = %d\n",
        ATDV_NAMEP(nDeviceHandle), ATDV_LASTERR(nDeviceHandle));
    /*

```

```
        .  
        .  
        Perform Error Processing  
        */  
    }  
  
    /*  
    .  
    .  
    continue processing  
    .  
    */  
}
```

This chapter describes the IP Media Library support for “Echo Cancellation”, a feature that reduces traces of an output signal (echo) from an incoming signal.


- [Overview of Echo Cancellation](#) 59
- [Echo Cancellation Parameters](#) 60

11.1 Overview of Echo Cancellation

Echo cancellation is a technique used to significantly reduce traces of an outgoing prompt in the incoming signal. These traces are referred to as echo. The echo canceller is the component in the HMP software responsible for performing echo cancellation.

Figure 12 demonstrates how the echo canceller works. After the incoming signal is processed by the echo canceller, the resulting signal no longer has significant echo and is then sent to the host application.

Figure 12. Echo Cancellation



If echo cancellation is not used, the incoming signal usually contains an echo of the outgoing prompt. Without echo cancellation, an application must ignore all incoming energy until the prompt and its echo terminate.

With echo cancellation, the caller may interrupt the prompt, and the incoming speech signal can be passed to the application.

Echo cancellation may be required when IP media resources receive media streams from the PSTN via the DTI resources of the T1/E1 single span (DNI300TEPHMP) or the T1/E1 quad span (DNI1200TEPHMP) boards. Echo cancellation is not required for media streams received from IP connections, PSTN connections via the T1/E1 dual span (DNI601TEPHMP) board, which provides onboard echo cancellation as part of the DTI resources, or via the DSI162 digital station interface boards.

Echo cancellation on an IP device can be monitored and controlled at run time using the **ipm_GetParm()** and **ipm_SetParm()** functions in the IP Media Library.

11.2 Echo Cancellation Parameters

The **ipm_GetParm()** and **ipm_SetParm()** functions use the IPM_PARM_INFO data structure to retrieve and set parameters in general. For echo cancellation, the following parameters are supported:

PARMCH_ECACTIVE

Enables or disables echo cancellation on an IP device. Possible values are:

- 0 - Disable echo cancellation (default)
- 1 - Enable echo cancellation

PARMCH_ECHOTAIL

Set or retrieve the echo tail length. The duration of an echo is measured in milliseconds. The echo canceller software can remove some limited number of these milliseconds; this number is known as the tail length of the echo canceller. The longer the tail length, the more echo is cancelled from the incoming signal, but this means more processing power is required. When determining the tail length value, consider the length of the echo delay in the system as well as the overall system configuration. Possible values are in the range 8 to 64 milliseconds (the default is 64 milliseconds).

PARMCH_ECNLP_ACTIVE

Set or retrieve the Non-Linear Processing (NLP) value. NLP is a process used to block or suppress the residual (echo-cancelled) signal, when there is no near end speech. This process can be used with comfort noise generation (CNG) to produce background noise. Background noise energy estimation is used to adjust the level of comfort noise generated. This allows the speaker to listen to the same level of background noise when the non-linear processor is switched on and off due to double-talk situations or near end speech. A typical usage of this feature is background noise used in dictation applications to let the user know that the application is working. Possible values are:

- 0 - NLP off
- 1 - NLP on (default)

For details on the **ipm_GetParm()** and **ipm_SetParm()** functions and the IPM_PARM_INFO data structure, see the *IP Media Library API for HMP Library Reference*.

This chapter contains information on how to compile and link your IPML applications under the Linux* and Windows* operating systems. The information is presented in the following topics:

- [Compiling and Linking under Linux 61](#)
- [Compiling and Linking under Windows 62](#)

12.1 Compiling and Linking under Linux

The following topics discuss compiling and linking requirements:

- [Include Files](#)
- [Required Libraries](#)

12.1.1 Include Files

To use IP media API functions in your Linux application, certain include files (also known as header files) and library files are required. You must add statements for these include files in your application. The following header files contain equates that are required for each Linux application that uses the IP media library:

ipmerror.h
IP media library error header file

ipmlib.h
IP media library header file

12.1.2 Required Libraries

The following library files must be linked to the application **in the following order**:

libipm.so
Linking this file is mandatory. Specify `-lipm` in makefile.

libgc.so
Required only if the application uses R4 Global Call library functions directly, for example, `gc_OpenEx()`. Specify `-lgc` in makefile.

libdxxx.so
Required only if the application uses R4 voice library functions directly, for example, `dx_play()`. Specify `-ldxxx` in makefile.

libsrl.so
The Standard Runtime Library (SRL) is mandatory. Specify `-lsrl` in makefile.

libpthread.so

POSIX threads system library. Specify `-lpthread` in makefile.

libdl.so

Dynamic Loader system library. Specify `-ldl` in makefile.

12.2 Compiling and Linking under Windows

The following topics discuss compiling and linking requirements:

- [Include Files](#)
- [Required Libraries](#)

12.2.1 Include Files

To use IP media library API functions in your Windows application, certain include files (also known as header files) and library files are required. You must add statements for these include files in your application. The following header files contain equates that are required for each Windows application that uses the IP media library:

ipmerror.h

IP media library error header file

ipmlib.h

IP media library header file

12.2.2 Required Libraries

The following library files must be linked to the application:

libipm.lib

Linking this file is mandatory.

libgc.lib

Required only if the application uses R4 Global Call library functions directly, for example, **gc_OpenEx()**. Use the `-lgc` argument to the system linker.

libdxxxmt.lib

Required only if the application uses R4 voice library functions directly, for example, **dx_play()**.

libsrlmt.lib

The Standard Runtime Library (SRL) is mandatory.

A

- alarm state 40
- Application Development Guidelines 29
- application development guidelines 23
- architecture 11
- ATDV_ERRMSGP() 19, 21
- ATDV_LASTERR() 19, 21
- ATDV_NAMEP() 20
- ATDV_SUBDEVS() 20

B

- building applications 61

C

- compiling and linking
 - under Linux 61
 - under Windows 62

D

- dev_Connect() 29
- dev_Disconnect() 29
- DTMF
 - detection 27
 - generation 28
- DTMF mode 24
 - in-band 24
 - out-of-band 26
 - RFC 2833 25
- DTMF Modes 24
- dx_play() 61, 62

E

- echo cancellation
 - controlling non-linear processing 60
 - enabling 60
 - overview 59
 - setting the tail length 60
- equired libraries 62
- error handling 21
- event handling 19

- events
 - QoS 39

F

- features 11
- full-duplex streaming
 - code example 56
 - configuration for 54

G

- gc_Listen() 23
- gc_OpenEx() 61, 62
- generating DTMF 28
- Global Call library
 - relationship with IP media 12
- Global Call library, relation with 12

H

- half-duplex streaming
 - code example 56
 - configuration for 54

I

- in-band mode 24
 - scenario diagram 25
- include files 61, 62
- IP media
 - architecture 12
 - relationship to Global Call 12
 - standard runtime library support 13
- IP media software
 - media device naming 13
- ipm_Close() 13
- IPM_DIGIT_INFO 27
- ipm_DisableEvents() 40
- ipm_EnableEvents() 40
- ipm_GetParm() 49
- ipm_GetQoSThreshold() 40
- ipm_Listen() 23
- ipm_Open() 13, 24, 25, 26
- IPM_PARM_INFO 24

IPM_QOS_THRESHOLD_DATA 38
 IPM_QOS_THRESHOLD_INFO 40
 ipm_ReceiveDigits() 23, 27
 ipm_SendDigits() 23, 28
 ipm_SetParm() 49
 ipm_SetParm() 24, 25, 26
 ipm_SetQoSThreshold() 40
 ipm_StartMedia() 40
 ipm_Stop() 40
 IPMEV_QOS_ALARM_DATA 40

J

jitter 38

L

lost packets 38

M

media channel device naming 13
 mode
 DTMF 24

N

notification of DTMF detection 27

O

out-of-band mode 26
 scenario diagram 27

P

programming models 15

Q

QoS
 alarm and alarm recovery scenarios 41
 alarm state 40
 alarm types 37
 description 37
 events 39
 example code 44
 parameters 38, 42
 threshold attributes 38, 42
 using alarms 40
 quality of service (QoS) 37

R

required libraries 61
 RFC 2833 mode 25
 RFC 2833 scenario diagram 26
 RTCP timeout 38
 RTP timeout 38

S

setting DTMF parameters 24
 setting in-band mode 24
 setting out-of-band mode 26
 setting RFC 2833 mode 25
 sr_dishdlr() 19
 sr_enbhdlr() 19
 sr_getboardcnt() 13
 sr_getevtdev() 19
 sr_getevttype() 19
 sr_waitevt() 19
 sr_waitevtEx() 19
 SRL event management functions 19
 SRL standard attribute functions 19
 Standard Runtime Library support 13
 state models 17

T

T.38 Fax Server Scenario 31

V

volume control 49